

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication **26100**.



PO Box 1519, Fort Collins CO 80522-1519, USA
1000 East Drake Road, Fort Collins CO 80525, USA
Phone +1 (970) 482-5811 • Fax +1 (970) 498-3058

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches,
as well as authorized distributors and other authorized service and sales
facilities throughout the world.

Complete address / phone / fax / email information for all locations is
available on our website.

2013/4/Colorado



Software Manual

Woodward Computer Based Training— Graphical Application Programmer (GAP)

Getting Started

Manual 26100

WARNING

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.



Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.



This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26311**, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, on the *publications page* of the Woodward website:

www.woodward.com/publications

The latest version of most publications is available on the *publications page*. If your publication is not there, please contact your customer service representative to get the latest copy.



Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.

NOTICE

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

NOTICE

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Computer Based Training Module

This Computer Based Training (CBT) module covers "Graphical Application Program (GAP)". The CBT includes animations, reviews, and quizzes to illustrate and reinforce GAP concepts. The CBT takes approximately four hours to complete and once completed, provides an excellent source of reference material. The CBT uses a variety of presentation modes to enhance the learning experience. Visual representation of each topic is displayed along with text explaining each point. Animations are then used to activate functions and in some cases, allow hands-on interaction with the user.

System Requirements

The minimum system requirements are a PC with a Pentium™ 100 MHz processor, 32 MB of RAM memory, and Windows 95. Resolution of 800 x 600, color = 16 bit. Use of a system that does not meet these requirements will in most cases degrade the performance.

Installation Procedure

1. Insert the CD-ROM into the disk drive.
2. The Auto run feature should start the program automatically.
3. If the program does not start automatically when you insert the disk into the CD-ROM drive, you may start it manually by double-clicking on the "Setup.exe" icon.
4. Follow the instructions presented during the installation.

Running the CBT Software

This booklet provides instructions on how to start the software. On-line help is available in the Help menu of the program, once it is running.