



## GCP-30 Series Genset Control



**Configuration**  
Software version 4.3xxx

**WARNING**

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown unit(s), that operates totally independently of the prime mover control unit(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled unit(s) fail.

**CAUTION**

To prevent damage to a control system that uses an alternator or battery-charging unit, make sure the charging unit is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive units.

**Important Definitions****WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury. Appropriate precautions have to be taken.

**CAUTION**

Indicates a potentially hazardous situation that, if not avoided, could result in damage to equipment. This note should absolutely be observed when connecting the unit.

**NOTE**

References to other notes and supplements as well as tables and lists are identified by means of the "i" symbol. Most of the referenced sections are included in the Annex.

Woodward Governor Company reserves the right to update any portion of this publication at any time. Information provided by Woodward Governor Company is believed to be correct and reliable. However, Woodward Governor Company assumes no responsibility unless otherwise expressly undertaken.

© Woodward Governor Company  
All Rights Reserved.

# Revision History

Rev.	Date	Editor	Changes
NEW	04-06-02	Tr	Release
A	04-09-23	TP	Parameter list added, extensive linguistic update and various minor corrections, functionality V4.3xxx
B	05-06-15	TP	Various minor corrections, description GCP-31 RPQ-SC08 (Rental Package) added

# Contents



## NOTE

All functions described in this manual are included in all controls (all versions) of the GCP-30 and AMG 2 series. Any differences between the control units will be indicated by having the model number for the applicable control unit at the beginning of the text. Please note that the AMG series controller is not explicitly described in this manual.

**[GCP-32]** Functions marked and described like this are for applications with 2 power circuit breakers (unit type GCP-32 and AMG 2/N2PB).

**[GCP-31]** Functions marked and described like this are for applications with 1 power circuit breaker (unit type GCP-31 and AMG 2/N1PB).

only **B+X** The functions marked and described like this are contained in all units except the Rental Package (unit types GCP-31 and GCP-32, Packages **BPD**, **BPQ**, **XPQ**, and **XPQ**).

nur **RPQ** The functions marked and described like this are ONLY contained in the Rental Package (unit type GCP-31 **RPQ+SC08**).

<b>CHAPTER 1. GENERAL INFORMATION.....</b>	<b>7</b>
Functional Overview.....	8
<b>CHAPTER 2. FUNCTION.....</b>	<b>9</b>
Considerations To Be Taken: .....	9
Different Options .....	9
Systems With One Power Circuit Breaker.....	9
Systems With Asynchronous/Induction Generators (Special Hardware!!).....	10
Signals.....	10
Discrete Inputs.....	10
Control Outputs.....	12
<b>CHAPTER 3. PARAMETER .....</b>	<b>14</b>
Basic Data.....	15
Version Number (Software Version).....	15
Configuration Access.....	15
Direct Configuration .....	16
Generator Number.....	17
Language Manager ( <b>Package XP</b> , <b>RP</b> , <b>Option ZE</b> ).....	17
Service Display .....	17
Event Logger ( <b>Package XP</b> , <b>Option ZE</b> ).....	18
Possible Event Logger Entries.....	18
Analog Inputs.....	20

Measuring .....	21
Rated Values Of The Frequency.....	21
PTs (Voltage Transformers, only B + X Packages) .....	22
Rated Voltage Values.....	23
Generator Current .....	26
Mains Current/Mains Power Measurement.....	27
Password Configuration .....	30
Controller .....	31
Table Of Set Point Values .....	31
Analog Controller Outputs (Package Q, Option Q).....	31
Real Power Controller, Set Point Values .....	35
Frequency Controller.....	36
Voltage Controller.....	39
Power Factor $\cos \varphi$ Controller.....	43
Real Power Controller .....	45
Load And/Or Var Sharing .....	50
Automatic.....	53
Load Management .....	53
Stop Of The Engine At Mains Failure [GCP-31] .....	60
Interface.....	61
Breaker .....	62
Functional Description.....	62
Breaker Logic .....	68
Start/Stop Ramp, Open GCB With F2 Alarm .....	74
GCB Pulse/Continuous Pulse .....	75
Open/Close GCB.....	76
Synchronization (With Synchronous Generators Only) .....	77
Phase Matching (only RPQ Package).....	78
Synchronization Time Monitoring (With Synchronous Generators Only) .....	79
Dead Bus Start (With Synchronous Generators Only).....	80
Connection Functions (With Induction/Asynchronous Generators Only) .....	81
Connect Time Monitoring (With Induction/Asynchronous Generators Only).....	82
Breaker Monitoring .....	83
Mains Decoupling.....	84
Emergency Power (AMF) .....	86
Emergency Power With Breaker Logic "PARALLEL" .....	87
Emergency Power With Breaker Logic "OPEN TRANSIT." .....	87
Emergency Power With Breaker Logic "CLOSED TRANSIT." .....	88
Emergency Power With Breaker Logic "INTERCHANGE" .....	88
Emergency Power With Breaker Logic "EXTERNAL" .....	88
Emergency power With MCB Malfunction.....	88
Emergency Power; Parameters .....	89
Protection.....	90
Generator Power Monitoring .....	91
Mains Power Monitoring (not with RPQ Package).....	92
Generator Overload Monitoring.....	93
Generator Reverse/Reduced Power Monitoring .....	94
Unbalanced Load Monitoring .....	95
Time-Overcurrent Monitoring .....	96
Generator Frequency Monitoring .....	98
Engine Overspeed Monitoring.....	98
Generator Voltage Monitoring .....	99
Mains Frequency Monitoring .....	100
Mains Voltage Monitoring.....	101
Phase/Vector Shift Monitoring $d\varphi/dt$ .....	102
Mains Settling Time.....	103
Battery Voltage Monitoring .....	104
Time Of Active Horn .....	104

Discrete Inputs .....	105
Alarm Inputs .....	106
Configuring The Text For The Discrete Inputs .....	107
Control Inputs .....	108
Terminal 6 .....	111
Analog Inputs (Package XP, Option T701) .....	114
Setting The Analog Inputs .....	114
Outputs .....	123
Analog outputs (Package XP, Option A2) .....	123
Relay Manager .....	124
Engine .....	125
Start/Stop Sequence 'Gas Engine' .....	126
Start/Stop Sequence 'Diesel Engine' .....	129
Cool Down .....	131
Delayed Engine Monitoring And Firing Speed .....	132
Pick-Up .....	133
Counter / Real Time Clock .....	134
Maintenance Call .....	134
Operating Hours Counter .....	134
Rental Duty Time Counter (only RPQ Package) .....	135
Start Counter .....	135
kWh Counter .....	136
Real Time Clock (Package XP, Option ZE) .....	137
Timer Switch (Package RPQ, Option Z01) .....	138
Current Slave Pointer .....	138
<b>CHAPTER 4. COMMISSIONING .....</b>	<b>139</b>
<b>APPENDIX A. ANALOG OUTPUT MANAGER (PACKAGE XP, OPTION A2) .....</b>	<b>141</b>
<b>APPENDIX B. RELAY MANAGER .....</b>	<b>144</b>
<b>APPENDIX C. INTERFACE PROTOCOL .....</b>	<b>148</b>
Transmission Telegram .....	148
Receiving Telegram .....	157
Framework Conditions To The CAN Bus .....	158
Transmission Telegram .....	158
Coding Of The Current Direction .....	158
Coding Of The Power Set Point Value .....	159
CAN IDs Guidance Bus .....	159
<b>APPENDIX D. LIST OF PARAMETERS .....</b>	<b>160</b>
<b>APPENDIX E. SERVICE OPTIONS .....</b>	<b>169</b>
Product Service Options .....	169
Returning Equipment For Repair .....	169
Packing A Control .....	170
Return Authorization Number RAN .....	170
Replacement Parts .....	170
How To Contact Woodward .....	171
Engineering Services .....	172
Technical Assistance .....	173

# Illustrations And Tables

---

## Illustrations

Figure 3-1: Control loop .....	31
Figure 3-2: Step response (Example).....	32
Figure 3-3: Step responds - governor configuration .....	34
Figure 3-4: CAN bus load/var sharing, wiring diagram.....	51
Figure 3-5: CAN bus load/var sharing, diagram.....	51
Figure 3-6: Breaker control logic 'Impulse'.....	75
Figure 3-7: Breaker control logic 'Continuous'.....	76
Figure 3-8: Characteristic of the time-overcurrent monitoring .....	96
Figure 3-11: Sprinkler operation.....	113
Figure 3-12: VDO transmitter 323.805/001/001 (slope).....	120
Figure 3-13: Start-Stop sequence: Gas engine .....	126
Figure 3-14: Wiring diagram for opening gas valves with the GCP-30 from V4.1001 .....	127
Figure 3-15: Start-stop sequence: Diesel engine.....	129
Figure 3-16: Delayed engine monitoring .....	132
Figure 4-1: Analog outputs - cos $\phi$ scaling.....	143

## Tables

Table 1-1: Manual - Overview.....	7
Table 1-2: Functional overview .....	8
Table 3-1: Event recorder - Messages, part 1 .....	19
Table 3-2: Event recorder – Messages, part 2.....	20
Table 3-3: Set point value table .....	31
Table 3-4: Limit values, permissible limits.....	62
Table 3-5: Limit values generator, dead bus start .....	65
Table 3-6: Limit values mains, dead bus start.....	66
Table 3-7: Limit values, Emergency power.....	86
Table 3-9: Discrete alarm inputs - delay stages .....	106
Table 3-10: Function - external operation mode selection.....	108

# Chapter 1.

## General Information

Type	English	German
<b>GCP-31/32 series</b>		
GCP-31/32 - Installation	37239	GR37239
GCP-31/32 - Configuration	<a href="#">this manual</a> ⇨	GR37278
GCP-31/32 - Function/Operation	37238	GR37238
GCP-31/32 - Application	37240	GR37240
<b>Option SB</b> - Caterpillar CCM coupling	37200	GR37200
<b>Option SC06/07/08</b> - CAN bus coupling	37182	GR37182
<b>Option SC04</b> - IKD1 and ST3 coupling	37236	GR37236
<b>Option SC02</b> - IKD1 coupling	37302	GR37302
<b>Option D08</b> - Preglow control	37286	GR37286
<b>Option T7</b> - 7 analog inputs	37261	GR37261
<b>Option TZ</b> - Temperature-dependent start/stop	37241	GR37241
<b>more options</b>	upon request	
<b>Additional manuals</b>		
<b>IKD 1 - Manual</b> Discrete expansion board with 8 discrete inputs and 8 relay outputs that can be coupled via the CAN bus to the control unit. Evaluation of the discrete inputs as well as control of the relay outputs is done via the control unit.	37135	GR37135
<b>IKN 1 - Manual</b> 20channel NiCrNi temperature scanner that monitors the temperature values for exceeding or falling below a threshold value, measured through senders on the IKN 1. A configured relay on the board of the IKN 1 will trip. The IKN 1 can be coupled with the control unit using the CAN bus to display measuring values as well as alarms.	37136	GR37136
<b>LeoPC1 - Manual</b> PC program for visualization, for configuration, for remote control, for data logging, for language upload, for alarm and user management and for management of the event recorder. This manual describes the use of the program.	37146	GR37146
<b>LeoPC1 - Manual</b> PC program for visualization, for configuration, for remote control, for data logging, for language upload, for alarm and user management and for management of the event recorder. This manual describes the programming of the program.	37164	GR37164
<b>GW 4 - Manual</b> Gateway for transferring the CAN bus to any other interface or bus.	37133	GR37133
<b>ST 3 - Manual</b> Control to govern the air fuel ratio of a gas engine. The ratio will be directly measured though a Lambda probe and controlled to a configured value.	37112	GR37112

Table 1-1: Manual - Overview

# Functional Overview



Function	Option	Package												
		GCP-31						GCP-32						
		BPD	BPQ	XPD	XPQ	XPQ+SB03	XPQ+SC06	RPQ+SC08	BPD	BPQ	XPD	XPQ	XPQ+SB03	XPQ+SC06
<b>Common Functions</b>														
1× readiness for operation relay	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4/6× control relay (form A, make contact)	Std.	✓	✓	✓	✓	✓	✓	4	✓	✓	✓	✓	✓	✓
7× freely configurable relay outputs (form A, make contact)	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2× three-position controller for n/f/V/P, cosφ	Std.	✓	--	✓	--	--	--	✓	✓	--	✓	--	--	--
2× three position controller for n/f/V/P, cosφ via relay manager	Q	☒	✓	☒	✓	✓	✓	✓	☒	✓	☒	✓	✓	✓
2× analog controller outputs for n/f/V/P/Q and PWM output	Q	☒	✓	☒	✓	✓	✓	✓	☒	✓	☒	✓	✓	✓
up to 14× discrete control inputs	Std.	6	6	6	6	6	6	14	6	6	6	6	6	6
up to 16× discrete alarm inputs	Std.	16	16	16	16	16	16	12	16	16	16	16	16	16
SYNCON Panel coupling via guidance bus	RPQ	--	--	--	--	--	--	✓	--	--	--	--	--	--
CAN bus interface 'guidance level'	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CAN bus interface to 2× IKD 1 and ST 3 (RPQ: no ST 3)	SC06	☒	☒	☒	☒	--	✓	✓	☒	☒	☒	☒	--	✓
CAN bus coupling to mtu MDEC and Scania EMS/S6	SC06	☒	☒	☒	☒	--	✓	✓	☒	☒	☒	☒	☒	✓
CAN bus coupling to SAE J1939	SC06	☒	☒	☒	☒	--	✓	✓	☒	☒	☒	☒	--	✓
RS-232 coupling via Caterpillar CCM to ECM & EMCP-II	SB03	☒	☒	☒	☒	✓	--	--	☒	☒	☒	☒	✓	--
7× analog inputs	T701	☒	☒	✓	✓	✓	✓	✓	☒	☒	✓	✓	✓	✓
1× Pickup input	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2× analog outputs + external operation mode selection by term. 127/128	A2	☒	☒	✓	✓	✓	✓	✓	☒	☒	✓	✓	✓	✓
Password system	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Configuration via DPC possible (direct configuration)	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Event recorder with real-time clock	ZE	☒	☒	✓	✓	✓	✓	✓	☒	☒	✓	✓	✓	✓
Language manager for LCD texts	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Running hours, maintenance, start, and kWh counter	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Additional running hours counter w. minute resolution (rental duty time)	RPQ	--	--	--	--	--	--	✓	--	--	--	--	--	--
<b>Control/Synchronization</b>														
Synchronization of 1 breaker with V and f correction	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Synchronization of 2 breakers with V and f correction	Std.	--	--	--	--	--	--	--	✓	✓	✓	✓	✓	✓
Closing to a dead/voltage free busbar (dead bus start)	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Voltage control	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Power factor (cosφ) control	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Speed/frequency control	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Phase control, V/f droop control	RPQ	--	--	--	--	--	--	✓	--	--	--	--	--	--
Generator real power control & import/export real power control	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Real & var sharing	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Analog setpoint value for real power	T701	☒	☒	✓	✓	✓	✓	✓	☒	☒	✓	✓	✓	✓
Analog mains interchange (import/export) real power measuring	T701	☒	☒	✓	✓	✓	✓	✓	☒	☒	✓	✓	✓	✓
Breaker logic "open transition" & "closed transition"	Std.	--	--	--	--	--	--	--	✓	✓	✓	✓	✓	✓
Breaker logic "soft loading"	Std.	--	--	--	--	--	--	--	✓	✓	✓	✓	✓	✓
Breaker logic "parallel operation"	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Breaker logic "external"	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Remote control via interface	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
<b>Protective Functions</b>														
Over-/undervoltage protection, generator $V_{Gen}>/<$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Over-/undervoltage protection, mains $V_{Mains}>/<$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Over-/underfrequency protection $f>/<$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
dq/dt vector/phase jump protection $dq/dt$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Reverse/reduce power protection $+/-P_{Gen}<$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Overload protection $P_{Gen}>$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Unbalanced load protection $\Delta P_{Gen}>$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Time-overcurrent protection $I_{umz}>/>>$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Battery voltage protection $U_{Bat}<$	Std.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Table 1-2: Functional overview

# Chapter 2.

## Function

### Considerations To Be Taken:



#### Different Options

According to a control unit's configuration, different parameters may be displayed and not all parameters will be available:

- Various inputs and outputs will be present or deleted, corresponding to the control configuration (depending on your order). Please refer to the wiring diagram and the notes regarding the **packages** and **options** contained in these. Refer to the data plate to see if the corresponding **option** is contained in the control. If the data plate has been removed, the configuration screens may be called up in succession and the **options** may be determined with the assistance of this manual.
- Specific display screens correspond to specific types of interfaces.

#### Systems With One Power Circuit Breaker

If a control with a 2-power-circuit-breaker logic [GCP-32] or a 1-power-circuit-breaker logic [[GCP-31] is installed for use with one power circuit breaker, the following shall apply:

- If the control unit application is to be operated in an isolated operation or an isolated parallel operation (the MCB is opened), the following signals must be applied:
  - "Reply: MCB is open" / "Isolated operation" (terminal 54): HIGH signal (logical "1") and
  - "Enable MCB" (terminal 53): LOW signal (logical "0").
  - Condition: The Parameter 164 "Emergency power" must be set to "OFF".
- If the control unit application is to be operated in a mains parallel operation (the MCB always is closed if the generator operates in mains parallel), the following signals have to be applied:
  - "Reply: MCB is open" / "Isolated operation" (term. 54): LOW-Signal (log. "0") and
  - "Enable MCB" (terminal 53): HIGH signal (logical "1").
- If the control unit application is to be operated in isolated(parallel) as well as in mains parallel operation (the MCB can be opened or closed), the following signals have to be applied:
  - Reply, that the GCB is closed (terminal 4) and
  - Reply, that the MCB is closed (terminal 54) and
  - "Enable MCB" (terminal 53)

Case A - The MCB must remain closed (except at an emergency power operation): The "Enable MCB" (terminal 53) always has to be logical "1".

Case B - The MCB can be opened (also outside an emergency power operation): The "Enable MCB" (terminal 53) must be set logical "1" if a mains parallel operation has to be established (a synchronization of the MCB has to be performed). During the synchronization of the MCB (GCP-31: this function is performed externally from the controller) the generator frequency is controlled with a slightly higher value than the mains frequency (df max/2). Additionally a message is displayed on the controller. The "Enable MCB" (terminal 53) has to be logically "0", if the system has to be operated in isolated operation (control of set point frequency and set point voltage).

## Systems With Asynchronous/Induction Generators (Special Hardware!!)

In the case of systems with asynchronous/induction generators, the following must be noted:

- Systems with asynchronous/induction generators are 1-power-circuit-breaker systems [GCP-31].
- Connect the remnant voltage to terminals 23/24. Terminals 23/24 are voltage sensitive and can detect voltages from 0.5-480 volts. These terminals are utilized to determine the frequency (rotary speed) of the remnant voltage with small amplitudes. If the GCB is not closed, only the remanence voltage, which is less than 10 volts, is measured instead of the generator voltage. The generator voltage and frequency is monitored only once the GCB is closed. If the control is in mains parallel operation, the inputs from 23/24 are no longer taken into account.

## Signals



### Discrete Inputs



#### NOTE

All emergency power (Parameter 164 "Emergency power" has to be configured to ON) or Critical (Sprinkler) mode operations (terminal 6 must be configured accordingly; Parameter 239) will be carried out in the TEST and AUTOMATIC operation modes regardless of the discrete inputs "Automatic 1" and "Automatic 2". If terminals 3 and 5 are enabled simultaneously, priority is given to terminal 3.

#### Automatic 1 (Start/Stop the engine)

Terminals 3/7

Selection of the operation mode AUTOMATIC with "real power set point value 1" as well as starting/stopping of the engine.

**Set** ..... If the control is in AUTOMATIC mode (selected using the mode selection switch on the front panel) the "real power set point value 1" (Parameter 46) is controlled in mains parallel mode. In the case of baseload (C), the engine is started immediately and mains parallel operation is performed following the synchronization of the generator power circuit breaker GCB. In the case of incoming/import (I) or outgoing/export power (E), starting is performed by automatic start/stop operation. If no automatic start/stop operation is enabled (Parameter 108), the engine is started immediately. The set point value can be modified via both the configuration mode and via the "up/down" push buttons in AUTOMATIC mode.

**Reset** ..... If the engine does not run either in Critical (Sprinkler) mode or emergency power mode, the GCB is opened, a cool down is performed and the engine is stopped.

**Automatic 2 (Start/Stop the engine)**

Terminals 5/7

Selection of the operation mode AUTOMATIC with "real power set point value 2" as well as starting/stopping of the engine.

**Set**.....If the control is in AUTOMATIC mode (selected using the mode selection switch on the front panel) the "real power set point value 2" (Parameter 47) is controlled in mains parallel mode. In the case of a baseload (C), the engine is started immediately and mains parallel operation is performed following the synchronization of the generator power circuit breaker GCB. In the case of incoming/import (I) or outgoing/export power (E), starting is performed by automatic start/stop operation. If no automatic start/stop operation is enabled (Parameter 109), the engine is started immediately. The set point value can be modified via both the configuration mode and via the "up/down" push buttons in AUTOMATIC mode.

**Reset**.....If the engine does not run either in Critical (Sprinkler) mode or emergency power mode, the GCB is opened, a cool down is performed and the engine is stopped.

If a set point value is specified externally (e. g. via an 0/4 to 20 mA analog input or a bi-directional interface), the external set point value is adjusted with the discrete input (see Table 3-3: Set point value table).

**Multifunction**

Terminals 6/7

Discrete input terminal 6 may reveal different functions. Please note that, when used as a Critical (Sprinkler) mode input, the discrete input reveals negative functional logic. The selection of the logic is made using Parameter 239.

**Reply: GCB is open**

Terminals 4/7

With this input (logical "1") the control is signaled that the GCB is open (the "GCB ON" LED is off).

**[GCP-32] Reply: MCB is open**

Terminals 54/7

With this input (logical "1") the control is signaled that the MCB is open (the LED "MCB ON" is off).

**[GCP-31] Isolated operating / reply external breaker**

Terminals 54/7

With this input (logical "1") the control is signaled that the genset is operated in isolated operation (the LED "Mains parallel" is off). This discrete input is used to decide whether, after closing the GCB, frequency control (terminal 54 = logical "1") or real power control (terminal 54 = logical "0") is to be carried out.

**Enable MCB**

Terminals 53/7

**Set**.....A mains parallel operation is enabled and the MCB (GCP-31: this function is performed externally from the controller) is operated.

**Reset**.....The MCB is not operated. Depending on the reply of the MCB, an isolated operation or a main parallel operation is performed.

**Discrete inputs**

Terminals 34 to 36/33 and 61 to 73/60

Freely programmable alarm inputs with message text, alarm class, time delay, delayed engine monitoring and NO/NC function.

## Control Outputs

### Readiness for operation

Terminals 18/19

Setting this relay signals the readiness for operation of the control. If this relay is disabled, the proper function of the control can no longer be guaranteed. Appropriate actions must be initiated once this relay has been disabled (e.g. open GCB, shut-down engine).

### Preheating (Diesel engine)

pre-assigned to terminals 37/38

When this relay is enabled, the diesel engine's glow plugs are enabled (please note chapter "Diesel Engine").

### Ignition "ON" (Gas engine)

pre-assigned to terminals 37/38

When this relay is enabled, the ignition of the gas engine is switched on (please note chapter "Gas Engine").

### Fuel relay / gas valve

Terminals 43/44

#### **a) Diesel engine: fuel relay (Parameter 305)**

##### **a.1) Operating solenoid**

Enabling this relay will initiate the starting sequence of the diesel engine. If the engine is to be shutdown the relay will immediately de-energize. If the speed of the engine drops below the adjustable ignition speed, the relay also de-energizes (note chapter "Diesel Engine").

##### **a.2) Stopping solenoid**

Enabling this relay will stop the engine.

#### **b) Gas engine: gas valve**

Enabling this relay will initiate the starting sequence of the gas engine. The gas valve will be opened. If the engine is to be shut down the relay will immediately de-energize. If the speed of the engine falls below the adjustable firing speed (Parameter 308), the relay also de-energizes (note chapter "Gas Engine").

### Starter

Terminals 45/46

Enabling this relay will engage the starter. When the firing speed is reached (Parameter 308), at STOP mode, or after expiration of the crank time (Parameter 295 or Parameter 301), the starter is disengaged.

### Centralized alarm

pre-assigned to terminals 47/48

Enabling this relay will issue a centralized alarm. This permits a horn or buzzer to be operated by the control unit during a fault condition. The operator can reset the relay by pressing the push-button "RESET" for a short period. The relay will be set again in the event of another alarm. The centralized alarm is set for alarms of alarm classes F1 through F3.

**Command: close GCB**

Terminals 14/15

Enabling this relay will close the GCB. If the GCB closing command is configured to continuous current (Parameter 129), in response to a missing discrete input "Reply: GCB is open" the relay is maintained in its closed state; this also applies if the voltages of the generator and the busbar are equal. In the event of a class F3 alarm this relay de-energizes immediately. In the event of a class F2 alarm or for shutdown the relay does not de-energize immediately, it will de-energize if the power is less than 3.125 % of the rated generator power. If operation of the GCB is configured as a momentary pulse, the relay de-energizes after the pulse is output. This function must be used in conjunction with an external holding coil for the GCB.

**Command: open GCB**

Terminals 41/42

Enabling this relay will open the GCB. Following "Reply: GCB is open", the relay output is de-energized.

**[GCP-32] Command: close MCB**

Terminals 16/17

Enabling this relay will close the MCB. This output is always a momentary pulse. For the MCB to remain closed an external holding coil must be used.

**[GCP-32] Command: open MCB**

Terminals 39/40

By enabling this relay, the MCB will open. Following "Reply: MCB is open", the relay output is de-energized.

**Relay manager**

Terminals 74 to 83, 37/38, 47/48

The "Relay Manager" manages the relays listed here (Parameter 286).

Default values:

- Relay 1 to 5 = relay number (e. g. relay 1 = alarm class 1, relay 2 = alarm class 2, etc.)
- Relay 6 = Ignition / preheating
- Relay 7 = Centralized alarm

## Chapter 3. Parameter

Configuration may be performed via the front panel keys or using a PC and the PC program LeoPC1 via the serial interface. Use LeoPC1 version 3.1 or higher for this. Additionally it is possible to configure the unit via CAN bus. The following Baud rates are therefore usable:

- Configuration via direct configuration plug (RS-232) = 9,600 Baud (8 Bit, no parity, 1 Stop bit)
- CAN bus (CiA) (RS-485) = 125, 250 or 500 kBaud configurable via the serial interface.



### CAUTION

For configuration of this control (firmware software version starting with 4.3xxx) a PC software with the following version number or higher must be used:

**LeoPC1 from 3.1**

Not all parameters may be configured directly at the GCP with Option SCxx anymore. Therefore, it is recommended to have LeoPC1 and the specific configuration files available when commissioning.

Because of functional enhancements within the controls of the GCP-30 Series it is necessary (beginning with firmware version 4.3xxx of the GCP) to use a newer version of the configuration software LeoPC1. This version at least must be 3.1 or higher. If the LeoPC1 software you currently use has an older version the latest version can be ordered at our technical sales or can be downloaded on our homepage at <http://www.woodward.com/software>.

After an updated version of LeoPC1 has been installed older project files may still be used. These can be transferred to the appropriate file locations within the new program.



### WARNING

Please note that configuration only should be performed while the system is not operating.



### NOTE

Before configuring a control unit, familiarize yourself with the parameters listed at the end of this manual.

You can scroll through the parameters if you are in configuration mode (simultaneously pressing of "Digit↑" and "Cursor→" push buttons permits access to the configuration mode) using "Select". If you press and hold the "Select" push button the scroll function will be activated, allowing for the parameter screens to be advanced through more rapidly. The control unit will permit the operator to reverse up to four previous screens (exception: it is not possible to reverse from the first parameter to the last parameter or to backup through the service screens). To perform the reverse function through the parameter screens, the "Select" and "Cursor→" push buttons must be pressed and released simultaneously. The control unit will revert to automatic mode, if an entry isn't performed, a change made or any other action performed for 90 seconds.



### NOTE

There are two different types of hardware, which are described in this manual: A 120 Vac version [1] and a 480 Vac version [4]. The configuration screens and parameters differ in both versions, and the setting limits also differ. The two types are identified by the preceding voltage values ([1] ... or [4] ...).

# Basic Data



## Version Number (Software Version)

Parameter 1

Software version

Software version Vx.xxxxx
------------------------------

Display of the software version.

## Configuration Access

The control is equipped with a three-level code and configuration hierarchy, which enables it to access various configuration screens for different users. A distinction is made between:

**Code level 0 (CS0)** - User: Third party

This code level enables no access to the parameters. The configuration is blocked.

**Code level 1 (CS1)** - User: Customer

This code level entitles the user to change a few selected parameters. Changing passwords is not possible at this level.

**Code level 2 (CS2)** - User: Commissioner

With code level 2 the user is granted full access rights, and therefore has direct access to all parameters (displaying and changing). Additionally, the user may change the passwords for levels 1 and 2 in this level. In this code level the password protection may be completely disabled (see below).



### NOTE

Once a password has been set it will not change unless a person alters that parameter with access to it regardless of how often the configuration mode is accessed. If an incorrect code number is entered, the code level is set to CS0 and the control is therefore locked for external users (setting of password on page 28). The control unit automatically reverts to code level CS0 two hours after the entry of a password. By entering the correct password, the corresponding level may again be accessed.

The code level may also be accessed using the PC program LeoPC1.

Parameter 2

Enter code number

0000 to 9999

Enter code 0000
--------------------

Upon accessing the configuration mode a four-digit password is requested which identifies the level of access the user is to be granted. The displayed number XXXX is a randomly generated number that must be changed to the correct password and confirmed with the "Select" push-button. If the random number has been confirmed with "Select" without being changed, the control's access level remains as it was. Two four-digit code numbers (0000-9999) exist for accessing the parameters . Changing the code level and setting up new code words for the users can only be accomplished on the CS2 level. No assignment is required for the "third party" user level, as the user does not usually receive access to the configuration level (protected via the code).

## Direct Configuration



### NOTE

To carry out direct configuration, you require a direct configuration cable (Part #5417-557), the LeoPC1 1 program (supplied with the cable) and the corresponding configuration files. Please consult the online help installed when the program is installed for a description of the LeoPC1 1 PC program and its setup.

**Remote configuration:** For remote configuration the level CS2 password must be entered via the parameter "password", otherwise, the values can only be read but not written. Entering via the CAN bus has no influence on the displayed parameters. If the control is in code level CS0, the same level of access will be granted as described in the previous section. The configuration via the bus is enabled for 2 hours from that point in time from the time that the last readout of configuration was performed. After two hours the password must be entered again to access the parameters. The password must also be entered prior to loading languages.



### WARNING

If Parameter 3 "Direct para." is configured to "YES", communication via the interface with terminals X1-X5 is **blocked**. If communication is to be re-established via interface X1-X5 after finishing the configuration of the control (e.g. CAN bus connection via a Gateway GW 4), Parameter 3 must be configured to "NO"!

The direct configuration port is disabled (Parameter 3 is automatically switched from YES to NO) once the firing speed (Parameter 308) has been reached. This requires any further configuration of the control to be accomplished via the front display and push buttons or via the CAN bus interface. The deactivation of direct configuration is performed as a safety precaution. If multiple systems starting simultaneously (e. g. emergency power situation) a simultaneous switching of the generator breakers to the dead busbar is prevented.

Parameter 3

Direct para.	YES
--------------	-----

Direct configuration	YES/NO
----------------------	--------

- |           |   |
|-----------|---|
| YES ..... | Configuration via the lateral plug is enabled, and any <b>CAN bus connection</b> that may be available <b>via terminals X1-X5 is disabled</b> . The following conditions must be met in order to carry out configuration via the lateral plug: <ul style="list-style-type: none"> <li>- A connection must be established via the direct configuration cable between the control and the PC,</li> <li>- The baud rate of the LeoPC1 program must be set to 9,600 Baud and</li> <li>- The corresponding configuration file must be used (file name: "xxxx-xxxx-yyy-zz.asm").</li> </ul> |
| NO .....  | Configuration via the lateral plug cannot is disabled, and any available <b>CAN bus connection via the terminals X1-X5 is enabled</b> .   |

### Generator Number

Parameter 4

Generator number 0
-----------------------

**Generator number (number of the control on the CAN bus)**

**1 to 14**

If several controls are available and these are coupled via a CAN bus, a different number must be assigned to each control for differentiation purposes. The generator number 1 should be assigned even in the case of a single control. The control number entered here corresponds to the control number in the program LeoPC1. The parameter range from 1 to 8 is valid for the Rental Package [RPQ+SC08](#).

### Language Manager (Package XP, RP, Option ZE)

In order to load a different language into the control, follow the steps below:

- 1.) A communication link between your PC and the control unit must be established via the direct configuration cable (DPC). To do this insert the serial cable into the COM port of your PC and the RJ45 plug into the communication port of the control unit (a connection via CAN and GW 4 is also possible).
- 2.) Enter the password for code level CS2 into the control (Parameter 2).
- 3.) If the direct configuration cable (DPC) is to be utilized, the Parameter 3 "Direct para." must be configured as "YES". If a GW 4 or the CAN bus is to be utilized for configuration, the Parameter 3 "Direct para." must be configured as "NO".
- 4.) If the desired language is to be loaded via the CAN bus, enter the number (1 to 14) into the "Generator number" screen (Parameter 4), so that LeoPC1 is able to communicate with the desired control unit.
- 5.) Scroll to the configuration screen "Language" (Parameter 5) and select the primary language for the control unit by selecting "first".
- 6.) Start the program LeoPC1, and log into the program by selecting "System" from the tool bar and "User login..." from the drop down menu. Enter the user name and password and click the "OK" button.
- 7.) Open the applicable \*.cfg file for the application by selecting "File" from the tool bar and "open" from the drop down menu. Select the proper \*.cfg file from the window that appears.
- 8.) To start communication between the control unit and LeoPC1 select "Communication" from the tool bar and "Connect" from the drop down menu.
- 9.) Select "Devices" from the tool bar and "Parameterize..." from the drop down menu. A window will appear with all the tunable parameters in it. Move the cursor over the numbers for the password and double click.
- 10.) Enter the password for the code level CS 2 (Parameter 2).
- 11.) Close the parameterization window.
- 12.) Select "Devices" from the tool bar and "Load language..." from the drop down menu.
- 13.) Load the desired language file using the button "Load LNG file ..."
- 14.) Select the desired language and click the "Transfer language" button.
- 15.) If an additional language is to be loaded into the control unit, return to step 5 and select "second" (not possible via LeoPC1). Repeat all steps in order as when programming the first language.

Parameter 5

Language -----
-------------------

**Language**

**first/second**

**first** ..... All texts are displayed in the first language.  
**second** ..... All texts are displayed in the second language.

### Service Display

Please note the description of these screens in manual 37238.

# Event Logger (Package XP, Option ZE)



## NOTE

Displaying and clearing of events depends on access authorization:

- Displaying of events.....Access authorization CS# 1 und CS# 2
- Clearing of events .....Access authorization CS# 2

# CS = Code level (see chapter "Configuration" on page 15).

When an event (see following table) occurs it is stored in the event logger. The following information is recorded:

- Event
- Date of occurrence
- Time of occurrence

Up to 50 events can be stored in the event logger (beginning with the most current one). For more than 50 entries, the oldest event will be deleted. By pressing the "RESET" push-button, the event that is displayed is cleared. The events are displayed on two lines. The top line indicates the date and time of the event that has occurred; the lower line shows the type of event.

Parameter 6

check event list
YES

Event logging	YES/NO
---------------	--------

- YES .....The events can be viewed and acknowledged.
- NO .....The events cannot be viewed and acknowledged.



## NOTE

Starting from version 4.3010, the event logger can also be read via CAN. This enables to read the event logger via GW4/modem for example.

If the event logger is to be read via CAN, the respective connection, e.g. GW4, has to be selected in LeoPc1. Reading the event logger is then performed like for direct configuration.

## Possible Event Logger Entries

Parameter 7

YY-MM-DD ss:mm
xxxxxxxxxxxxxxxxxxxx

50 x alarm log
----------------

- YY-MM-DD ss:mm..... Display of day and time of the event.
- xxxxxxxxxxxxxxxxxxxx ... See bottom table.

Event type	XXXXXXXXXXXXXXXXXX	
	German	English
<b>Internal events</b>		
Engine overspeed (Pickup)	Überdrehzahl	Over speed
Generator overfrequency	Überfrequenz	Overfrequency
Generator underfrequency	Unterfrequenz	Underfrequency
Generator overvoltage	Gen.-Überspg.	Gen. overvolt.
Generator undervoltage	Gen.-Unterspg.	Gen. undervolt.
Generator overcurrent, level 1	Gen.-Überstrom 1	Gen. overcurr. 1
Generator overcurrent, level 2	Gen.-Überstrom 2	Gen. overcurr. 2
Reverse/reduced load	Rück/Minderleist	Revers/min.power
Overload	Gen.-Überlast	Gen. overload
Unbalanced load	Schiefelast	Load unbalance
Mains overvoltage	Netz-Überspg.	Mains- overvolt.
Mains undervoltage	Netz-Unterspg.	Mains- undervolt.
Mains overfrequency	Netz-Überfreq.	Mains- underfreq.
Mains underfrequency	Netz-Unterfreq.	Mains- overfreq.
Mains phase/vector jump	Phasensprung	Phase shift
Mains df/dt (optional)	df/dt-Fehler	df/dt error
Battery undervoltage	Batt.-Unterspg.	Batt. undervolt.
GCB synchronization time monitoring	Synch.Zeit GLS	GCB syn.failure
MCB synchronization time monitoring	Synch.Zeit NLS	MCB syn.failure
Switching to dead busbar time monitoring	Stör. df/dU-max.	Failure df/dVmax
Fault P-control: GCB will be opened after time boost/settle	R-Rampe:GLS auf	P-ramp:open GCB
GCB malfunction on closing	Störung GLS ZU	GCBclose failure
MCB malfunction on closing	Störung NLS ZU	MCBclose failure
GCB malfunction on opening	Störung GLS AUF	GCB open failure
MCB malfunction on opening	Störung NLS AUF	mCB open failure
Faulty reference power zero control with interchange synchronization on GCB	Bezugsleist. <>0	Power not zero
Maintenance call	Wartung	Service
Interface monitoring X1-X5	Fehl.Schnit.X1X5	Interf.err. X1X5
Interface monitoring Y1-Y5	Fehl.Schnit.Y1Y5	Interf.err. Y1Y5
Pickup/generator frequency mismatch	Pickup/Gen.Freq.	Pickup/Gen.freq.
Plausibility control power (optional)	L.-Plausibilität	Plausibility ch.
Shutdown malfunction	Abstellstörung	Stop failure
Start failure	Fehlstart	Start failure
Unintentional stop	ungewollter Stop	unintended stop
<b>Discrete Inputs in the GCP/AMG</b>		
Discrete input [D01]	frei parametrierbar	freely configurable
Discrete input [D02]		
Discrete input [D03]		
Discrete input [D04]		
Discrete input [D05]		
Discrete input [D06]		
Discrete input [D07]		
Discrete input [D08]		
Discrete input [D09]		
Discrete input [D10]		
Discrete input [D11]		
Discrete input [D12]		
Discrete input [D13]		
Discrete input [D14]		
Discrete input [D15]		
Discrete input [D16]		

Table 3-1: Event recorder - Messages, part 1

External expansions			
Discrete input [D1.01] of IKD1.1	Option SC06 + IKD1	frei parametrierbar	
Discrete input [D1.02] of IKD1.1	Option SC06 + IKD1		
Discrete input [D1.03] of IKD1.1	Option SC06 + IKD1		
Discrete input [D1.04] of IKD1.1	Option SC06 + IKD1		
Discrete input [D1.05] of IKD1.1	Option SC06 + IKD1		
Discrete input [D1.06] of IKD1.1	Option SC06 + IKD1		
Discrete input [D1.07] of IKD1.1	Option SC06 + IKD1		
Discrete input [D1.08] of IKD1.1	Option SC06 + IKD1		
Discrete input [D2.01] of IKD1.2	Option SC06 + IKD1		
Discrete input [D2.02] of IKD1.2	Option SC06 + IKD1		
Discrete input [D2.03] of IKD1.2	Option SC06 + IKD1		
Discrete input [D2.04] of IKD1.2	Option SC06 + IKD1		
Discrete input [D2.05] of IKD1.2	Option SC06 + IKD1		
Discrete input [D2.06] of IKD1.2	Option SC06 + IKD1		
Discrete input [D2.07] of IKD1.2	Option SC06 + IKD1		
Discrete input [D2.08] of IKD1.2	Option SC06 + IKD1		
Air-fuel-ratio sender alarm from ST 3	Option SC06 + ST3		Lambdasonde
Lambda probe			
Other Events			
Switched into operation mode MANUAL	BAW Hand	Manual mode	
Switched into operation mode AUTOMATIC	BAW Automatik	Automatic mode	
Switched into operation mode STOP	BAW Stop	Stop mode	
Switched into operation mode TEST	BAW Probe	Test mode	
Switched into operation mode Load TEST	BAW Lastprobe	Loadtest mode	
"MCB OFF" push-button pressed (in MANUAL MODE)	Taste NLS AUS	Button MCB OFF	
"GCB OFF" push-button pressed (in MANUAL MODE)	Taste GLS AUS	Button GCB OFF	
"GCB ON" push-button pressed (in MANUAL MODE)	Taste GLS EIN	Button GCB ON	
"MCB ON" push-button pressed (in MANUAL MODE)	Taste NLS EIN	Button MCB ON	
"START" push-button pressed (in MANUAL MODE)	Taste Hand START	Button START	
"STOP" push-button pressed (in MANUAL MODE)	Taste Hand STOP	Button STOP	
Remote start	Fernstart	Remote start	
Remote stop	Fernstop	Remote stop	
Remote acknowledgment via interface	Fernquittierung	Remote acknowl.	
Remote acknowledgment via terminal 6	Quittierung Kl.6	Acknowledg-ter 6	
Acknowledgment via "RESET" button	Quittierg. Taste	Ackn.button QUIT	
Mains failure (AMF)	Netzausfall	Mains failure	
Return of the mains (this entry occurs once the mains settling time expired)	Netzwiederkehr	Mains o.k.	
Emergency power (AMF) started	Notstrom Anfang	Emerg. run start	
Emergency power (AMF) ended	Notstrom Ende	Emerg. run stop	
Engine successfully started (engine enabled, firing speed exceeded)	Aggr. gestartet	Start of engine	
Engine stopped (engine not enabled, firing speed was undershot)	Aggregatestop	Stop of engine	

Table 3-2: Event recorder – Messages, part 2

## Analog Inputs

The control unit is not able to display the entire text for the analog alarms. The 6 digits on the left side of the screen are reserved for the analog values to be monitored. If the text for these alarms is expanded, the monitored values will be overwritten and not displayed. The text below is the message that is displayed for each of the fault conditions.

- WIRE\_\_\_\_\_Wire break
- ALARM\_\_\_\_\_Limit value 1
- STOP\_\_\_\_\_Limit value 2

Parameter 8

```
YY-MM-DD ss:mm
STOP Analog inpu
```

### Example

Limit value 2 (STOP) of the analog input 1 was exceeded. The text of the analog alarm input will be moved 6 letters to the right. In this case the measured value disappears. Please note this text displacing already during the configuration of the analog input!

# Measuring



## WARNING

The following values must be entered correctly for the generator to be monitored. Failure to do so may lead to incorrect measuring resulting in damage to or destruction of the generator and/or personal injury or death.

Parameter 9

**Configure measuring** YES

### Configuration of the measuring

YES/NO

Various parameters are grouped together in blocks to allow navigation through the large number of configuration screens more rapidly. Selecting "YES" or "NO" has no effect on whether or not control or monitoring is carried out. The input merely has the following effect:

**YES**..... The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO**..... The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

## Rated Values Of The Frequency

Parameter 10

**Generator freq. f set** 00.0Hz

only B + X Packages

### Generator set point frequency

40.0 to 70.0 Hz

The generator set point frequency is configured here. This is required for the frequency controller in isolated and no-load operation. In most cases, the values entered into this screen will be 50 Hz or 60 Hz. It is possible to configure other values into this parameter.

Parameter 11

**Rated system frequency** 00.0Hz

only B + X Packages

### Rated system frequency

50/60 Hz

The rated system frequency is the value that the generator is going to connect to. This parameter is dependent on the individual country or individual system.

Parameter 12

**Rated Frequency1 System 1** 00.0Hz

only RPQ Package

### Rated system frequency 1

50.0 to 60.0 Hz

The rated frequency of system 1 is configured here. The parameter becomes active if the discrete input at terminal 71 is not energized (refer to Discrete Input section in Installation Manual 37320).

Parameter 13

**Setpoint Frequ. System 1** 00.0Hz

only RPQ Package

### Generator set point frequency 1

45.0 to 65.0 Hz

The generator set point frequency in system 1 is configured here. This is required for the frequency controller in isolated and no-load operation. In most cases, the values entered into this screen will be 50 Hz or 60 Hz. It is possible to configure other values into this parameter. It is possible to configure other values into this parameter. The parameter becomes active if the discrete input at terminal 71 is not energized (refer to Discrete Input section in Installation Manual 37320).

Parameter 14

**Rated Frequency2**  
System 2 00.0Hz

only RPQ Package

**Rated system frequency 2** **50.0 to 60.0 Hz**

The rated frequency of system 2 is configured here. The parameter becomes active if the discrete input at terminal 71 is energized (refer to Discrete Input section in Installation Manual 37320).

Parameter 15

**Setpoint Freq.**  
System 2 00.0Hz

only RPQ Package

**Generator set point frequency 2** **40.0 to 700 Hz**

The generator set point frequency in system 2 is configured here. The parameter becomes active if the discrete input at terminal 71 is energized (refer to Discrete Input section in Installation Manual 37320).

**PTs (Voltage Transformers, only B + X Packages)**



**WARNING**

If the value of the following parameter is changed, the values of the following parameters have to be checked:

- Generator rated voltage (Parameter 22)
- Voltage controller dead band (Parameter 71)
- Synchronizing dVmax (Parameter 133)
- Dead bus start GCB dVmax (Parameter 147)
- Threshold generator overvoltage (Parameter 202)
- Threshold generator undervoltage (Parameter 204)

Parameter 16

**Gen.volt.transf.**  
secondary 000V

only B + X Packages

**Secondary gen. voltage transformer** **[1] 50 to 125 V; [4] 50 to 480 V**

ⓘ This value corresponds to the **secondary** voltages of the PTs, which are directly connected to the control.

The secondary voltage is set here in V. This parameter is used to display the secondary voltages on the control unit screen.

Parameter 17

**Gen.volt.transf.**  
primary 00.000kV

only B + X Packages

**Primary gen. voltage transformer** **0.050 to 65.000 kV**

ⓘ This value corresponds to the **primary** voltages of the PTs.

The primary voltage is set her in kV. This parameter is used to display the primary voltages on the control unit screen. In the case of measured voltages of 100 V without a measurement transducer, 00.100 kV must be set here; for 400 V = 00.400 kV.

Parameter 18

**Bus.volt.transf.**  
secondary 000V

only B + X Packages

**Secondary busbar voltage transformer** **[1] 50 to 125 V; [4] 50 to 480 V**

ⓘ This value corresponds to the **secondary** voltages of the PTs, which are directly connected to the control.

The secondary voltage is set here in V. This parameter is used to display the secondary voltages on the control unit screen.

Parameter 19

**Bus.volt.transf.**  
primary 00.000kV

only B + X Packages

**Primary busbar voltage transformer** **0.050 to 65.000 kV**

ⓘ This value corresponds to the **primary voltages** of the PTs.

The primary voltage is set here in kV. This parameter is used to display the primary voltages on the control unit screen. In the case of measured voltages of 100 V without a measurement transducer, 00.100 kV must be set here; for 400 V = 00.400 kV.



## WARNING

If the value of the following parameter is changed, the values of the following parameters have to be checked:

- Threshold mains overvoltage (Parameter 212)
- Threshold mains undervoltage (Parameter 214)

Parameter 20

```
mains volt.trans
secondary 000V
```

only B + X Packages

**Secondary mains voltage transformer**

[1] 50 to 125 V; [4] 50 to 480 V

- ① This value corresponds to the **secondary** voltages of the PTs, which are directly connected to the control.

The secondary voltage is set here in V. This parameter is used to display the secondary voltages on the control unit screen.

Parameter 21

```
mains volt.trans
primary 00.000kV
```

only B + X Packages

**Primary mains voltage transformer**

0.050 to 65.000 kV

- ① This value corresponds to the **primary** voltages of the PTs.

The primary voltage is set here in kV. This parameter is used to display the primary voltages on the control unit screen. In the case of measured voltages of 100 V without a measurement transducer 00.100 kV must be set here, for 400 V = 00.400 kV.

## Rated Voltage Values

Parameter 22

```
Gen.voltage
U set 000V
```

only B + X Packages

**Generator setpoint voltage**

[1] 50 to 125 V; [4] 50- to 530 V

- ① This value corresponds to the **secondary** voltages of the PTs, which are directly connected to the control.

This value of the voltage specifies the set point of the generator voltage for no-load and isolated operation. The proportional entry of the parameter "Start voltage V controller" (Parameter 67) refers to this value.

Parameter 23

```
Rated voltage in
system 000V
```

only B + X Packages

**Rated voltage**

[1] 50 to 125 V; [4] 50 to 480 V

The rated voltage ( $V_{L-L}$ ) is preset with this value.

The proportional entries of the following parameters refer to this value:

- Generator voltage monitoring
- Mains voltage monitoring
- Dead band voltage controller
- Synchronization dV max
- Dead bus GCB dV max

Instead of these two voltage parameters, The following voltage system parameters are displayed for the **RPQ Package**:

The respective system is activated using the discrete input at the terminals 72 and 73. Refer to the Discrete Input section in Installation Manual 37320 for further information about this.

Parameter 24

<b>Rated Voltage</b>	
<b>System y</b>	000V

[y = 1 to 4]  
only **RPQ Package**

**Rated voltage system y [y = 1 to 4] [4] 50 to 480 V**

This value configures the rated voltage ( $V_{ph-ph}$ ).  
The percentage values of the following parameters refer to this value:

- Generator voltage monitoring
- Mains voltage monitoring
- Insensitivity voltage controller
- Synchronizing dV max
- Dead bus start GCB dV max

Parameter 25

<b>Setpoint Voltage</b>	
<b>System y</b>	000V

[y = 1 to 4]  
only **RPQ Package**

**Generator set point voltage system y [y = 1 to 4] [4] 50 to 530 V**

This voltage value configures the set point of the generator voltage in isolated and no-load operation. The percentage value of the parameter "Start voltage U control." (Parameter 67) refers to this value.

Parameter 26

<b>CT generator</b>	
<b>System y</b>	0000/x

[y = 1 to 4]  
only **RPQ Package**

**Current transformer generator system y [y = 1 to 4] 10 to 7.000/{X} A**

The input of the CT ratio is necessary in order to display and control the actual values. The CT ratio must be selected so that, at maximum power, at least 60 % of the CT nominal current flows. A lower percentage may lead to malfunctions. Additional inaccuracies in the control and monitoring functions also occur.

{x} = 1 A.....Secondary current = 1 A at primary rated current = {X} A;  
{x} = 5 A.....Secondary rated current = 5 A at primary rated current = {X} A;  
{X}.....e.g. from the main series 10, 15, 20, 30, 50 or 75 A and the decimal fractions and multiples of these or the corresponding secondary series with 25, 40 or 60 A.

Parameter 27

<b>Gen Rated curr.</b>	
<b>System y</b>	0000A

[y = 1 to 4]  
only **RPQ Package**

**Generator rated current system y [y = 1 to 4] 10 to 7.000 A**

Here the generator rated current is configured (only the percentage inputs for current protection refer to this parameter).

Parameter 28

<b>Gen rated power</b>	
<b>System y</b>	0000kW

[y = 1 to 4]  
only **RPQ Package**

**Generator rated power system y [y = 1 to 4] 5 to 9.999 kW**

Here the generator rated power is configured. The exact value of the generator rated power is absolutely vital. Many measurement, control and monitoring functions refer to this value (e.g. the percentage input for the power protection).

Parameter 29

Volt.meas./mon. -----
--------------------------

This parameter affects the display.

### Voltage measuring/voltage monitoring

### Ph-neut./Ph-Ph

**Ph-neut/Ph-neut** The electrical system(generator, busbar, and mains) consists of the three phase conductors and a neutral conductor. Thus the N lug (terminal 0) must be connected.

The phase-phase conductor voltages and the phase-neutral voltages are shown in the display.

The voltage monitoring entries are referred to the phase-neutral voltages ( $V_{L-N}$ ).

**Ph-neut/Ph-Ph** The electrical system(generator, busbar, and mains) consists of the three phase conductors and a neutral conductor. Thus the N lug (terminal 0) must be connected.

The phase-phase conductor voltages and the phase-neutral voltages are shown in the display.

The voltage monitoring entries are referred to the phase-phase voltages ( $V_{L-L}$ ).

**Ph-Ph/Ph-Ph** The electrical system(generator, busbar, and mains) consists only of the three phase conductors (without neutral conductor). Thus the N lug (terminal 0) cannot be connected.

Only the phase conductor voltages are shown in the display.

The voltage monitoring entries are referred to the phase-phase voltages ( $V_{L-L}$ ).



### NOTE

Terminal 0 must be isolated for the setting 'Ph-Ph/Ph-Ph' (voltage measuring Ph-Ph, voltage monitoring Ph-Ph) since a contact voltage in inadmissible range may occur at terminal 0.

# Generator Current

Parameter 30

**Current transf.  
generator 0000/x**

## Generator CT's

10 to 7,000/{X} A

The input of the CT ratio is necessary in order to display and control the actual values. The CT ratio must be selected so that, at maximum power, at least 60 % of the CT nominal current flows. A lower percentage may lead to malfunctions. Additional inaccuracies in the control and monitoring functions also occur.

- {x} = 1 A.....Secondary current = 1 A at primary rated current = {X} A;
- {x} = 5 A.....Secondary rated current = 5 A at primary rated current = {X} A;
- {X}.....e.g. from the main series 10, 15, 20, 30, 50 or 75 A and the decimal fractions and multiples of these or the corresponding secondary series with 25, 40 or 60 A.

Parameter 31

**Power measuring  
gen.-----**

## Generator power measurement

singlephase / threephase

With regard to the measurement of generator power, single-phase or three-phase measurement may be selected. If "single-phase power measurement" is set, the current and the voltage in phase L1 are used for power measurement. If "three-phase power measurement" is set, all three phase currents and the relevant voltages are used for power measurement.

- single-phase power measurement:  $P = \sqrt{3} \times V_{L12} \times I_{L1} \times \cos\phi$ .
- threephase power measurement:  
 $P = V_{L1N} \times I_{L1} \times \cos\phi + V_{L2N} \times I_{L2} \times \cos\phi + V_{L3N} \times I_{L3} \times \cos\phi$ .



### NOTE

With a positive real power, a positive real current flows in the "k-l" direction in the CT. Positive reactive power means that with a positive effective direction, inductive reactive (lagging) current flows in the effective direction. If the control is connected to the terminals of a generator and if the outgoing circuits of the CT facing the generator are connected to "k", the unit shows a positive real power when the generator supplies real power. In this regard, note the explanations in manual 37238.

Parameter 32

**Rated power  
generator 0000kW**

## Generator rated power

5 to 9,999 kW

Here the generator rated power is configured. The exact value of the generator rated power is absolutely vital. Many measurement, control and monitoring functions refer to this value (e.g. the percentage input for the power protection).

Parameter 33

**Rated current  
generator 0000A**

## Generator rated current

10 to 7,000 A

Here the generator rated current is configured (only the percentage inputs for current protection refer to this parameter).

## Mains Current/Mains Power Measurement

### Mains power **actual value** measurement via analog input (Package XP, Option T701)

Measurement of the mains power **actual value** via an analog input T{x} [x = 1-7] is possible if at least one of the analog inputs T{x} [x = 1-7] is a 0/4-20 input. Selection of the analog input is performed with the following parameters.

Parameter 34

<b>Analog in Pmains</b> <b>OFF</b>
---------------------------------------

Package XP, Option T701 only

#### Analog input P-mains: Selection

OFF / T{x}

**OFF**..... The mains interchange (import/export) real power **actual value** is calculated out of the measured mains current and the measured mains voltage. The analog inputs can either be used as real power **set point values** or as freely configurable alarm inputs. The following screens of this function are not displayed.

**T{x}**..... The mains interchange (import/export) real power **actual value** can be transmitted to the control by a measuring transducer and can be measured via the configured free scalable 0/4-20 mA input T{x} (x = 1-7) (other types of analog inputs cannot be used). The following screens of this function are displayed.

#### Note

Please note that the selected analog input T{x}

- Must be configured to OFF (Parameter 243) in chapter "Analog inputs" and that this analog input
- Must not be configured as generator real power **set point value** (Parameter 91)
- T{x}: Dependent on the control model these analog inputs are included and possibly built as 0/4-20 mA type. If the controller being configured is an analog input model, only 0/4-20 mA inputs may be used (only these inputs are displayed for selection at this parameter).
- LeoPC1 is not a dynamic program and must be restarted after reconfiguration of a control unit has been started so the changes are reflected in the graphical display of the PC program.

#### Priority of the functions of the analog inputs

The following priorities are valid if more than one function has been assigned to a analog input:

- Highest priority: Mains interchange (import/export) real power **actual value**
- Middle priority: Generator real power **set point value**
- Lowest priority: Measuring input as common analog value

Parameter 35

Analog in Pmains 0-00mA
----------------------------

Package XP, Option T701 only

**Analog input P mains: Range** **0 to 20 mA / 4 to 20 mA**

The measuring range 0 to 20 mA or 4 to 20 mA is selected with this parameter. If the range selected is 4 to 20 mA and the current is lower than 2 mA, a broken wire alarm is issued.

**Note**

It is possible to adjust the display range of the mains interchange (import/export) real power **actual value**. Thereto the wanted value must be entered and saved using the Parameter 244 "name and unit" of the selected analog input (see chapter "Analog inputs").



**NOTE**

For an import/export real power control application, ensure that the set point value selected is in the middle of the measuring range. This will allow the controller dynamic to be used to its fullest capacity.

Parameter 36

Analog in Pmains 0%      0000kW
------------------------------------

Package XP, Option T701 only

**Mains real power 0/4 mA** **[1] -9,990 to 9,990 kW; [4] -6,900 to 6,900 kW**

The scaleable analog input is assigned a numerical value, which corresponds to the lowest input value → (0 % corresponds to -500 kW; 0 or 4 mA).

Parameter 37

Analog in Pmains 100%    0000kW
------------------------------------

Package XP, Option T701 only

**Mains real power 20 mA** **[1] -9,990 to 9,990 kW; [4] -6,900 to 6,900 kW**

The scaleable analog input is assigned a numerical value, which corresponds to the highest input value → (100 % corresponds to 500 kW; 20 mA).

**Mains current measurement via mains CT**

Parameter 38

Current transf. mains      0000/x
--------------------------------------

**Mains current transformer** **5 to 7,000/{X} A**

The input of the CT ratio is necessary in order to display and control the actual values. The CT ratio must be selected so that at maximum power the CT is at 60 % of the converter's nominal current flow. A lower percentage may lead to malfunctions due to loss of resolution. Additional inaccuracies in the control and monitoring functions also occur.

- {x} = 1 A.....Secondary rated current = 1 A at primary rated current = {X} A;
- {x} = 5 A.....Secondary rated current = 5 A at primary rated current = {X} A;
- {X}.....e. g. from the main series 10, 15, 20, 30, 50 or 75 A and the decimal fractions and multiples of these or the corresponding secondary series with 12.5, 25, 40 or 60 A.

Parameter 39

LS 4 mode	ON
-----------	----

GPC-31/XP,  
Option L4 only

**LS 4 mode**

**ON/OFF**

**ON**..... The GCP is operating in LS 4 mode. The GCP controller expects CAN bus messages from an LS 4 and reacts accordingly. Additionally the GCP controller transmits messages to the LS 4.

**OFF**..... The control GCP operates as a normal genset control without LS 4 functionality.

Parameter 40

Rated power in system	00000kW
-----------------------	---------

GPC-31/XP,  
Option L4 only

**Rated power in the system**

**0 to 16,000 kW**

The LS 4 transmits the current mains interchange real power in percent related to the rated power in the system to the GCP controller.

**Note**

This configuration is valid only if parameter "LS 4 mode" is configured to ON.

**ATTENTION**

Since the LS 4 is only able to transmit a percentage value related to the rated power, it is absolutely necessary to configure the rated power in all units (LS 4 and GCP Parameter 32) to the same value.

**Measurement Units**



**NOTE**

LeoPC1 is not a dynamic program and must be restarted after reconfiguration of a control unit has been started so the changes are reflected in the graphical display of the PC program.

Parameter 41

Temperature in	-----
----------------	-------

**Analog inputs; temperature measurement in ...**

**Celsius / Fahrenheit**

The analog input for temperature measurement may be configured to display in °C or °F. The configured engineering unit is displayed in the LC display or transmitted via the CAN bus to other HMIs within the control system.

°C ⇔ °F	°F ⇔ °C
$T [°F] = (T [°C] \times 1,8) + 32$	$T [°C] = (T [°F] - 32) / 1,8$

Parameter 42

Pressure in	-----
-------------	-------

**Analog inputs; pressure measurement in ...**

**bar / psi**

The analog input for temperature measurement may be configured to display in bar or phi. The configured engineering unit is displayed in the LC display or transmitted via the CAN bus to other His within the control system.

bar ⇔ psi	psi ⇔ bar
$P [psi] = P [bar] \times 14,503$	$P [bar] = P [psi] / 14,503$

## Password Configuration



### NOTE

Once a password has been set, it will not change unless a person alters that parameter with access to, it regardless of how often the configuration mode is accessed. If an incorrect code number is entered, the code level is set to CS0 and the control is therefore locked for external users.

The control unit automatically reverts to code level CS0 two hours after the entry of a password or if the power supply is disconnected from the control unit. By entering the correct password, the corresponding level may again be accessed.

Parameter 43

Define level 1 code           0000
---------------------------------------

**Code level 1 (Customer) 0000 to 9999**

---

This parameter is only accessible with code level 2 rights. After the password has been set for this parameter, only the personnel who are assigned this password will have access rights to this code level. When the CS1 (Customer) password is entered, only select parameters may be accessed.

The default setting for this code level (CS) is **CS1 = 0 0 0 1**

Parameter 44

Define level 2 code           0000
---------------------------------------

**Code level 2 (Commissioner) 0000 to 9999**

---

This parameter is only accessible with code level 2 rights. After the password has been set for this parameter, only the personnel who are assigned this password will have access rights to this code level. When the CS1 (Customer) password is entered, only select parameters may be accessed.

The default setting for this code level (CS) is **CS2 = 0 0 0 2**

# Controller



## WARNING

Incorrect settings may lead to the errors in measurements and failures within the control unit resulting in destruction of equipment or injury to personnel.

Parameter 45

Configure controller	YES
----------------------	-----

### Configuration of the controller

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:  
**YES**..... The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).  
**NO**..... The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

## Table Of Set Point Values

Automatic 1	Automatic 2	Control via interface	External set point value	Specification of the set point value through
energized	insignificant	insignificant	insignificant	Set point 1 (Parameter 46)
de-energized	energized	OFF	OFF	Set point 2 (Parameter 47)
de-energized	energized	insignificant	ON	Externally via 0/4-20 mA input (Package XP, Option T701; Parameter 91)
de-energized	energized	ON	OFF	Externally via interface
de-energized	de-energized	OFF	OFF	Standby only: Emergency power (AMF)

Table 3-3: Set point value table

## Analog Controller Outputs (Package Q, Option Q)

As an alternative to a three-position controller output, the control may also be equipped with an analog controller output. If this option is selected, additional screens are displayed in the configuration mode. The analog PID controller forms a closed-loop control loop with the controlled system (usually a first-order lag element). The parameters of the PID controller (proportional-action coefficient  $K_{PR}$ , derivative-action time  $T_V$ , and reset time  $T_n$ ) can be modified individually. The additional configuration screens are used for this purpose.




Figure 3-1: Control loop

If an abrupt disturbance variable is applied to the control loop, the reaction of the controlled system can be recorded at the output as a function of time (step response).




Figure 3-2: Step response (Example)

Various values can be obtained from the step response; these are required for adjusting the controller to its optimum setting:

**Rise time  $T_{rise}$ :** Period starting when the value of the control variable leaves a predefined tolerance range for the control variable following a step in the disturbance variable or reference input variable and ending the first time the value re-enters this range.

**Settling time  $T_{sett}$ :** Period starting when the value of the control variable leaves a predefined tolerance range for the control variable following a step in the disturbance variable or reference input variable and ending when the value re-enters this range permanently.

**Overshoot  $x_m$ :** Highest transient set point value deviation during the transition from one steady-state condition to a new steady-state condition following modification of the disturbance variable or reference input variable ( $x_{m\text{ optimal}} \leq 10\%$ ).

**System deviation  $x_d$ :** Permanent deviation from the final value (PID controller:  $x_d = 0$ ).

The values for  $K_{PR}$ ,  $T_n$ , and  $T_V$  may be determined through various calculations from the values in the table above. Through these calculations (calculating compensation, adjustment of the time constants, T-sum rule, symmetric optimum, and/or Bode-diagram) it is possible to determine the optimal controller settings. Other setting procedures and information may be obtained from current literature.



## CAUTION

The following must be observed regarding the controller setting:

- Ensure that the emergency shutdown system is operational.
- While determining the critical frequency, pay attention to the amplitude and frequency.
- If the two values change uncontrollably:

**→ EMERGENCY SHUTDOWN ←**

**Initial state:** The start position of the controller is determined using the initial state of the controller. If the controller is switched off, the basic setting can be used to output a fixed controller position. If operation mode MANUAL has been selected, the initial state signal is output only with the "START" push button. Even when the analog controller is switched off, the initial state can be freely adjusted (e.g. the speed controller can be controlled in a linear manner). On setting the "STOP" push button, the analog controller is switched off again.

Controller outp. Init.state= 000%
--------------------------------------

**Initial state**

**0 to 100 %**

The value input in this parameter represents analog controller output setting with controller switched off. This value is also used as the initial state value.

**General settings:** The setting rule described below only serves as an example. It cannot be assumed that this is the proper method of control for your system since every system behaves uniquely.

There are various methods of setting a controller. The setting rules of Ziegler and Nichols are explained below (determination for abrupt disturbances on the system input); this setting method assumes a pure lag element connected in series with a first-order lag system.

1. Controller operated as a P-only controller  
(where  $T_n = \infty$  [screen setting:  $T_n = 0$ ],  $T_V = 0$ ).
2. Increase gain  $K_{PR}$  (P-gain) until  $K_P = K_{pkrit}$  when the control loop starts to oscillates continuously.



## ATTENTION

If the engine starts to oscillate uncontrollably, carry out an emergency shutdown and alter the screen setting accordingly.

3. At the same time, measure the critical cycle duration  $T_{crit}$
4. Set the parameters:

**PID-controller**

$$K_{PR} = 0.6 \times K_{Pcrit}$$

$$T_n = 0.5 \times T_{crit}$$

$$T_V = 0.125 \times T_{crit}$$

**PI-controller**

$$K_{PR} = 0.45 \times K_{Pcrit}$$

$$T_n = 0.83 \times T_{crit}$$




Figure 3-3: Step responds - governor configuration

**P-gain**  
Kpr = 000

**P-gain ( $K_{PR}$ )** Proportional-action coefficient

**1 to 240**

The proportional-action coefficient  $K_{PR}$  indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

**Reset time**  
Tn = 00.0s

**Reset time ( $T_n$ )**

**0.2 to 60.0 s**

The reset time  $T_n$  represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take to long to settle at a steady state.

**Derivative time**  
Tv=0.00s

**Derivative-action time ( $T_V$ )**

**0.00 to 6.00 s**

The derivative-action time  $T_V$  represents the D-component of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the actuator in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brake for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

## Real Power Controller, Set Point Values

These screens appear only if the generator real power controller has been configured to "ON" (Parameter 87).



### NOTE

The fixed-value power control does not take into account the mains interchange point. If excess power is generated, it will be exported to the mains. If there isn't enough power generated, the deficit in power will be imported from the mains.

Engine starting depends on whether an automatic start/stop operation has been enabled or disabled (Parameter 108 or Parameter 109). If it has been disabled, the engine will always start.

Parameter 46

Power controller
Pset1 I0000kW

#### P controller: set point 1

C/I/E 0 to 6,900 kW

Set point 1 is active when **Automatic 1** (voltage applied to terminal 3) is enabled. The mains interchange (import/export) real power is then controlled to the configured value.

Real generator power is controlled to the entered value.

**C**..... The letter C stands for fixed set point control (= base load). The generator will supply a constant level of power. The engine is always started on activation of fixed set point power.

Real mains interch. (import/export) real power is controlled to the entered value.

**I**..... The letter I stands for import power (power supplied by the mains). The mains always supply the power set here as long as the minimum and maximum generator real power are not exceeded (generator power swings).

**E**..... The letter E stands for export power (power supplied to the mains). The power set here is always supplied to the mains as long as the minimum and maximum generator real power are not exceeded (generator power swings).

Parameter 47

Power controller
Pset2 L0000kW

#### P controller: set point 2

C/I/E 0 to 6,900 kW

Set point 2 is active when **Automatic 2** (voltage applied to terminal 5) is enabled and no external set point value (0/4 to 20 mA or interface) has been enabled. The mains interchange (import/export) real power is controlled to the configured value.

Real generator power is controlled to the entered value.

**C**..... The letter C stands for fixed set point control (= base load). The generator will supply a constant level of power. The engine is always started on activation of fixed set point power.

Real mains interch. (import/export) real power is controlled to the entered value.

**I**..... The letter I stands for import power (power supplied by the mains). The mains always supply the power set here as long as the minimum and maximum generator real power are not exceeded (generator power swings).

**E**..... The letter E stands for export power (power supplied to the mains). The power set here is always supplied to the mains as long as the minimum and maximum generator real power are not exceeded (generator power swings).

# Frequency Controller

Parameter 48

Initial state  
Frequency 000%

Package Q, Option Q only

**f controller: initial frequency** **0 to 100 %**

Analog controller output setting with disabled controller. The set value in percent refers to the range between minimum and maximum value of the output signal (see Parameter 60 and Parameter 61).

Parameter 49

Freq.controller  
ON

**f controller: activation** **ON/OFF**

**ON** .....The generator frequency is controlled. The generator frequency is controlled through various methods depending on the task (isolated operation / synchronization). The subsequent screens of this function are displayed.

**OFF** .....Control is not carried out, and the subsequent screens of this function are not displayed.

Parameter 50

f-contr. active  
at: 00.0Hz

**f controller: starting frequency** **0.0 to 70.0 Hz**

The frequency controller is activated when the generator frequency has exceeded the value configured here. The undesired adjustment of the set point value of a lower-level controller can therefore be overridden when starting the engine.

Parameter 51

Delay time for  
f-contr. 000s

**f controller: delayed start** **0 to 999 s**

The time set in this parameter must expire before the frequency controller is enabled.

Parameter 52

Freq.controller  
ramp 00Hz/s

**f controller: set point ramp** **1 to 50 Hz/s**

The different set point values are supplied to the controller via this ramp. The slope of the ramp is used to alter the rate at which the controller modifies the set point value. The faster the change in the set point is to be carried out, the greater the value entered here must be.

Parameter 53

Freq.controller  
droop 00,0%

only RPQ Package

**f controller: droop** **0 to 20 %**

If the droop control is active, the droop portion configured here is considered for frequency control.



**NOTE**

The parameters for the speed/frequency controller influence the generator real power controller.

Parameter 54

```
F/P contr.type
-----
```

Package Q, Option Q only

**f controller: type**

**THREESTEP / ANALOG / PWM**

**THREESTEP** The signal to control the speed/frequency/real power is output via the relay manager to any configured relay. You can use the following functions of the relay manager:

- function 114 = n+ / f+ / P+
- function 115 = n- / f- / P-

Please note to wire an external RC protection (manual 37239).

**ANALOG** .... A control is done via the analog controller outputs to terminals 8/9/10. Selection of the type of the signal (mA or V) to be utilized is determined in Parameter 58. If a voltage output is desired, and jumper must be installed between terminals 8/9 (see manual 37239).

**PWM** ..... A control of speed/frequency/real power is carried out via a PWM signal. The settings in the Parameter 59 "Level PWM" are to be used. If a PWM output is desired, and jumper must be installed between terminals 8/9 (see manual 37239).

**Three-position controller (standard; Package Q, Option Q: setting 'THREESTEP')**

Parameter 55

```
Freq.controller
deadband 0.00Hz
```

**f controller: dead band**

**0.02 to 1.00 Hz**

**Isolated operation** The generator set point frequency is controlled in such a manner that, in its adjusted state, the current value deviates from the generator set point frequency by this configured dead band at most.

**Synchronization** The generator frequency is controlled in such a manner that, in its adjusted state, the differential frequency reaches the dead band at most. The mains or busbar frequency are used as the set point value.

Parameter 56

```
Freq.controller
time pulse>000ms
```

**f controller: minimum frequency**

**10 to 250 ms**

This parameter is the minimum ON time for the relays to be able to respond in a reliable manner to the raise/lower signals. The shortest possible time must be set here to ensure optimum control behavior.

Parameter 57

```
Freq.controller
gain Kp 00.0
```

**f controller: gain**

**0.1 to 99.9**

The gain factor  $K_p$  influences the operating time of the relays. By increasing the number in this parameter, the operating time can be increased in the event of a certain control deviation.

Analog controller output (**Package Q, Option Q: setting 'ANALOG/PWM'**)

Parameter 58

**F/P contr.output**  
-----

Package Q, Option Q only

**f controller: output range**

**see below**

If Parameter 54 has been configured to "ANALOG" this parameter must be configured to the appropriate type of analog controller. The range of the analog output is configured here. To switch from a current to a voltage or PWM output a jumper must be added to terminals 8/9. The ranges are listed below

Type	Setting in above configuration screen	Jumper between term. 8/9	Range	Lower level	Upper level
Current	+/-20mA (+/-10V)	no	+/-20mA	-20 mA	+20 mA
	+/-10mA (+/-5V)		+/-10mA	-10 mA	+20 mA
	0 to 10mA (0 to 5V)		0-10mA	0 mA	10 mA
	0 to 20mA (0 to 10V)		0-20mA	0 mA	20 mA
	4 to 20mA		4-20mA	4 mA	20 mA
	10 to 0mA (5 to 0V)		10-0mA	10 mA	0 mA
	20 to 0mA (10 to 0V)		20-0mA	20 mA	0 mA
	20 to 4mA		20-4mA	20 mA	4 mA
Voltage	+/-20mA (+/-10V)	yes	+/-10V	-10 Vdc	+10 Vdc
	+/-10mA (+/-5V)		+/-5V	-5 Vdc	+5 Vdc
	+/-3V		+/-3V	-3 Vdc	+3 Vdc
	+/-2.5V		+/-2.5V	-2.5Vdc	+2.5 Vdc
	+/-1V		+/-1V	-1 Vdc	+1 Vdc
	0 to 10mA (0 to 5V)		0 to 5V	0 Vdc	5 Vdc
	0.5V to 4.5V		0.5 to 4,5V	0.5 Vdc	4.5 Vdc
	0 to 20mA (0 to 10V)		0 to 10V	0 Vdc	10 Vdc
	10 to 0mA (5 to 0V)		5 to 0V	5 Vdc	0 Vdc
	4.5V to 0.5V		4.5 to 0,5V	4.5 Vdc	0.5 Vdc
	20 to 0mA (10 to 0V)		10 to 0V	10 Vdc	0 Vdc



**NOTE**

The control logic of the PWM signal can be inverted by following steps:

- Select "F/P contr.type" (Parameter 54) = ANALOG.
- Select with Parameter 58 "F/P contr.output" any of above inverted control outputs (e.g. "10 to 0mA (5 to 0V)", "4.5V to 0.5V", "20 to 0mA (10 to 0V)" or "20 to 4mA").
- Back up one screen (Parameter 54; by pressing "Select" and "Cursor→" simultaneously).
- Select "F/P contr.type" (Parameter 54) = PWM.

Now the PWM signal is inverted.

Parameter 59

**Level PWM**  
-----

Package Q, Option Q only

**f controller: PWM level**

**3.0 to 10.0 V**

If PWM has been selected in Parameter 58 the level of the PWM signal can be adjusted here.

Parameter 60

**Stepper sign.frq (min.)** 000%

Package Q, Option Q only

**f controller: minimum value**

**0 to 100%**

This parameter permits the operator to clamp or limit the lower analog output value.

Example: A 1 to 4V analog output is needed for the voltage controller to operate properly. A jumper is installed on the terminals as described above and the analog output of 0 to 5V is selected. The number to be configured in this parameter is determined by dividing the desired lower limit by the range (1/5=0.20 or 20%). 20% is the value to be configured in this parameter.

Parameter 61

Stepper sign.frq (max.)	000%
----------------------------	------

Package Q, Option Q only

**f controller: maximum value**

**0 to 100%**

This parameter permits the operator to clamp or limit the upper analog output value.

Example: A 1 to 4V analog output is needed for the voltage controller to operate properly. A jumper is installed on the terminals as described above and the analog output of 0 to 5V is selected. The number to be configured in this parameter is determined by dividing the desired upper limit by the range (4/5=0.80 or 80%). 80% is the value to be configured in this parameter.

Parameter 62

Freq. controller gain Kpr	000
------------------------------	-----

Package Q, Option Q only

**f controller:P gain**

**1 to 240**

The proportional coefficient specifies the gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 63

Freq. controller reset Tn	00.0s
------------------------------	-------

Package Q, Option Q only

**f controller: Reset time**

**0.0 to 60.0 s**

The reset time  $T_n$  identifies the I part of the PID controller. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take too long to settle at a steady state.

Parameter 64

Freq. controller derivat. Tv	0.00s
---------------------------------	-------

Package Q, Option Q only

**f controller: Derivative-action time**

**0.00 to 6.00 s**

The derivative-action time  $T_v$  identifies the D part of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the actuator in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brake for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

## Voltage Controller

Parameter 65

Starting point voltage	000%
---------------------------	------

Package Q, Option Q only

**V controller: initial state**

**0 to 100 %**

Analog controller output setting with disabled controller. The set value in percent refers to the range between minimum and maximum value of the output signal (see Parameter 75 and Parameter 76).

Parameter 66

Volt. controller	ON
------------------	----

**V controller: activation**

**ON/OFF**

**ON**..... Generator voltage control is carried out. The subsequent screens of this function are displayed.

**OFF**..... Generator voltage control is not carried out, and the subsequent screens of this function are not displayed.

Parameter 67

Start voltage  
U control. 000V

V controller: start voltage 12.0 to 100.0 %

| ⓘ This value refers to the generator set point voltage (Parameter 22). |

The voltage controller will be enabled, once the generator voltage has exceeded this value. This prevents an unintentional change of the set point of the voltage regulator when starting the engine.

Parameter 68

Delayed. Start  
U contr. 000s

V controller: delayed start 0 to 999 s

The start voltage of the voltage controller must exceed the threshold value for at least this period of time.

Parameter 69

Volt.controller  
droop 00,0%

only RPQ Package

V controller: droop 0 to 20 %

If the droop control is active, the droop portion configured here is considered for voltagecontrol.



**NOTE**

The following parameters for the voltage controller influence the power factor cos φ controller.

Parameter 70

V/Q contr.type  
-----

Package Q, Option Q only

V controller: type THREESTEP / ANALOG

**THREESTEP** The signal to control the voltage/power factor is output via the relay manager to any configured relay. You can use the following functions of the relay manager:

- function 116 = U+/Q+
- function 117 = U-/Q-

Please note to wire an external RC protection (manual 37239).

**ANALOG.....**Control is performed via the analog controller outputs to terminals 11/12/13. The type of signal (mA or V) to be utilized may be selected in Parameter 74 and along with the instructions on the installation of an external jumper between terminals.

**Three-position controller (standard; Package Q, Option Q: setting 'THREESTEP')**

Parameter 71

Volt.controller  
dead band 00.0%

V controller: dead band 00.1 to 15.0 %

| ⓘ This value refers to the parameter "rated voltage in system" (Parameter 19). |

**Isolated operation** The generator set point voltage is controlled in such a manner that the current value will deviate from the generator set point voltage by no more than the configured dead band.

**Synchronization** The generator voltage is controlled in such a manner that the differential voltage will not exceed the configured dead band. The mains or busbar voltage are used as the set point value.

Parameter 72

Volt.controller  
time pulse>000ms

V controller: minimum voltage 20 to 250 ms

This parameter is the minimum ON time for the relays to be able to respond in a reliable manner to the raise/lower signals. The shortest possible time must be set here to ensure optimum control behavior.

Parameter 73

Volt. controller gain Kp	00.0
--------------------------	------

**V controller: gain**

**0.1 to 99.9**

The gain factor  $K_p$  influences the operating time of the relays. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

**Analog controller (Package Q, Option Q: setting 'ANALOG')**

Parameter 74

V/Q contr.output	-----
------------------	-------

Package Q, Option Q only

**V controller: range**

**see below**

If the Parameter 70 has been configured to "ANALOG" this parameter must be configured to the appropriate type of analog controller. The range of the analog output is configured here. If a current analog output is to be utilized do not install a jumper between terminals 11/12. If a voltage analog output is to be utilized, a jumper must be installed between terminals 11/12. The following analog output ranges may be used with this controller.

Type	Setting in above configuration screen	Jumper between term. 11/12	Range	Lower level	Upper level
Current	+/-20mA (+/-10V)	no	+/-20mA	-20 mA	+20 mA
	+/-10mA (+/-5V)		+/-10mA	-10 mA	+20 mA
	0 to 10mA (0 to 5V)		0-10mA	0 mA	10 mA
	0 to 20mA (0 to 10V)		0-20mA	0 mA	20 mA
	4 to 20mA		4-20mA	4 mA	20 mA
	10 to 0mA (5 to 0V)		10-0mA	10 mA	0 mA
	20 to 0mA (10 to 0V)		20-0mA	20 mA	0 mA
Voltage	20 to 4mA	yes	20-4mA	20 mA	4 mA
	+/-20mA (+/-10V)		+/-10V	-10 Vdc	+10 Vdc
	+/-10mA (+/-5V)		+/-5V	-5 Vdc	+5 Vdc
	+/-3V		+/-3V	-3 Vdc	+3 Vdc
	+/-2.5V		+/-2.5V	-2.5Vdc	+2.5 Vdc
	+/-1V		+/-1V	-1 Vdc	+1 Vdc
	0 to 10mA (0 to 5V)		0 to 5V	0 Vdc	5 Vdc
	0.5V to 4.5V		0.5 to 4.5V	0.5 Vdc	4.5 Vdc
	0 to 20mA (0 to 10V)		0 to 10V	0 Vdc	10 Vdc
	10 to 0mA (5 to 0V)		5 to 0V	5 Vdc	0 Vdc
	4.5V to 0.5V		4.5 to 0.5V	4.5 Vdc	0.5 Vdc
	20 to 0mA (10 to 0V)		10 to 0V	10 Vdc	0 Vdc

Parameter 75

Stepper sign.vol (min.)	000%
-------------------------	------

Package Q, Option Q only

**V controller: minimum value**

**0 to 100%**

This parameter permits the operator to clamp or limit the lower analog output value.

Example: A 1 to 4V analog output is needed for the voltage controller to operate properly. A jumper is installed on the terminals as described above and the analog output of 0 to 5V is selected. The number to be configured in this parameter is determined by dividing the desired lower limit by the range (1/5=0.20 or 20%). 20% is the value to be configured in this parameter.

Parameter 76

Stepper sign.vol  
(max.) 000%

Package Q, Option Q only

**V controller: maximum value** **0 to 100%**

This parameter permits the operator to clamp or limit the upper analog output value.

Example: A 1 to 4V analog output is needed for the voltage controller to operate properly. A jumper is installed on the terminals as described above and the analog output of 0 to 5V is selected. The number to be configured in this parameter is determined by dividing the desired upper limit by the range (4/5=0.80 or 80%). 80% is the value to be configured in this parameter.

Parameter 77

Volt.controller  
gain Kpr 000

Package Q, Option Q only

**V controller: P-gain** **1 to 240**

The proportional coefficient specifies the gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 78

Volt.controller  
reset Tn 00.0s

Package Q, Option Q only

**V controller: reset time** **0.0 to 60.0 s**

The reset time  $T_n$  identifies the I portion of the PID loop. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take to long to settle at a steady state.

Parameter 79

Volt.controller  
derivat.Tv 0.00s

Package Q, Option Q only

**V controller: derivative-action time** **0.00 to 6.00 s**

The derivative-action time  $T_v$  identifies the D part of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the actuator in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brake for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

## Power Factor $\cos \phi$ Controller

Parameter 80

Pow. fact. contr. ON
-------------------------

**cos  $\phi$  controller: activation**

**ON/OFF**

**ON**..... In a mains parallel operation automatic control of the power factor is carried out. If there are excessively low currents (secondary current less than 5 %  $I_{rated}$ ) the power factor cannot be accurately measured. In order to prevent power swings, the controller automatically locks the power factor at a set value. The subsequent screens of this function are displayed.

**OFF**..... Power factor control is not performed, and the subsequent screens of this function are not displayed.

Parameter 81

Pow. fact. contr. setpoint 0.00
------------------------------------

**cos  $\phi$  controller: set point**

**i0.70 to 1.00 to c0.70**

The desired power factor may be configured here so that the reactive power is regulated in the system. The designations "i" and "c" stand for inductive/lagging (generator overexcited) and capacitive/leading (generator underexcited) reactive power. This set point is active only in mains parallel operation.



### NOTE

Please note the settings for the voltage controller in chapter "Voltage Controller" at page 39. The settings there for the voltage controller also influence the  $\cos \phi$  controller.

### Three-position controller (standard; **Package Q**, **Option Q**: setting 'THREESTEP')

Parameter 82

Pow. fact. contr. dead band 00.0%
--------------------------------------

**cos  $\phi$  controller: dead band**

**0.5 to 25.0 %**

The control automatically calculates the amount of reactive power which belongs to the power factor  $\phi_{setpoint}$ . In a mains parallel operation, the reactive power is controlled in such a manner in its regulated state that the actual value does not deviate from the generator power factor  $\cos \phi$  set point value by more than the percentage value of the sensitivity setting. In this case, the percentage value refers to the generator rated power (Parameter 32).

Parameter 83

Pow. fact. contr. gain Kp 00.0
-----------------------------------

**cos  $\phi$  controller: gain**

**0.1 to 99.9**

The gain factor  $K_p$  influences the operating time of the relays. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

**Analog controller (Package Q, Option Q: setting 'ANALOG')**

Parameter 84

<b>Pow.fact.contr.</b>	
<b>gain Kpr</b>	<b>000</b>

Package Q, Option Q only

**cos  $\phi$  controller:P-gain****1 to 240**

The proportional coefficient specifies the gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 85

<b>Pow.fact.contr.</b>	
<b>reset Tn</b>	<b>00.0s</b>

Package Q, Option Q only

**cos  $\phi$  controller:reset time****0.0 to 60.0 s**

The reset time  $T_n$  identifies the I portion of the PID loop. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take too long to settle at a steady state.

Parameter 86

<b>Pow.fact.contr.</b>	
<b>derivat.Tv</b>	<b>0.00s</b>

Package Q, Option Q only

**cos  $\phi$  controller:derivative-action time****0.00 to 6.00 s**

The derivative-action time  $T_v$  identifies the D part of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the actuator in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brake for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

### Real Power Controller

Parameter 87

Power controller  
ON

**P controller: activation**

**ON/OFF**

**ON**..... In mains parallel operation the real power is automatically adjusted to the pre-selected set point (Parameter 46 or Parameter 47) when the real power controller is configured ON. The subsequent screens of this function are displayed.

**OFF**..... Real power control is not performed, and the subsequent screens of this function are not displayed.

Parameter 88

power controller  
ramp 000%/s

**P controller: set point ramp %/s**

**0 to 100 %/s**

Different set point values are supplied to the controller through this ramp in a percent per second reference to the generator rated power (Parameter 32). The slope of the ramp is used to determine the rate at which the controller modifies the set point value. The more rapidly the change in the set point is to be carried out, the greater this value has to be.

### Power Limitation

Parameter 89

Power limit  
P max. 000%

**P controller: maximum power limitation**

**10 to 120 %**

If the maximum real generator load is to be limited, a percentage based on the rated generator power (Parameter 32) must entered here. The controller adjusts the generator in such a manner that this value is not exceeded. This parameter limits the set point of the real power controller when the generator is in a mains parallel operation.

Parameter 90

Power limit  
P min. 00%

**P controller: minimum power limitation**

**0 to 50 %**

If the minimum real generator load is to be limited, a percentage based on the rated generator power (Parameter 32) must entered here, in accordance with the specified setting limits. The controller adjusts the generator so that the real power generated does not fall below this limit. This parameter is ignored in the case of fixed-set point control or isolated operation.

### External setpoint value (Package XP, Option T701)

The generator real power **set point value** may be monitored via an analog input T{x} [x = 1 to 7] if one of the analog inputs T{x} [x = 1 to 7] is utilized as a 0/4 to 20 mA input. The selection of the analog input is done using the following parameters.

Parameter 91

Power setpoint	
external	OFF

Package XP, Option T701 only

**P set point value: external set point value** **OFF / T{x}**

**OFF** .....If this parameter is configured to "OFF" a generator real power **set point value** is not monitored via the 0/4 to 20 mA input to the control. The analog inputs can be used either as a mains interchange (import/export) real power **actual** value or as freely configurable alarm inputs. If terminal 5 is utilized, the internal set point value 2 "P<sub>set2</sub>" (Parameter 47) is used as set point value. The subsequent screens of this function are not displayed.

**T{x}** .....The generator real power **set point value** is monitored by the control via an external signal using the 0/4 to 20 mA inputs (T{x}, {x} = 1 to 7). If terminal 5 is utilized, the internal set point value 2 "P<sub>set2</sub>" (Parameter 47) is used as set point value. The subsequent screens of this function are displayed.

#### Note

Please note the following if analog input T{x} has been selected:

- Parameter 243 in chapter "Analog inputs" must be configured as OFF
- Parameter 34) in chapter "Measuring" must not be configured as mains interchange real power **actual value**.
- T{x}: Depending on the configuration of the control it is possible that various analog inputs other than the 0/4 to 20mA type may be used. For this function, only 0/4 to 20mA may be used.
- LeoPC1 is not a dynamic program and must be restarted after reconfiguration of a control unit has been started so the changes are reflected in the graphical display of the PC program.

#### Priority of the functions of the analog inputs

The following priority is valid if more than one function has been assigned to a analog input:

- Highest priority: Mains interchange real power **actual value** measurement
- Middle priority: Real power **set point value**
- Lowest priority: Measuring input as common analog value

Parameter 92

**Analog input**  
0-00mA

Package XP, Option T701 only

**P set point value: range**

**0 to 20 / 4 to 20 mA**

The analog input of the real power controller can be switched here between 0 to 20 mA and 4 to 20 mA depending on the set point source.

**0 to 20 mA** ... Minimum value of the set point at 0 mA; maximum value at 20 mA.

**4 to 20 mA** ... Minimum value of the set point at 4 mA; maximum value at 20 mA.



**CAUTION**

The interchange real power set point may also be scaled. When controlling the interchange power, it is vital to ensure that C power is not entered simultaneously with I or E power when scaling the external analog input.

<b>External setpoint</b>	<b>0/4 mA</b>	<b>C</b>	<b>I</b>	<b>E</b>	<b>I</b>	<b>E</b>
<b>External setpoint</b>	<b>20 mA</b>	<b>C</b>	<b>I</b>	<b>E</b>	<b>E</b>	<b>I</b>

Parameter 93

**Ext. setpoint**  
0mA 0000kW

Package XP, Option T701 only

**P set point value: scaling minimum value**

**C/I/E 0 to 9,999 kW**

The minimum value of the generator real power is defined here (e. g. 0 kW).

Parameter 94

**Ext. setpoint**  
20mA 0000kW

Package XP, Option T701 only

**P set point value: scaling maximum value**

**C/I/E 0 to 9,999 kW**

The maximum value of the generator real power is defined here (e. g. 100 kW).

Three-position controller (standard; Package Q, Option Q: setting 'THREESTEP')

Parameter 95

Power controller dead band 00.0%
-------------------------------------

**P controller: dead band** **0.1 to 25.0 %**

---

In a mains parallel operation, the real power is controlled in such a manner in its regulated state that the actual value does not deviate from the generator real power set point value by more than the percentage value of the sensitivity setting. In this case, the percentage value refers to the generator rated power (Parameter 32).

Parameter 96

Power controller gain Kp 00.0
----------------------------------

**P controller: gain factor** **0.1 to 99.9**

---

The gain factor  $K_p$  influences the operating time of the relays. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 97

Powercontr. dead band ratio *0.0
-------------------------------------

**P controller: dead band factor** **1.0 to 9.9**

---

If no adjusting pulses have been output for at least 5 seconds after the last adjustment of the controller, the dead band is expanded by this factor.

*For example:* In the case of an dead band of 2.5 % and a factor of 2.0 the dead band is increased after 5 s to 5.0 %. If the control deviation subsequently exceeds 5.0 %, again, the controller's original sensitivity is automatically reset (2.5 %). This input can be used, in the event of small control deviations, to avoid unnecessarily frequent actuation processes, thereby protecting the voltage regulator.

## Analog controller (Package Q, Option Q: setting 'ANALOG')

Parameter 98

Power controller gain Kpr	000
------------------------------	-----

Package Q, Option Q only

### P controller: P gain

1 to 240

The proportional coefficient specifies the gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 99

Power controller reset Tn	00.0s
------------------------------	-------

Package Q, Option Q only

### P controller: reset time

0.0 to 60.0 s

The reset time  $T_n$  identifies the I portion of the PID loop. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take too long to settle at a steady state.

Parameter 100

Power controller derivat.Tv	0.00s
--------------------------------	-------

Package Q, Option Q only

### P controller: derivative-action time

0.00 to 6.00 s

The derivative action time  $T_v$  identifies the D part of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the actuator in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brake for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

## Partial load lead

Parameter 101

Warm up load limit value	000%
-----------------------------	------

### P controller: part-load lead limit

5 to 110 %

If the engine requires a warm-up period, a lower fixed load value power may be entered for the engine warm-up period. The setting for the generator load that is to be utilized during this warm-up phase is made with this parameter. The fixed load is a percentage of the generator rated power (Parameter 32).

Parameter 102

Warm up load time	000s
----------------------	------

### P controller: part-load lead time

0 to 600 s

The length of the warm-up period with part-load following the initial closure of the GCB in mains parallel operation is configured here. If an engine warm-up period is not desired, this parameter must be set to zero.

## Load And/Or Var Sharing

The control ensures load and/or var sharing adjusted to the rated power of the generators under every operating condition (mains parallel operation, isolated operation in parallel with other gensets, or reverse synchronization of the busbar to the mains).

The controls with the GCB close and not in constant/base load mode will load and/or var share.

The rated power of the generators is max. 10 MW. Thus, up to 14 generators with a maximum of 10 MW each may share the power.

**Operating in mains parallel with mains interchange (import/export) real power control:** Each controller participating in load/var sharing controls the generator set to which it is assigned so that the real power set point at the mains interchange remains constant. The real power set point for the mains interchange must be configured identically in each controller.

All controllers communicate via a CAN bus. This enables the controllers to adjust the real power generated by the generator while remaining within the rated power of the generator. A smaller generator will contribute less real power as compared to a large generator, but they will both be utilized to the same capacity factor. An example of this would be a 100KW generator and a 1000KW generator and a mains interchange of 825KW. The 100KW generator would contribute 75KW and the 1000KW generator would contribute 750 KW or both generators would be at 75% of their rated capacity.

No reactive power sharing is performed when operating in parallel with the mains. The reactive power will be defined by the configured power factor set point of the individual controllers.

The parameter "kW/kvar sharing: reference variable kW" can be used now to define the priority of the reference variable (real power at interchange) for real power sharing. A higher percentage influences the control more towards the real power set point for the interchange. A lower percentage influences the control more towards real power sharing.

The parameter "kW/kvar sharing: reference variable kvar" has no influence here.

**Isolated operation in parallel:** Each controller participating in load/var sharing controls the generator set to which it is assigned in such a manner that the set frequency and the set voltage at the bus remain constant. This makes it imperative that the same frequency and voltage set points are configured for each controller.

All controllers communicate via a CAN bus. This enables the controllers to adjust the real power generated by the generator while remaining within the rated power of the generator. A smaller generator will contribute less real power as compared to a large generator, but they will both be utilized to the same capacity factor. An example of this would be a 100KW generator and a 1000KW generator and a load of 825KW. The 100KW generator would contribute 75KW and the 1000KW generator would contribute 750 KW or both generators would be at 75% of their rated capacity.

The reactive power will be allocated in a way that it is the same for all generators involved.

The parameter "kW/kvar sharing: reference variable kW" can be used now to define the priority of the reference variable (frequency) for real power sharing. A higher percentage influences the control more towards frequency control. A lower percentage influences the control more towards real power sharing.

The parameter "kW/kvar sharing: reference variable kvar" can be used now to define the priority of the reference variable (voltage) for reactive power sharing. A higher percentage influences the control more towards voltage control. A lower percentage influences the control more towards reactive power sharing.

**Reverse synchronization of the busbar to the mains:** Distribution is carried out according to the type of isolated operation. The set point value for the bus frequency is determined by the mains frequency +  $df_{\max}/2$ .

Example: If  $df_{\max} = 0.2$  Hz, this results for  $df_{\max}/2 = 0.1$  Hz (i.e. in a system of 50 Hz, the busbar will be raised to 50.1 Hz).

The relay issues "Command: close GCB" to all controls so they may be paralleled.

**Prerequisites:** The rated system frequencies, the start/stop parameters, and the breaker logics must all be set to the same values for all controls participating in the distribution control.

**Description of the interface for distribution control:** Distribution control is based on a multi-master-capable bus between the controls. This structure enables the parallel operation of up to 14 gensets.

The following must be noted to ensure proper operation:

- The maximum bus length must not exceed 250 meters (820 feet).
- The bus must be terminated at each end with terminating resistors that correspond to the wave impedance of the bus cable (approx. 80-120 Ω).
- The bus must be of a linear structure. Dead-end feeders are not permissible.
- Shielded "Twister-Pairs" are recommended for use as the bus cable (e.g.: Lappkabel Unitronic LIYCY (TP) 2x2x0.25, UNITRONIC-Bus LD 2x2x0.22).
- The bus cable must not be routed in the vicinity of heavy current power lines.

**Wiring diagram**




Figure 3-4: CAN bus load/var sharing, wiring diagram

**Diagram of load/var sharing via the CAN bus:** The parameter "Active load sharing factor" determines if and how a generator carries out real power or frequency control when paralleled with other generators in an isolated operation. This parameter is defined as a percentage. In figure below 10 % means increased real power control and 99 % increased frequency control. This parameter must be configured individually for each generator.

In the illustrated control system, it must be noted that each control calculates the mean utilization factor of all controls from the data transmitted via the CAN bus and then compares this with its own utilization factor. The utilization factor is compared with the reference variable and results in a new reference variable. Frequency and real power control are carried out simultaneously in these controls (corresponding to the reference variable).

Frequency control is carried out via the measured voltage/frequency of the voltage system. The Pickup is used merely for monitoring functions, or is available as a current control value to the secondary controller.




Figure 3-5: CAN bus load/var sharing, diagram

Parameter 103

Active power load-share ON

**kW/kvar sharing: load sharing** **ON/OFF**

**ON** .....Real power is shared between multiple generators operating in parallel. The generator outputs are distributed depending on the configured value. The subsequent screens of this function are displayed.  
**OFF** .....No real power sharing is carried out, and the subsequent screens of this function are not displayed.

Parameter 104

Act. load share factor 00%

**kW/kvar sharing: reference variable kW** **10 to 99 %**

Increasing the load share factor increases the priority of the primary control variable to the control. The lower the factor is configured, the greater the priority of the secondary control variable.

Definition "Primary control variable"

- Isolated operation = frequency
- Mains parallel operation = real power (at the mains interchange point)

Definition "Secondary control variable"

- Isolated operation = real power related to the other generators
- Mains parallel operation = real power related to the other generators

The smaller this factor the higher the priority to equally share the load to all generators.

Parameter 105

Reactive power load share ON

**kW/kvar sharing: var sharing** **ON/OFF**

**ON** .....Reactive power is shared between multiple generators operating in parallel. The generator outputs are distributed depending on the configured value. The subsequent screens of this function are displayed.  
**OFF** .....No reactive load sharing is carried out, and the subsequent screens of this function are not displayed.

Parameter 106

React.load share factor 00%

**kW/kvar sharing: reference variable kvar** **10 to 99 %**

Increasing the load share factor increases the priority of the primary control variable (the voltage) to the control. The lower the factor is configured, the greater the priority of the secondary control variable (generator reactive power). Var sharing is activated during isolated parallel operating only.

# Automatic



Parameter 107

Configure automatic	YES
------------------------	-----

## Configuration of automatic

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:

**YES**..... The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO**..... The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

## Load Management



### NOTE

To enable the automatic start/stop function, Parameter 103 "Active power load-share" must be configured to "ON", regardless if additional generators are available for load sharing.



### NOTE

To carry out an automatic start/stop of the engine, all participating controls must be configured with the identical rated power (Parameter 32).

## Load-dependent start/stop in mains parallel operation

Parameter 108

Loadd.start/stop at ter.3	ON
------------------------------	----

## Load dependent start/stop: enable via terminal 3

ON/OFF

**ON**..... If the control input "Automatic 1" (terminal 3) is enabled, an automatic start/stop is performed on the basis of the generator set point real power 1 (Parameter 46). If terminal 5 is enabled simultaneously, terminal 3 has priority. The subsequent screens of this function are displayed.

**OFF**..... No automatic start/stop is performed. The adjustment of the pre-specified set point value is always carried out. The subsequent screens of this function are not displayed.

Parameter 109

Loadd.start/stop at ter.5	ON
------------------------------	----

## Load dependent start/stop: enable via terminal 5

ON/OFF

**ON**..... If the control input "Automatic 2" (terminal 5) is enabled, an automatic start/stop is performed on the basis of the generator set point real power 2 (Parameter 47). If terminal 3 is enabled simultaneously, terminal 3 has priority. The subsequent screens of this function are displayed.

**OFF**..... No automatic start/stop is performed. The adjustment of the pre-specified set point value is always carried out. The subsequent screens of this function are not displayed.

Single generator in mains parallel operation

The load-dependent start/stop function is activated when all of the following conditions have been met:

- the operation mode AUTOMATIC has been selected
- interchange power control (import/export power) has been activated by one of the two discrete inputs ("Automatic 1" or "Automatic 2") ("I" or "E" power)
- one or both parameters "Load-dependent start/stop on terminal 3/5" (Parameter 108 or Parameter 109) has been configured to "ON".

Parameter 110

**Minimum load  
generator 0000kW**

**Load dependent start/stop: generator minimum set point power 0 to 6,900 kW**

For the mains interchange (import/export) real power control to function, a generator power set point value is required. In many cases, starting of the engine should only be performed once a specific generator power set point value has been reached in order to operate the generator with a reasonable degree of efficiency. For example: At least 40 kW of real power has to be supplied by 80 kW generator before the engine is to be started.

Parameter 111

**Add-on delay  
mains oper. 000s**

**Load dependent start/stop: start delay 0 to 999 s**

Starting may be delayed even if the generator start power limit has been reached. In order to avoid starting the engine in the event of short-term load swings, a start delay may be entered here in seconds. The start power (Parameter 110) must therefore be present without interruption during this period of time, in order to ensure that the engine is started. If the load drops below the set start power limit before the time configured here expires, the counter is reset to 0.

Parameter 112

**Shed-off delay  
mains oper. 000s**

**Load dependent start/stop: stop delay 0 to 999 s**

Stopping can be delayed even if the generator stop power limit has been reached. In order to avoid shutting the engine down in the event of short-term load swings, a stop delay may be entered here in seconds. The stop power (Parameter 113) must therefore be present without interruption during this period of time, in order to ensure that the engine is stopped. If the load rises above the set stop power limit before the time configured here expires, the counter is reset to 0.

Stopping hysteresis



**NOTE**

The following Parameter 113 is used to determine stopping hysteresis for single gensets in mains parallel operation, for generators connected to other generators in mains parallel operation, and in isolated operation in parallel with other gensets. However, the parameter appears only once in this text.

Parameter 113

**Hysteresis add-.  
on/off op.0000kW**

**Load dependent start/stop: hysteresis 0 to 9,999 kW**

The stop power value of the generator is determined via a hysteresis. The hysteresis is used to prevent the engine continuously starting and shutting down again.

Mains parallel operation (mains interchange (import/export) real power control with one generator)**General**Case 1: Start of the engine

If  $[P_{NT.setpoint} - P_{NT.actual} > P_{start}]$  the engine starts. (a)

Case 2: Stop of the engine

If  $[P_{NT.setpoint} - P_{NT.actual} + P_{GN.actual.tot} < P_{start} - P_{Hyst}]$  the engine stops. (b)

**Example**

The power supplied by the mains, which is to be adjusted, is 50 kW. This value is entered into the set point value screen (see chapter "Controller") as "I0050kW". The generator should be operated with at least 30 kW.

$P_{NT.setpoint} = -50$  kW Incoming/import power has to be entered negative, output/export power positive.  
 $P_{star} = 30$  kW The minimum power requested by the generator.  
 $P_{Hyst} = 10$  kW The power hysteresis for stopping.

When inserted into the above-mentioned formula, this means:

Case 1: The engine starts with the following import mains power: If formula (a) is inverted, this results in

$$[P_{NT.actual} < P_{NT.setpoint} - P_{start}] \Rightarrow P_{NT.actual} < -50 \text{ kW} - 30 \text{ kW} = -80 \text{ kW} \Rightarrow \text{"I0080 kW"}$$

The power supplied by the mains must be at least 80 kW in order for the engine to start. This is then operated with a minimum power of 30 kW.

Case 2: The engine stops if it has to supply less than the minimum power minus hysteresis. This is the case with the following generator power: If formula (b) is inverted, this results in

$$[P_{GN.actual} = \text{stop power engine} < -P_{NT.setpoint} + P_{NT.actual} + P_{start} - P_{hyst}].$$

$$[P_{GN.actual} < -50 \text{ kW} + 50 \text{ kW} + 30 \text{ kW} - 10 \text{ kW} = 20 \text{ kW}].$$

If the generator falls below its minimum power minus hysteresis, the engine is stopped. The power imported from the mains therefore remains at the value that is to be controlled until just prior to stopping. Following stopping, the power supplied by the mains increases to 70 kW.

Load sharing with other generators in mains parallel operation

The load-dependent start/stop function is activated for every control when the following criteria has been met:

- the operation mode AUTOMATIC has been selected
- interchange power control (import/export power) has been activated by one of the two discrete inputs ("Automatic 1" or "Automatic 2") (" E " or " I " power)
- all parameters, such as start/stop power, start/stop delays, and selected set point values are identical for all generators involved
- one or both parameters "Load-dependent stop/start on terminal 3/5" has been configured to "ON"
- the parameter "Load sharing" or "var sharing" have been configured to "O N"
- **the same rated power** is available from **all generators**.



**NOTE**

The following Parameter 114 only applies if more than one generator is to be started in mains parallel operation. The first engine is started as described under single generator in mains parallel operation on the basis of the minimum generator power.

Parameter 114

Reserve power  
mains op. 0000kW

**Load dependent start/stop: reserve power**

**0 to 9,999 kW**

Starting of an additional engine is determined via the reserve power. The reserve power results from the currently available **total** generator **rated** real power (generator **rated** real power × number of closed GCB's) and the currently available **total** generator **actual** real power. If the currently available **total** generator **actual** real power is subtracted from the currently available **total** generator **rated** real power, this results in the system's **reserve power**. If negative deviation from this reserve power occurs, the next engine is started.

$$\begin{aligned} & \text{Currently available total generator rated real power} \\ & - \text{Currently available total generator actual real power} \\ & = \text{Reserve power} \end{aligned}$$

Parameter 115

Priority of  
generators 0

**Load dependent start/stop: priority of generators**

**0 to 14**

This priority specifies the sequence in which the individual engines are started. The control with the lowest configured number has the highest priority. This engine is the first to be started and the last to be stopped. In the event of identical priorities, the starting sequence is determined by the operating hours. In this case, the engine with the lowest operating hours takes priority. In the event of the same number of operating hours, the engine with the lowest control number (generator number, Parameter 4) is started.

Mains parallel operation(mains interchange (import/export) real power control with several generators)**General**Case 3: Start of the first engine

All GCBs are open.

If  $[P_{NT.setpoint} - P_{NT.actual} > P_{start}]$  the first engine is started. (c)

Case 4: Starting of additional engines

At least one GCB in the group is closed.

If  $[P_{GN.actual.tot} + P_{reserve.parallel} > P_{rated.tot}]$  the next engine is started. (d)

Case 5: Stopping

At least two GCB's in the group are closed.

If  $[P_{GN.act.tot} + P_{reserve.parallel} + P_{hyst} + P_{rated} < P_{rated.tot}]$  a engine is stopped. (e)

Case 6: Stopping of the last engine

Only one GCB in the group is closed.

If  $[P_{NT.setpoint} - P_{NT.actual} + P_{GN.actual.tot} < P_{start} - P_{hyst}]$  the last engine is stopped. (f)

**Example**

The real power supplied by the mains, which is to be adjusted, is 0 kW. This value is entered as the set point value (see chapter "Controllers") as "I0000kW" (corresponds to "E0000kW"). The reserve power in the system should be 40 kW. The power hysteresis should be 20 kW. Three generators are to be operated within the group. The rated power of a generator is 200 kW. The minimum power of a generator should be 30 kW.

$P_{Rated}$	= 200 kW	Rated power of a generator.
$P_{Rated.tot}$		Total of the rated power values of the gensets with closed GCB's.
$P_{Start.tot}$	= 30 kW	Minimum power of a generator.
$P_{NT.actual}$		Current mains power.
$P_{NT.setpoint}$	= B0000 kW	Set point mains power
$P_{Reserve.Parallel}$	= 40 kW	Reserve power in mains parallel operation
$P_{Hyst}$	= 20 kW	Power hysteresis
No. GCB		Number of closed GCB's

Case 3: Power supplied by the mains, with which the first engine is started:

$$P_{NT.actual} < P_{NT.setpoint} - P_{start.gen}$$

$$P_{NT.actual} < 0 \text{ kW} - 30 \text{ kW} = -30 \text{ kW} \Rightarrow I0030 \text{ kW}.$$

The power supplied by the mains must be at least 30 kW in order for the first engine to start. This is then operated with a minimum power of 30 kW.

Case 4: Generator real power, at which the second engine is started:

$$P_{GN.actual} > P_{rated.tot} - (P_{Reserve.Parallel} / \text{No. GCB}).$$

$$P_{GN.actual} > 200 \text{ kW} - (40 \text{ kW} / 1) = 160 \text{ kW}.$$

If the generator real power exceeds 160 kW, negative deviation from the pre-specified reserve power has occurred. As a result of this, the next engine is started.

Case 4: Generator real power of each individual generator, at which the third engine is started:

$$P_{GN.actual} > P_{rated.tot} - (P_{reserve.parallel} / \text{No. GCB}) - P_{rated}$$

$$P_{GN.actual} > 400 \text{ kW} - (40 \text{ kW} / 2) - 200 \text{ kW} = 180 \text{ kW}.$$

If the generator real power of both generators exceeds 360 kW (each generator supplies more than 180 kW), negative deviation from the pre-specified reserve power has occurred. As a result of this, the next engine is started.

Case 5: Generator real power of each individual generators, at which one engine is stopped:

$$P_{GN.actual.tot} < P_{rated.tot} - P_{reserve.parallel} - P_{rated} - P_{hyst}$$

$$P_{GN.actual.tot} < 600 \text{ kW} - 40 \text{ kW} - 200 \text{ kW} - 20 \text{ kW} = 340 \text{ kW}.$$

$$(P_{GN.actual} < P_{GN.actual.tot}) / \text{No. GCB} = 340 \text{ kW} / 3 = 113.3 \text{ kW}.$$

If the generator real power of the three generators falls below 340 kW (each individual generator below 113.3 kW), one engine is stopped. After one engine has been stopped, the reserve power is still available.

Case 5: Generator real power of each individual generator, at which one of the two engines is stopped:

$$P_{GN.actual.tot} < P_{rated.tot} - P_{reserve.parallel} - P_{rated} - P_{hyst}$$

$$P_{GN.actual.tot} < 400 \text{ kW} - 40 \text{ kW} - 200 \text{ kW} - 20 \text{ kW} = 140 \text{ kW}.$$

$$(P_{GN.actual} < P_{GN.actual.tot}) / \text{No. GCB} = 140 \text{ kW} / 2 = 70 \text{ kW}.$$

If the generator real power of the two generators falls below 140 kW (each individual generator below 70 kW), one engine is stopped. After the engine has been stopped, the reserve power is still available.

Case 6: Generator real power, at which the last engine is stopped:

$$P_{GN.actual} < - P_{NT.setpoint} + P_{NT.actual} + P_{start.gen} - P_{hyst}$$

$$P_{GN.actual} < - 0 \text{ kW} + 0 \text{ kW} + 30 \text{ kW} - 20 \text{ kW} = 10 \text{ kW}.$$

If the generator falls below its minimum real power minus hysteresis, the engine is stopped. The power imported from the mains therefore remains at the value that is to be controlled until just prior to stopping. Following stopping, the power supplied by the mains increases to 10 kW.

***Isolated operation in parallel with other generators***

The load-dependent start/stop function is activated for every control when the following criteria has been met:

- the operation mode AUTOMATIC has been selected
- all parameters, such as start power (Parameter 110), stop power (Parameter 113), start delay (Parameter 111), stop delay (Parameter 112) and the frequency set point values (Parameter 10) are identical for all controls involved
- one or both parameters "Load-dependent stop/start on terminal 3/5" (Parameter 108 or Parameter 109) has/have been configured to "ON"
- the parameters "Load sharing" (Parameter 103) or "var sharing" (Parameter 105) have been configured as "ON"
- **All generators** are configured to **the same rated power** (Parameter 32)

**NOTE**

The reserve power (Parameter 116) should be selected in such a manner that expected load swings will not overload the generator.

Parameter 116

Reserve power isol.op. 0000kW
----------------------------------

**Load dependent start/stop: reserve power (isolated operation)****0 to 9,999 kW**

Starting of an additional engine is determined via the reserve power. The reserve power results from the currently available **total** generator **rated** real power (generator **rated** real power × number of closed GCB's) and the currently available **total** generator **actual** real power. If the currently available **total** generator **actual** real power is subtracted from the currently available **total** generator **rated** real power, this results in the system's **reserve power**. If negative deviation from this reserve power occurs, the next engine is started.

Currently available **total** generator **rated** real power  
 - Currently available **total** generator **actual** real power  
 = **Reserve power**

Parameter 117

Add-on delay isol.op. 000s
-------------------------------

**Load dependent start/stop: start delay (isolated operation)****0 to 999 s**

Starting may be delayed even if the engine's start power (Parameter 110) has been reached. In order to avoid starting the engine in the event of short-term load swings, a start delay may be entered in seconds. The start power (Parameter 110) must therefore be present without interruption during this period of time, in order to ensure that the engine is started. If the load drops below the set start power limit before the time configured here expires, the counter is reset to 0.

Parameter 118

Shed-off delay isol.op. 000s
---------------------------------

**Load dependent start/stop: stop delay (isolated operation)****0 to 999 s**

Stopping can be delayed even if the engine's stop power (Parameter 113) has been reached. In order to avoid shutting the engine down in the event of short-term load swings, a stop delay may be entered in seconds. The stop power (Parameter 113) must therefore be present without interruption during this period of time, in order to ensure that the engine is stopped. If the load rises above the set stop power limit before the time configured here expires, the counter is reset to 0.

**General**

Case 7: Start of the engine

If  $[P_{GN.actual.tot} + P_{reserve.isolated} + > P_{rated.tot}]$  the engine is started. (f)

Case 8: Stop of the engine

If  $[P_{GN.actual.tot} + P_{reserve.isolated} + P_{hyst} + P_{rated} + < P_{rated.tot}]$  the engine is stopped. (g)

**Example**

Two generators in an isolated operation are used in parallel with other generators. One generator should always be in operation.

- $P_{rated} = 200 \text{ kW}$  Rated real power of a genset.
- $P_{Reserve.isolated} = 60 \text{ kW}$
- $P_{hyst} = 30 \text{ kW}$

Case 8: Generator real power, at which the second engine is started:

$$P_{GN.actual} > P_{rated.tot} - P_{reserve.isolated}$$

$$P_{GN.actual} > 200 \text{ kW} - 60 \text{ kW} = 140 \text{ kW}.$$

If the generator real power exceeds 140 kW negative deviation from the pre-specified minimum reserve power occurs. As a result of this, the next engine is started.

Case 9: Generator real power, at which the second engine is stopped:

$$P_{GN.actual.tot} < P_{rated.tot} - P_{reserve.isolated} - P_{rated} - P_{hyst}$$

$$P_{GN.actual.tot} < 400 \text{ kW} - 60 \text{ kW} - 200 \text{ kW} - 30 \text{ kW} = 110 \text{ kW}.$$

$$P_{GN.actual} < P_{GN.actual.tot} / \text{No. GCB} = 110 \text{ kW} / 2 = 55 \text{ kW}.$$

If, in the case of outgoing isolated load, the total actual generator real power is reduced to such an extent that one generator is enough to ensure the reserve power, the second engine is stopped.

**Stop Of The Engine At Mains Failure [GCP-31]**

Parameter 119

<b>Mains error - stop eng.</b>	<b>ON</b>
--------------------------------	-----------

**Engine stop at mains failure**

**ON/OFF**

- ON** .....If the mains fail for at least the time of the mains settling time (Parameter 165) and the discrete input "Enable MCB" (terminal 53) is enabled (the mains parallel operation is enabled), the engine is stopped. When the mains returns and the mains settling time (Parameter 220) has expired, the engine is started and the GCB is synchronized.
- OFF** .....If the mains fail for at least the time of the emergency power start delay (Parameter 165) and the discrete input "Enable MCB" (terminal 53) is enabled (the mains parallel operation is enabled), the GCB is opened. The engine will continue running in idle mode. When the mains returns and the mains settling time (Parameter 220) has expired, the GCB is synchronized.

## Interface



### NOTE

For remote acknowledgement of alarms, a remote stop while in idle mode must be performed. If the control is in an isolated operation, an acknowledgement combined with a remote start must be performed.

Parameter 120

Control via COM X1X5	ON
-------------------------	----

#### Control via interface COM X1-X5

ON/OFF

**ON**..... Control via the interface is enabled if the direct configuration (Parameter 3) has been configured as "OFF", the control via X1X5 (Parameter 120) has been configured to "ON", the operation mode is set to AUTOMATIC and the discrete input "Automatic 2" (terminal 5) has been enabled. The engine can be started and stopped and the breakers can be opened via a remote signal. The generator real power and the generator power factor  $\phi$  set point value may also be transmitted.

**OFF**..... The control via the X1X5 interface is disabled. The internally generator real power setpoint value 2 (Parameter 47) is selected with the discrete input "Automatic 2" and the internal power factor  $\cos \phi$  (Parameter 81) set point value is used. Interface monitoring is disabled.

Parameter 121

Supervision COMX1X5	ON
------------------------	----

if COMX1X5 = ON only

#### Remote monitoring of the interface

ON/OFF

**ON**..... Monitoring of the interface is enabled. If control signals are not received (ID 503) every 90 seconds, a warning alarm of class 1 is triggered.

**OFF**..... Monitoring of the interface is disabled.

Parameter 122

Ackn. F2,F3 via COM interf	ON
-------------------------------	----

if COMX1X5 = ON only

#### Remote acknowledgement of F2/F3 alarms via the interface

ON/OFF

**ON**..... Alarm acknowledgement of alarms of the alarm classes F2/F3 via the interface is enabled.

**OFF**..... Alarm acknowledgement of alarms of the alarm classes F2/F3 via the interface is disabled. Acknowledgment can be performed via the discrete input "Acknowledgment" (terminal 6) or via the push button "RESET".



### NOTE

For the description of the second interface (**Option SB** and **Option SC**) refer to the following manuals:

- **Option SB** (e.g. **Option SB03**) = manual 37200
- **Option SC** (e.g. **Option SC06**) = manual 37182

Parameter 123

Power On Mode:	STOP
----------------	------

only RPQ Package

#### Start in mode:

STOP, MANUAL, AUTOMATIC, as before

**STOP** ..... The unit is in STOP operating mode after applying battery voltage.

**MANUAL**.... The unit is in MANUAL operating mode after applying battery voltage.

**AUTOMATIC** The unit is in AUTOMATIC operating mode after applying battery voltage.

**as before** ..... The unit is in the same operating mode after applying battery voltage as it was before disconnecting the battery voltage.

**Note:** The operating mode may be changed with the terminals 126, 127, and 128.

Parameter 124

Interchange Mode in Manual	ON
-------------------------------	----

only RPQ Package

**Interchange mode in manual** **ON/OFF**

- OFF** .....Interchange mode (enabled by the DI at terminal 126) may also be performed in AUTOMATIC operating mode.
- ON** .....Interchange mode (enabled by the DI at terminal 126) may **only** be performed in AUTOMATIC operating mode.

## Breaker



Parameter 125

Configure breaker	YES
----------------------	-----

**Configuration of the breakers** **YES/NO**

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:

- YES** .....The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).
- NO** .....The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

## Functional Description

### Permissible Limits

If the generator or mains monitoring for over-/undervoltage (Parameter 201) or over-/underfrequency (Parameter 195) is disabled, the CB logic (Parameter 126) and the control system are controlled by internally defined limit values.

For the busbar, always the internally defined limit values are used.

	Voltage	Frequency
Generator	$V_{Gen}: 75 \text{ to } 115 \% V_{RatedSystem}$	$f_{Gen}: 80 \text{ to } 110 \% f_{RatedSystem}$
Busbar	$V_{Busbar}: 85 \text{ to } 112.5 \% V_{RatedSystem}$	$f_{Busbar}: 90 \text{ to } 110 \% f_{RatedSystem}$
Mains	$V_{Mains}: 85 \text{ to } 112,5 \% U_{RatedSystem}$	$f_{Mains}: 90 \text{ to } 110 \% f_{RatedSystem}$

Table 3-4: Limit values, permissible limits

The permissible limits refer to the respective rated values in the system, i.e. the rated system voltage, configured in Parameter 23, and the rated system frequency, configured in Parameter 11.

## Synchronization

### Synchronization of the GCB

The GCB will be synchronized with frequency and voltage correction if the following conditions are met simultaneously.

#### **Automatic mode**

- The operation mode AUTOMATIC is selected
- One of the circuit breaker logics (Parameter 126) "PARALLEL" (mains parallel operation), "INTER-CHANGE" (mains interchange (import/export) real power control) or "CLOSED TRANSIT." (make-before-break/overlap synchronization) has been selected
- No class F2 or F3 alarms are present
- An "Automatic 1" (terminal 3) or "Automatic 2" (terminal 5) input has been enabled, a remote starting signal has been activated via the interface, or an additional engine will be started in an emergency power operation and will be synchronized to the busbar
- The busbar has been energized (the control measures a voltage)
- The engine is running and the generator voltage and frequency are within the permissible limits
- The delayed engine monitoring (Parameter 307) has expired (this does not apply in the case of emergency power)
- The rotating field of the generator and the mains voltages are identical and no alarms are displayed

#### **Manual mode**

- The operation mode MANUAL has been selected
- One of the circuit breaker logics (Parameter 126) "PARALLEL" (mains parallel operation), "INTER-CHANGE" (mains interchange (import/export) real power control) or "CLOSED TRANSIT." (make-before-break/overlap synchronization) has been selected
- No class F2 or F3 alarms are present;
- The busbar has been energized (the control measures a voltage)
- The engine is running and the generator voltage and frequency are within the permissible limits
- The push-button "GCB ON" has been pressed
- The rotating field of the generator and the mains voltages are identical and no alarms are displayed

#### **Load test mode**

- The operation mode TEST has been selected
- One of the circuit breaker logics (Parameter 126) "PARALLEL" (mains parallel operation), "INTER-CHANGE" (mains interchange (import/export) real power control) or "CLOSED TRANSIT." (make-before-break/overlap synchronization) has been selected;
- No class F2 or F3 alarms are present;
- The busbar has been energized (the control measures a voltage)
- The engine is running and the generator voltage and frequency are within the permissible limits
- The push-button "GCB ON" has been pressed
- The rotating field of the generator and the mains voltages are identical and no alarms are displayed

### Synchronization of the MCB [GCP-32]

The MCB will be synchronized with frequency and voltage correction if the following conditions are met simultaneously:

#### **Automatic mode**

- The operation mode AUTOMATIC has been selected
- One of the circuit breaker logics (Parameter 126) "PARALLEL" (mains parallel operation), "INTERCHANGE" (mains interchange (import/export) real power control) or "CLOSED TRANSIT." (make-before-break/overlap synchronization) has been selected
- No class F2 or F3 alarms are present
- The busbar has been energized (the control measures a voltage)
- The mains voltage is present and within the permissible limits
- The engine is running and the generator voltage and frequency are within the permissible limits
- The discrete input "Reply: GCB is open" has not been enabled (the GCB is closed)
- The discrete input "Enable MCB" has been enabled;
- The rotating field of the generator and the mains voltages are identical and no alarms are displayed

#### **Manual operation**

- The operation mode MANUAL has been selected;
- One of the circuit breaker logics (Parameter 126) "PARALLEL" (mains parallel operation), "INTERCHANGE" (mains interchange (import/export) real power control) or "CLOSED TRANSIT." (make-before-break/overlap synchronization) has been selected;
- No class F2 or F3 alarms are present;
- The busbar has been energized (the control measures a voltage);
- The mains voltage is present and within the permissible limits;
- The engine is running and the generator voltage and frequency are within the permissible limits;
- The discrete input "Reply: GCB is open" has not been enabled (the GCB is closed);
- The discrete input "Enable MCB" has been enabled;
- The push-button "MCB ON" has been pressed;
- Load test: On termination of the load test (circuit breaker logics (Parameter 126) "INTERCHANGE" (mains interchange (import/export) real power control) or "CLOSED TRANSIT." (make-before-break/overlap synchronization), the GCB is opened;
- The rotating field of the generator and the mains voltages are identical (and no alarms are displayed);

## Dead Bus Start

### Dead bus start of the GCB

The GCB will be closed without synchronization if the following conditions are met simultaneously:

#### Automatic mode

- The operation mode AUTOMATIC has been selected
- No class F2 or F3 alarms are present
- The Parameter 145 "GCB dead bus start" has been configured to "ON"
- The busbar has not been energized (the control measures no voltage)
- The engine is running, and the generator voltage and frequency are within the permissible limits
- The discrete input "Reply: MCB is open" has been enabled (the MCB is open)
- If load is shared via the CAN bus
  - No GCB may be closed if the configured system is isolated operation in parallel with other generators
  - The generator with the lowest control/generator number (Parameter 4) will be the first to close its GCB

#### Manual mode

- The operation mode MANUAL has been selected
- No class F2 or F3 alarms are present
- The busbar has not been energized (the control measures no voltage)
- The engine is running, and the generator voltage and frequency are within the permissible limits
- The discrete input "Reply: MCB is open" has been enabled (the MCB is open)
- If load is shared via the CAN bus
  - No GCB may be closed if the configured system is isolated operation in parallel with other generators
  - The generator with the lowest control/generator number (Parameter 4) will be the first to close its GCB)
- The push-button "GCB ON" has been pressed

#### Disabled generator monitoring:

If the generator monitoring for over-/undervoltage (Parameter 201) or over-/underfrequency (Parameter 195) is disabled, the internally defined limit values are used.

Generator monitors	Voltage	Frequency
ON	Monitor values	Monitor values
OFF	$V_{Gen} < 75 \% V_{RatedSystem}$ $V_{Gen} > 115 \% V_{RatedSystem}$	$f_{Gen} < 80 \% f_{RatedSystem}$ $f_{Gen} > 110 \% f_{RatedSystem}$

Table 3-5: Limit values generator, dead bus start

The permissible limits refer to the respective rated values in the system, i.e. the rated system voltage, configured in Parameter 23, and the rated system frequency, configured in Parameter 11.

**Dead bus start of the MCB [GCP-32]**

The MCB will close without synchronization if the following conditions are met simultaneously:

**Automatic mode**

- The operation mode AUTOMATIC has been selected
- The Parameter 149 "MCB dead bus start" has been configured to "ON"
- The busbar is not been energized (the control measures no voltage)
- The mains voltage is present and within the permissible limits
- The discrete input "Reply: GCB is open" has been enabled (the GCB is open)
- The discrete input "Enable MCB" has been enabled
- If load is shared via the CAN bus
  - No MCB may be closed if the configured system is isolated operation in parallel with other generators
  - The generator with the lowest control/generator number (Parameter 4) will be the first to close its MCB

**Manual mode**

- The operation mode MANUAL has been selected
- The busbar is not been energized (the control measures no voltage)
- The mains voltage is present and within the permissible limits
- The discrete input "Reply: GCB is open" has been enabled (the GCB is open)
- The discrete input "Enable MCB" has been enabled
- The push button "MCB ON" has been pressed
- If load is shared via the CAN bus
  - No MCB may be closed if the configured system is isolated operation in parallel with other generators
  - The generator with the lowest control/generator number (Parameter 4) will be the first to close its MCB

**Operation mode STOP**

- If "Enable MCB" (terminal 53) has been enabled and "Switch MCB in stop mode" (Parameter 162) is configured "YES", the MCB will close when all generators are in STOP mode

**Disabled mains monitoring:**

If the mains monitoring for over-/undervoltage (Parameter 211) or over-/underfrequency (Parameter 206) is disabled, the internally defined limit values are used.

Mains monitors	Voltage	Frequency
ON	Monitor values	Monitor values
OFF	$V_{Mains} < 85 \% V_{RatedSystem}$ $V_{Mains} > 12.5 \% V_{RatedSystem}$	$f_{Mains} < 90 \% f_{RatedSystem}$ $f_{Mains} > 110 \% f_{RatedSystem}$

Table 3-6: Limit values mains, dead bus start

The permissible limits refer to the respective rated values in the system, i.e. the rated system voltage, configured in Parameter 23, and the rated system frequency, configured in Parameter 11.

## Open Breaker

### Open GCB

The GCB will be opened both when the relay "Command: GCB close" de-energizes (only if "continuous pulse" has been configured; Parameter 130), and relay "Command: GCB open" is energized. The GCB will be opened under the following circumstances:

- If a mains failure is detected and the mains decoupling is configured to the GCB (Parameter 159 or Parameter 160 depending on control unit)
- In the operation mode STOP
- If a class F2 or F3 alarm is present
- Upon pressing the push-button "GCB OFF" or [GCP-32] "MCB ON" (depending on the breaker logic which has been configured) in operation mode MANUAL
- Upon pressing the push-button "STOP" in operation mode MANUAL
- Upon pressing the push-button "GCB OFF" or [GCP-32] "MCB ON" (depending on the breaker logic which has been configured) in operation mode LOAD TEST
- In the event of an automatic stopping in the operation mode AUTOMATIC
- [GCP-32] following the "CLOSED TRANSIT." (make-before-break/overlap synchronization) of the MCB
- [GCP-32] before the MCB is closed to the dead busbar in the case of the breaker logic "OPEN TRANSIT." (break-before-make/changeover)
- In critical mode/sprinkler operation, provided that no emergency power operation is present
- [GCP-32] following the "INTERCHANGE" (mains interchange (import/export) real power control) of the MCB

### Open MCB [GCP-32]

The MCB will be opened via closing the relay "Command: MCB open" (configuration of "continuous pulse" is not possible for the MCB). The MCB will be opened under the following circumstances:

- If a mains monitoring triggers and the mains decoupling is configured to EXT (Parameter 160)
- If emergency power (AMF) is enabled (mains failure)
- following the "CLOSED TRANSIT." (make-before-break/overlap synchronization) of the GCB
- Before the GCB is closed to the dead busbar in the case of the breaker logic "OPEN TRANSIT." (break-before-make/changeover)
- Upon pressing the push-button "MCB OFF" or "GCB ON" (depending on the breaker logic which has been configured) in operation mode MANUAL
- Upon pressing the push-button "MCB OFF" or "GCB ON" (depending on the breaker logic which has been configured) in operation mode LOAD TEST
- Following the soft loading (interchange synchronization) of the MCB

## Breaker Logic



### NOTE

Using the discrete input "Change breaker logic via terminal 64" (Parameter 233), the breaker logic may be switched between two different breaker logics (description on page 108). The desired standard breaker logic is configured via the following parameter (Parameter 126). If Parameter 232 is configured to "ON", the discrete input terminal 64 is used as a Control input. When a signal to terminal 64 is detected, the breaker logic configured in Parameter 233 is used. If the signal is terminated, the breaker logic configured in Parameter 126 is used again. Therefore it is possible during operation to change between the breaker logic "PARALLEL" (automatic synchronizing) and "EXTERNAL" (manual synchronizing).

Parameter 126

**Breaker logic:**  
-----

**Breaker logic**

see below

The control automatically controls the two breakers (MCB and GCB). Up to five (5) breaker logic modes may be selected. These are:

**GCP-31**  
EXTERNAL  
PARALLEL  
---  
---  
---

**GCP-32**  
EXTERNAL  
PARALLEL  
OPEN TRANSIT.  
CLOSED TRANSIT.  
INTERCHANGE

A detailed explanation for each mode may be found in the following text.

## Breaker Logic "PARALLEL"

Parallel operation is enabled via configuration of the parameter (Parameter 126) to "PARALLEL".



### NOTE

Parallel breaker logic must be selected for the following operation modes:

- Isolated operation
- Isolated operation in parallel with other generators
- Mains parallel operation

In the event of an add-on request the following occurs:

- The GCB is synchronized and closed
- The necessary generator assumes load and real power or reactive power is controlled

Following the shed-off request the following occurs:

- The generator sheds load and the generator power factor  $\varphi$  is controlled to "1.00" (unity)
- The GCB is opened
- The engine is shut down following the configured cool down period

[GCP-32] The MCB is synchronized and closed if

- Terminal 53 "Enable MCB" has been enabled
- The GCB is closed

[GCP-32] The MCB is closed onto the dead busbar if

- The GCB is open
- The MCB is open
- The busbar is dead (de-energized)
- Terminal 53 "Enable MCB" has been enabled



### NOTE

When a stop command is issued to the engine, with the exception of a class F3 alarm, soft loading (power reduction) is carried out before opening the GCB.

### Breaker Logic "INTERCHANGE" [GCP-32]

Mains interchange (import/export) real power control is enabled via configuration of the parameter (Parameter 126) to "INTERCHANGE".

 **NOTE**  
For this breaker logic to function correctly, the mains power measurement must be connected properly. The power measurement must also be assigned the properly process identifier (C, I, or E).

In the event of an add-on request, a change is made from mains to generator supply. The following occurs:

- The GCB is synchronized and closed
- The generator assumes load until the mains interchange (import/export) real power is "zero"
- The MCB is opened

When a shed-off request has been issued, a change is made from generator to mains supply. The following occurs:

- The MCB is synchronized and closed
- The generator sheds load until real power is "zero"
- The GCB is opened

### Breaker Logic "CLOSED TRANSIT." [GCP-32]

Closed transition (make-before-break/overlap synchronization) is enabled via configuration of the parameter (Parameter 126) to "CLOSED TRANSIT.".

 **NOTE**  
The circuit breakers are opened irrespectively of the power.

In the event of an engine request, a change is made from mains to generator supply. The following occurs:

- The GCB is synchronized and closed
- The MCB is opened and the generator assumes all loads

After the engine shed-off request has been issued, a change is made from generator to mains supply. The following occurs:

- The MCB is synchronized and closed
- The GCB is opened and the mains assume all loads

 **NOTE**  
The maximum time between reply CB and CB open command is 500 ms.

**Breaker Logic "OPEN TRANSIT." [GCP-32]**

Open transition (break-before-make/change over logic) is enabled via configuration of Parameter 126 to "OPEN TRANSIT."

In the event of an engine add-on request, a change is made from mains to generator supply. The following occurs:

- The MCB is opened
- The GCB is closed

After the engine shed-off request has been issued, a change is made from generator to mains supply. The following occurs:

- The GCB is opened
- The MCB is closed

**Breaker Logic "EXTERNAL"**

External breaker logic is enabled via configuration of Parameter 126 to "EXTERNAL".

All breaker control must be carried out via master controller (e.g. a PLC). The GCP controller will only issue opening and closing pulses to the MCB and GCB when in the MANUAL operating mode. The GCP controller always issues the breaker open command under fault conditions.

Overview GCP-32

STOP	TEST	MANUAL	AUTOMATIC
------	------	--------	-----------

<p><b>EXTERNAL:</b> Breaker logic "External"                  The MCB and the GCB are operated in MANUAL operation mode only in this breaker logic mode. In a mains parallel operation, uncoupling from the mains is carried out via the MCB or the GCB in the event of a mains failure. The breakers will not automatically close in emergency power operation. Emergency power operation in accordance with European Community Specification DIN VDE 0108 is not possible in this power circuit breaker logic.</p>			
<p>The GCB is opened.</p>	<p>The GCB and the MCB are not operated. .   <u>Exception:</u> The breakers are opened for decoupling from the mains.</p>	<p>The MCB and the GCB may be manually opened and closed without synchronization. The circuit breakers are opened for decoupling from the mains.</p>	<p>The GCB is opened if the genset is stopped or if decoupling from the mains, but will not close if the engine is started. The MCB is opened only if decoupling from the mains, and is never closed.</p>

<p><b>PARALLEL:</b> Breaker logic "Mains parallel operation"                  The MCB and GCB are synchronized to permit continuous mains parallel operation in this breaker logic mode.</p>			
<p>The GCB is opened; the MCB is not operated.</p>	<p>The GCB and the MCB are not operated.   <u>Exception:</u> Load test by actuating the "GCB ON" push-button. Termination of the load test with the "GCB OFF" push-button.   <u>Emergency power:</u> Automatic closing of the GCB. If there is a dead busbar and terminal 53 "Enable MCB" is energized, the MCB will be closed.</p>	<p>Mains parallel operation can be initiated by pressing the "GCB ON" or "MCB ON" push-button.</p>	<p>The GCB is synchronized via an add-on request and a mains parallel operation is performed. When a shed-off request is issued, the generator sheds load and opens the GCB and the engine is shut down following the configured cool down period.   <u>Emergency power:</u> The emergency power operation is terminated following the expiration of the mains settling time. The MCB is synchronized and closed, putting the system back into a mains parallel operation.</p>

<p><b>OPEN TRANSIT.:</b> Breaker logic "Open transition / change-over / brake-before-make"                  The MCB and GCB are never synchronized in this breaker logic mode.</p>			
<p>The GCB is opened; the MCB is not operated.</p>	<p>The GCB and the MCB are not operated.   <u>Exception:</u> Load test by actuating the "GCB ON" push-button. Termination of the load test via the "GCB OFF" or "MCB ON" push-button(s).   <u>Emergency power:</u> Automatic closing of the GCB. If there is a dead busbar and terminal 53 "Enable MCB" is energized, the MCB will be closed.</p>	<p>A change can be made to either generator or mains operation by pressing either the "GCB ON" or "MCB ON" push-button. The "STOP" push-button opens the GCB and simultaneously stops the engine.</p>	<p>A change is made to generator operation through an add-on request. Once the add-on request is terminated, the system changes back to mains operation. The MCB is closed when the busbar is dead, even if there has not been an add-on request. Emergency power operations are terminated following the expiration of the mains settling timer. The GCB opens and the MCB closes, transferring all loads to the mains.</p>

STOP	TEST	MANUAL	AUTOMATIC
<p><b>CLOSED TRANSIT.:</b> Breaker logic "Closed transition / make-before-brake / overlap synchronization"                      The MCB and the GCB are synchronized, in order to avoid a dead busbar in this breaker logic mode. Immediately after the synchronization of one breaker, the other is opened. Continuous mains parallel operation is not possible.</p>			
<p>The GCB is opened; the MCB is not operated.</p>	<p>The GCB and the MCB are not operated.</p> <p><u>Exception:</u> Load test by actuating the "GCB ON" push-button. Termination of the load test via the "GCB OFF" or "MCB ON" push-button(s).</p> <p><u>Emergency power:</u> Automatic closing of the GCB. If there is a dead busbar and terminal 53 "Enable MCB" is energized, the MCB will be closed.</p>	<p>Synchronization of either the generator or the mains can be initiated by pressing the "GCB ON" or "MCB ON" push-button.</p>	<p>The GCB is synchronized via an add-on request. After the GCB closes the MCB is opened. Following the shed-off request being issued, the MCB is synchronized and closed. After the MCB has closed the GCB is opened.</p> <p><u>Emergency power:</u> The emergency power operation is terminated following the expiration of the mains settling time and the MCB synchronizing to the generator. The MCB closes and the GCB opens immediately afterwards.</p>

<p><b>INTERCHANGE:</b> Breaker logic "Soft loading / interchange synchronization"                      The MCB and the GCB are synchronized, in order to avoid a dead busbar in this breaker logic mode. The operation of a breaker under load is avoided by utilizing the ability to soft load. Continuous mains parallel operation is not possible with this breaker logic. Following the shed-off request, the MCB synchronizes and closes, the generator soft unloads to the mains and the GCB opens. After the GCB is open the engine is stopped following the expiration of the configured cool down period.</p>			
<p>The GCB is opened; the MCB is not operated.</p>	<p>The GCB and the MCB are not operated.</p> <p><u>Exception:</u> Load test by actuating the "GCB ON" push-button. Termination of the load test via the "GCB OFF" or "MCB ON" push-button.</p> <p><u>Emergency power:</u> Automatic closing of the GCB. If there is a dead busbar and terminal 53 "Enable MCB" is energized, the MCB will be closed.</p>	<p>Synchronization of either the generator or the mains can be initiated by pressing the "GCB ON" or "MCB ON" push-button.</p>	<p>Via an engine request, the GCB is synchronized and the generator power is increased. The MCB is then opened. Following the disabling of the engine request, the MCB is reverse synchronized and the GCB is then opened.</p> <p><u>Emergency power:</u> The emergency power operation is terminated following the expiration of the mains settling time. The MCB closes, the load is transferred, and the GCB opens.</p>

Overview GCP-31

STOP	TEST	MANUAL	AUTOMATIC
------	------	--------	-----------

<b>EXTERNAL:</b> Breaker logic "External"			
The GCB is never synchronized in this operation mode. Decoupling from the mains when in a mains parallel operation is carried out via the GCB in the event of mains faults. The breaker will not automatically close in emergency power operations.			
The GCB is opened.	The GCB is not operated.  <u>Exception:</u> The breaker is opened for decoupling from the mains.	The GCB can be manually opened and closed without synchronization. The breaker is opened for decoupling from the mains.	The GCB is opened for stopping or for decoupling from the mains, but is not closed in the event of an add-on request.

<b>PARALLEL:</b> Breaker logic "Mains parallel"			
This operation mode may be used both in the case of an isolated system, an isolated parallel system, and a system that is operated in mains parallel.			
The GCB is opened.	The GCB is not operated.  <u>Exception:</u> Load test by actuating the "GCB ON" push-button. Termination of the load test with the "GCB OFF" push-button.  <u>Emergency power:</u> The GCB is opened for decoupling from the mains.	Mains parallel operation can be performed via the "GCB ON" push-button.	The GCB is synchronized via an add-on request and mains parallel operation is performed. When a shed-off request is issued, the generator sheds load, the GCB is opened, and the engine is shut down following the configured cool down period.

Start/Stop Ramp, Open GCB With F2 Alarm

Parameter 127

Add-on/off ramp max.time	000s
-----------------------------	------

**Start/stop ramp** 0 to 999 s

This time can be used to influence two functions:

**Stop:** The maximum amount of time generator will shed load is set here. If the generator load does not drop below 3 % of the generator rated power (Parameter 32) within this time, the GCB is opened.

**Start with soft loading:** If the mains interchange (import/export) real power value does not reach 0 kW in breaker logic "INTERCHANGE" within the time configured here; a class F1 alarm and an alarm message are issued. At the same time, the relay manager relay, which is programmed with relay manager function 78 (Appendix B) is enabled and the MCB is prevented from opening.

Parameter 128

Open GCB with F2 max.time	000s
------------------------------	------

**Max. perm. time with F2 alarms for starting a further engine** 0 to 999 s

**Prerequisite:** Load sharing (Parameter 103) and automatic start/stop (Parameter 108 or Parameter 109) are configured to "ON". The generator is in isolated operation and at least one additional generator is connected to a busbar.

If a class F2 alarm occurs the engine shutdown may be delayed by the time configured here. This permits another engine to attempt to start in order to assume the load. After the configured time expires the engine with the F2 alarm condition will shutdown regardless if another engine was able to start and assume the load.

## GCB Pulse/Continuous Pulse

Closing and opening of the GCB and the MCB are described in the following figures (Figure 3-6 and Figure 3-7). Changing of the breaker control logic is configured using Parameter 129 and has the described effect on the signal sequence (the operation of the MCB cannot be carried out by means of the continuous pulse). If the "Automatic breaker deblocking" (Parameter 137) is configured to "ON", an open pulse is issued prior to each close pulse. The discrete input "Enable MCB" (terminal 54) enables/disables closing the MCB. A closed MCB is not opened.

### • Breaker logic: 'Impulse'




Figure 3-6: Breaker control logic 'Impulse'

**'Impulse' logic (GCB and MCB):** 1 Enable MCB; 2 Synchronization; 3 Connect time reached:

- **close GCB/MCB:** 4 Closing pulse for GCB/MCB enabled; 5 Inherent delay; 6 Reply GCB/MCB; 7 Closing pulse disabled;
- **open GCB/MCB:** 9 Opening pulse GCB/MCB enabled; 10 Inherent delay; 11 Reply GCB/MCB; 12 Time delay (GCB: 2 s; MCB: 0.8 s); 13 Opening pulse disabled.

• **Beaker logic: 'Continuous'**




Figure 3-7: Breaker control logic 'Continuous'

**'Continuous' logic (GCB only):** 1 Enable; 2 Synchronization; 3 Connect time reached:

- **close GCB:** 4 GCB close continuous pulse enabled; 5 Inherent delay; 6 Reply GCB;
- **open GCB:** 9 Continuous pulse disabled and GCB open pulse enabled; 10 Switcher time element; 11 Reply GCB; 12 Opening pulse disabled.

Parameter 129

GCB close.relay  
-----

**Signal logic for the GCB**

**Impulse/Constant**

**Constant** .....The relay "Command: close GCB" can be looped directly into the self-holding circuit of the breaker. Following the connect impulse has been issued and the reply of the breaker has been received, the relay "Command: close GCB" remains energized as long as the following conditions are fulfilled:

"Reply: GCB is closed" is active.  
The angle between generator voltage and busbar voltage is within +/- 14°.

If the breaker must be opened, the relay de-energizes.

**Impulse** .....The relay "Command: close GCB" outputs a connect impulse. The GCB self-holding function must be performed by an external holding circuit. The reply of the GCB is used to detect the closed breaker.

In both cases, the relay "Command: open GCB" (terminal 41/42) is energized to open the GCB.

**Open/Close GCB**

Parameter 130

GCB open relay  
-----

**Opening the GCB (terminal 41/42)**

**NO-contact/NC-contact**

**NC-contact**...If the GCB is to be opened, the relay "Command: open GCB" (terminal 41/42) remains energized. Following the "Reply: GCB is open" the relay de-energizes.

**NO-contact** .If the GCB is to be opened, the relay "Command: open GCB" (terminal 41/42) de-energizes. Following the "Reply: GCB is open" the relay energizes again.

## Synchronization (With Synchronous Generators Only)

Parameter 131

<b>Synchronize</b>	
df max	0.00Hz

**Max. perm. differential frequency for synchronization (pos. slip) 0.02 to 0.49 Hz**

The prerequisite for a connect command being issued is that the differential frequency is below the configured differential frequency. This value specifies the upper frequency (positive value corresponds to positive slip → generator frequency is higher than the busbar frequency in the case of GCB synchronization; busbar frequency is higher than the mains frequency in the case of MCB synchronization).

Parameter 132

<b>Synchronize</b>	
df min	-0.00Hz

**Max. perm. differential frequency for synchronization (neg. slip) 0.00 to -0.49 Hz**

The prerequisite for a connect command being issued is that the differential frequency is above the configured differential frequency. This value specifies the lower frequency limit (negative value corresponds to negative slip → generator frequency is less than the busbar frequency in the case of GCB synchronization; busbar frequency is lower than the mains frequency for MCB synchronization).

Parameter 133

<b>Synchronize</b>	
dV max	00.0%

**Max. perm. differential voltage for synchronization 01.0 to 20.0 %**

ⓘ This value refers to the parameter "Rated volt. in system" (Parameter 19).

A connect command will only be issued when the measured voltage falls below the configured differential voltage.

Parameter 134

<b>Synchronize</b>	
time pulse>	0.00s

**Min. pulse duration of connect relay for synchronization 0.02 to 0.26 s**

The duration of the close pulse can be adjusted to the breaker (valid for synchronization and dead bus start).

Parameter 135

<b>Closing time</b>	
GCB	000ms

**Inherent delay of GCB for synchronization 40 to 300 ms**

The inherent closing time of the GCB corresponds to the lead-time of the close command. The close command will be issued independently of the differential frequency at the entered time before the synchronous point.

Parameter 136

<b>Closing time</b>	
MCB	000ms

**Inherent delay of MCB for synchronization 40 to 300 ms**

The inherent closing time of the MCB corresponds to the lead-time of the close command. The close command will be issued independently of the differential frequency at the entered time before the synchronous point.

Parameter 137

<b>Automat. breaker deblocking</b>	
	ON

only B + X Packages

**Automatic circuit breaker deblocking ON/OFF**

**ON**..... Prior to each close pulse, a "Command: open GCB", or "Command: open MCB" is issued for 1 second. A close signal is then enabled until the breaker is closed.

**OFF**..... Initialization of the circuit breaker initialization on closing is performed **only** by the close pulse. No open pulse is issued prior to the close pulse.

### Phase Matching (only RPQ Package)

Parameter 138

**Phase matching**  
ON

only RPQ Package

**Phase matching** **ON/OFF**

**ON** .....Synchronization will be performed with phase matching.  
**OFF** .....Synchronization will be performed with slightly positive slip.

Parameter 139

**Phase matching**  
**gain** 00

only RPQ Package

**Phase matching gain** **1 to 36**

The phase matching effect on the frequency control may be affected with this gain factor.

Parameter 140

**Phase matching**  
**df start** 00,0Hz

only RPQ Package

**Phase matching df start** **0,02 to 0,25 Hz**

Phase matching will only be enabled if the frequency difference of the voltages to be synchronized is below the value configured here.

Parameter 141

**Detection Mains**  
**connected** < 00°

only RPQ Package

**Mains connection detection (angle)** **1 to 15°**

If the phase angle between busbar and mains is below the angle configured here for at least the time configured in the next parameter (Parameter 142), the unit detects the connection between busbar and mains and indicates this with the message "Mains connected".

Parameter 142

**Detection Mains**  
**conn. after** 000s

only RPQ Package

**Mains connection detection (time)** **0 to 999 s**

If the phase angle between busbar and mains is below the angle configured above (Parameter 141) for at least the time configured here, the unit detects the connection between busbar and mains and indicates this with the message "Mains connected".

### Synchronization Time Monitoring (With Synchronous Generators Only)

If the following parameter (Parameter 143) is configured to "ON", synchronization time monitoring is performed: If the synchronization of the GCB or [GCP-32] MCB is initiated, the timer is started following the termination of the delayed engine monitoring. If the breaker has not closed following the expiration of the configured time, an F1 alarm message is issued.



#### NOTE

If during an enabled "MCB monitoring" (Parameter 158) an alarm is detected while closing the MCB, an emergency power operation is performed (if this has been configured to ON; Parameter 164).

Parameter 143

**Sync.time contr.**  
ON

#### Monitoring of synchronization time

ON/OFF

- ON**..... Synchronization time will be monitored. The subsequent screens of this function are displayed.
- OFF**..... Synchronization time will not be monitored. Synchronization will be attempted until it can be accomplished. The subsequent screens of this function are not displayed.

Parameter 144

**Sync.time contr.**  
**delay**      000s

#### Final value for synchronization time monitoring

10 to 999 s

If the synchronization of the GCB or MCB is initiated, the timer is started following the termination of the delayed engine monitoring. If the breaker cannot be closed and this time has expired, an alarm message is issued and the control continues to attempt to close the breaker. The relay assigned relay manager function 16 (GCB) and/or 70 (MCB) is energized.

**Issuing of class F1 alarm**

### Dead Bus Start (With Synchronous Generators Only)

If the busbar is de-energized, a dead bus start of the GCB or the MCB is performed. If closing commands for the MCB and the GCB are issued simultaneously, priority is given to the MCB provided the discrete input "Enable MCB" (terminal 54) has been enabled.

Parameter 145

GCB dead bus op.  
ON

**Dead bus start of the GCB** **ON/OFF**

- ON**.....A dead bus start is performed in the event of a de-energized busbar and an open MCB. The subsequent screens of this function are displayed.
- OFF** .....A dead bus start is not performed. The subsequent screens of this function are not displayed.

Parameter 146

GCB dead bus op.  
df max 0.00Hz

**Maximum differential frequency for GCB dead bus start** **0.05 to 5.00 Hz**

The prerequisite to issuing a close command is that the monitored generator frequency may deviate from the generator rated frequency by no more than this value.

Parameter 147

GCB dead bus op.  
dV max. 00,0%

**Maximum differential voltage for GCB dead bus start** **01,0 to 15,0 %**

| ⓘ This value refers to the parameter "rated voltage in system" (Parameter 19). |

The prerequisite to issuing a close command is that the monitored generator voltage may deviate from the generator rated frequency by no more than this value.

Parameter 148

GCB dead bus op  
max.time 000s

**Maximum time for closing the GCB** **0 to 999 s**

If the GCB is to be closed onto a dead busbar, this timer is initiated at the start of the breaker closing sequence. If the breaker fails to close before the configured time expires, a class 1 alarm is issued.

**Issuing of class F1 alarm**

Parameter 149

MCB dead bus op.  
ON

**Dead bus closing of the MCB** **ON/OFF**

- ON**.....A dead bus closing of the MCB is performed in the event of a de-energized busbar and an open GCB. The subsequent screens of this function are displayed.
- OFF** .....A dead bus closing of the MCB is not performed. The subsequent screens of this function are not displayed.

## Connection Functions (With Induction/Asynchronous Generators Only)

Parameter 150

Switching-on GCB ON
------------------------

**Connection of the GCB** **ON/OFF**

**ON**..... Generator frequency control is performed with the set point of the mains frequency. The GCB is closed after meeting all connection criteria listed below. The subsequent screens of this function are displayed.

**OFF**..... The GCB is not closed. The subsequent screens of this function are not displayed.

Parameter 151

Switching-on GCB df max 0.00Hz
-----------------------------------

**Max. perm. diff. frequency for GCB connection (pos. slip)** **0.05 to 9.99 Hz**

The prerequisite for issuing a close command is the monitored generator frequency may deviate from the generator rated frequency by no more than this value. This value specifies the upper frequency limit (positive value corresponds to positive slip → generator frequency is higher than the busbar frequency in the case of GCB synchronization).

Parameter 152

Switching-on GCB df min -0,00Hz
------------------------------------

**Min. perm. diff. frequency for GCB connection (neg. slip)** **0.0 to -9.99 Hz**

The prerequisite for issuing a close command is the monitored generator frequency may deviate from the generator rated frequency by no more than this value. This value specifies the lower frequency limit (negative value corresponds to negative slip → generator frequency is less than the busbar frequency in the case of GCB synchronization).

Parameter 153

Switching-on GCB T.impuls >0.00s
-------------------------------------

**Time pulse for the GCB** **0.02 to 0.26 s**

The duration of the close pulse can be adjusted to the breaker.

Parameter 154

Automat. breaker deblocking ON
-----------------------------------

**Automatic circuit breaker deblocking** **ON/OFF**

**ON**..... Prior to each close pulse, a "Command: open GCB", or "Command: open MCB" is issued for 1 second. A close signal is then enabled until the breaker is closed.

**OFF**..... Initialization of the circuit breaker closing is performed **only** by the close pulse. No open pulse is issued prior to the close pulse.

### Connect Time Monitoring (With Induction/Asynchronous Generators Only)

If Parameter 154 is configured to "ON", closing time monitoring is performed: A timer is started when the closing of the GCB is initiated following the termination of the delayed engine monitoring. If the breaker has not closed following the expiration of the configured time, an F1 alarm message is issued.

Parameter 155

Switch.time cntr  
ON

**Breaker close time monitoring** **ON/OFF**

---

**ON**.....Connect time monitoring is carried out. The subsequent screen of this function is displayed.

**OFF**.....Unsuccessful connection is not monitored. The subsequent screen of this function is not displayed.

Parameter 156

Switch.time cntr  
delay 000s

**Delay of breaker close time monitoring** **2 to 999 s**

---

When the closing of the GCB is initiated, a timer is started. If the GCB has not closed before the expiration of the timer, a warning message "Connect time GCB" is issued. A further attempt is made to connect the power circuit breaker. The relay assigned relay manager function 16 (GCB) and/or 70 (MCB) is energized.

**Issuing of class F1 alarm**

### Breaker Monitoring

**Upon CLOSING** - If "GCB monitoring" (Parameter 157) and/or "MCB monitoring" (Parameter 158) have been configured "ON", GCB and/or MCB monitoring is performed (exception: the breaker logic is configured "EXTERNAL" (Parameter 126). If the breaker cannot be closed after five attempts, a class F1 alarm is issued. If a relay has been assigned relay manager functions 74 or 75, it will be energized.

**Upon OPENING** - When opening a circuit breaker an open pulse is issued. If a reply is detected 2 seconds after the open pulse was issued that the MCB or GCB has not opened, an class F1 alarm message is issued. If a relay has been assigned relay manager functions 76 or 77, it will be energized:

Parameter 157

**Supervision GCB**  
**ON**

**GCB monitoring** **ON/OFF**

**ON**..... Monitoring of the GCB is performed except when the breaker logic is configured as "EXTERNAL". If the breaker cannot be closed after five attempts, an alarm message is issued. The relay assigned relay manager function 75 is energized. Following the issuing of the alarm message, further attempts are made to close the GCB. If load sharing has been enabled (Parameter 103), the closing command to the breaker is cancelled if an alarm is issued so that another control may close its breaker. If a "Reply: GCB is open" message is not detected 2 seconds after a "Command: open GCB" pulse is issued, an alarm message is issued. The relay assigned relay manager function 77 is energized.

**Issuing of class F1 alarm**

**OFF**..... No GCB monitoring is performed.

Parameter 158

**Supervision MCB**  
**ON**

**MCB monitoring** **ON/OFF**

**ON**..... Monitoring of the MCB is performed except when the breaker logic is configured as "EXTERNAL". If the breaker cannot be closed after five attempts, an alarm message is issued. The relay assigned relay manager function 74 is energized. Following the issuing of the alarm message, further attempts are made to close the MCB. If load sharing has been enabled (Parameter 103) the closing command to the breaker is cancelled if an alarm is issued so that another control may close its breaker. If a "Reply: MCB is open" message is not detected 2 seconds after a "Command: open MCB" pulse is issued, an alarm message is issued. The relay assigned relay manager function 76 is energized.

**Issuing of class F1 alarm**

**OFF**..... No MCB monitoring is performed.

## Mains Decoupling



### NOTE

If the mains monitoring (frequency and voltage) is disabled, no mains decoupling is performed.

Parameter 159

Mains decoupling  
via -----

at GCP-31 only

#### Decoupling from the mains via ...

GCB; GCB->EXT; EXT; EXT->GCB

**GCB** .....If a mains failure (Parameter 206 to Parameter 219) occurs the GCB will be opened. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]).

**GCB->EXT**..If a mains failure (Parameter 206 to Parameter 219) occurs the GCB will be opened. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]). An alarm message will be issued with the end of the delay time (Parameter 161) if terminal 4 does not detect a reply that the GCB has opened. The relay assigned relay manager function 76 will be energized as well. The "Command: open GCB" relay (terminal 41/42) will be de-energized and the "Command: MCB open" relay (terminals 39/40) is energized.

**Issuing of class F1 alarm**

**EXT**.....If a mains failure (Parameter 206 to Parameter 219) occurs the relay with the "Command: MCB open" relay (terminals 39/40) will be energized. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]).

**EXT->GCB**..If a mains failure (Parameter 206 to Parameter 219) occurs the relay with the "Command: MCB open" relay (terminals 39/40) will be energized. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]). An alarm message will be issued with the end of the delay time (Parameter 161) if terminal 54 does not detect a reply that the breaker has opened. The relay assigned relay manager function 77 will be energized as well. The "Command: MCB open" relay (terminals 39/40) will be de-energized and the "Command: open GCB" relay (terminals 41/42) is energized.

**Issuing of class F1 alarm**



**NOTE**

If the mains monitoring (frequency and voltage) is disabled, no mains decoupling is performed.

Parameter 160

Mains decoupling via -----
-------------------------------

at GCP-32 only

**Decoupling from the mains via ...**

**GCB; GCB->MCB; MCB; MCB->GCB**

**GCB** ..... If a mains failure (Parameter 206 to Parameter 219) occurs the GCB will be opened. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]).

**GCB->MCB** If a mains failure (Parameter 206 to Parameter 219) occurs the GCB will be opened. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]). An alarm message will be issued with the end of the delay time (Parameter 161) if terminal 4 does not detect a reply that the GCB has opened. The relay assigned relay manager function 76 will be energized as well. The "Command: open GCB" relay (terminal 41/42) will de-energize and the "Command: open MCB" relay (terminals 39/40) is energized.

<b>Issuing of class F1 alarm</b>
----------------------------------

**MCB** ..... If a mains failure (Parameter 206 to Parameter 219) occurs the MCB will be opened. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]).

**MCB->GCB** If a mains failure (Parameter 206 to Parameter 219) occurs the MCB will be opened. (The mains failure is detected by means of the mains voltage [terminals 50/51/52]). An alarm message will be issued with the end of the delay time (Parameter 161) if terminal 54 does not detect a reply that the MCB has opened. The relay assigned relay manager function 77 will be energized as well. The "Command: open MCB" relay (terminals 39/40) will de-energize and the "Command: open GCB" relay (terminals 41/42) is energized.

<b>Issuing of class F1 alarm</b>
----------------------------------

Parameter 161

Mains decoupling -> after 0.00s
------------------------------------

**Mains decoupling after**

**0.10 to 5.00 s**

The maximum amount of time that the mains decoupling should be completed in.



**WARNING**

During maintenance of the busbar be aware that an open MCB will be closed by the GCP when the mains settling time (Parameter 220; starts when voltage is detected on the mains) expires if Parameter 162 is configured as "YES". Configuring Parameter 162 as "NO" or take other measures to prevent the busbar from being energized.

Parameter 162

Switch MCB in STOP mode NO
-------------------------------

**Operate MCB in operation mode STOP**

**YES/NO**

**YES** ..... The MCB will be operated by the GCP in STOP mode (the busbar will be closed onto the mains if the controller is changed into this STOP mode). It is necessary that "Enable MCB" (terminal 54) be energized as well.

**NO** ..... The MCB will not be operated by the GCP in STOP mod (the busbar will not be connected or remains unconnected if the control unit is changed into STOP mode).

## Emergency Power (AMF)



Parameter 163

Configure emergency	YES
---------------------	-----

### Configuration of the emergency power (AMF)

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:

**YES** .....The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO** .....The parameters in the next block are not displayed, cannot be modified and are therefore skipped.



**NOTE**

Emergency power is only possible with synchronous generators utilizing 2 circuit breakers (i.e. **GCP-32** or **GCP-31** with LS 4 coupling).

**Prerequisite:** The emergency power (AMF) function may only be enabled with synchronous generators using Parameter 163 ("Emergency power"). Emergency power operations are only performed in AUTOMATIC or TEST mode regardless of the status of the discrete inputs "Automatic 1" and "Automatic 2".



**NOTE**

If the "Engine enable" or "Engine block" function is assigned to terminal 6 (Parameter 240), emergency power can be prevented or interrupted from an external source through a discrete input. Refer to "Terminal 6" on page 111.

If Parameter 236 is configured ON and discrete input 11 at terminal 68 is energized, emergency power operation will also be prevented or interrupted (see Enable 'Emergency OFF' via terminal 68 on page 110).

**Activation of emergency power:** If a mains voltage fault (over-/undervoltage, -frequency or phase/vector jump) is detected on any single phase of terminals 50/51/52 without interruption for the duration of the emergency power start delay time (Parameter 165), emergency power is activated. A mains voltage fault is defined as follows: If the mains watchdogs (Parameter 206 and/or Parameter 211) are configured to ON and the applicable limit values set there are surpassed; otherwise, the limits are internally defined as follows:

Mains watchdogs	Voltage	Frequency
ON	Monitoring values (see Parameter 206ff)	Monitoring values (see Parameter 211ff)
OFF	$V_{mains} < 85 \% V_{rated}$ $V_{mains} > 112 \% V_{rated}$	$f_{mains} < 90 \% f_{rated}$ $f_{mains} > 110 \% f_{rated}$

Table 3-7: Limit values, Emergency power

Emergency power (AMF) is also initiated through the detection of a breaker alarm when the MCB is closed. In order to enable this, Parameter 164 ("Emergency power) and Parameter 158 ("MCB monitoring") must be configured to "ON".

The following actions occur in an emergency power operation:

- If emergency power is triggered, the engine is started unless the sequence is interrupted by an alarm or the change of the operation mode.
- If the mains return during the start cycle, the MCB is not opened. The engine starts and continues running until the mains settling time (Parameter 220) expires. If another mains fault occurs during this time, the MCB is opened and the GCB is closed to the dead busbar. The engine shuts down following the expiration of the mains settling time (Parameter 220) if no additional mains faults occur.
- The GCB will be closed regardless of the engine delay time once the dead bus limits have been reached.
- If the mains returns during emergency power operation while the GCB is closed, the MCB will be synchronized after the mains settling time (Parameter 220) has expired.

**Emergency power:** In the event of an active emergency power operation, the message "Emergency power" is displayed.

### Emergency Power With Breaker Logic "PARALLEL"

**Emergency power:** Following a mains fault the "emergency power start delay" (Parameter 165) must expire before the engine is started. Once the voltage and frequency limit values are reached, the MCB is opened and the GCB is closed to the dead busbar. The generator supplies the load.

**Return of the mains:** Following the return of the mains the control remains in the emergency power operation until the mains settling time has expired (Parameter 220) before synchronization of the MCB is initiated. After closing the MCB, the control returns to its original operation mode. If the engine is to be shut down after the emergency power operation is over, a power reduction (soft unloading) is carried out if the real power controller (Parameter 87) is configured to ON.

If the mains return during the start cycle, the MCB is not opened. The engine remains in idle mode during the mains settling time (Parameter 220) in order to enable the immediate closing of the GCB in the event of further mains faults.

### Emergency Power With Breaker Logic "OPEN TRANSIT."

**Emergency power:** Following a mains fault the "emergency power start delay" (Parameter 165) must expire before the engine is started. Once the voltage and frequency limit values are reached, the MCB is opened and the GCB is closed to the dead busbar. The generator supplies the load.

**Return of the mains:** Following the return of the mains the control remains in the emergency power operation until the mains settling time has expired (Parameter 220) before transitioning back (via an open transition/over a dead busbar) to mains supply. If an engine request is present following the expiration of the mains settling time (Parameter 220), the generator will remain in isolated operation.

If the mains return during the start cycle, the MCB is not opened. The engine remains in idle mode during the mains settling time (Parameter 220) in order to enable the immediate closing of the GCB in the event of further mains faults.

## Emergency Power With Breaker Logic "CLOSED TRANSIT."

**Emergency power:** Following a mains fault the "emergency power start delay" (Parameter 165) must expire before the engine is started. Once the voltage and frequency limit values are reached, the MCB is opened and the GCB is closed to the dead busbar. The generator supplies the load.

**Return of the mains:** Following the return of the mains the control remains in the emergency power operation until the mains settling time has expired (Parameter 220). Synchronization of the MCB (via a closed transition/over a live busbar) to mains supply is initiated if no engine request is present. Following the closure of the MCB, the GCB is opened immediately and without any power reduction (soft unloading). If an engine request is present following the expiration of the mains settling time (Parameter 220), the generator will remain in isolated operation.

If the mains return during the start cycle, the MCB is not opened. The engine operates in idle mode during the mains settling time (Parameter 220) in order to enable the immediate closing of the GCB in the event of further mains faults.

## Emergency Power With Breaker Logic "INTERCHANGE"

**Emergency power:** Following a mains fault the "emergency power start delay" (Parameter 165) must expire before the engine is started. Once the voltage and frequency limit values are reached, the MCB is opened and the GCB is closed to the dead busbar. The generator supplies the load.

**Return of the mains:** Following the return of the mains the control remains in the emergency power operation until the mains settling time has expired (Parameter 220). Synchronization of the MCB (via a closed transition/over a live busbar) to mains supply is initiated if no engine request is present. Following the closure of the MCB, the GCB is opened after a power reduction (soft unloading) is performed if the real power controller (Parameter 87) is configured to "ON". If an engine request is present following the expiration of the mains settling time (Parameter 220), the generator will remain in isolated operation.

If the mains return during the start cycle, the MCB is not opened. The engine operates in idle mode during the mains settling time (Parameter 220) in order to enable the immediate closing of the GCB in the event of further mains faults.

## Emergency Power With Breaker Logic "EXTERNAL"



### ATTENTION

This breaker logic will not permit emergency power in accordance with DIN VDE 0108!

**Emergency power:** Following a mains fault the "emergency power start delay" (Parameter 165) must expire before the engine is started. Once the voltage and frequency limit values are reached, the MCB is opened and the GCB is closed to the dead busbar. The generator supplies the load. No further operation of the GCB and the MCB are performed, regardless if the mains return.

## Emergency power With MCB Malfunction

**MCB malfunction:** In the operation mode AUTOMATIC without a starting request, the control is in emergency power standby. If the MCB opens without initiation, the control attempts to reclose the breaker. If the MCB cannot be reclosed due to an MCB failure, the engine is started and the alarm message "MCB malfunction" is displayed, if Parameter 163 ("Emergency power") and Parameter 158 ("Supervision MCB") are configured to "ON". The GCB is closed and emergency power subsequently supplies the busbar. Following acknowledgement of the "MCB malfunction" alarm, the MCB synchronized from generator supply to mains supply and the engine shut down after the expiration of the mains settling time (Parameter 220).

## Emergency Power; Parameters

Parameter 164

<b>Emergency power</b> ON
------------------------------

**Emergency power**

**ON/OFF**

**ON**..... If the control is in AUTOMATIC or TEST mode and a mains failure occurs, the engine is started and an automatic emergency power operation is performed. The subsequent parameters of this function are displayed. Emergency power is also initiated by the detection of a breaker failure when the MCB is to be closed. In order to enable this, the Parameter 158 ("Supervision MCB") must be configured to "ON".

**OFF**..... Emergency power operation is not enabled and the subsequent parameters of this function are not displayed.

Parameter 165

<b>Emergency power</b> start del. 00.0s
--

**Start delay for emergency power**

**0.5 to 99.9 s**

In order to start the engine and to carry out an emergency power operation, the mains must fail for at least this delay time.

# Protection



Parameter 166

Configure monitoring	YES
-------------------------	-----

## Configuration of the protection

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" affects only the display of the subjacent menus. This parameter has the following effects:

**YES** .....The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO** .....The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

## Generator Power Monitoring

It is possible to monitor two independently configurable generator power limit values. It is possible to output the tripping to one of these freely configurable relays by means of the relay manager (relay manager function 56 and 80). This function makes it possible to initiate external load shedding.



### NOTE

With this function **no** centralized alarm is issued and **no** message is displayed. A relay output is enabled which must be externally evaluated.



### WARNING

This function does **not** operate as generator protection.

If generator protection is necessary, either the generator protection of this control (Parameter 178 and Parameter 183) or an external protection device should be used.

Parameter 167

```
Gen.power monit.
ON
```

#### Generator power monitoring

ON/OFF

**ON**..... The generator power is monitored (relay manager function 56 and 80 must each be assigned to one relay). The subsequent screens of this function are displayed.

**OFF**..... Monitoring is not carried out, and the subsequent screens of this function are not displayed.

Parameter 168

```
Gen.power monit.
resp.val1 000kW
```

#### Power monitoring threshold value, level 1

0 to 9,999 kW

If this threshold value has been exceeded for at least the delay time (Parameter 170), the relay assigned relay manager function 56 energizes.

Parameter 169

```
Gen.power monit.
hyst.lv1 000kW
```

#### Power monitoring hysteresis, level 1

0 to 999 kW

If the monitored generator power level drops below the threshold value configured in Parameter 168 by value configured here, hysteresis occurs and the relay de-energizes.

Parameter 170

```
Gen.power monit.
delay lv1 000s
```

#### Power monitoring delay, level 1

0 to 650 s

For the control unit to recognize a power monitoring fault condition, the threshold value configured in Parameter 168 must be exceeded without interruption for this period of time.

Parameter 171

```
Gen.power monit.
resp.val2 000kW
```

#### Power monitoring threshold value, level 2

0 to 9,999 kW

If this threshold value has been exceeded for at least the delay time (Parameter 173), the relay assigned relay manager function 80 energizes.

Parameter 172

```
Gen.power monit.
hyst.lv2 000kW
```

#### Power monitoring hysteresis, level 2

0 to 999 kW

If the monitored generator power level drops below the threshold value configured in Parameter 171 by value configured here, hysteresis occurs and the relay de-energizes.

Parameter 173

```
Gen.power monit.
delay lv2 000s
```

#### Power monitoring delay, level 2

0 to 650 s

For the control unit to recognize a power monitoring fault condition, the threshold value configured in Parameter 171 must be exceeded without interruption for this period of time.

### Mains Power Monitoring (not with RPQ Package)

It is possible to monitor two independently configurable generator power limit values. It is possible to output the tripping to one of the freely configurable relays by means of the relay manager (relay manager function 67). This function makes it possible to initiate external load shedding.



#### NOTE

With this function no centralized alarm is issued and no message is displayed. A relay output is enabled which must be externally evaluated.



#### WARNING

This function does not operate as generator protection. If generator protection is necessary, either the generator protection of this control (Parameter 178 and Parameter 183) or an external protection device should be used.

Parameter 174

Mains power mon.  
ON

Mains power monitoring ON/OFF

ON.....The generator power is monitored (relay manager function 67 must be assigned to one relay). The subsequent screens of this function are displayed.

OFF.....Monitoring is not carried out, and the subsequent screens of this function are not displayed.

Parameter 175

Mains power mon.  
res.val. I0000kW

Power monitoring threshold value I/E 0 to 9,999 kW

If this threshold value has been exceeded for at least the delay time (Parameter 177), the relay assigned relay manager function 57 energizes. Imported power is entered with a " - " before the value, exported power is entered with a " + " before the value. If the value is confirmed, the " - " becomes an " I " and the " + " becomes an " E ".

Parameter 176

Mains power mon.  
hysteresis 000kW

Power monitoring hysteresis 0 to 999 kW

If the monitored generator power level drops below the threshold value configured in Parameter 175 by value configured here, hysteresis occurs and the relay de-energizes.

Parameter 177

Mains power mon.  
delay 000s

Power monitoring delay 0 to 650 s

For the control unit to recognize a power monitoring fault condition, the threshold value configured in Parameter 175 must be exceeded without interruption for this period of time.

## Generator Overload Monitoring



### NOTE

All percentage values refer to a percentage of the generator rated power (Parameter 32; page 26).

**Function:** "Positive real power not within the permissible range" - The single-phase or three-phase measured generator real power is above the configured limit value of the real power.

Parameter 178

Overload monit. ON
-----------------------

**Generator overload monitoring** **ON/OFF**

**ON**.....Monitoring of the generator real power will be performed. The subsequent parameters of this function are displayed.  
**OFF**.....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 179

Gen.overload MOP resp.value 000%
-------------------------------------

**Generator overload monitoring threshold value MOP** **80 to 150 %**

If this threshold value has been exceeded for at least the delay time (Parameter 180), the following alarm class is initiated (MOP ..Mains Parallel Operation).

<b>Issuing of class F2 alarm</b> without power reduction
---

Parameter 180

Gen.overload MOP delay 00s
-------------------------------

**Generator overload monitoring delay** **0 to 99 s**

For the control unit to recognize a generator overload monitoring fault condition, the threshold value configured in Parameter 179 must be exceeded without interruption for this period of time (MOP ..Mains Parallel Operation).

Parameter 181

Gen.overload IOP resp.value 000%
-------------------------------------

**Generator overload monitoring threshold value IOP** **80 to 150 %**

If this threshold value has been exceeded for at least the delay time (Parameter 182), the following alarm class is initiated (IOP ..Isolated Parallel Operation).

<b>Issuing of class F2 alarm</b> without power reduction
---

Parameter 182

Gen.overload IOP delay 00s
-------------------------------

**Generator overload monitoring delay** **0 to 99 s**

For the control unit to recognize a generator overload monitoring fault condition, the threshold value configured in Parameter 181 must be exceeded without interruption for this period of time (IOP ..Isolated Parallel Operation).

# Generator Reverse/Reduced Power Monitoring



## NOTE

All percentage values refer to a percentage of the generator rated power (Parameter 32; page 26).

**Function:** "Real power not within the permissible range" - The real power measured in a single-phase or in a three-phase system is below the configured limit value for the minimum load or below the configured value for reverse power. By setting positive threshold values (minimum load monitoring), a shutdown can be performed before the generator ends up in reverse power.

Parameter 183

Rev./red.power  
monitoring ON

**Reverse/reduced power monitoring** **ON/OFF**

- ON .....Monitoring of the generator reverse/reduced power will be performed. The subsequent parameters of this function are displayed.
- OFF .....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 184

Rev./red.power  
resp.value -00%

**Reverse/reduced power monitoring threshold value** **-99 to 99 %**

**Reverse power monitoring:** If the current value falls below the negative threshold value for at least the delay time (Parameter 185), the following alarm class is initiated.

**Reduced power monitoring:** If the current value falls below the positive threshold value for at least the delay time (Parameter 185), the following alarm class is initiated.

**Issuing of class F3 alarm**

Parameter 185

Rev./red.power  
delay 0.0s

**Reverse power monitoring delay** **0.0 to 9.9 s**

For the control unit to recognize a reverse/reduced power monitoring fault condition, the threshold value configured in Parameter 184 must be exceeded without interruption for this period of time.

## Unbalanced Load Monitoring



### NOTE

All percentage values refer to a percentage of the generator rated power (Parameter 33; page 26).

**Function:** "Generator load imbalance not within the permissible range" - The percentage threshold value specifies the permissible deviation of one phase current to the arithmetic mean value of all three phase currents.

Parameter 186

Load unbalanced  
monitoring ON

#### Unbalanced load monitoring

ON/OFF

**ON**.....Monitoring for unbalanced load of the generator real power will be performed. The subsequent parameters of this function are displayed.  
**OFF**.....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 187

Load unbalanced  
max. 000%

#### Maximum permissible unbalanced load

0 to 100 %

If the threshold value has been exceeded for at least the delay time (Parameter 188; e.g. because of an asymmetric load), the following alarm class is initiated.

Issuing of class F3 alarm

Parameter 188

Load unbalanced  
delay 00.00s

#### Unbalanced load monitoring delay

0.02 to 9.98 s

For the control unit to recognize an unbalanced load monitoring fault condition, the threshold value configured in Parameter 187 must be exceeded without interruption for this period of time.

## Time-Overcurrent Monitoring



### NOTE

All percentage values refer to a percentage of the generator rated power (Parameter 33; page 26).

**Function:** The GCP-30 utilizes a two tier time-overcurrent monitoring with separate adjustable time delays. The threshold values and delays can be selected so that the monitored current level is independent from the tripping time. The level 2 overcurrent is used as a fast-triggering high-current stage for protection against short circuits. The level 1 overcurrent reacts overcurrents below level 2 but above permissible limits that are present over a longer period of time.




Figure 3-8: Characteristic of the time-overcurrent monitoring

Parameter 189

Gen. overcurrent monitoring	ON
-----------------------------	----

#### Overcurrent monitoring

ON/OFF

**ON** .....Monitoring of the generator current will be performed for overcurrent. The subsequent parameters of this function are displayed.  
**OFF** .....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 190

Gen. overcurrent limit 1	000%
--------------------------	------

#### Threshold value overcurrent limit 1

0 to 300 %

If the threshold value has been exceeded for at least the delay time (Parameter 191), the following alarm class is initiated.

Issuing of class F3 alarm
---------------------------

Parameter 191

Gen. overcurrent delay 1	00.00s
--------------------------	--------

#### Independent time overcurrent, delay, limit 1

0.02 to 9.98 s

For the control unit to recognize a time-overcurrent fault condition, the threshold value configured in Parameter 190 must be exceeded without interruption for this period of time.

Parameter 192

**Gen. overcurrent  
limit 2      000%**

**Independent time overcurrent, threshold value, limit 2**

**0 to 300 %**

If this threshold value has been exceeded for at least the delay time (Parameter 193), the following alarm class is initiated.

**Issuing of class F3 alarm**

Parameter 193

**Gen. overcurrent  
delay 2      00.00s**

**Independent time overcurrent, delay, limit 2**

**0.02 to 9.98 s**

For the control unit to recognize a time-overcurrent fault condition, the threshold value configured in Parameter 192) must be exceeded without interruption for this period of time.

Parameter 194

**Gen. overcurrent  
Cool down      ON**

**Open GCB with coasting due to overcurrent**

**ON/OFF**

**ON**..... If the GCB is opened due to an overcurrent fault condition, an engine cool-down is performed prior to engine stop.  
**OFF**..... The engine is stopped without a cool-down.

### Generator Frequency Monitoring

**Function:** "Generator frequency not within the permissible range" - The generator frequency is outside of the limit values set for overfrequency or underfrequency. The engine is shut down immediately (class F3 alarm), and an alarm message is displayed. The activation of generator underfrequency monitoring is delayed by means of "Delayed engine monitoring" (Parameter 307) in order to enable correct generator start-up.

Parameter 195

**Gen. frequency-  
monitoring**    ON

**Generator frequency monitoring** **ON/OFF**

**ON**.....Monitoring of the generator frequency will be performed. The subsequent parameters of this function are displayed.  
**OFF** .....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 196

**Gen. overfreq.**  
f >        000.0%

**Threshold value: generator overfrequency** **50.0 to 140.0 %**

| ⓘ This value refers to the parameter "Rated freq. in system" (Parameter 11). |

If this threshold value has been exceeded for at least delay time (Parameter 197), the following alarm class is initiated.

**Issuing of class F3 alarm**

Parameter 197

**Gen. overfreq.  
delay**        0.00s

**Generator overfrequency delay** **0.02 to 9.98 s**

For the control unit to recognize a generator overfrequency fault condition, the threshold value configured in Parameter 196 must be exceeded without interruption for this period of time.

Parameter 198

**Gen. underfreq.**  
f <        000.0%

**Generator underfrequency threshold value** **50.0 to 140.0 %**

| ⓘ This value refers to the parameter "Rated freq. in system" (Parameter 11). |

If the current value has been fallen below this threshold value for at least the delay time (Parameter 199), the following alarm class is initiated.

**Issuing of class F3 alarm**

Parameter 199

**Gen. underfreq.  
delay**        0.00s

**Generator underfrequency delay** **0.02 to 9.98 s**

For the control unit to recognize a generator underfrequency fault condition, the threshold value configured in Parameter 198 must be exceeded without interruption for this period of time.

### Engine Overspeed Monitoring

Parameter 200

**Engine overspeed**  
> 0000 rpm

**Engine overspeed monitoring** **0 to 9,999 rpm**

The overspeed monitoring is performed in addition to and independent of the generator frequency if the Magnetic Pickup Unit (MPU) has been enabled (Parameter 309). If the MPU has been disabled, the monitoring is disabled. If this threshold value is been exceeded the following alarm class is initiated.

**Issuing of class F3 alarm**

## Generator Voltage Monitoring

The line-to-line (wye) voltage is monitored.

**Function:** "Generator voltage not within the permissible range" - If one or more phases of the generator voltage exceeds the limit values set for overvoltage or undervoltage, the engine is shut down immediately (class F3 alarm) and an alarm message is displayed. The activation of generator undervoltage monitoring is delayed by means of "Delayed engine monitoring" (Parameter 307) in order to enable generator start-up.

Parameter 201

**Gen. voltage monitoring** ON

**Generator voltage monitoring** ON/OFF

**ON**..... Monitoring of the generator voltage will be performed. The subsequent parameters of this function are displayed.  
**OFF**..... Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 202

**Gen. overvoltage**  
U > 000.0%

**Generator overvoltage threshold value** 020,0 to 150,0 %

| ⓘ This value refers to the parameter "Rated volt. in system" (Parameter 19). |

If this threshold value has been exceeded for at least the delay time (Parameter 203), the following alarm class is initiated.

**Issuing of class F3 alarm**



### NOTE

The threshold value for generator overvoltage may not exceed 149 V [1] or 495 V [4] for delta connections, because higher voltages cannot be detected.

Parameter 203

**Gen. overvoltage delay** 0.00s

**Generator overvoltage delay** 0.02 to 9.98 s

For the control unit to recognize a generator overvoltage fault condition, the threshold value configured in Parameter 202 must be exceeded without interruption for this period of time.

Parameter 204

**Gen. undervoltage**  
U < 000.0%

**Generator undervoltage threshold value** 020,0 to 150,0 %

| ⓘ This value refers to the parameter "Rated volt. in system" (Parameter 19). |

If the current value has been fallen below this threshold value for the delay time (Parameter 205), the following alarm class is initiated.

**Issuing of class F3 alarm**

Parameter 205

**Gen. undervoltage delay** 0.00s

**Generator undervoltage delay** 0.02 to 9.98 s

For the control unit to recognize a generator undervoltage fault condition, the threshold value configured in Parameter 204 must be exceeded without interruption for this period of time.

### Mains Frequency Monitoring

Monitoring the mains frequency is absolutely vital if a generator is operated in conjunction with the infinite grid. In the event of mains failure (e.g. utility power outage) the generator that is operating in parallel with the utility must be automatically disconnected from the mains. Decoupling from the mains only occurs when both power circuit breakers (MCB and GCB) are closed.

The limit values configured below are utilized for the assessment emergency power operations if the following parameters are enabled. The parameters below define if the mains are or aren't present. The breaker opening times do not affect these parameters.

**Function:** "Mains frequency not within the permissible range" - The mains frequency exceeds the limit values configured for overfrequency or underfrequency. The power circuit breaker that disconnects from the mains is immediately opened. The prerequisite of mains frequency monitoring is that the generator is operating in mains parallel (the MCB and GCB are both closed).

Parameter 206

Mains frequency monitoring ON

Mains frequency monitoring ON/OFF

ON .....Monitoring of the mains frequency will be performed. The subsequent parameters of this function are displayed.  
OFF .....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 207

Mains overfreq. f > 000.0%

Mains overfrequency threshold value 80.0 to 140.0 %

ⓘ This value refers to the parameter "Rated freq. in system" (Parameter 11).

If this threshold value has been exceeded for at least the delay time (Parameter 208), the following alarm class is issued. Depending on the configured mains decoupling procedure, the GCB, MCB, or an external CB will be opened.

Issuing of class F0 alarm

Parameter 208

Mains overfreq. delay 0.00s

Mains overfrequency delay 0.02 to 9.98 s

For the control unit to recognize a mains overfrequency fault condition, the threshold value configured in Parameter 207 must be exceeded without interruption for this period of time.

Parameter 209

Mains underfreq. f < 000.0%

Mains underfrequency threshold value 80.0 to 140.0 %

ⓘ This value refers to the parameter "Rated freq. in system" (Parameter 11).

If the current value has been fallen below this threshold value for at least the delay time (Parameter 210), the following alarm class is issued. Depending on the configured mains decoupling procedure, the GCB, MCB, or an external CB will be opened.

Issuing of class F0 alarm

Parameter 210

Mains underfreq. delay 0.00s

Mains underfrequency delay 0.02 to 9.98 s

For the control unit to recognize a mains underfrequency fault condition, the threshold value configured in Parameter 209 must be exceeded without interruption for this period of time.

## Mains Voltage Monitoring

Monitoring the mains voltage is absolutely vital if a generator is operated in conjunction with the infinite grid. In the event of mains failure (e.g. utility power outage) the generator that is operating in parallel with the utility must be automatically disconnected from the mains. Decoupling from the mains only occurs when both power circuit breakers (MCB and GCB) are closed.

The line-to-line (wye) voltage is monitored in all cases.

The limit values configured below are utilized for the assessment emergency power operations if the following parameters are enabled. The parameters below define if the mains are or aren't present. The breaker opening times do not affect these parameters.

**Function:** "Mains voltage not within the permissible range" - If one or more phases of the generator voltage exceeds the limit values set for overvoltage or undervoltage, the power circuit breaker that disconnects from the mains is immediately opened. The prerequisite of mains voltage monitoring is that the generator is operating in mains parallel (the MCB and GCB are both closed).

Parameter 211

<b>Mains voltage monitoring</b> ON
------------------------------------

**Mains voltage monitoring** ON/OFF

**ON**.....Monitoring of the mains voltage will be performed. The subsequent parameters of this function are displayed.  
**OFF**.....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 212

<b>Mains overvolt.</b> U >            000.0%
---

**Mains overvoltage threshold value** 20.0 to 150.0 %

| ⓘ This value refers to the parameter "Rated volt. in system" (Parameter 19). |

If this threshold value has been exceeded for at least the delay time (Parameter 213), the following alarm class is issued. Depending on the configured mains decoupling procedure, the GCB, MCB, or an external CB will be opened.

<b>Issuing of class F0 alarm</b>
----------------------------------

Parameter 213

<b>Mains overvolt.</b> delay            0.00s
--

**Mains overvoltage delay** 0.02 to 9.98 s

For the control unit to recognize a mains overvoltage fault condition, the threshold value configured in Parameter 212 must be exceeded without interruption for this period of time.

Parameter 214

<b>Mains undervolt.</b> U <            000.0%
--

**Mains undervoltage threshold value** 20.0 to 150.0 %

| ⓘ This value refers to the parameter "Rated volt. in system" (Parameter 19). |

If the current value has been fallen below this threshold value for the delay time (Parameter 215), the following alarm class is issued. Depending on the configured mains decoupling procedure, the GCB, MCB, or an external CB will be opened.

<b>Issuing of class F0 alarm</b>
----------------------------------

Parameter 215

<b>Mains undervolt.</b> delay            0.00s
---

**Mains undervoltage delay** 0.02 to 9.98 s

For the control unit to recognize a mains undervoltage fault condition, the threshold value configured in Parameter 214 must be exceeded without interruption for this period of time.

### Phase/Vector Shift Monitoring $d\phi/dt$

A phase/vector shift is a sudden change in the voltage curve that is caused by a large generator load change. The measuring circuit detects a change in a single sine wave. This sine wave is compared with a calculated mean value from previous measurements. Monitoring encompasses all three phases. The threshold value in degrees specifies the difference in time between the mean and the measured value in reference to a full cycle. Monitoring can be set in various manners. The phase/vector shift watchdog may be used as an additional means for decoupling from the mains. The minimum voltage that the phase shift is activated is 70 % of the rated secondary voltage.

**Function:** "Voltage cycle duration not within the permissible range" - The voltage cycle duration exceeds the configured limit value for the phase/vector shift. The result is the power circuit breaker that disconnects from the mains is opened and an alarm message is displayed. The prerequisite for phase/vector shift monitoring is that the generator is operating in a mains parallel operation (the MCB and GCB are both closed).

Parameter 216

**Phase shift monitoring ON**

**Phase/vector shift monitoring ON/OFF**

- ON** .....Monitoring of the mains frequency will be performed for phase/vector shift. The subsequent parameters of this function are displayed.
- OFF** .....Monitoring is disabled, and the subsequent screens of this function are not displayed.

Parameter 217

**Monitoring -----**

**Phase/vector shift monitoring one-/threephase / only threephase**

- one-/threephase**..During single-phase voltage phase/vector shift monitoring, tripping occurs if the phase/vector shift exceeds the configured threshold value (Parameter 218) in at least one of the three phases. Note: If a phase/vector shift occurs in one or two phases, the single-phase threshold value (Parameter 218) is taken into consideration; if a phase/vector shift occurs in all three phases, the three-phase threshold value (Parameter 219) is taken into consideration. Single phase monitoring is very sensitive and may lead to nuisance tripping if the selected phase angle settings are too small.
- only threephase**..During three-phase voltage phase/vector shift monitoring, tripping occurs only if the phase/vector shift exceeds the specified threshold value (Parameter 219) in all three phases within 2 cycles.

**Issuing of class F0 alarm**



## NOTE

If monitoring is configured to "threephase", only the second of the following two parameters is visible; if monitoring is configured to "one-/threephase", both parameters are visible.

Parameter 218

Phase shift one-phase	00°
--------------------------	-----

This screen is visible only if monitoring is configured to "one/three-phase".

**Phase/vector shift monitoring threshold value single-phase**

**3 to 30 °**

If the electrical angle of the mains voltage shifts more than this configured value in any single phase, a class F0 alarm is initiated. Depending on the configured mains decoupling procedure, the GCB, MCB, or an external CB will be opened.

Parameter 219

Phase shift three-phase	00°
----------------------------	-----

**Phase/vector shift monitoring threshold value three-phase**

**3 to 30 °**

If the electrical angle of the mains voltage shifts more than this configured value in all three phases, a class F0 alarm is initiated. Depending on the configured mains decoupling procedure, the GCB, MCB, or an external CB will be opened.

## Mains Settling Time

Parameter 220

Mains settling time	000s
------------------------	------

**Mains settling time**

**0 to 999 s**

It is possible to delay the synchronization of the generator to the mains for the period of time configured here. This will permit the user to ensure that the mains voltage is stable while the generator continues to operate in an isolated (parallel) mode or idle offline.

### Note

For devices with one circuit breaker, refer also to Parameter 119.

If a GCP-32 has both the MCB and GCB open and the mains return, the mains settling time is reduced to 2 seconds when the mains return if the mains settling time is configured for longer.

### Battery Voltage Monitoring

Parameter 221

**Batt.undervolt.**  
**U <           00.0V**

**Battery voltage monitoring: Threshold value** **9.5 to 30.0 V**

If the measured value falls below this threshold value for at least the delay time (Parameter 222), the following alarm class is issued.

**Issuing of class F1 alarm**

Parameter 222

**Batt.undervolt.**  
**delay           00s**

**Battery undervoltage delay** **0 to 99 s**

For the control unit to recognize a battery undervoltage fault condition, the threshold value configured in Parameter 221 must be exceeded without interruption for this period of time.

**Note:** Regardless of the configured battery voltage monitoring threshold, readiness for operation is withdrawn and an alarm message is issued if the power supply voltage falls below 9 Vdc or if the power supply voltage falls below 11 Vdc during the start sequence.

### Time Of Active Horn

Parameter 223

**Horn self reset**  
**0000s**

**Horn acknowledgment after** **1 to 9.999 s**

The horn (centralized alarm) will remain active for the time configured and then deactivate (acknowledged) automatically.

# Discrete Inputs



Parameter 224

Configure dig.inputs	YES
-------------------------	-----

## Configuration of discrete inputs

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:

**YES**..... The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO**..... The parameters in the next block are not displayed, cannot be modified and are therefore skipped.



### NOTE

The discrete inputs can be used as alarm inputs or control inputs. If they were configured as alarm inputs (Parameter 230 to Parameter 238 are configured to "OFF") the parameters in "Alarm Inputs" (page 106) are valid. If they have been configured as control inputs (Parameter 230 to Parameter 238 are configured to "ON") the parameters in "Control Inputs" (page 108) are valid.

## Alarm Inputs

Discrete input	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Name	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	G
Terminal	34	35	36	61	62	63	64	65	66	67	68	69	70	71	72	73
Function	A	A	A	A	A/C	A/C	A/C	A	A	A/C	A	A	A/C	A	A	A

A..Alarm input; A/C..Alarm or control input (dependent on the configuration)



### NOTE

**Operating current (NO):** The discrete input is enabled by energizing it.  
This does not provide wire break monitoring!

**Closed circuit current (NC):** The discrete input is enabled by de-energizing it.  
This may provide wire break monitoring.

**Example:** Discrete inputs 1 through 4 (same procedure for inputs 5 to 16)

Parameter 225

Dig. input	1234
function	EEEE

#### Function of the discrete alarm inputs 1 to 4

E/D

The discrete inputs may be operated by an operating current contact or a closed circuit current contact. The closed circuit current input may be used to monitor for a wire break. A positive or negative voltage difference may be utilized.

**D** .....The discrete input is normally de-energized and analyzed as "enabled" by energizing the input (N.O.; D = normally de-energized).

**E** .....The discrete input is normally energized and analyzed as "enabled" by de-energizing the input (N.C.; E = normally energized).

Parameter 226

Dig. input	1234
delay	0000

#### Delay time of the discrete alarm inputs 1 to 4

0 to 9

A delay time in stages can be assigned to each alarm input. The individual stages are listed below. The discrete input must be present without interruption throughout the delay time in order to be "enabled".

Delay stage	Delay stage
0	100 ms
1	200 ms
2	500 ms
3	1 s
4	2 s
5	5 s
6	10 s
7	20 s
8	50 s
9	100 s

Table 3-9: Discrete alarm inputs - delay stages

Parameter 227

Delayed by	1234
eng. speed	YYYY

#### Delayed by firing speed of the discrete alarm inputs 1 to 4

Y/N

If the discrete input used as an alarm input is only to be monitored when the engine is running ("firing speed reached") is specified here.

**Y** .....After engine monitoring has been enabled the discrete input is monitored.

**N** .....The discrete input is always monitored.

Parameter 228

Dig. input	1234
error class	0000

**Alarm class of the discrete alarm inputs 1 to 4****F0 to F3**

Different alarm classes can be assigned to each discrete alarm input. The alarm classes are listed below.

The monitoring functions are divided into four alarm classes:

- F0 - Warning alarm** - This alarm does not lead to an interruption of the operation. An alarm message is displayed without a centralized alarm (horn)  
→ Alarm text.
- F1 - Warning alarm** - This alarm does not lead to an interruption of the operation. A centralized alarm is issued.  
→ Alarm text + flashing "alarm" LED + group alarm relay (horn).
- F2 – Triggering alarm** - This alarm leads to the shutdown of the engine. A power reduction is performed prior to the GCB being opened. An engine cool down is performed.  
→ Alarm text + flashing "alarm" LED + group alarm relay (horn) + cool down.
- F3 – Triggering alarm** - This alarm leads to the immediate opening of the GCB and shutdown of the engine.  
→ Alarm text + flashing "alarm" LED + group alarm relay (horn) + shutdown.

**Configuring The Text For The Discrete Inputs****NOTE**

If terminal 6 is configured to "Sprinkler operation" (override or critical mode; Parameter 239) or if a gas engine is selected (Parameter 290), the EMERGENCY STOP function must always be assigned to terminal 34. If terminal 34 is not a discrete input, the EMERGENCY STOP function is assigned to the discrete input with the lowest terminal number (this discrete input is then normally the input with terminal number 61).

**NOTE**

Certain special characters, numbers, upper and lower case letters may be set.

**NOTE**

If the unit is equipped with a second interface (Y1-Y5), the alarm texts can only be configured via LeoPC1.

Parameter 229

Errortxt.term.34
EMERGENCY STOP

**Setting the alarm texts**

These parameters are used to enter the alarm texts (in this example for terminal 34 the alarm text "EMERGENCY STOP"). The text for these parameters is user defined. Terminal 34 is the recommended terminal to assign EMERGENCY STOP functions to.

## Control Inputs

### Acknowledge firing speed via terminal 62

Parameter 230

Firing speed by Term. 62	ON
-----------------------------	----

#### Firing speed reached via terminal 62

ON/OFF

**OFF** .....This terminal is used as an alarm input.

**ON** .....Configuring the starting sequence logic:

If Parameter 225 is configured to "E", the discrete input utilizes "N.O." contacts and the starter disengages when the status of this discrete input becomes TRUE. Once the delayed engine monitoring time has expired, the discrete input changes to "N.C." logic internally even though "N.O." logic is still programmed. This permits the controller to generate an alarm condition in the event of a voltage loss (including a configured time delay). This input will operate on the inverse of this principle as well. If Parameter 225 is configured to "D", the discrete input utilizes "N.C." logic to disengage the starter in the event of a voltage loss. Once the delayed engine monitoring has expired, the discrete input changes to "N.O." logic internally even though "N.C." logic is still programmed and will initiate an alarm as soon as voltage is applied.

### Block operation mode selector switch via terminal 63

Parameter 231

Op.mode blocked by Ter.63	ON
------------------------------	----

#### Disabling the change of the mode using terminal 63

ON/OFF

**OFF** .....This terminal is used as an alarm input.

**ON** .....Terminal 63 is used as control input.

If terminal 63 is energized, the operation mode cannot be changed using the pushbuttons on the face of the control unit.

If this input is configured as control input **and** energized, it is possible for units with **Option A2** from version 4.3010 to select the operation mode externally using the control inputs at terminals 127 and 128. The functionality is described in the following table:

Operation mode blocked (terminal 63)	Input STOP (terminal 127)	Input AUTOMATIC (terminal 128)	Function
de-energized	not applicable	not applicable	The operation mode can be selected using the buttons at the front of the GCP. (The terminals 127/128 have no effect.)
energized	de-energized	de-energized	No change in operation mode. After connecting the supply voltage, the unit is in STOP operation mode. The operation mode selection buttons at the front of the GCP are blocked.
energized	energized	de-energized	The STOP operation mode is activated. After connecting the supply voltage, the unit is in STOP operation mode. The operation mode selection buttons at the front of the GCP are blocked.
energized	de-energized	energized	The AUTOMATIC operation mode is activated. After connecting the supply voltage, the unit changes to AUTOMATIC operation mode via STOP.
energized	energized	energized	The STOP operation mode is activated. After connecting the supply voltage, the unit is in STOP operation mode. The operation mode selection buttons at the front of the GCP are blocked.

Table 3-10: Function - external operation mode selection

### Change breaker logic via terminal 64

Parameter 232

<b>Breaker logic by Term64 ON</b>
---------------------------------------

#### Breaker logic via terminal 64 ON/OFF

---

- OFF**..... This terminal is used as an alarm input.  
**ON**..... This terminal is used as control input.
- High signal If this terminal utilizes a HIGH signal (energized), the breaker logic of Parameter 233 will be used.
  - Low signal If this terminal utilizes a LOW signal (de-energized), the breaker logic of Parameter 126 will be used.

Parameter 233

<b>Breaker logic: -----</b>
---------------------------------

Visible only if breaker logic via terminal 64 is configured to "ON".

#### Breaker logic via terminal 64 see page 68

---

Selection of the breaker logic that is to be used once terminal 64 is enabled. This parameter is only visible if Parameter 232 has been configured to ON (for the description of the breaker logic note chapter "Breaker logic", page 68).

### Frequenz/Leistungs-Sollwertvorgabe über Klemmen 65 und 66 (only RPQ Package)

Parameter 234

<b>f/P setpoint by term. 65/66 ON</b>
---

only RPQ Package

#### Frequency/power set point via terminals 65/66 ON/OFF

---

- OFF**..... These terminals are evaluated as alarm inputs.  
**ON**..... These terminals are used as control inputs to change the frequency or power set point (depending on the currently active control).  
 The set point value will be lowered if terminal 65 is energized.  
 The set point value will be raised if terminal 66 is energized.

**Note:** If several of the terminals 65, 66, 67, 69 are energized in their function as control input, the terminal with the lowest number is prioritized.

### Enable 'Close GCB without engine delay' via terminal 67 (only B + X Packages)

Parameter 235

<b>Close GCB asap by Ter. 67 ON</b>
---

only B + X Packages

#### Close GCB before the del. engine monit. expires via terminal 67 ON/OFF

---

- OFF**..... This terminal is used as an alarm input.  
**ON**..... This terminal is used as control input.
- High signal If this terminal utilizes a HIGH signal (energized), the GCB closes before the delayed engine monitoring expires.
  - Low signal If this terminal utilizes a LOW signal (de-energized), the GCB closes after the delayed engine monitoring has been expires.

### Enable 'Emergency OFF' via terminal 68

Parameter 236

**Emergency OFF  
by Ter.68 OFF**

only version 4.3010 or later

#### Prevent an emergency power operation via terminal 68 ON/OFF

- OFF .....This terminal is used as an alarm input.
- ON .....This terminal is used as control input.
- High signal If this terminal utilizes a HIGH signal (energized), an emergency power operation is prevented or terminated. The unit operates as if Parameter 164 "Emergency power" is disabled.
  - Low signal If this terminal utilizes a LOW signal (de-energized), the setting of Parameter 164 "Emergency power" is taken over.

### Spannung/Leistungsfaktor-Sollwertvorgabe über Klemmen 67 und 69 (nur RPQ Package)

Parameter 237

**V/Q setpoint by  
term.67/69 ON**

only RPQ Package

#### Frequency/power set point via terminals 67/69 ON/OFF

- OFF .....These terminals are evaluated as alarm inputs.
- ON .....These terminals are used as control inputs to change the voltage or power factor set point (depending on the currently active control). The set point value will be lowered if terminal 67 is energized. The set point value will be raised if terminal 69 is energized.

### Enable 'Idle mode' via terminal 70

Parameter 238

**Idle Mode  
by term.70 ON**

#### Enable idle mode via terminal 70 ON/OFF

- OFF .....This terminal is used as an alarm input.
- ON .....This terminal is used as control input. The relay programmed with the relay manager function 133 reacts together with the logical status of terminal 70 according to the configured NO/NC logic and inverting the relay output. This relay must be wired to the "idle input" of the speed governor normally.
- High signal Energizing the terminal 70 discrete input enables the idle mode. The message "Idle Mode" is displayed in all operational modes (except STOP mode) when a start request is initiated and during the postrun time so long as there are no other message with a higher display priority (i.e. preglow). The generator under-voltage and underfrequency protections are disabled while in the idle mode and the warning limit value for the oil pressure VDO input is suppressed. These protections are enabled after terminal 70 is de-energized and the monitored frequency is measured within 1 Hz of the rated generator frequency or after 60 seconds passes, which ever occurs first.
  - Low signal The idle mode is disabled and the protections become active again (see above description).

## Terminal 6



### ATTENTION

The various functions of terminal 6 are enabled at different signal levels!

Parameter 239

Function term.6

-----

#### Function of terminal 6

This parameter is used to assign a function to the terminal 6 discrete input. The following functions may be selected for the discrete input:

- **Sprinkler operation** By **de-energizing** terminal 6 (setting a LOW signal), the sprinkler operation (critical mode) is enabled in accordance with the functional description. The sprinkler operation is terminated by energizing terminal 6 (application of a HIGH signal). For a description of the sprinkler operation function read "Sprinkler (Critical) Operation" on page 112).

**Note:** No load-dependent starting and stopping is possible in sprinkler operation.

**Attention: This is a negative logic function!**
- **Engine enabled** Terminal 6 has the same function as the STOP push-button: De-energizing terminal 6 (application of a LOW signal) prevents the engine from starting and stops the engine if it is already running. Applying a HIGH signal enables the starting of the engine

**Attention:** By the use of this function, the emergency power operation may be aborted or prevented. The emergency power operation is not possible without enabling this function! The enable engine function only functions in the AUTOMATIC operation mode.
- **Engine blocked** By energizing terminal 6 (application of a HIGH signal) a start of the engine can be prevented. If the engine is running due to an active emergency power operation, energizing this discrete input will stop it. The engine block function is only possible in the AUTOMATIC operation mode. The function of this mode is the opposite of the function of the "Engine enabled" mode.
- **Ext. acknowledgment** Alarms can be acknowledged externally by energizing terminal 6 (change from a LOW to a HIGH signal) in the STOP and AUTOMATIC operation modes. In order to achieve additional acknowledgements, terminal 6 must first be de-energized and then energized again. If terminal 6 is continuously energized (HIGH signal), there is no effect on the acknowledgment and suppression of alarm messages.
- **STOP mode** By energizing terminal 6 (application of a HIGH signal) the STOP mode is enabled. If the signal is removed (de-energized), the operation mode will revert back to the mode that was active prior to terminal 6 being energized.
- **Start without CB** If the terminal 6 is energized, the engine starts. No synchronization is performed and the GCB is not closed (no switching to dead busbar). The GCB is closed only if an emergency power operation is enabled. After the return of the mains, the load is transferred to the mains according to the configured breaker logic. An engine start command from terminal 6 is a higher priority than a start command from terminals 3/5. If terminal 6 is selected, terminals 3/5 are ignored. If the generator is in a mains parallel operation mode with "Parallel" breaker logic and terminal 6 is energized, the GCB is opened following a power reduction. The generator will continue to operate without load and an open GCB.

**Note:** No load-dependent starting and stopping is possible in sprinkler operation.

### Starting Without Closing GCB

Parameter 240

Start withno GCB cool down	ON
-------------------------------	----

Only if terminal 6 has been configured to "start without CB".

**Perform engine cool down if starting without CB has been selected** ON/OFF

- ON** .....After removing the start request, an engine cool down is performed for the time configured in Parameter 306.
- OFF** .....After removing the start request, the engine is stopped immediately without an engine cool down.

### Sprinkler Alarm Classes During Sprinkler Coasting

Parameter 241

Sprinkler shutd. F1 active	ON
-------------------------------	----

Only if terminal 6 has been configured to "Sprinkler operation".

**Sprinkler alarm classes only active if terminal 6 is active** ON/OFF

- ON** .....If terminal 6 is configured as "Sprinkler operation", the primary alarm classes will be enabled again after the sprinkler coasting has expired (energizing terminal 6 and sprinkler coasting 10 minutes).
- OFF** .....If terminal 6 has been configured to "Sprinkler operation", the primary alarm classes will be enabled again after the sprinkler demand has concluded (energizing terminal 6).

### Sprinkler (Critical) Operation (only **B** + **X Packages**)



#### NOTE

The function "Sprinkler operation" must be assigned to terminal 6.



#### ATTENTION

Please note that terminal 6 must be energized (apply a HIGH signal) so that a Sprinkler (critical) operation is **not** performed. De-energizing terminal 6 (a LOW signal) initiates a Sprinkler (critical) operation ⇒ **negative logic function**.

**Sprinkler "ON":** If the signal at terminal 6 drops to a Low signal (de-energizes), the Sprinkler (critical) operation ON command is initiated. The message "Sprinkler operation" is shown on the display. Up to 6 attempts are made to start the engine if it is not in operation. All fault conditions, which result in a shutdown, become messages with the exceptions of terminals 34 or 61 and overspeed. The alarm input for terminal 34 retains its set alarm class. Terminal 61 is used for this if terminal 34 is not present on the control. It is recommended that EMERGENCY STOP be assigned to one of these terminals.


**NOTE**

If "Sprinkler operation" (terminal 6) has been activated, class F2 and F3 alarms are converted to class F1 alarms (exception: terminal 34 or 61 and overspeed).

Class F2 and class F3 alarms ⇒ Class F1 alarm

**"Sprinkler shutdown F1 active":** Parameter 241 permits the user to select whether the Sprinkler alarm classes are active during the Sprinkler coasting or if the primary alarm class will be active after the Sprinkler (critical mode) request (terminal 6) has terminated.

A distinction is made between three operating conditions:



1.) MCB is closed

(⇒ mains voltage available):

- a) The engine is stopped: The engine will be started and the GCB will not be closed.
- b) The engine runs with the GCB open.

2.) MCB is opened

(⇒ mains voltage not available and the Parameter 164 "Emergency power" is ON)

- a) The GCB will be closed or remains closed.
- b) In the event of a generator overload, the GCB will open  
Following the alarm acknowledgement the GCB will be closed again.

Figure 3-11: Sprinkler operation

3.) MCB is open

(⇒ mains voltage available):

- a) The MCB will be synchronized,
- b) Following the synchronization of the MCB, the GCB will be opened.

**Sprinkler "OFF":** Disabling the Sprinkler (critical) mode discrete input (energizing terminal 6) terminates the Sprinkler ON command and the message "Sprinkler coasting" appears on the display screen. The message "Sprinkler coasting" appears. The Sprinkler (critical mode) operation is automatically finished 10 minutes later. Earlier termination can be achieved by the changing into the STOP mode. When the Sprinkler (critical mode) operation has concluded, fault conditions that result in shutdowns are enabled again.

## Analog Inputs (Package XP, Option T701)



Parameter 242

Configure analg.inp.	YES
-------------------------	-----

### Configuration of analog inputs

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:

**YES** .....The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO** .....The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

### Setting The Analog Inputs

**Note**

The analog inputs [T1] to [T7] are only available in the **XP packages** as well as the **T701 option**. The following specification for the inputs is possible:

- Scaleable analog input 0/4 to 20 mA (page 115),
- Pt100 input (page 114), and
- VDO input (temperature, page 117 or pressure, page 118).

Analog input	1	2	3	4	5	6	7
Assignment	0/4 to 20 mA			Pt100		VDO #1	VDO #2
Terminal	93/94/95	96/97/98	99/100/101	101/102/103	104/105/106	107/108/109	110/111/112
Function	Alarm input/Control input <sup>1</sup>			Alarm input			

VDO #1 = 0 to 180 Ohm, VDO #2 = 0 to 380 Ohm



**NOTE**

If you want to visualize the analog inputs via the PC program LeoPC1 (Firmware Version 4.0.xxx or higher) please note the following:

1. Establish a connection between LeoPC1 and the GCP-30.
2. Select in the menu "Devices" the topic "Refresh Configuration".
3. Restart LeoPC1 according to the requests.

<sup>1</sup> The 0/4 to 20 mA inputs can be configured with the functions "Real power set value", "Mains interchange (import/export) real power actual value" or "Alarm input". Read the description in this manual.

Scaleable analog input 0/4 to 20 mA (analog input [T1]-[T3])



**NOTE**

The scalable analog inputs 0/4 to 20 mA can be configured alternatively for the following functions:

- Mains interchange (import/export) real power **actual** value, or
- real power **set point** value.

If one of the both functions is assigned to an available 0/4 to 20 mA input T{x} (see Parameter 34 and Parameter 91), the corresponding analog input T{x} **must be** configured to **OFF**. The analog input can no longer be used as an alarm input.

**Priority of the analog input functions**

The following priority is valid if more than one function has been assigned to a analog input:

- **Highest priority:** Mains interchange (import/export) real power **actual** value measurement
- **Middle priority:** Real power **set point** value
- **Lowest priority:** Measuring input as common analog value

0/4 to 20 mA sensors may be measured here. A description and an engineering unit may be assigned to the input. The analog input is displayed with its description. Two limit levels can be monitored. The first limit level initiates a class F1 alarm, the second limit level initiates a class F3 alarm.

Parameter 243

Analog input x scalable	ON
----------------------------	----

[x = 1 to 3]

**0/4 to 20 mA input; enable/disable**

**ON/OFF**

- ON**..... The value of this input appears in the display, and monitoring is enabled. The subsequent parameters of this function are displayed.
- OFF**..... No display or monitoring is performed, and the subsequent parameters of this function are not displayed.



**NOTE**

If the unit is equipped with a second interface (Y1-Y5), this parameter can only be configured via LeoPC1.

Parameter 244

Name and unit -----
------------------------

**0/4 to 20 mA input; description**

**User defined text**

The description of the analog input may be programmed using this parameter. A maximum of four zeros may be used as placeholders for the numerical measuring values. Characters may divide the placeholders (i.e. a comma). The measured values subsequently appear wherever the zeros are placed.

Parameter 245

<b>Analog input x</b> 0-00mA
---------------------------------

[x = 1 to 3]

**0/4 to 20 mA input; measuring range** **0 to 20 mA / 4 to 20mA**

The measuring range 0 to 20 mA or 4 to 20 mA is selected via this parameter. If 4 to 20 mA is configured and a current of less than 2 mA is measured, the controller assumes a wire break has occurred (see below).

Parameter 246

<b>Value at</b> 0%            0000
---------------------------------------

**0/4 to 20 mA input; smallest input value** **-9,999 to 9,999**

The user must assign a numeric value to the scaleable analog input that corresponds to the smallest input value → Definition of the lower value (i.e. 0 %, 0 kW, 0 V) at the minimum analog input value of 0 mA or 4 mA.

Parameter 247

<b>Value at</b> 100%            0000
---

**0/4 to 20 mA input; largest input value** **-9,999 to 9,999**

The user must assign a numeric value to the scaleable analog input that corresponds to the largest input value → Definition of the upper value (i.e. 100 %, 500 kW, 400 V) at the maximum analog input value of 20 mA.

Parameter 248

<b>Limit warning</b> value            -0000
--

**0/4 to 20 mA input; limit value for class F1 alarm** **-9,999 to 9,999**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 251) for at least the delay time (Parameter 250), the following alarm class is initiated.

<b>Issuing of class F1 alarm</b>
----------------------------------

Parameter 249

<b>Limit shutdown</b> value            -0000
---

**0/4 to 20 mA input; limit value for class F3 alarm** **-9,999 to 9,999**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 251) for at least the delay time (Parameter 250), the following alarm class is initiated.

<b>Issuing of class F3 alarm</b>
----------------------------------

Parameter 250

<b>Delay</b> limit 1/2       000s
--------------------------------------

**0/4 to 20 mA input; delay time for limit values of class F1 and F3 alarm** **0 to 650 s**

In order to initiate an alarm, the measured value must be over or under (dependent upon Parameter 251) the configured threshold value (Parameter 248 or Parameter 249) without interruption for at least this time.

Parameter 251

<b>Monitoring for</b> -----
--------------------------------

**0/4 to 20 mA input; monitoring for ...** **high limit mon. / low limit mon.**

A fault condition is recognized when the measured value has exceeded or fallen below the threshold value (Parameter 248 or Parameter 249).

**high limit mon.:** The measured value must exceed the threshold value.

**low limit mon.:** The measured value must fall below the threshold value.

**Pt100 Input (Analog Input [T4] to [T5], only B + X Packages)**

Pt100 inputs may be measured here. The analog input is displayed with its description. Two threshold limits can be monitored. The first level initiates a class F1 alarm, the second level initiates a class F3 alarm.

Parameter 252

Temperature x Pt100	ON
------------------------	----

[x = 4 to 5]  
only B + X Packages

**Pt100 input; enable/disable** **ON/OFF**

**ON**..... The value of this input appears in the display, and monitoring is enabled. The subsequent parameters of this function are displayed.  
**OFF**..... No display or monitoring is performed, and the subsequent parameters of this function are not displayed.



**NOTE**

If the unit is equipped with a second interface (Y1-Y5), the alarm texts can only be configured via LeoPC1.

Parameter 253

***name*** -----000°C
--------------------------

only B + X Packages

**Pt100 input; description** **User defined text**

The description of the analog input may be programmed using this parameter. A maximum of eleven characters may be used to describe the measured value. In the event of an alarm, the description and the monitored value are displayed with an exclamation mark before the temperature.

Parameter 254

Limit warning	000°C
------------------	-------

only B + X Packages

**Pt100 input; limit value for class F1 alarm** **0 to 200 °C**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 257) for at least the delay time (Parameter 256), the following alarm class is initiated.

<b>Issuing of class F1 alarm</b>
----------------------------------

Parameter 255

Limit shutdown	000°C
-------------------	-------

only B + X Packages

**Pt100 input; limit value for class F3 alarm** **0 to 200 °C**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 257) for at least the delay time (Parameter 256), the following alarm class is initiated.

<b>Issuing of class F3 alarm</b>
----------------------------------

Parameter 256

Delay limit	1/2	000s
----------------	-----	------

only B + X Packages

**Pt100 input; delay time for limit values of class F1 and F3 alarm** **0 to 650 s**

In order to initiate an alarm, the measured value must be over or under (dependent upon Parameter 257) the configured threshold value (Parameter 254 or Parameter 255) without interruption for at least this time.

Parameter 257

Monitoring for -----
-------------------------

only B + X Packages

**Pt100 input; monitoring for ...** **high limit mon. / low limit mon.**

A fault condition is recognized when the measured value has exceeded or fallen below the threshold value (Parameter 254 or Parameter 255).

**high limit mon.:** The measured value must exceed the threshold value.

**low limit mon.:** The measured value must fall below the threshold value.



**NOTE**

If temperature limit monitoring is not required, a threshold value, which is higher than the expected temperature must be configured to the corresponding parameter (e.g. the ambient temperature is 100 °C).

**0 to 400 Ohms Input (Analog Input [T5], only RPQ Package)**

Parameter 258

<b>Name and unit</b> -----
-------------------------------

only RPQ Package

**0 to 400 Ohms input; description** **User defined text**

This parameter is used to configure a custom name for the input. Digits for the measured values may be reserved with a maximum of four zeros. The placeholders may be interrupted by any symbol, for example a comma. The measured values appear then where the zeros have been placed before as placeholders.

**Note:** This input is usually utilized as an input for a **tank gauge**.

Parameter 259

<b>Value at</b> <b>0%</b> <b>0000</b>
--

only RPQ Package

**0 to 400 Ohms input; smallest input value** **-9999 to 9999**

The user must assign a numeric value to the scaleable analog input that corresponds to the smallest input value → Definition of the lower value (i.e. 0 %, e.g. 0 liters) at the minimum analog input value (0 Ohms).

Parameter 260

<b>Value at</b> <b>100%</b> <b>0000</b>
--

only RPQ Package

**0 to 400 Ohms input; largest input value** **-9999 to 9999**

The user must assign a numeric value to the scaleable analog input that corresponds to the largest input value → Definition of the upper value (i.e.100 %, e.g. 1000 liters) at the maximum analog input value (400 Ohms).

Parameter 261

<b>Limit warning</b> <b>value</b> <b>0000</b>
--

only RPQ Package

**0 to 400 Ohms input; limit value for class F1 alarm** **-9999 to 9999**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 264) for at least the delay time (Parameter 263), the following alarm class is initiated.

<b>Issuing of class F1 alarm</b>
----------------------------------

Parameter 262

<b>Limit shutdown</b> <b>value</b> <b>0000</b>
---

only RPQ Package

**0 to 400 Ohms input; limit value for class F3 alarm** **-9999 to 9999**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 264) for at least the delay time (Parameter 263), the following alarm class is initiated.

<b>Issuing of class F3 alarm</b>
----------------------------------

Parameter 263

<b>Delay</b> <b>limit</b> <b>1/2</b> <b>000s</b>
---

only RPQ Package

**0 to 400 Ohms input; delay time for limit values of class F1 and F3 alarm** **0 to 650 s**

In order to initiate an alarm, the measured value must be over or under (dependent upon Parameter 264) the configured threshold value (Parameter 260 or Parameter 261) without interruption for at least this time.

Parameter 264

<b>Monitoring for</b> -----
--------------------------------

only RPQ Package

**0 to 400 Ohms input; monitoring for ...** **high limit mon. / low limit mon.**

A fault condition is recognized when the measured value has exceeded or fallen below the threshold value (Parameter 260 or Parameter 261).

**high limit mon.:** The measured value must exceed the threshold value.

**low limit mon.:** The measured value must fall below the threshold value.

VDO Input 'Pressure' (Analog Input [T6])



**NOTE**

The default threshold values are configured in "bar". If the unit "psi" is configured (Parameter 171) the display of the measured values as well as the transmission via the interface appears in "psi".

VDO inputs for pressure may be measured here. The analog input is displayed with its description. Two threshold levels can be monitored. The first level initiates a class F1 alarm, the second level initiates a class F3 alarm.

Parameter 265

Analog input 6 VDO                    ON
---

**VDO input, pressure; enable/disable** **ON/OFF**

**ON**..... The value of this input appears in the display, and monitoring is enabled. The subsequent parameters of this function are displayed.  
**OFF**..... No display or monitoring is performed, and the subsequent parameters of this function are not displayed.



**NOTE**

If the unit is equipped with a second interface (Y1-Y5), the alarm texts can only be configured via LeoPC1.

Parameter 266

Name and unit -----
------------------------

**VDO input, pressure; description** **User defined text**

The description of the analog input may be programmed using this parameter. A maximum of four zeros may be used as placeholders for the numerical measured values. Characters may divide the placeholders (i.e. a comma). The measured values subsequently appear wherever the zeros are placed. The measured value will always be displayed and transmitted via the interface in bar [ $\times 0.1$ ] or psi [ $\times 0.1$ ].

Parameter 267

Analog input 6 VDO                    0-00bar
--

**VDO input, pressure; measuring range** **0 to 5 / 0 to 10 bar**

The measuring range of the analog input can be selected.  
**0 to 5 bar** ..... Measuring range 0 to 180 Ohm  
**0 to 10 bar** ... Measuring range 0 to 180 Ohm

Parameter 268

Limit warning value                00.0bar
---

**VDO input, pressure; limit value for class F1 alarm** **0.0 to 10.0 bar**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 271) for at least the delay time (Parameter 270), the following alarm class is initiated.

<b>Issuing of class F1 alarm</b>
----------------------------------

Parameter 269

Limit shutdown value                00.0bar
--

**VDO input, pressure; limit value for class F3 alarm** **0.0 to 10.0 bar**

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 271) for at least the delay time (Parameter 270), the following alarm class is initiated.

<b>Issuing of class F3 alarm</b>
----------------------------------



Parameter 274

Limit warning  
value 000°C

VDO input, temperature; limit value for class F1 alarm 40 to 120 °C

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 277) for at least the delay time (Parameter 276), the following alarm class is issued.

Issuing of class F1 alarm

Parameter 275

Limit  
shutdown 000°C

VDO input, temperature; limit value for class F3 alarm 40 to 120 °C

If the measured value exceeds or falls below this configured threshold value (dependent upon Parameter 277) for at least the delay time (Parameter 276), the following alarm class is issued.

Issuing of class F3 alarm

Parameter 276

Delay  
limit 1/2 000s

VDO input, temperature; delay time for limit values of class F1 and F3 alarm 0 to 650 s

In order to initiate an alarm, the measured value must be over or under (dependent upon Parameter 277) the threshold value (Parameter 274 or Parameter 275) without interruption for at least this time.

Parameter 277

Monitoring for  
-----

VDO input, temperature; monitoring for ... high limit mon. / low limit mon.

A fault condition is recognized when the measured value has exceeded or fallen below the threshold value (Parameter 274 or Parameter 275).

**high limit mon.:** The measured value must exceed threshold value.

**low limit mon.:** The measured value must fall below the threshold value.

### Monitoring Of The Measuring Range (All Analog Inputs)

Parameter 278

Ana. input --,-

Analog inputs; monitoring of the measuring range

This message appears when the measured value exceeds or falls below the measuring range occurs. A fault condition is initiated depending on the values specified below.



#### NOTE

If it is determined that the measuring range has been exceeded (wire break) and a fault condition has been initiated, limit value monitoring for the affected analog input is deactivated.

Fault conditions initiate when the measuring range is monitored at:

4 to 20 mA	2 mA and below
Pt100	216 °C and above
180 Ω VDO, 0 to 5 Bar	305 Ω and above
180 Ω VDO, 0 to 10 Bar	305 Ω and above

### Engine Delayed Monitoring Of The Analog Inputs

Parameter 279

Ana.in 12345678  
SV.del. NNNNNJNN

#### Analog inputs; engine delayed monitoring

Y/N

The analog inputs may be disabled until the engine has reached rated speed ("firing speed reached"). This parameter specifies which analog inputs are to be constantly enabled and temporarily disabled by configuring a "Y" or an "N" below the input number.

**Y** .....Once the firing speed has been reached monitoring of the analog input is enabled (the green LED "Protection" illuminates).

**N** .....The analog input is monitored always.

**Note:** Above screen (8 inputs) appears if at least 5 analog inputs are equipped. If less than 5 inputs are equipped, a screen with 4 inputs appears. If less inputs are equipped than inputs appear in the screen, only the entries for the equipped inputs are valid.

### Analog Inputs Selectable as Control Inputs

Parameter 280

Ana.in 12345678  
control NNNNNNNN

#### Analog input as control input

J/N

This parameter defines for each analog input whether it operates as control input or not.

**J** .....The analog input operates as control input: The analog value is displayed and the configured relays are energized when reaching the configured limits. However, no alarm is issued. No guidance bus output is performed as well.

(This setting has no effect on the behavior in case a wire breaks)

**N** .....The analog input operates as described for the above settings.

**Note:** Above screen (8 inputs) appears if at least 5 analog inputs are equipped. If less than 5 inputs are equipped, a screen with 4 inputs appears. If less inputs are equipped than inputs appear in the screen, only the entries for the equipped inputs are valid.

# Outputs



Parameter 281

<b>Configure outputs</b>	<b>YES</b>
--------------------------	------------

## Configuration of the outputs

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:  
**YES**..... The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).  
**NO**..... The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

## Analog outputs (Package XP, Option A2)

The analog output manager can be used to apply a specific measurement variable to the available analog outputs. The output may be carried out as a 0 to 20 mA or as a 4 to 20 mA value. A list of the possible functions is contained in Appendix A. Each variable is assigned a unique number. The variable may be scaled via an upper and a lower input value. The inputs may also be assigned with prefixes (for further details, see "Analog output manager" in Appendix A).



### NOTE

The list of values and limits for the analog output manager is contained in Appendix A: "Analog Output Manager" starting on page 141.

**Possible outputs:** Analog outputs terminals 120/121 and 122/123

**Example:** Analog output terminals 120/121

Parameter 282

<b>Analg.out.120121</b>	
<b>Parameter</b>	<b>00</b>

## Function for analog output

0 to 22

The number of the desired function is configured here. A list of all selectable functions, together with output and limit value ranges, is contained in Appendix A.

Parameter 283

<b>Analg.out.120121</b>	
<b>0-00mA</b>	

## Analog output range

OFF / 0 to 20 / 4 to 20 mA

The output range 0 to 20 mA or 4 to 20 mA is selected using this parameter.

Parameter 284

<b>Analg.out.120121</b>	
<b>0%</b>	<b>0000</b>

## Scaling the lower output value

0 to 9,990

The configurable limit for the 0% value is contained in Appendix A.

Parameter 285

<b>Analg.out.120121</b>	
<b>100%</b>	<b>0000</b>

## Scaling the upper output value

0 to 9,990

The configurable limit for the 100% value is contained in Appendix A.

## Relay Manager

The relay manager enables the assignment of an arbitrary combination of functions to each relay. In order to achieve this, each function of the control has its own number. A text, which describes a logical condition that energizes the relay, must now be entered in the configuration menu for each relay. Up to three function numbers may be combined in this link. The length of the text must not exceed 16 characters. The control can detect incorrect function numbers or formula constructions and will not accept these.



### NOTE

The relay manager functions are listed in Appendix B: "Relay Manager" starting on page 144.

Permissible text/symbols for logic functions and their meaning include:

- + .....OR operator (logic function)
- \* .....AND operator (logic function)
- .....NOT operator (logic function)
- 1, 2, 3, ... .....Function numbers
- +/\* .....the following applies "\*" before "+"

**Example**  
of logical  
conditions  
and relevant  
texts

Function	Programmed text
Relay picks up, if ...	
... function 22 is applied.	22
... function 22 is not applied.	- 22
... both function 2 and function 27 are applied.	2 * 27
... function 2 or function 27 is applied.	2 + 27
... not function 5 or function 3 or function 13 are applied.	3 + -5 + 13
... function 4 or 7 or 11 is applied.	4 + 7 + 11
... not function 4 and not function 7 and not function 11 are applied.	- 4 * -7 * -11
... function 4 and 7 and 11 are applied.	4 * 7 * 11
... function 7 and 11 are simultaneously or function 4 is applied.	4 + 7 * 11
... not function 4 or not function 7 or not function 11 are applied.	-4 + -7 + -11



### NOTE

Entering an illegal logical combination deletes the equation.

Parameter 286

**Assignm.relay x**  
**3+-8+13**

[x = 1 to 7]

### Programming relay outputs

The relay x [x = 1 to 7] energizes, if the logical equation is met.

Example: 3 + -8 + 13 (OR link)

- 3 a class F3 alarm has occurred
- 8 operation mode MANUAL has not been selected
- 13 "Generator underspeed" alarm is present

# Engine



Parameter 287

**Configure engine** YES

## Configuration of the engine

YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:

**YES**..... The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO**..... The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

Parameter 288

**Aux.services prerun** 000s

## Engine; auxiliary prerun (start preparation)

0 to 999 s

Prior to each starting sequence, a relay output (relay manager function 52) can be enabled for this time (i.e. prelube pumps run). A message is displayed when the relay output is enabled. This relay output is automatically enabled in MANUAL operation mode. The relay output is present until the operation mode is changed.

### CAUTION

This delay is ignored in the event of emergency power operation. The engine is started immediately.

Parameter 289

**Aux.services postrun** 000s

## Engine; auxiliary postrun

0 to 999 s

The relay output (relay manager function 52) can be enabled for this time following each engine cool down (i.e. operate a coolant pump). If the operation mode is changed from MANUAL to STOP or to AUTOMATIC without an engine start request, the relay remains enabled for this postrun time and a message is displayed.

Parameter 290

**Start-stop-logic for** -----

## Engine; start/stop sequence for ...

DIESEL/GAS/EXTERNAL

**DIESEL**..... Start/stop logic is performed for a diesel engine.  
**GAS** ..... Start/stop logic is performed for a gas engine.  
**EXTERNAL** External start/stop sequence (the start/stop sequence is disabled).

### Start/Stop Sequence 'Gas Engine'



**NOTE**

The configured number of start attempts (Parameter 294) will be performed.




Figure 3-13: Start-Stop sequence: Gas engine

The signs and indices mean:

- tSta..... Approach idle gas position [s]
- tZV..... Firing delay [s]
- tGV ..... Gas delay [s]
- tSPZ ..... Time between two start attempts [s]
- tMV..... Delayed engine monitoring [s]
- tZN..... Ignition coasting [s]; pre-specified: 5 s
- tN ..... Engine cool down time [s]
- (1) ..... Disengagement of the starter; Ignition and gas also ON
- (2) ..... Switching ON the ignition

### Starting Sequence

If the control is equipped with a three-position frequency controller, a continuous signal (time adjustable via Parameter 298) is output prior to starting the engine at the "Frequency lower" relay output. The starter is then enabled. Following the expiration of the ignition delay time (Parameter 292) and if the engine is rotating with at least the configured "minimum speed for ignit." (Parameter 291), the ignition is enabled. Following the expiration of the gas valve delay (Parameter 293), the gas valve is then enabled. If the starting sequence finishes successfully (the firing speed (Parameter 308) was exceeded) the starter is disengaged. The gas valve and the ignition remain enabled by means of the firing speed. After reaching the "f-controller: starting frequency" (Parameter 50) and the delayed engine monitoring has expired (Parameter 307), the speed controller is enabled.

### Stopping Sequence

When the start request is terminated, a power reduction is performed (if the real power controller is enabled, Parameter 87). After the GCB has opened, an engine cool down is performed (Parameter 306). When the engine cool down period expires, the gas valve is closed, and the engine is stopped. If the engine speed falls below the firing speed (Parameter 308), an engine starting sequence is disabled for 10 seconds. If the engine cannot be stopped, an alarm message is issued after 30 s, and a class F3 alarm is initiated.

**Following negative deviation from the firing speed, the ignition remains enabled for an additional 5 seconds so that the remaining gas is able to combust.**

### Safety Instructions To Control Gas Valves

In order to ensure a safe shutdown of the gas valves, a separate shutdown circuit must be utilized. To prevent gas from escaping through the gas line due to stuck relays the following is recommended.

#### Controlling gas valves with the GCP-30

The GCP-30 relay manager from V4.1001 and on contains function 131. This function exists in the GCP- 30 so that a relay configured with this function behaves like the "Gas valve" relay.

The wiring diagram shown below is an example of a recommended gas valve control system in the gas line.




Figure 3-14: Wiring diagram for opening gas valves with the GCP-30 from V4.1001

Parameter

Parameter 291

Min. speed for  
ignit. 000 rpm

This screen is only visible if the parameter "Pickup" is set "ON".

Gas engine; minimum start speed 0 to 999 rpm

**ⓘ** The minimum starter speed can only be detected using an enabled magnetic pick-up (Parameter 280).

Once the ignition delay (Parameter 292) has expired, the engine must exceed the speed configured with this parameter in order to enable the ignition relay (relay manager function 84).

Parameter 292

Ignition delay  
00s

Gas engine; ignition delay 0 to 99 s

In gas engine applications a purging operation is frequently desired prior to starting. The ignition delay is initiated when the starter is engaged. If this time has expired and the "Minimum speed for ignition" (Parameter 291) has been exceeded, the ignition is enabled.

Parameter 293

Gasvalve delay  
00s

Gas engine; gas valve delay 0 to 99 s

This timer is initiated once the ignition is enabled. Once this timer has expired and the engine speed is at least 150 rpm, the gas valve is opened. Upon reaching the firing speed (Parameter 308) the relay remains energized until the engine stops.

Parameter 294

Max. attempts to  
start 0

Gas engine; maximum number of start attempts 1 to 6

The control will initiate up to this number of start attempts. If the engine cannot be started within this number of start attempts, an alarm message is issued.

Parameter 295

Starter time  
00s

Gas engine; engagement time of the starter 2 to 99 s

The maximum amount of time the starter will crank the engine during a start sequence.

Parameter 296

Start pause time  
00s

Gas engine; time between two start attempts 1 to 99 s

The delay time between the individual start attempts.

Parameter 297

f lower before  
start ON

with three-step controllers only

Gas engine; approach low-idle position ON/OFF

If this function is enabled and the control is equipped with a three-step frequency controller, the command "lower engine speed" is issued for the time configured in Parameter 298 before the starter is engaged. The low-idle position must either be equipped with a limiting switch or the engine potentiometer must be equipped with a slipping clutch to protect the devices. A message is displayed.

**CAUTION**

The engine starting is delay by means of the low-idle position in the event of emergency power operation.

Parameter 298

time f lower  
bef.start 000s

with three-step controllers only

Gas engine; approach low-idle position (time) 0 to 999 s

The duration that the "lower engine speed" signal (Parameter 297) is output.

### Start/Stop Sequence 'Diesel Engine'



**NOTE**

The configured number of start attempts (Parameter 300) will be performed.




Figure 3-15: Start-stop sequence: Diesel engine

The signs and indices mean:

tSta ..... Approach idle fuel position [s]

tVG ..... Preglow time [s]

tEin ..... Crank time [s]

tSPZ ..... Time between two start attempts [s]

tMV ..... Delayed engine monitoring [s]

tN ..... Engine cool down time [s]

### Starting Sequence

If the control is equipped with a three-position frequency controller, a continuous signal (time adjustable via Parameter 304) is output prior to starting the engine at the "Frequency lower" relay output. Following the expiration of this time, the "Pre-glow" relay will be enabled (pre-glow time is configurable via Parameter 299). Following preheating, the fuel relay is enabled (Parameter 305), followed by the crank relay. Once the firing speed (Parameter 308) has been exceeded, the starter disengages, and the fuel relay remains enabled by means of the firing speed. After reaching the "f-controller: starting frequency" (Parameter 50) and the delayed engine monitoring has expired (Parameter 307), the speed controller is enabled.

### Stopping Sequence

When the start request is terminated, a power reduction is performed (if the real power controller is enabled, Parameter 87). Once the GCB has opened, an engine cool down is performed (Parameter 306). When the engine cool down period expires, the fuel relay is de-energized and the engine is stopped. If the engine speed falls below the firing speed (Parameter 308), the engine starting sequence is disabled for 10 seconds. If the engine cannot be stopped, an alarm message is issued after 30 s, and a class F3 alarm is initiated.

### Parameter

Parameter 299

<b>Preglow time</b>	00s
---------------------	-----

**Diesel engine; pre-glow time** **0 to 99 s**

Prior to each starting sequence, the engine glow plugs are enabled for this time period.

Parameter 300

<b>Max. attempts to start</b>	0
-------------------------------	---

**Diesel engine; maximum number of start attempts** **1 to 6**

The control will initiate up to this number of start attempts. If the engine cannot be started within this number of start attempts, an alarm message is issued.

Parameter 301

<b>Starter time</b>	00s
---------------------	-----

**Diesel engine; crank time** **2 to 99 s**

The maximum amount of time the starter will crank the engine during a start sequence.

Parameter 302

<b>Start pause time</b>	00s
-------------------------	-----

**Diesel engine; time between two start attempts** **1 to 99 s**

The delay time between the individual start attempts.

Parameter 303

<b>f lower before start</b>	OFF
-----------------------------	-----

**Diesel engine; approach low-idle position** **ON/OFF**

If this function is enabled and the control is equipped with a three-step frequency controller, the command "lower engine speed" is issued for the time configured in Parameter 304 before the starter is engaged. The low-idle position must either be equipped with a limiting switch, or the engine potentiometer must be equipped with a slipping clutch to protect the devices. A message is displayed.

with three-step controllers only

#### CAUTION

The engine starting is delay by means of the low-idle position in the event of emergency power operation.

Parameter 304

time f lower bef.start 000s
--------------------------------

with three- step controllers only

**Diesel engine; approach low-idle position (time)****0 to 999 s**

The duration that the "lower engine speed" signal (see Parameter 303) is output.

Parameter 305

Fuel relay logic -----
---------------------------

**Diesel engine; fuel solenoid logic****open to stop / close to stop**

**open to stop** . The operating solenoid is energized prior to each start sequence. In order to shutdown the engine, the operating solenoid is de-energized.

**close to stop** In order to shutdown the engine, the stop solenoid is energized. The stop solenoid remains energized for an additional 10 seconds once the engine speed drops below firing speed (Parameter 308) **and** the generator voltage is less than 20 V.

## Cool Down

Parameter 306

Cool down time 000s
------------------------

**Engine; cool down time****0 to 999 s**

If the engine performs a normal shutdown (i.e. STOP mode initiated) or stoppage by means of a class F2 alarm has been initiated, an engine cool down period with an open GCB and frequency control is performed for this time. If the engine cool down has terminated (cool down time has been expired) and engine speed (Parameter 308) is still detected after 30 seconds, an engine failure to stop message is displayed.

### Note

An engine cool down is performed only if the reply of a closed GCB (terminal 4) has been enabled for at least 5 seconds.

### Delayed Engine Monitoring And Firing Speed



Figure 3-16: Delayed engine monitoring

Parameter 307

Delayed engine monitoring 00s

Engine; delayed engine monitoring

1 to 99 s

Delay between reaching the firing speed and monitoring of selected alarms (e.g. oil pressure, generator underfrequency, etc.).

Parameter 308

Firing speed reached f >00Hz

Engine; firing speed reached

5 to 70 Hz

Setting of the firing speed: Once this firing speed has been reached, the starter is disengaged (switched off) and the frequency controller starts governing.

Note

Accurate measurement is possible above 15 Hz, even if 5 Hz are displayed. If the Pickup measurement has been configured to "ON", values down to 5 Hz are displayed.

Pick-Up

Measuring the engine speed can be performed alternatively by means of a Magnetic Pickup, the generator frequency, or a tacho generator. Refer to the wiring diagram that pertains to your specific controller in manual 37239, chapter 4.

Parameter 309

Pickup input ON

Pickup; Pickup measurement

ON/OFF

ON..... Engine speed monitoring is performed by means of a Magnetic Pickup. Once firing speed has been achieved, the starter disengagement is initiated by the MPU measurements.

OFF..... Frequency monitoring/control is performed by means of the generator frequency measurement. Once firing speed has been achieved, the starter disengagement is initiated by the generator frequency measurements.

Parameter 310

Number of pickup teeth 000

Pickup; number of Pickup teeth

30 to 280

Number of pulses per revolution.

Plausibility monitoring:

Plausibility monitoring is the comparison of the measured electrical frequency (determined from the generator voltage) and mechanical speed (determined from the Pickup signal). If the two frequencies are not identical, a class F1 alarm is initiated. The plausibility monitoring is enabled by the expiration of delayed engine monitoring (Parameter 307) and performed continuously while the generator is operating.

Parameter 311

Gen. rated speed 0000 rpm

Pickup; rated speed at rated frequency

0 to 3,000 rpm

Number of revolutions per minute at rated frequency speed.

# Counter / Real Time Clock



Parameter 312

Configure counters	YES
--------------------	-----

## Configuration of the counters YES/NO

Parameters are grouped together in blocks to permit quicker navigation through the large number of configuration screens. Selecting "YES" or "NO" has no effect if controlling or monitoring is performed. This parameter has the following effects:

**YES** .....The configuration screens in the next block are displayed and can either be viewed ("Select" push-button) or modified ("Cursor→", "Digit↑" or "Select" push-buttons).

**NO** .....The parameters in the next block are not displayed, cannot be modified and are therefore skipped.

## Maintenance Call

Parameter 313

Service interval in	0000h
---------------------	-------

## Counter; maintenance call 0 to 9,999 h

A maintenance interval can be specified with this parameter. After the engine has been in operation for the number of hours configured here, a maintenance message (class F1 alarm) is displayed. Following the acknowledgement of the message, the counter is reset to this value.

**Note**  
Entering "0" will disable the maintenance call.



### NOTE

- In order to reset the maintenance call prior to the configured time (maintenance call alarm not yet initiated), perform the following procedure:
- Navigate to the display screen "Service in 000h" using the "Select" button.
  - Press and hold the "Digit" button for 10 seconds.
  - The new maintenance interval is displayed.

## Operating Hours Counter

Parameter 314

Set oper.hours counter	0000h
------------------------	-------

## Counter; operating hours counter 0 to 65,000 h

This parameter can be used to specify the number of hours an engine has been in operation. This permits the user to display the correct number of engine hours if this controller is used on an older engine or this controller is to replace an older controller.

**Note:** The operating hours counter may only be accessed from code level 2 with the [RPQ Package](#).



### NOTE

If the unit is equipped with option SC06, SC07, or SC08, and the MDEC or J1939 coupling is enabled as well, the operating hours will be taken over from the engine control unit. Please refer to manual 37313 for further information.

**NOTE**

If a value is to be input in this parameter other than the factory default, the controller must be in code level CS2. For safety reasons, the counter is set in a 2-step sequence.

The following sequence applies:

1. Step: Set and store the desired operating hours
2. Step: Integrate the value which has been saved by ...
  - Terminate the configuration mode and switch to automatic mode
  - Display of the operating hours
  - Press and hold the "Digit" push-button for at least 5 seconds.

**Rental Duty Time Counter (only RPQ Package)**

The RPQ Rental Package provides an rental duty time counter with minute resolution (max. 9999:59h). It may be accessed in every code level. This counter is an additional operating hours counter which may be used for charging the cost when renting the unit.

The rental duty time counter may be reset to 0 before utilization for example. In order to perform this, the unit must be in code level 2, the rental duty time counter must be displayed, and then the Digit button must be pressed for at least 5 s.

**NOTE**

The rental duty time counter cannot be used to count the actual operating hours because it may be re-set independently from the operating hours counter.

**Start Counter**

Parameter 315

Set start counter	00000
----------------------	-------

**Counter; number of engine starts****0 to 32,000**

The start counter is used to display how many times the engine has been started. Following each starting attempt the start counter is increased by one. This permits the user to display the correct number of starts if this controller is used on an older engine, a starter is replaced, or this controller is to replace an older controller.

Only maintenance personnel should configure the start counter!

**NOTE**

If the engine start counter is to be changed from the factory default setting, the controller must be in code level CS2. For safety reasons, the counter is set in a 2-step sequence.

The following sequence applies:

1. Step: Set and store the desired number of starts
2. Step: Integrate the value which has been saved by ...
  - Terminate the configuration mode and switch to automatic mode
  - Display the number of engine starts
  - Press and hold the "Digit" push-button for at least 5 seconds

## kWh Counter

Parameter 316

kWh counter
set in       ---

Counter; kWh counter set in ...

kWh/MWh

The power produced may be measured in kWh or MWh. The user defined which scale is desired for the controller with this parameter.

Parameter 317

kWh counter
set        00000---

Counter; kWh counter set for ...

0 to 65,500 kWh/MWh

The user may input values into the kWh/MWh counter (depending on Parameter 316) with this parameter. This permits the user to display the correct number of kWh/MWh for a generator if this controller is used on an older engine or this controller is to replace an older controller.



### NOTE

If the kWh counter is to be changed from the factory default setting, the controller must be in code level CS2. The counter is set in a two-step procedure due to safety reasons.

The following proceeding is valid:

- 1. Step:       Set and store the desired counter values for the parameters 293 and 294
- 2. Step:       Integrate the stored value by ...
  - Terminate the configuration mode and change to automatic mode
  - Displaying the kWh counter
  - Press and hold the "Digit" push-button for at least 5 seconds

## Real Time Clock (Package XP, Option ZE)



### NOTE

If several GCP-30 control units are on one common CAN bus all clocks are synchronized daily at 12:00 o'clock (noon) to the time of the control with the lowest control/generator number. This makes it essential that each control unit has a different control number.

Parameter 318

<b>Time</b>	00:00
-------------	-------

#### Real time clock; time

Setting of the hours and minutes of the internal real time clock.

Hour	
00	0 <sup>th</sup> hour of the day
01	1 <sup>st</sup> hour of the day
...	...
23	23 <sup>rd</sup> hour of the day
Minute	
00	0 <sup>th</sup> minute of the hour
01	1 <sup>st</sup> minute of the hour
...	...
59	59 <sup>th</sup> minute of the hour

Parameter 319

<b>Year, month</b>	00,01
--------------------	-------

#### Real time clock; year/month

Setting the year and month of the internal real time clock.

Year	
99	Year 1999
00	Year 2000
01	Year 2001
...	...
Month	
01	January
02	February
...	...
12	December

Parameter 320

<b>Day/weekday</b>	01/1
--------------------	------

#### Real time clock; day/weekday

Setting of the day and weekday of the internal real time clock.

Day	
01	1st of the month
02	2nd of the month
...	...
31	31st of the month, if available
Weekday	
1	Monday
2	Tuesday
...	...
7	Sunday

### Timer Switch (Package RPQ, Option Z01)

The relay with Parameter 147 may be enabled time-dependent. There are two parameters to configure an enable and a disable time for this relay. Another parameter is available to configure the weekdays at which these times are enabled.

If you want to perform a time-dependent genset start for example, this relay output may be connected to the input at terminal 3.

Parameter 321

Timer on  
at 00:00

**Timer enable time** **00:00 to 23:59**

The time at which the relay with Parameter 147 is to be enabled must be configured here.

Parameter 322

Timer off  
at 00:00

**Timer disable time** **00:00 to 23:59**

The time at which the relay with Parameter 147 is to be disabled must be configured here. (The time configured here must be later than the enable time because the enable and disable time must always be within one day.)

Parameter 323

Week M S  
days NNNNNNN

**Weekdays** **Y/N**

**Y(es)** .....The switch times configured above are considered on the assigned weekdays.

**N(o)** .....No switch times are considered on the assigned weekdays.



#### NOTE

Since this function affects a relay only, it cannot be enabled and disabled separately. If the function shall not be used, Parameter 147 must not be configured in the Relay Manager.

### Current Slave Pointer

A current slave pointer, which records and stores the maximum generator current, is implemented in the control. The display of the maximum generator current can be selected in the **Automatic mode** by pressing the "Message" push-button. The following screen appears in the display:

Parameter 324

000 000 000 000  
max. Gen.current

**Current slave pointer; display of the maximum generator current**

The maximum generator current in each phase is displayed.

**Reset:** Pressing and holding the "reset" button for 3 seconds while the current slave pointer screen is being displayed will reset the memory.

## Chapter 4. Commissioning



### DANGER - HIGH VOLTAGE

When commissioning the control, please observe all safety rules that apply to the handling of live equipment. Ensure that you know how to provide first aid in the event of an uncontrolled release of energy and that you know where the first aid kit and the nearest telephone are. Never touch any live components of the system or on the back of the system:

**LIFE THREATENING**



### CAUTION

Only a qualified technician may commission unit. The "EMERGENCY-STOP" function must be operational prior to commissioning of the system, and must not depend on the unit for its operation.



### CAUTION

Prior to commissioning ensure that all measuring devices are connected in correct phase sequence. The connect command for the unit circuit breaker must be disconnected at the unit circuit breaker. The field rotation must be monitored for proper rotation. Any absence of or incorrect connection of voltage measuring devices or other signals may lead to malfunctions and damage the unit, the engine, and/or components connected to the unit!

#### Commissioning Procedure:

1. After wiring the unit and ensuring all voltage-measuring devices are phased correctly, apply the control system voltage (i.e. 12/24 Vdc). The "Operation" LED will illuminate.
2. By simultaneously pressing the two push-buttons "Digit↑" and "Cursor→", the configuration mode is accessed. After entering the access code number, the unit may be configured according to the application requirements (see the chapter regarding the parameters).
3. After applying the measuring variables, the unit will display the measured values. These values should be confirmed with a calibrated measuring instrument.
4. The initial start of the engine should be performed in the **MANUAL operation mode** (press the "MANUAL" push-button). Start the engine ("START" push-button) and then stop it ("STOP" push-button). All generator measured values must be checked. Any alarm messages should be investigated as well.
5. Check the automatic start sequence by means of the **TEST operation mode** (press the "TEST" push-button). Test the protections that result in alarms with shutdowns.

6. "AUTO" operation mode (press the "AUTO" push-button): Applying the automatic control inputs and the engine start request can now carry out automatic starting with subsequent synchronization.

Check synchronization: Check the generator and the generator busbar rotating fields. Check the connect command with a zero voltmeter (determination of the phase angle) at the generator power circuit breaker (GCB). If several correct synchronizing pulses have been output, switch the operation mode to "STOP" and reconnect the connect pulse "Command: close GCB" with the engine in "STOP" mode.

7. If steps 1 through 6 have been carried out successfully, parallel operations may be commenced. It is recommended to start with a constant power/baseload operation (approx. 25 % of the generator rated power) initially. While this operation is being carried out, the displayed measured values must be verified. Test the GCB shutdown. Check the real power controller and if necessary the power factor controller for proper operation. Enter various set point values and verify proper operation.

8. If the mains parallel operation performs in a satisfactory manner, the synchronization of the mains power circuit breaker (MCB) must be checked:

A power failure in the system must be simulated or observed by the controller. During a mains parallel operation, change the operation mode from AUTOMATIC to MANUAL. Open the MCB ("MCB ON" LED will turn off). Press the AUTOMATIC push-button to return the controller back to the AUTOMATIC operation mode.

Check the generator busbar and the mains rotating field. Check the connect command with a zero voltmeter (determination of the phase angle) at the MCB. If several correct synchronizing pulses have been output, switch the operation mode to "STOP" and re-connect the connect pulse "Command: close MCB" with the engine in "STOP" mode.

9. Test the emergency power operation functions



## NOTE

The automatic operation mode is influenced by the input signals "Automatic 1" and "Automatic 2". Ensure that the power circuit breaker reply messages are processed as the reverse of the condition (i.e. when the circuit breaker is closed the reply message for the inputs: CB is open (terminal 54) is 0 volts. The CB aux contacts should be configured as normally closed! Refer to the description of the auxiliary and control inputs starting on page 10. It is vital that these replies be connected!

Electrical insulation between voltage supply and discrete control and feedback inputs: By the use of corresponding external wiring, the common reference point of the discrete inputs can be electrically isolated from the supply voltage (0 V, terminal 2). This is necessary if the discrete inputs are not to be triggered with 24 Vdc and electrical isolation of the control voltage (e. g. 220 Vdc, 220 Vac) from the supply voltage must be insured.

## Appendix A. Analog output manager (Package XP, Option A2)



### NOTE

The functions listed below can only be output correctly if the existing version of the control permits this.

Function	Output	Value	Input of the two limit values
0	The analog output is disabled.	N/A	N/A
1	Actual generator real power	[dimensionless]	0% Lower power limit (can also be negative) e.g. -0050 kW 100% Upper power limit (can also be negative) e.g. 0200 kW
2	Actual generator power factor $\phi$ [e.g. (-070 to +080) /100] (Definition at end of Table)	[dimensionless]	0% Lower interval to power factor $\phi=1$ e.g. -0030 corresponds to $\cos 0.70$ 100% Upper interval to power factor $\phi=1$ e.g. 0030 corresponds to $\sin 0.70$
3	Actual generator frequency	[Hz*100]	0% Lower frequency e.g. 0000 corresponds to 00.00 Hz. 100% Upper frequency e.g. 7000 corresponds to 70.00 Hz.
4	Actual generator reactive power	[kvar]	0% capacitive reactive power (negative) e.g. -0100 kvar 100% inductive reactive power (positive) e.g. +0100 kvar
5	Rated power of all generators connected to generator busbar minus nominal actual power	[kW]	0% Lower power (can also be negative) e.g. -0050 kW
6	Total actual power of all generators connected to generator busbar	[kW]	100% Upper power (can also be negative) e.g. 0200 kW
7	Generator apparent current in L1	[A]	0% Lower current output e.g. 0000 A 100% Upper current output e.g. 500 A
8	Generator apparent current in L2	[A]	
9	Generator apparent current in L3	[A]	

Function	Output	Value	Input of the two limit values
10	Speed via Pickup	[min <sup>-1</sup> ]	0% Lower speed e.g. 0000 rpm 100% Upper speed e.g. 3000 rpm
11	Analog input [T1] (Package XP, Option T701)	[°C] or [°F] or freely scaleable	0% Lower measured value e.g. 0000 corresponds to 000 °C at temperature input 100% Upper measuring value e.g. 0255 corresponds to 255 °C at temperature input  0% Lower measured value e.g. 0000 corresponds to 00.0 bar oil pressure 100% Upper measured value e.g. 0100 corresponds to 10.0 bar oil pressure
12	Analog input [T2] (Package XP, Option T701)	[°C] or [°F] or freely scaleable	
13	Analog input [T3] (Package XP, Option T701)	[°C] or [°F] or freely scaleable	
14	Analog input [T4] (Package XP, Option T701)	[°C] or [°F] or freely scaleable	
15	Analog input [T5] (Package XP, Option T701)	[°C] or [°F] or freely scaleable	
16	Analog input [T6] (Package XP, Option T701)	[Bar] or [PSI] or freely scaleable	
17	Analog input [T7] (Package XP, Option T701)	[Bar] or [PSI] or freely scaleable	
18	--free--	[°C] or [°F] or freely scaleable	
19	Actual mains interchange (import/export) real power	[kW]	0% lower power e.g. -0800 kW 100% upper power e.g. 0800 kW
20	Mains apparent current in L1	[A]	0% Lower current output e.g. 0000 A 100% Upper current output e.g. 500 A
21	Mains power factor φ [e. g. (-070 to +080) /100] (Definition at end of Table)	[dimension- less]	0% Lower interval to power factor φ=1 e.g. -0030 corresponds to k0,70 100% Upper interval to power factor φ=1 e.g. 0030 corresponds to i0,70
22	Actual mains reactive power	[kvar]	0% capacitive reactive power (negative) e.g. -0100 kvar 100% inductive reactive power (positive) e.g. +0100 kvar

The designation 0 % stands for either 4 mA or 0 mA; the designation 100 % stands for 20 mA. The values may also be assigned with prefixes (see relay manager function 1).

**Definition of power factor  $\cos \varphi$  scaling:** According to the scaling of the analog output, the power factor  $\cos \varphi$  can be output within the range from capacitive values ranging from  $c0.00$  via power factor  $\varphi = 1$  to inductive values up to  $i0.00$ .




Figure 4-1: Analog outputs -  $\cos \varphi$  scaling

## Appendix B. Relay Manager

No.	Output	Explanation
1	Alarm class 1	
2	Alarm class 2	
3	Alarm class 3	
4	Firing speed reached (engine runs)	
5	Mains failure; undelayed	The function reacts according to the status of the breakers. The conditions described in chapter "Emergency power" apply.
6	Battery undervoltage	
7	AUTOMATIC operation mode	
8	MANUAL operation mode	
9	TEST operation mode	
10	STOP operation mode	
11	Generator undervoltage	
12	Generator overvoltage	
13	Generator underfrequency	
14	Generator overfrequency	
15	Generator overcurrent level 1	
16	"Synchronization GCB" or "Connect GCB" time monitoring alarm	
17	Engine start failure	
18	Generator unbalanced load	
19	Generator overload	
20	Generator reverse/reduced power	
21	Readiness for operation	Output via relay manager
22 <sup>#1</sup>	Analog input [T1], level 1	
23 <sup>#1</sup>	Analog input [T1], level 2	
24 <sup>#1</sup>	Analog input [T2], level 1	
25 <sup>#1</sup>	Analog input [T2], level 2	
26 <sup>#1</sup>	Analog input [T3], level 1	
27 <sup>#1</sup>	Analog input [T3], level 2	
28 <sup>#1</sup>	Analog input [T4], level 1	
29 <sup>#1</sup>	Analog input [T4], level 2	
30 <sup>#1</sup>	Analog input [T5], level 1	
33 <sup>#1</sup>	Analog input [T5], level 2	
32 <sup>#1</sup>	Analog input [T6], level 1	
33 <sup>#1</sup>	Analog input [T6], level 2	
34 <sup>#1</sup>	Analog input [T7], level 1	
35 <sup>#1</sup>	Analog input [T7], level 2	
36	Discrete input [D01]	
37	Discrete input [D02]	
38	Discrete input [D03]	
39	Discrete input [D04]	
40	Discrete input [D05]	
41	Discrete input [D06]	
42	Discrete input [D07]	
43	Discrete input [D08]	
44	Discrete input [D09]	
45	Discrete input [D10]	
46	Discrete input [D11]	
47	Discrete input [D12]	
48	Discrete input [D13]	
49	Discrete input [D14]	
50	Discrete input [D15]	

<sup>#1</sup> (Package XP, Option T701)

No.	Output	Explanation
51	Discrete input [D16]	
52	Auxiliary services	i.e. prelube/cooling pumps
53 <sup>#1</sup>	--Internal--	
54	Centralized alarm (class F1, F2, or F3 alarm; enabled until acknowledgement)	
55	TEST or AUTOMATIC operation mode selected	
56	Generator power watchdog, level 1	
57	MCB is closed	
58	GCB is closed	
59 <sup>#1</sup>	--Internal--	
60	Mains parallel operation is desired: disable interlock of GCB <> MCB	
61	Overcurrent I/t or generator overcurrent, level 2	
62	Introduce load-shedding: Connection / synchronization of GCB is carried out or circuit breaker is closed	Signal is enabled prior to connection / synchronization and remains enabled after circuit breaker is closed.
63	Connection / synchronization MCB carried out or circuit breaker is closed	Signal is enabled prior to connection / synchronization and remains enabled after circuit breaker is closed.
64	Overspeed via Magnetic Pickup	
65	Emergency power is active	
66	Shutdown malfunction	
67	Power watchdog for power supplied by the mains	
68	Maintenance call	
69	Pickup/gen. differential frequency	The monitored generator frequency and the engine speed from the MPU are different
70	"Synchronization MCB" or "Connect MCB" time monitoring alarm.	
71	GCB synchronization carried out	
72	MCB synchronization carried out	
73	Lamp test active	
74	Malfunction "Reply: GCB is open" - fault on closing	The GCB cannot be closed after 5 attempts.
75	Malfunction "Reply: MCB is open" - fault on closing	The MCB cannot be closed after 5 attempts.
76	Malfunction "Reply: GCB is open" - fault on opening	2 s following the "Command: open GCB" a reply continues to be detected.
77	Malfunction "Reply: MCB is open" - fault on opening	2 s following the "Command: open MCB" a reply continues to be detected.
78	Power supplied by the mains <> 0	In the event of interchange synchronization, the zero incoming power cannot be attained. The MCB is prevented from opening as a result of this. Reset via acknowledgment.
79	Connect time on dead bus start exceeded	
80	Generator power watchdog, level 2	

<sup>#1</sup> special versions only

No.	Output	Explanation
81	Left mains rotating field	
82	Engine enable	<p><b>Set engine enable</b> As long as there is a start request for the engine and during cool down (as long as the operation of the engine is enabled, i.e. operation mode AUTOMATIC and discrete input 3/5, emergency power, start via interface, manual start, etc.).</p> <p><b>Reset engine enable</b> If the start request is no longer present, in the event of manual stoppage, with a class F3 alarm, during the engine stop time (prior to a further attempt at starting), and if "zero" speed is detected and there is not a start request present or coasting is not taking place.</p>
83	"RESET" push-button pressed	
84	Preheating/firing ON (pre-assigned to relay [7])	pre-assigned default value
85	Group alarm of class F1, F2, or F3 alarm (pre-assigned to relay [8])	pre-assigned default value Horn: after 2 min independent shutoff
86 <sup>#1</sup>	CHP operation power reduction level 1	
87 <sup>#1</sup>	CHP operation power reduction level 2	
88	Generator voltage and frequency are not available (undelayed)	
89	Busbar voltage and frequency are not available (undelayed)	
90 <sup>#1</sup>	--Internal--	
91	Pickup has nominal speed (+/-6 %)	
92	Mains voltage fault via protection device	
93	Mains frequency fault via protection device	
94	Phase/vector shift fault via protection device	
95 <sup>#2</sup>	Load balance monitoring	
96	Delayed engine monitoring time exceeded	
97	Sprinkler mode is active (included Sprinkler coasting)	
98 <sup>#3</sup>	IKD1 discrete input 1	
99 <sup>#3</sup>	IKD1 discrete input 2	
100 <sup>#3</sup>	IKD1 discrete input 3	
101 <sup>#3</sup>	IKD1 discrete input 4	
102 <sup>#3</sup>	IKD1 discrete input 5	
103 <sup>#3</sup>	IKD1 discrete input 6	
104 <sup>#3</sup>	IKD1 discrete input 7	
105 <sup>#3</sup>	IKD1 discrete input 8	
106 <sup>#3</sup>	IKD2 discrete input 1	
107 <sup>#3</sup>	IKD2 discrete input 2	
108 <sup>#3</sup>	IKD2 discrete input 3	
109 <sup>#3</sup>	IKD2 discrete input 4	
110 <sup>#3</sup>	IKD2 discrete input 5	
111 <sup>#3</sup>	IKD2 discrete input 6	
112 <sup>#3</sup>	IKD2 discrete input 7	
113 <sup>#3</sup>	IKD2 discrete input 8	

<sup>#1</sup> (Option TZ01), <sup>#2</sup> (Option UW1), <sup>#3</sup> (Option SC06)

No.	Output	Explanation	
114 <sup>#1</sup>	Three-position controller: n+ / f+ / P+	(use an external RC protection circuit)	
115 <sup>#1</sup>	Three-position controller: n- / f- / P-		
116 <sup>#1</sup>	Three-position controller: V+ / Q+		
117 <sup>#1</sup>	Three-position controller: V- / Q-		
118 <sup>#2</sup>	Mains monitoring df/dt		
119 <sup>#3</sup>	Wire break Analog input [T1]		
120 <sup>#3</sup>	Wire break Analog input [T2]		
121 <sup>#3</sup>	Wire break Analog input [T3]		
122 <sup>#3</sup>	Wire break Analog input [T4]		
123 <sup>#3</sup>	Wire break Analog input [T5]		
124 <sup>#3</sup>	Wire break Analog input [T6]		
125 <sup>#3</sup>	Wire break Analog input [T7]		
126 <sup>#4</sup>	Relay for gas supply test		
127 <sup>#5</sup>	Temperature too low and generator voltage/frequency within range		
128 <sup>#6</sup>	--Internal--	Direct configuration via LeoPC1 starting with <b>Version 3.0.015</b> possible.	
129 <sup>#7</sup>	Failure lambda probe		
130 <sup>#7</sup>	Lambda controller ON		
131	Fuel relay is ON / stop relay is ON / gas valve is ON		
132 <sup>#5</sup>	Temperature dependent enabling of a fan		
133	Idle mode active		
134 <sup>#7</sup>	IKD1 communication OK		
135 <sup>#7</sup>	IKD2 communication OK		
136 <sup>#7</sup>	ST3 communication OK		
137 <sup>#7</sup>	MDEC communication OK		
138 <sup>#7</sup>	J1939 communication OK		
139	Phase rotation generator/busbar or busbar/mains mismatch		
140	Direction of rotation, mains voltage: CW		
141	Direction of rotation, generator voltage: CCW		
142	Direction of rotation, generator voltage: CW		
143	Starter engaged (cranking)		
144	GCB is to be opened		
145 <sup>#6</sup>	--Internal--		
146	Parallel operation CB		from V4.3010
147 <sup>#8</sup>	Timer switch		
148	Unintended stop		from V4.3010
149	Interface error X1/X5		from V4.3010
150 <sup>#9</sup>	ECU yellow alarm		from V4.3030
151 <sup>#9</sup>	ECU red alarm	from V4.3030	
152 <sup>#10</sup>	Mains connected detected by angle		
153 <sup>#10</sup>	Mains power measurement active		

<sup>#1</sup> (Package Q, Option Q), <sup>#2</sup> (Option DFDT), <sup>#3</sup> (Package XP, Option T701), <sup>#4</sup> (Option D02), <sup>#5</sup> (Option TZ02),  
<sup>#6</sup> special versions only, <sup>#7</sup> (Option SC06), <sup>#8</sup> (Package RPQ, Option Z01), <sup>#9</sup> (Option SCxx), <sup>#10</sup> (Package RPQ)

# Appendix C. Interface Protocol

## Transmission Telegram



MUX	No.	Contents (words)	Unit	Note																														
0/1	1	Generator voltage delta $V_{12}$	$V \times 10^{UGNEXPO}$																															
0/2	2	Generator frequency $f$	$Hz \times 100$																															
0/3	3	Actual generator real power $P$	$W \times 10^{PGNEXPO}$																															
1/1	4	Exponents		High Byte: PGNEXPO Generator power Low Byte: UGNEXPO Generator voltage																														
1/2	5	Real power set point value	see note	$W \times \frac{PGNWD}{2.800} \times 10^{PGNEXPO}$																														
1/3	6	Conversion factor Steps $\rightarrow$ kW		PGNWD (internal)																														
2/1	7	Busbar voltage delta $V_{12}$	$V \times 10^{UGSSEXPO}$																															
2/2	8	Mains voltage delta $V_{12}$	$V \times 10^{UNTEXPO}$																															
2/3	9	Currently present alarm class		<table border="0" style="width: 100%;"> <tr> <td style="width: 15%;">Bit 15 = 1</td> <td style="width: 15%;">--Internal--</td> <td style="width: 70%;"></td> </tr> <tr> <td>Bit 14 = 1</td> <td>--Internal--</td> <td></td> </tr> <tr> <td>Bit 13 = 1 \</td> <td rowspan="2">Alarm class F2 or alarm class F3</td> <td>Bit 12 = 1 /</td> </tr> <tr> <td>Bit 11 = 1 \</td> <td rowspan="2">LED "Alarm" flashes</td> <td>Bit 10 = 1 /</td> </tr> <tr> <td>Bit 9 = 1</td> <td>--Internal--</td> <td></td> </tr> <tr> <td>Bit 8 = 1</td> <td>--Internal--</td> <td></td> </tr> <tr> <td>Bit 7 = 1 \</td> <td rowspan="2">Alarm class F3</td> <td>Bit 6 = 1 /</td> </tr> <tr> <td>Bit 5 = 1 \</td> <td rowspan="2">Alarm class F2</td> <td>Bit 4 = 1 /</td> </tr> <tr> <td>Bit 3 = 1 \</td> <td rowspan="2">Alarm class F1</td> <td>Bit 2 = 1 /</td> </tr> <tr> <td>Bit 1 = 1 \</td> <td rowspan="2">Alarm class F0</td> <td>Bit 0 = 1 /</td> </tr> </table> <p><i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i></p>	Bit 15 = 1	--Internal--		Bit 14 = 1	--Internal--		Bit 13 = 1 \	Alarm class F2 or alarm class F3	Bit 12 = 1 /	Bit 11 = 1 \	LED "Alarm" flashes	Bit 10 = 1 /	Bit 9 = 1	--Internal--		Bit 8 = 1	--Internal--		Bit 7 = 1 \	Alarm class F3	Bit 6 = 1 /	Bit 5 = 1 \	Alarm class F2	Bit 4 = 1 /	Bit 3 = 1 \	Alarm class F1	Bit 2 = 1 /	Bit 1 = 1 \	Alarm class F0	Bit 0 = 1 /
Bit 15 = 1	--Internal--																																	
Bit 14 = 1	--Internal--																																	
Bit 13 = 1 \	Alarm class F2 or alarm class F3	Bit 12 = 1 /																																
Bit 11 = 1 \		LED "Alarm" flashes	Bit 10 = 1 /																															
Bit 9 = 1	--Internal--																																	
Bit 8 = 1	--Internal--																																	
Bit 7 = 1 \	Alarm class F3	Bit 6 = 1 /																																
Bit 5 = 1 \		Alarm class F2	Bit 4 = 1 /																															
Bit 3 = 1 \	Alarm class F1		Bit 2 = 1 /																															
Bit 1 = 1 \		Alarm class F0	Bit 0 = 1 /																															
3/1	10		Control register 2		<table border="0" style="width: 100%;"> <tr> <td style="width: 15%;">Bit 15 = 1 \</td> <td rowspan="2">Terminal 3 is energized</td> <td>Bit 14 = 1 /</td> </tr> <tr> <td>Bit 13 = 1 \</td> <td rowspan="2">Terminal 5 is energized</td> <td>Bit 12 = 1 /</td> </tr> <tr> <td>Bit 11 = 1 \</td> <td rowspan="2">--Internal--</td> <td>Bit 10 = 1 /</td> </tr> <tr> <td>Bit 9 = 1 \</td> <td rowspan="2">Terminal 53 is energized</td> <td>Bit 8 = 1 /</td> </tr> <tr> <td>Bit 7 = 1 \</td> <td rowspan="2">Terminal 4 is energized</td> <td>Bit 6 = 1 /</td> </tr> <tr> <td>Bit 5 = 1 \</td> <td rowspan="2">Terminal 54 is energized</td> <td>Bit 4 = 1 /</td> </tr> <tr> <td>Bit 3 = 1 \</td> <td rowspan="2">Terminal 6 is energized</td> <td>Bit 2 = 1 /</td> </tr> <tr> <td>Bit 1 = 1 \</td> <td rowspan="2">Shutdown power reached</td> <td>Bit 0 = 0 /</td> </tr> <tr> <td>Bit 1 = 0 \</td> <td rowspan="2">Shutdown power not reached</td> <td>Bit 0 = 1 /</td> </tr> </table> <p><i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i></p>	Bit 15 = 1 \	Terminal 3 is energized	Bit 14 = 1 /	Bit 13 = 1 \	Terminal 5 is energized	Bit 12 = 1 /	Bit 11 = 1 \	--Internal--	Bit 10 = 1 /	Bit 9 = 1 \	Terminal 53 is energized	Bit 8 = 1 /	Bit 7 = 1 \	Terminal 4 is energized	Bit 6 = 1 /	Bit 5 = 1 \	Terminal 54 is energized	Bit 4 = 1 /	Bit 3 = 1 \	Terminal 6 is energized	Bit 2 = 1 /	Bit 1 = 1 \	Shutdown power reached	Bit 0 = 0 /	Bit 1 = 0 \	Shutdown power not reached	Bit 0 = 1 /		
Bit 15 = 1 \	Terminal 3 is energized	Bit 14 = 1 /																																
Bit 13 = 1 \		Terminal 5 is energized	Bit 12 = 1 /																															
Bit 11 = 1 \	--Internal--		Bit 10 = 1 /																															
Bit 9 = 1 \		Terminal 53 is energized	Bit 8 = 1 /																															
Bit 7 = 1 \	Terminal 4 is energized		Bit 6 = 1 /																															
Bit 5 = 1 \		Terminal 54 is energized	Bit 4 = 1 /																															
Bit 3 = 1 \	Terminal 6 is energized		Bit 2 = 1 /																															
Bit 1 = 1 \		Shutdown power reached	Bit 0 = 0 /																															
Bit 1 = 0 \	Shutdown power not reached		Bit 0 = 1 /																															

MUX	No.	Contents (words)	Unit	Note
3/2	11	Actual mains interchange (import/export) real power	$W \times 10^{PNTXPO}$	
3/3	12	Control register 1  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1 \ Starting enabled (in isolated operation or Bit 14 = 1 / mains parallel operation) Bit 13 = 1 \ --Internal-- Bit 12 = 1 / Bit 11 = 1 \ Execution of acknowledgment Bit 10 = 1 / of a class F2/F3 alarm Bit 9 = 1 \ Execution of acknowledgment Bit 8 = 1 / of a class F1 alarm Bit 7 = 1 \ --Internal-- Bit 6 = 1 / Bit 5 = 1 \ State of generator busbar 1 = OK Bit 4 = 1 / --Internal-- Bit 3 = 1 \ --Internal-- Bit 2 = 1 / Bit 1 = 1 \ --Internal-- Bit 0 = 0 /
4/1	13	Alarm message IKD (SC06)  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1 Failure DI8 of the IKD1 Bit 14 = 1 Failure DI7 of the IKD1 Bit 13 = 1 Failure DI6 of the IKD1 Bit 12 = 1 Failure DI5 of the IKD1 Bit 11 = 1 Failure DI4 of the IKD1 Bit 10 = 1 Failure DI3 of the IKD1 Bit 9 = 1 Failure DI2 of the IKD1 Bit 8 = 1 Failure DI1 of the IKD1 Bit 7 = 1 --Internal-- Bit 6 = 1 --Internal-- Bit 5 = 1 --Internal-- Bit 4 = 1 --Internal-- Bit 3 = 1 --Internal-- Bit 2 = 1 --Internal-- Bit 1 = 1 --Internal-- Bit 0 = 1 --Internal--
4/2	14	Internal alarm 6  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1 MPU plausibility fault Bit 14 = 1 Engine shutdown malfunction Bit 13 = 1 Time overrun, GCB dead bus switching Bit 12 = 1 --Internal-- Bit 11 = 1 MCB open switch malfunction Bit 10 = 1 GCB open switch malfunction Bit 9 = 1 MCB synchronization time monitoring Bit 8 = 1 GCB synchronization time monitoring Bit 7 = 1 Range alarm analog input [T8] Bit 6 = 1 Range alarm analog input [T7] Bit 5 = 1 Range alarm analog input [T6] Bit 4 = 1 Range alarm analog input [T5] Bit 3 = 1 Range alarm analog input [T4] Bit 2 = 1 Range alarm analog input [T3] Bit 1 = 1 Range alarm analog input [T2] Bit 0 = 1 Range alarm analog input [T1]
4/3	15	Generator voltage delta $V_{23}$	$V \times 10^{UGNEXPO}$	
5/1	16	Generator voltage delta $V_{31}$	$V \times 10^{UGNEXPO}$	
5/2	17	Generator voltage wye $V_{1N}$	$V \times 10^{UGNEXPO}$	
5/3	18	Generator voltage wye $V_{2N}$	$V \times 10^{UGNEXPO}$	
6/1	19	Generator voltage wye $V_{3N}$	$V \times 10^{UGNEXPO}$	

MUX	No.	Contents (words)	Unit	Note						
6/2	20	Configuration [T1]-[T4]  <i>#1#:</i> The analog input is not available or he has been configured either as real power set point value or as mains (import/export) real power value.  <i>Note</i> – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).	Display in ...	#1#    °C    °F    bar/10    psi/10    %    no unit						
			Analog input [T4]							
			Bit 15 =	0	0	0	1	1	1	0
			Bit 14 =	0	1	1	0	0	1	0
			Bit 13 =	0	0	1	0	1	0	1
			Bit 12 =	0	1	0	1	0	0	1
			Analog input [T3]							
			Bit 11 =	0	0	0	1	1	1	0
			Bit 10 =	0	1	1	0	0	1	0
			Bit 9 =	0	0	1	0	1	0	1
			Bit 8 =	0	1	0	1	0	0	1
			Analog input [T2]							
			Bit 7 =	0	0	0	1	1	1	0
			Bit 6 =	0	1	1	0	0	1	0
			Bit 5 =	0	0	1	0	1	0	1
Bit 4 =	0	1	0	1	0	0	1			
Analog input [T1]										
Bit 3 =	0	0	0	1	1	1	0			
Bit 2 =	0	1	1	0	0	1	0			
Bit 1 =	0	0	1	0	1	0	1			
Bit 0 =	0	1	0	1	0	0	1			
6/3	21	Engine speed measured via the Pickup	min <sup>-1</sup>							
7/1	22	Generator current in L1	A × 10 <sup>IGNEXPO</sup>							
7/2	23	Generator current in L2	A × 10 <sup>IGNEXPO</sup>							
7/3	24	Generator current in L3	A × 10 <sup>IGNEXPO</sup>							
8/1	25	Actual generator reactive power	var × 10 <sup>PGNEXPO</sup>	positive = inductive						
8/2	26	Generator cos φ		Example: FF9EH    cos φ = c 0,98 (capacitive) FF9DH    cos φ = c 0,99 (capacitive) 0064H    cos φ = 1,00 0063H    cos φ = i 0,99 (inductive) 0062H    cos φ = i 0,98 (inductive)						
8/3	27	Current reserve power in the system	kW							
9/1	28	Current actual real power in the system	kW							
9/2	29	Number of participants on the CAN bus								
9/3	30	H . B .    Mains status L . B .    Generator status		FFH    Voltage and frequency available 00H    Voltage and frequency not available						
10/1	31	Exponents		High Byte: IGNEXPO    Generator current Low Byte: ---    free						
10/2	32	Busbar frequency	Hz × 100							

MUX	No.	Contents (words)	Unit	Note
10/3	33	Configuration [T5]-[T8]	Display in ...	#1# °C °F bar/10 psi/10 % no unit
		<p><i>#1#:</i> The analog input is not available or he has been configured either as real power setpoint value or as mains (import/export) real power value.</p> <p><i>Note</i> – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</p>	Analog input [T8]	
			Bit 15 =	0 0 1 1 1 1 1 0
			Bit 14 =	0 1 1 0 0 1 0
			Bit 13 =	0 0 1 0 1 0 1
			Bit 12 =	0 1 0 1 0 0 1
			Analog input [T7]	
			Bit 11 =	0 0 0 1 1 1 0
			Bit 10 =	0 1 1 0 0 1 0
			Bit 9 =	0 0 1 0 1 0 1
			Bit 8 =	0 1 0 1 0 0 1
			Analog input [T6]	
			Bit 7 =	0 0 0 1 1 1 0
			Bit 6 =	0 1 1 0 0 1 0
			Bit 5 =	0 0 1 0 1 0 1
			Bit 4 =	0 1 0 1 0 0 1
			Analog input [T5]	
			Bit 3 =	0 0 0 1 1 1 0
			Bit 2 =	0 1 1 0 0 1 0
			Bit 1 =	0 0 1 0 1 0 1
			Bit 0 =	0 1 0 1 0 0 1
11/1	34	Mains voltage delta $V_{23}$	$V \times 10^{\text{UNTEXPO}}$	
11/2	35	Mains voltage delta $V_{31}$	$V \times 10^{\text{UNTEXPO}}$	
11/3	36	Mains voltage wye $V_{1N}$	$V \times 10^{\text{UNTEXPO}}$	
12/1	37	Mains voltage wye $V_{2N}$	$V \times 10^{\text{UNTEXPO}}$	
12/2	38	Mains voltage wye $V_{3N}$	$V \times 10^{\text{UNTEXPO}}$	
12/3	39	Mains frequency out off $V_{N12}/V_{N23}/V_{N31}$	$\text{Hz} \times 100$	
13/1	40	Mains current in L1	$A \times 10^{\text{UNTEXPO}}$	
13/2	41	Mains reactive power	$\text{var} \times 10^{\text{PNTTEXPO}}$	
13/3	42	Mains power factor $\phi$		Example: FF9EH cos $\phi$ = c 0.98 (capacitive) FF9DH cos $\phi$ = c 0.99 (capacitive) 0064H cos $\phi$ = 1.00 0063H cos $\phi$ = i 0.99 (inductive) 0062H cos $\phi$ = i 0.98 (inductive)
14/1	43	Exponents		High Byte: PNTTEXPO Mains power Low Byte: UNTEXPO Mains voltage
14/2	44	Exponents		High Byte: INTTEXPO Mains current Low Byte: USSEXPO Busbar voltage
14/3	45	Engine operating hours ( H . W . )	$h \times 2^{16}$	Double word
15/1	46	Engine operating hours ( L . W . )	h	
15/3	47	Hours until next maintenance	h	
15/3	48	Engine start number		

MUX	No.	Contents (words)	Unit	Note
16/1	49	Operation mode  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1   LOAD TEST operation mode
				Bit 14 = 1   STOP operation mode
				Bit 13 = 1   TEST operation mode
				Bit 12 = 1   MANUAL operation mode
				Bit 11 = 1   AUTOMATIC operation mode
				Bit 10 = 1   --Internal--
				Bit 9 = 1   --Internal--
				Bit 8 = 1   --Internal--
				Bit 7 = 1   Emergency power is ON
				Bit 6 = 0   Emergency power is OFF
				Bit 7 = 0   Emergency power is OFF
				Bit 6 = 1   Emergency power is OFF
				Bit 5 = 1   Delayed engine monitoring is ON
				Bit 4 = 1   Delayed engine monitoring is ON
				Bit 3 = 1   Cool down expired
Bit 2 = 1   Cool down expired				
Bit 1 = 1   --Internal--				
Bit 0 = 1   --Internal--				
16/2	50	Generator active energy ( H . W . )	kWh × 2 <sup>16</sup>	Double word
16/3	51	Generator active energy ( L . W . )	kWh	
17/1	52	Battery voltage	V × 10	
17/2	53	Internal alarm 1  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1 \ Bit 14 = 1 /   F3: Generator overfrequency 1
				Bit 13 = 1 \ Bit 12 = 1 /   F3: Generator underfrequency 1
				Bit 11 = 1 \ Bit 10 = 1 /   F3: Generator overvoltage 1
				Bit 9 = 1 \ Bit 8 = 1 /   F3: Generator undervoltage 1
				Bit 7 = 1 \ Bit 6 = 1 /   --Internal--
				Bit 5 = 1 \ Bit 4 = 1 /   F1: Battery undervoltage
				Bit 3 = 1 \ Bit 2 = 1 /   F3: Generator overload
				Bit 1 = 1 \ Bit 0 = 1 /   F3: Generator reverse power
				Bit 15 = 1 \ Bit 14 = 1 /   F0: Mains overfrequency
				Bit 13 = 1 \ Bit 12 = 1 /   F0: Mains underfrequency
				Bit 11 = 1 \ Bit 10 = 1 /   F0: Mains overvoltage
Bit 9 = 1 \ Bit 8 = 1 /   F0: Mains undervoltage				
Bit 7 = 1 \ Bit 6 = 1 /   Interface fault X1-X5				
Bit 5 = 1   GCB opened; "Time ad-on ramp" expired				
Bit 4 = 1   --Internal--				
Bit 3 = 1 \ Bit 2 = 1 /   --Internal--				
Bit 1 = 1 \ Bit 0 = 1 /   F0: Mains phase/vector jump				
17/3	54	Internal alarm 2  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		

MUX	No.	Contents (words)	Unit	Note																																
18/1	55	Internal alarm 3  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte) ,the message is active (otherwise inactive).</i>		<table border="1"> <tr> <td>Bit 15 = 1 \</td> <td>F3: Time-overcurrent, level 2 or inverse time-overcurrent, IEC255</td> </tr> <tr> <td>Bit 14 = 1 /</td> <td></td> </tr> <tr> <td>Bit 13 = 1 \</td> <td>F3: Generator overspeed (Pickup)</td> </tr> <tr> <td>Bit 12 = 1 /</td> <td></td> </tr> <tr> <td>Bit 11 = 1 \</td> <td>Import power 0 kW not reached</td> </tr> <tr> <td>Bit 10 = 1 /</td> <td></td> </tr> <tr> <td>Bit 9 = 1 \</td> <td>F3: Generator unbalanced load</td> </tr> <tr> <td>Bit 8 = 1 /</td> <td></td> </tr> <tr> <td>Bit 7 = 1 \</td> <td>F3: Time-overcurrent, level 1</td> </tr> <tr> <td>Bit 6 = 1 /</td> <td></td> </tr> <tr> <td>Bit 5 = 1 \</td> <td>Interface fault Y1-Y5</td> </tr> <tr> <td>Bit 4 = 1 /</td> <td></td> </tr> <tr> <td>Bit 3 = 1 \</td> <td>F1: Maintenance call</td> </tr> <tr> <td>Bit 2 = 1 /</td> <td></td> </tr> <tr> <td>Bit 1 = 1 \</td> <td>Start failure</td> </tr> <tr> <td>Bit 0 = 1 /</td> <td></td> </tr> </table>	Bit 15 = 1 \	F3: Time-overcurrent, level 2 or inverse time-overcurrent, IEC255	Bit 14 = 1 /		Bit 13 = 1 \	F3: Generator overspeed (Pickup)	Bit 12 = 1 /		Bit 11 = 1 \	Import power 0 kW not reached	Bit 10 = 1 /		Bit 9 = 1 \	F3: Generator unbalanced load	Bit 8 = 1 /		Bit 7 = 1 \	F3: Time-overcurrent, level 1	Bit 6 = 1 /		Bit 5 = 1 \	Interface fault Y1-Y5	Bit 4 = 1 /		Bit 3 = 1 \	F1: Maintenance call	Bit 2 = 1 /		Bit 1 = 1 \	Start failure	Bit 0 = 1 /	
Bit 15 = 1 \	F3: Time-overcurrent, level 2 or inverse time-overcurrent, IEC255																																			
Bit 14 = 1 /																																				
Bit 13 = 1 \	F3: Generator overspeed (Pickup)																																			
Bit 12 = 1 /																																				
Bit 11 = 1 \	Import power 0 kW not reached																																			
Bit 10 = 1 /																																				
Bit 9 = 1 \	F3: Generator unbalanced load																																			
Bit 8 = 1 /																																				
Bit 7 = 1 \	F3: Time-overcurrent, level 1																																			
Bit 6 = 1 /																																				
Bit 5 = 1 \	Interface fault Y1-Y5																																			
Bit 4 = 1 /																																				
Bit 3 = 1 \	F1: Maintenance call																																			
Bit 2 = 1 /																																				
Bit 1 = 1 \	Start failure																																			
Bit 0 = 1 /																																				
18/2	56	Internal alarm 4  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte) ,the message is active (otherwise inactive).</i>		<table border="1"> <tr> <td>Bit 15 = 1 \</td> <td>F1: Analog input [T1], level 1</td> </tr> <tr> <td>Bit 14 = 1 /</td> <td></td> </tr> <tr> <td>Bit 13 = 1 \</td> <td>F3: Analog input [T1], level 2</td> </tr> <tr> <td>Bit 12 = 1 /</td> <td></td> </tr> <tr> <td>Bit 11 = 1 \</td> <td>F1: Analog input [T2], level 1</td> </tr> <tr> <td>Bit 10 = 1 /</td> <td></td> </tr> <tr> <td>Bit 9 = 1 \</td> <td>F3: Analog input [T2], level 2</td> </tr> <tr> <td>Bit 8 = 1 /</td> <td></td> </tr> <tr> <td>Bit 7 = 1 \</td> <td>F1: Analog input [T3], level 1</td> </tr> <tr> <td>Bit 6 = 1 /</td> <td></td> </tr> <tr> <td>Bit 5 = 1 \</td> <td>F3: Analog input [T3], level 2</td> </tr> <tr> <td>Bit 4 = 1 /</td> <td></td> </tr> <tr> <td>Bit 3 = 1 \</td> <td>F1: Analog input [T4], level 1</td> </tr> <tr> <td>Bit 2 = 1 /</td> <td></td> </tr> <tr> <td>Bit 1 = 1 \</td> <td>F3: Analog input [T4], level 2</td> </tr> <tr> <td>Bit 0 = 1 /</td> <td></td> </tr> </table>	Bit 15 = 1 \	F1: Analog input [T1], level 1	Bit 14 = 1 /		Bit 13 = 1 \	F3: Analog input [T1], level 2	Bit 12 = 1 /		Bit 11 = 1 \	F1: Analog input [T2], level 1	Bit 10 = 1 /		Bit 9 = 1 \	F3: Analog input [T2], level 2	Bit 8 = 1 /		Bit 7 = 1 \	F1: Analog input [T3], level 1	Bit 6 = 1 /		Bit 5 = 1 \	F3: Analog input [T3], level 2	Bit 4 = 1 /		Bit 3 = 1 \	F1: Analog input [T4], level 1	Bit 2 = 1 /		Bit 1 = 1 \	F3: Analog input [T4], level 2	Bit 0 = 1 /	
Bit 15 = 1 \	F1: Analog input [T1], level 1																																			
Bit 14 = 1 /																																				
Bit 13 = 1 \	F3: Analog input [T1], level 2																																			
Bit 12 = 1 /																																				
Bit 11 = 1 \	F1: Analog input [T2], level 1																																			
Bit 10 = 1 /																																				
Bit 9 = 1 \	F3: Analog input [T2], level 2																																			
Bit 8 = 1 /																																				
Bit 7 = 1 \	F1: Analog input [T3], level 1																																			
Bit 6 = 1 /																																				
Bit 5 = 1 \	F3: Analog input [T3], level 2																																			
Bit 4 = 1 /																																				
Bit 3 = 1 \	F1: Analog input [T4], level 1																																			
Bit 2 = 1 /																																				
Bit 1 = 1 \	F3: Analog input [T4], level 2																																			
Bit 0 = 1 /																																				
18/3	57	Internal alarm 5  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte) ,the message is active (otherwise inactive).</i>		<table border="1"> <tr> <td>Bit 15 = 1 \</td> <td>F1: Analog input [T5], level 1</td> </tr> <tr> <td>Bit 14 = 1 /</td> <td></td> </tr> <tr> <td>Bit 13 = 1 \</td> <td>F3: Analog input [T5], level 2</td> </tr> <tr> <td>Bit 12 = 1 /</td> <td></td> </tr> <tr> <td>Bit 11 = 1 \</td> <td>F1: Analog input [T6], level 1</td> </tr> <tr> <td>Bit 10 = 1 /</td> <td></td> </tr> <tr> <td>Bit 9 = 1 \</td> <td>F3: Analog input [T6], level 2</td> </tr> <tr> <td>Bit 8 = 1 /</td> <td></td> </tr> <tr> <td>Bit 7 = 1 \</td> <td>F1: Analog input [T7], level 1</td> </tr> <tr> <td>Bit 6 = 1 /</td> <td></td> </tr> <tr> <td>Bit 5 = 1 \</td> <td>F3: Analog input [T7], level 2</td> </tr> <tr> <td>Bit 4 = 1 /</td> <td></td> </tr> <tr> <td>Bit 3 = 1 \</td> <td>--Internal--</td> </tr> <tr> <td>Bit 2 = 1 /</td> <td></td> </tr> <tr> <td>Bit 1 = 1 \</td> <td>--Internal--</td> </tr> <tr> <td>Bit 0 = 1 /</td> <td></td> </tr> </table>	Bit 15 = 1 \	F1: Analog input [T5], level 1	Bit 14 = 1 /		Bit 13 = 1 \	F3: Analog input [T5], level 2	Bit 12 = 1 /		Bit 11 = 1 \	F1: Analog input [T6], level 1	Bit 10 = 1 /		Bit 9 = 1 \	F3: Analog input [T6], level 2	Bit 8 = 1 /		Bit 7 = 1 \	F1: Analog input [T7], level 1	Bit 6 = 1 /		Bit 5 = 1 \	F3: Analog input [T7], level 2	Bit 4 = 1 /		Bit 3 = 1 \	--Internal--	Bit 2 = 1 /		Bit 1 = 1 \	--Internal--	Bit 0 = 1 /	
Bit 15 = 1 \	F1: Analog input [T5], level 1																																			
Bit 14 = 1 /																																				
Bit 13 = 1 \	F3: Analog input [T5], level 2																																			
Bit 12 = 1 /																																				
Bit 11 = 1 \	F1: Analog input [T6], level 1																																			
Bit 10 = 1 /																																				
Bit 9 = 1 \	F3: Analog input [T6], level 2																																			
Bit 8 = 1 /																																				
Bit 7 = 1 \	F1: Analog input [T7], level 1																																			
Bit 6 = 1 /																																				
Bit 5 = 1 \	F3: Analog input [T7], level 2																																			
Bit 4 = 1 /																																				
Bit 3 = 1 \	--Internal--																																			
Bit 2 = 1 /																																				
Bit 1 = 1 \	--Internal--																																			
Bit 0 = 1 /																																				

MUX	No.	Contents (words)	Unit	Note
19/1	58	External alarm 1  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1 \ \ Discrete input [D01] Bit 14 = 1 /
				Bit 13 = 1 \ \ Discrete input [D02] Bit 12 = 1 /
				Bit 11 = 1 \ \ Discrete input [D03] Bit 10 = 1 /
				Bit 9 = 1 \ \ Discrete input [D04] Bit 8 = 1 /
				Bit 7 = 1 \ \ Discrete input [D05] Bit 6 = 1 /
				Bit 5 = 1 \ \ Discrete input [D06] Bit 4 = 1 /
				Bit 3 = 1 \ \ Discrete input [D07] Bit 2 = 1 /
				Bit 1 = 1 \ \ Discrete input [D08] Bit 0 = 1 /
19/2	59	External alarm 2  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1 \ \ Discrete input [D09] Bit 14 = 1 /
				Bit 13 = 1 \ \ Discrete input [D10] Bit 12 = 1 /
				Bit 11 = 1 \ \ Discrete input [D11] Bit 10 = 1 /
				Bit 9 = 1 \ \ Discrete input [D12] Bit 8 = 1 /
				Bit 7 = 1 \ \ Discrete input [D13] Bit 6 = 1 /
				Bit 5 = 1 \ \ Discrete input [D14] Bit 4 = 1 /
				Bit 3 = 1 \ \ Discrete input [D15] Bit 2 = 1 /
				Bit 1 = 1 \ \ Discrete input [D16] Bit 0 = 1 /
19/3	60	Internal alarm 7  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte), the message is active (otherwise inactive).</i>		Bit 15 = 1 --Internal--
				Bit 14 = 1 --Internal--
				Bit 13 = 1 --Internal--
				Bit 12 = 1 --Internal--
				Bit 11 = 1 --Internal--
				Bit 10 = 1 --Internal--
				Bit 9 = 1 --Internal--
				Bit 8 = 1 --Internal--
				Bit 7 = 1 MCB close malfunction
				Bit 6 = 1 GCB close malfunction
				Bit 5 = 1 --Internal--
				Bit 4 = 1 --Internal--
				Bit 3 = 1 --Internal--
Bit 2 = 1 --Internal--				
Bit 1 = 1 --Internal--				
Bit 0 = 1 Immediate stop				
20/1	61	Analog input [T1]		The measured value is transmitted.
20/2	62	Analog input [T2]		The measured value is transmitted.
20/3	63	Analog input [T3]		The measured value is transmitted.
21/1	64	Analog input [T4]		The measured value is transmitted.
21/2	65	Analog input [T5]		The measured value is transmitted.
21/3	66	Analog input [T6]		The measured value is transmitted.
22/1	67	Analog input [T7]		The measured value is transmitted.

MUX	No.	Contents (words)	Unit	Note	
22/2	68	Alarm messages IKD2 (SC06)  <i>Note – On double /fourfold bits the following is valid: If the indicated bit combination is fulfilled (high byte and low byte) ,the message is active (otherwise inactive).</i>		Bit 15 = 1	Failure DI8 of the IKD2
				Bit 14 = 1	Failure DI7 of the IKD2
				Bit 13 = 1	Failure DI6 of the IKD2
				Bit 12 = 1	Failure DI5 of the IKD2
				Bit 11 = 1	Failure DI4 of the IKD2
				Bit 10 = 1	Failure DI3 of the IKD2
				Bit 9 = 1	Failure DI2 of the IKD2
				Bit 8 = 1	Failure DI1 of the IKD2
				Bit 7 = 1	--Internal--
				Bit 6 = 1	--Internal--
				Bit 5 = 1	--Internal--
				Bit 4 = 1	--Internal--
				Bit 3 = 1	--Internal--
				Bit 2 = 1	--Internal--
				Bit 1 = 1	--Internal--
				Bit 0 = 1	--Internal--
				22/3	69
Bit 15 = x	A number is transmitted, please consult the table for the meaning of the number 69 of the telegram "Monitoring of the active display".				
Bit 14 = x					
Bit 13 = x					
Bit 12 = x					
Bit 11 = x					
Bit 10 = x					
Bit 9 = x					
Bit 8 = x					
Pickup					
Bit 7 = 1	Firing speed reached f > parameter				
Bit 6 = 1					
Bit 5 = 1					
Bit 4 = 1					
Bit 3 = 1	Speed existing without pickup (pickup = OFF): f > 15 Hz with pickup (pickup = ON): f > 5 Hz				
Bit 2 = 1					
Bit 1 = 1					
Bit 0 = 1					

**UGNEXPO** Exponent Generator voltage  
**IGNEXPO** Exponent Generator current  
**PGNEXPO** Exponent Generator power  
**PGNWD** Step conversion factor → kW

**USSEXPO** Exponent Busbar voltage  
**UNTEXPO** Exponent Mains voltage  
**PNTEXPO** Exponent Mains power

Meaning of the number 69 of the telegram " Currently active display message":

Number	Meaning
0	GCB synchronization
1	MCB synchronization
2	GCB dead bus start
3	MCB dead bus start
4	Crank
5	Start pause
6	Cool down 000s (000s: the remaining time is displayed)
7	Engine stop!
8	Preglow
9	Purging operation
10	Initial state
11	Auxiliary prerun
12	Auxiliary postrun
13	Mains settling 000s (000s: the remaining time is displayed)
14	Lambda initial state
15	Sprinkler coasting
16	Ignition
17	--Internal--
18	--Internal--
19	--Internal--
20	--Internal--
21	--Internal--
22	--Internal--
23	--Internal--
24	Phase rotation incorrect!
25	Start without closing GCB and simultaneous emergency power
26	Start without closing GCB
27	Sprinkler operation (critical mode) and simultaneous emergency power
28	Sprinkler operation (critical mode)
29	Emergency power
30	TEST
31	Load TEST
32	--Internal--
33	--Internal--
34	--Internal--
35	--Internal--
36	--Internal--
37	--Internal--
38	--Internal--
39	--Internal--
40	--Internal--
41	--Internal--
42	--Internal--
43	--Internal--
44	--Internal--
45	--Internal--
46	--Internal--
47	Power reduction
...	
255	No message on the display (basic screen)

## Receiving Telegram



The CAN protocol for remote control of the GCP is available upon request. Woodward however recommends the use of a GW 4. The following three data words can be received by the GCP. Refer to the GW 4 manual on how to control several GCP control units.

MUX	No.	Contents (words)	Unit	Note																																
1/1	1	Set point value for the generator real power	kW	with control argument; see below																																
1/2	2	Set point value for the generator power factor $\cos \phi$		Example: FF9EH $\cos \phi = c 0.98$ (capacitive) FF9DH $\cos \phi = c 0.99$ (capacitive) 0064H $\cos \phi = 1.00$ 0063H $\cos \phi = i 0.99$ (inductive) 0062H $\cos \phi = i 0.98$ (inductive)																																
1/3	3	Control word		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Bit 15 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 14 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 13 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 12 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 11 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 10 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 9 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 8 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 7 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 6 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 5 = 1</td><td>--Internal--</td></tr> <tr><td>Bit 4 = 1</td><td>Remote acknowledgement</td></tr> <tr><td>Bit 3 = 1</td><td>Always "0"</td></tr> <tr><td>Bit 2 = 1</td><td>Always "0"</td></tr> <tr><td>Bit 1 = 1</td><td>Remote stop (high priority)</td></tr> <tr><td>Bit 0 = 1</td><td>Remote start</td></tr> </table>	Bit 15 = 1	--Internal--	Bit 14 = 1	--Internal--	Bit 13 = 1	--Internal--	Bit 12 = 1	--Internal--	Bit 11 = 1	--Internal--	Bit 10 = 1	--Internal--	Bit 9 = 1	--Internal--	Bit 8 = 1	--Internal--	Bit 7 = 1	--Internal--	Bit 6 = 1	--Internal--	Bit 5 = 1	--Internal--	Bit 4 = 1	Remote acknowledgement	Bit 3 = 1	Always "0"	Bit 2 = 1	Always "0"	Bit 1 = 1	Remote stop (high priority)	Bit 0 = 1	Remote start
Bit 15 = 1	--Internal--																																			
Bit 14 = 1	--Internal--																																			
Bit 13 = 1	--Internal--																																			
Bit 12 = 1	--Internal--																																			
Bit 11 = 1	--Internal--																																			
Bit 10 = 1	--Internal--																																			
Bit 9 = 1	--Internal--																																			
Bit 8 = 1	--Internal--																																			
Bit 7 = 1	--Internal--																																			
Bit 6 = 1	--Internal--																																			
Bit 5 = 1	--Internal--																																			
Bit 4 = 1	Remote acknowledgement																																			
Bit 3 = 1	Always "0"																																			
Bit 2 = 1	Always "0"																																			
Bit 1 = 1	Remote stop (high priority)																																			
Bit 0 = 1	Remote start																																			

## Framework Conditions To The CAN Bus



### Transmission Telegram

The data of the following table can be handled by a Gateway GW 4 or a PLC and can be transferred to other busses. A GCP is sending the data via circular CAN messages.

The transmitting rate of this communication is 125 kBaud.

The CAN ID, on which the GCP is sending is calculated as follows:

**CAN ID = 800 + item/generator number** (or 320 + item/generator number)

(The item number, Parameter 4, is adjustable and influences directly the CAN ID on which the item sends the visualization message).

A visualization message which is send out of a GCP has 8 Bytes and is built as follows:

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
H'DD	MUX number	data word 1 High-Byte	data word 1 Low Byte	data word 2 High-Byte	data word 2 Low Byte	data word 3 High-Byte	data word 3 Low Byte

In a visualization message the byte 0 is always used to show the hexadecimal value DD. This one defines the message as a visualization message. As the complete transmission telegram of the GCP includes more than three words byte 1 sends additionally a MUX number starting with 0. Therefore it is theoretically possible to send (256 × 3 = 768) words via the CAN ID. The whole telegram is built up as follows:

- Line 1: MUX number 0, word 1
- Line 2: MUX number 0, word 2
- Line 3: MUX number 0, word 3
- Line 4: MUX number 1, word 1
- Line 5: MUX number 1, word 2
- Line 6: MUX number 1, word 3
- .
- .
- Line (n): MUX number (n-1/3), word 1
- Line (n+1): MUX number (n-1/2), word 2
- Line (n+2): MUX number (n-1/1), word 3

n depends on the total length of the item special telegram and cannot be larger than H'FF.

### Coding Of The Current Direction

The current direction can be recognized via the code word prefix. A positive transmitted value indicates power export (power output, supply) and a negative transmitted value indicates power import (power input, consumption).

## Coding Of The Power Set Point Value

The following power values may be pre-specified: constant/baseload power (C power), outgoing/export power (E power) and incoming/import power (I power). The real power set point value is transmitted in binary form using bits 0-13. The control argument must be transmitted in the basis of bits 14 and 15. In this case, the following coding applies:

Control argument	Bit 15	Bit 14
C power	0	1
E power	0	0
I power	1	1

### Example:

C power of 150 kW is to be compensated. The value transmitted is then:

01/00 0000 1001 0110 B ⇒ 4096 H

E power of 300 kW is to be compensated. The value transmitted is then:

00/00 0001 0010 1100 B ⇒ 012C H

I power of 600 kW is to be compensated. Negative power is transmitted. The value transmitted is then:

11/11 1101 1010 1000 B ⇒ FDA8 H

## CAN IDs Guidance Bus

The IDs given in the following are reserved for the data exchange between GCPs and LS4s. If third-party devices are connected to the bus, it has to be ensured their IDs do not result conflicts with these IDs.

	CAN-ID in	
	[hex]	[decimal]
<b>GCP sends</b>		
Distribution message to other GCPs	180 + GENNO	384 + GENNO
Control message to LS4 (the GCP with the lowest ID)	311	785
Visualization	320 + GENNO	800 + GENNO
<b>GCP receives</b>		
Distribution message from other GCP	180 + GENNO	384 + GENNO
Control message from an LS4	300 + GENNO	768 + GENNO
Configuration messages from a higher control	33F	831
<b>LS4 sends</b>		
Logic message to other LS4s	180 + LS4NO	384 + LS4NO
Control message to GCP (the LS4 with the lowest ID)	300 + GENNO	768 + GENNO
<b>LS4 receives</b>		
Logic message from other LS4	180 + LS4NO	384 + LS4NO
Control message from a GCP	311	785
Configuration messages and configuration messages from a higher control	33F	831
	[hex]	[decimal]
GENNO =	1 to E	1 to 14
LS4NO =	11 to 1E	17 to 30
	GENNO =	Generator number
	LS4NO =	LS4 number

# Appendix D. List of Parameters

Unit number      P/N \_\_\_\_\_ Rev \_\_\_\_\_

Version            GCP-30 \_\_\_\_\_

Project            \_\_\_\_\_

Serial number    S/N \_\_\_\_\_ Date \_\_\_\_\_

	Parameter	Setting range	Default value	Customer setting	
	Software version	-	V x.xxxx	-	-
	Enter code	0 to 9.999	XXXX		
	Direct para.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Generator number	1 to 14	1		
	Language	first/second	first	<input type="checkbox"/> f <input type="checkbox"/> s	<input type="checkbox"/> f <input type="checkbox"/> s
	Check event list	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
<b>GENERATOR AND MAINS ENVIRONMENT CONFIGURATION</b>					
	Configure measuring	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
B + X	Generator freq. f set	40.0 to 70.0 Hz	50.0 Hz		
B + X	Rated system frequency	50.0 to 60.0 Hz	50.0 Hz		
RPQ	Rated Frequency System 1	50.0 to 60.0 Hz	50.0 Hz		
RPQ L	Setpoint Frequ. System 1	45.0 to 65.0 Hz	50.0 Hz		
RPQ	Rated Frequency System 2	50.0 to 60.0 Hz	60.0 Hz		
RPQ L	Setpoint Frequ. System 2	45.0 to 65.0 Hz	60.0 Hz		
B + X	Gen.volt.transf. secondary	50 to 125/50 to 480 V	400 V		
B + X	Gen.volt.transf. primary	0.05 to 65.0 kV	0.4 kV		
B + X	Bus.volt.transf. secondary	50 to 125/50 to 480 V	400 V		
B + X	Bus.volt.transf. primary	0.05 to 65.0 kV	0.4 kV		
B + X	mains volt.trans. secondary	50 to 125/50 to 480 V	400 V		
B + X	mains volt.trans. primary	0.05 to 65.0 kV	0.4 kV		
B + X	Gen.voltage U set	50 to 125/50 to 530 V	100/400 V		
B + X	Rated voltage in system	50 to 125/50 to 480 V	100/400 V		
RPQ	Rated Voltage System 1	50 to 500 V	400 V		
RPQ	Setpoint Voltage System 1	50 to 530 V	400 V		
RPQ L	CT generator System 1	10 to 7,000/{X} A	500/{X} A		
RPQ L	Gen Rated curr. System 1	10 to 7,000 A	300 A		
RPQ L	Gen rated power System 1	5 to 9,999 kW	200 kW		
RPQ	Rated Voltage System 2	50 to 500 V	200 V		
RPQ	Setpoint Voltage System 2	50 to 530 V	200 V		
RPQ L	CT generator System 2	10 to 7,000/{X} A	500/{X} A		
RPQ L	Gen Rated curr. System 2	10 to 7,000 A	520 A		
RPQ L	Gen rated power System 2	5 to 9,999 kW	180 kW		
RPQ	Rated Voltage System 3	50 to 500 V	440 V		
RPQ	Setpoint Voltage System 3	50 to 530 V	440 V		
RPQ L	CT generator System 3	10 to 7,000/{X} A	500/{X} A		
RPQ L	Gen Rated curr. System 3	10 to 7,000 A	270 A		
RPQ L	Gen rated power System 3	5 to 9,999 kW	200 kW		
RPQ	Rated Voltage System 4	50 to 500 V	220 V		
RPQ	Setpoint Voltage System 4	50 to 530 V	220 V		
RPQ L	CT generator System 4	10 to 7,000/{X} A	500/{X} A		
RPQ L	Gen Rated curr. System 4	10 to 7,000 A	480 A		
RPQ L	Gen rated power System 4	5 to 9,999 kW	180 kW		

	Parameter	Setting range	Default value	Customer setting
<b>GENERATOR AND MAINS ENVIRONMENT CONFIGURATION</b>				
L	Volt.meas./mon.	Ph-neut/Ph-Ph [4/3] Ph-Ph/Ph-Ph [3/3] Ph-neut/Ph-neut [4/4]	Ph-neut/Ph-Ph	<input type="checkbox"/> 4/3 <input type="checkbox"/> 3/3 <input type="checkbox"/> 4/4
B + X	Current transf. generator	10 to 7,000/{X} A	500/{X} A	
L	Power measuring gen.	singlephase [1] threephase [3]	threephase	<input type="checkbox"/> 1 <input type="checkbox"/> 3
B + X	Rated power generator	5 to 9,999 kW	200 kW	
B + X	Rated current generator	10 to 7,000 A	300 A	
L	Analog in Pmains	OFF/T{x}	OFF	
L	Analog in Pmains	0 to 20 mA 4 to 20 mA	4 to 20 mA	<input type="checkbox"/> 0-20 mA <input type="checkbox"/> 4-20 mA
L	Analog in Pmains 0%	0 to +/-9,990/0 to +/-6,900 kW	-200 kW	
L	Analog in Pmains 100%	0 to +/-9,990/0 to +/-6,900 kW	200 kW	
L	Current transf. mains	5 to 7,000/{X} A	500 {X} A	
B + X	LS 4 mode	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
B + X	Rated power in system	0 to 16,000 kW	1,600 kW	
L	Temperature in	Celsius [°C] Fahrenheit [°F]	Celsius [°C]	<input type="checkbox"/> °C <input type="checkbox"/> °F
L	Pressure in	bar psi	bar	<input type="checkbox"/> bar <input type="checkbox"/> psi
	Define level 1 code	0 to 9999	0001	
	Define level 2 code	0 to 9999	0002	
<b>CONTROLLER CONFIGURATION</b>				
	Configure controller	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
	Power controller Pset1	C/I/E 0 to 6,900 kW	C 50 kW	
	Power controller Pset2	C/I/E 0 to 6,900 kW	C 80 kW	
	Initial state Frequency	0 to 100 %	50 %	
	Freq.controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off
	f-contr. active at:	0.0 to 70.0 Hz	40.0 Hz	
	Delay time for f-contr.	0 to 999 s	5 s	
	Freq.controller ramp	1 to 50 Hz/s	10 Hz/s	
RPQ	Frequ.controller droop	0 to 20 %	2 %	
L	F/P contr.type	Three-step Analog PWM	Analog	<input type="checkbox"/> Three-st. <input type="checkbox"/> Analog <input type="checkbox"/> PWM
	Freq.controller deadband	0.02 to 1.00 Hz	0.03 Hz	
	Freq.controller time pulse>	10 to 250 ms	80 ms	
	Freq.controller gain Kp	0.1 to 99.9	20.0	
	F/P contr.output	See table	+/-10 V	
	Level PWM	3.0 to 10.0 V	3.0 V	
	Stepper sign.frq (min.)	0 to 100 %	0 %	
	Stepper sign.frq (max.)	0 to 100 %	100 %	
	Freq.controller gain Kpr	1 to 240	20	
	Freq.controller reset Tn	0.0 to 60.0 s	1.0 s	
	Freq.controller derivat.Tv	0.00 to 6.00 s	0.00 s	
	Starting point voltage	0 to 100 %	50 %	
	Volt.controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off
	Start voltage U control.	12.0 to 100.0 %	75 %	
	Delayed. Start U contr.	0 to 999 s	3 s	
RPQ	Volt.controller droop	0.5 to 20 %	10 %	
L	V/Q contr.type	Three-step Analog	Analog	<input type="checkbox"/> Three-st. <input type="checkbox"/> Analog
	Volt.controller dead band	0.1 to 15.0 %	0.9 %	
	Volt.controller time pulse>	20 to 250 ms	80 ms	
	Volt.controller gain Kp	0.1 to 99.9	20.0	
	V/Q contr.output	See table	+/-10 V	
	Stepper sign.vol (min.)	0 to 100 %	0 %	
	Stepper sign.vol (max.)	0 to 100 %	100 %	
	Volt.controller gain Kpr	1 to 240	20	
	Volt.controller reset Tn	0.0 to 60.0 s	1.0 s	
	Volt.controller derivat.Tv	0.00 to 6.00 s	0.00 s	

	Parameter	Setting range	Default value	Customer setting
--	-----------	---------------	---------------	------------------

CONTROLLER CONFIGURATION				
	Pow.fact.contr.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
	Pow.fact.contr. setpoint	i0.70 to 1.00 to k0.70	1.00	<input type="checkbox"/> on <input type="checkbox"/> off
	Pow.fact.contr. dead band	0.5 to 25.0 %	0.5 %	
	Pow.fact.contr. gain Kp	0.1 to 99.9	20.0	
	Pow.fact.contr. gain Kpr	1 to 240	20	
	Pow.fact.contr. reset Tn	0.0 to 60.0 s	1.0 s	
	Pow.fact.contr. derivat.Tv	0.0 to 6.0 s	0.0 s	
	Power controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off
	power controller ramp	0 to 100 %/s	20 %/s	
	Power limit P max.	10 to 120 %	100 %	
	Power limit P min.	0 to 50 %	0 %	
	Power setpoint external	OFF/ T1 / T2 / T3	OFF	<input type="checkbox"/> OFF <input type="checkbox"/> T1 <input type="checkbox"/> T2 <input type="checkbox"/> T3
	Analog input	0 to 20 mA 4 to 20 mA	4 to 20 mA	<input type="checkbox"/> 0-20 mA <input type="checkbox"/> 4-20 mA
	Ext.setpoint 0mA	C/I/E 0 to 9,999 kW	C 0 kW	
	Ext.setpoint 20mA	C/I/E 0 to 9,999 kW	C 200 kW	
	Power controller dead band	0.1 to 25.0 %	0.5 %	
	Power controller gain Kp	0.1 to 99.9	20.0	
	Powercontr. dead band ratio	1.0 to 9.9	2.0	
	Power controller gain Kpr	1 to 240	20	
	Power controller reset Tn	0.0 to 60.0 s	1.0 s	
	Power controller derivat.Tv	0.0 to 6.0 s	0.0 s	
	Warm up load derivat.Tv	5 to 110 %	15 %	
	Warm up load time	0 to 600 s	0 s	
	Active power load-share	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off
	Act. load share factor	10 to 99 %	50 %	
	Reactive power load share	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
	React.load share factor	10 to 99 %	50 %	<input type="checkbox"/> on <input type="checkbox"/> off
LOAD MANAGEMENT CONFIGURATION				
	Configure automatic	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
	Loadd.start/stop at ter.3	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
	Loadd.start/stop at ter.5	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
	Minimum load generator	0 to 6,900 kW	15 kW	
	Add-on delay mains oper.	0 to 999 s	1 s	
	Shed-off delay mains oper.	0 to 999 s	3 s	
	Hysteresis add-. on/off op.	0 to 9,999 kW	5 kW	
	Reserve power mains op.	0 to 9,999 kW	10 kW	
	Priority of generators	0 to 14	0	
	Reserve power isol.op.	0 to 9,999 kW	20 kW	
	Add-on delay isol.op.	0 to 999 s	1 s	
	Shed-off delay isol.op.	0 to 999 s	4 s	
	Mains error - stop eng.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
L	Control via COM X1X5	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
L	Supervision COM X1X5	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
L	Ackn. F2,F3 via COM interf	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off
RPQL	Power On Mode	STOP / MANUAL / AUTO-MATIC / as before	STOP	<input type="checkbox"/> S <input type="checkbox"/> M <input type="checkbox"/> A <input type="checkbox"/> b
RPQL	Interchange Mode in Manual	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N

	Parameter	Setting range	Default value	Customer setting
<b>BREAKER CONFIGURATION</b>				
	Configure breaker	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
	Breaker logic:	EXTERNAL [EXT] PARALLEL [PAR] OPEN TRANSIT [OPEN] CLOSED TRANSIT [CLOSE] INTERCHANGE [CHANG]	PARALLEL	<input type="checkbox"/> EXT <input type="checkbox"/> EXT <input type="checkbox"/> PAR <input type="checkbox"/> PAR <input type="checkbox"/> OPEN <input type="checkbox"/> OPEN <input type="checkbox"/> CLOSE <input type="checkbox"/> CLOSE <input type="checkbox"/> CHANG <input type="checkbox"/> CHANG
	Add-on/off ramp max.time	0 to 999 s	20 s	
	Open GCB with F2 max.time	0 to 999 s	10 s	
	GCB close.relay	Impulse [I] Constant [C]	Constant	<input type="checkbox"/> I <input type="checkbox"/> I <input type="checkbox"/> C <input type="checkbox"/> D
	GCB open relay	NO-contact [NO] NC-contact [NC]	NO-contact	<input type="checkbox"/> NO <input type="checkbox"/> NO <input type="checkbox"/> NC <input type="checkbox"/> NC
synch	Synchronize df max	0.02 to 0.49 Hz	0.20 Hz	
..	Synchronize df min	0.0 to 0.49 Hz	-0.10 Hz	
..	Synchronize dV max	1.0 to 20.0 %	2.0 %	
..	Synchronize time pulse>	0.02 to 0.26 s	0.24 s	
..	Closing time GCB	40 to 300 ms	80 ms	
synch	Closing time MCB	40 to 300 ms	80 ms	
RPQ	Phase matching	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
..	Phase matching gain	1 to 36	2	
..	Phase matching df start	0.02 to 0.25 Hz	0.20 Hz	
..	Detection Mains connected <	1 to 15 °	5 °	
RPQ	Detection Mains conn. after	0 to 999 s	10 s °	
synch	Automat.breaker deblocking	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
..	Sync.time contr.	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
..	Sync.time contr. delay	10 to 999 s	180 s	
L	GCB dead bus op.	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
..	GCB dead bus op. df max	0.05 to 5.00 Hz	2.0 Hz	
..	GCB dead bus op. dV max.	1.0 to 15.0 %	10.0 %	
..	GCB dead bus op max.time	0 to 999 s	30 s	
synch	MCB dead bus op.	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
induct.	Switching-on GCB	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
..	Switching-on GCB df max	0.05 to 9.99 Hz	0.20 Hz	
..	Switching-on GCB df min	0.0 to 9.99 Hz	-0.10 Hz	
..	Switching-on GCB T.impuls >	0.02 to 0.26 s	0.24 s	
..	Automat.breaker deblocking	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
..	Switch.time cntr	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
induct.	Switch.time cntr delay	2 to 999 s	180 s	
	Supervision GCB	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Supervision MCB	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
GCP31	Mains decoupling via	GCB [GCB] GCB->EXT [GCB>EX] EXT [EXT] EXT->GCB [EX>GCB]	GCB	<input type="checkbox"/> GCB <input type="checkbox"/> GCB <input type="checkbox"/> GCB>EX <input type="checkbox"/> GCB>EX <input type="checkbox"/> EXT <input type="checkbox"/> EXT <input type="checkbox"/> EX>GCB <input type="checkbox"/> EX>GCB
GCP32	Mains decoupling via	GCB [GCB] GCB->MCB [GCB>MC] MCB [MCB] MCB->GCB [MC>GCB]	GCB	<input type="checkbox"/> GCB <input type="checkbox"/> GCB <input type="checkbox"/> GCB>MC <input type="checkbox"/> GCB>MC <input type="checkbox"/> MCB <input type="checkbox"/> MCB <input type="checkbox"/> MC>GCB <input type="checkbox"/> MC>GCB
L	Mains decoupling -> after	0.10 to 5.00 s	0.14 s	
	Switch MCB in STOP mode	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
<b>EMERGENCY POWER CONFIGURATION</b>				
	Configure emergency	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
	Emergency power	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Emergency power start del.	0.5 to 99.9 s	3.0 s	

	Parameter	Setting range	Default value	Customer setting
--	-----------	---------------	---------------	------------------

MONITORING CONFIGURATION				
	Configure monitoring	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
	Gen.power monit.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Gen.power monit. resp.val1	0 to 9,999 kW	100 kW	
	Gen.power monit. hyst.lv1	0 to 999 kW	10 kW	
	Gen.power monit. delay lv1	0 to 650 s	1 s	
	Gen.power monit. resp.val2	0 to 9,999 kW	120 kW	
	Gen.power monit. hyst.lv2	0 to 999 kW	10 kW	
	Gen.power monit. delay lv2	0 to 650 s	1 s	
	Mains power mon.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Mains power mon. res.val.	I/E 0 to 9,999 kW	E100 kW	
	Mains power mon. hysteresis	0 to 999 kW	10 kW	
	Mains power mon. delay	0 to 650 s	1 s	
	Overload monit.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Gen.overload MOP resp.value	80 to 150 %	120 %	
	Gen.overload MOP delay	0 to 99 s	1 s	
	Gen.overload IOP resp.value	80 to 150 %	105 %	
	Gen.overload IOP delay	0 to 99 s	1 s	
	Rev./red.power monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Rev./red.power resp.value	-99 to +99 %	-10 %	
	Rev./red.power delay	0,0 to 9,9 s	1.0 s	
	Load unbalanced	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Load unbalanced max.	0 to 100 %	30 %	
	Load unbalanced delay	0.02 to 9.98 s	1.00 s	
	Gen.overcurrent monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Gen.overcurrent limit 1	0 to 300 %	110 %	
	Gen.overcurrent delay 1	0.02 to 9.98 s	1.00 s	
	Gen.overcurrent limit 2	0 to 300 %	120 %	
	Gen.overcurrent delay 2	0.02 to 9.98 s	0.04 s	
	Gen.overcurrent Cool down	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Gen.frequency- monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Gen.overfreq. f >	50.0 to 140.0 %	110.0 %	
	Gen.overfreq. delay	0.02 to 9.98 s	0.30 s	
	Gen.underfreq. f <	50.0 to 140.0 %	90.0 %	
	Gen.underfreq. delay	0.02 to 9.98 s	0.30 s	
	Engine overspeed >	0 to 9,999 rpm	1,900 rpm	
	Gen.voltage monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Gen.overvoltage U >	20.0 to 150.0 %	110.0 %	
	Gen.overvoltage delay	0.02 to 9.98 s	0.30 s	
	Gen.undervoltage U <	20.0 to 150.0 %	90.0 %	
	Gen.undervoltage delay	0.2 to 9.98 s	0.30 s	
	Mains frequency monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Mains overfreq. f >	80.0 to 140.0 %	110.0 %	
	Mains overfreq. delay	0.02 to 9.98 s	0.06 s	
	Mains underfreq. f <	80.0 to 140.0 %	90.0 %	
	Mains underfreq. delay	0.02 to 9.98 s	0.06 s	
	Mains voltage monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Mains overvolt. U >	20.0 to 150.0 %	110.0 %	
	Mains overvolt. delay	0.02 to 9.98 s	0.06 s	
	Mains undervolt. U <	20.0 to 150.0 %	90.0 %	
	Mains undervolt. delay	0.02 to 9.98 s	0.06 s	
	Phase shift monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Monitoring	one-phase [1] three-phase [3]	three-phase	<input type="checkbox"/> 1 <input type="checkbox"/> 3 <input type="checkbox"/> 1 <input type="checkbox"/> 3
	Phase shift one-phase	3 to 30 °	12 °	
	Phase shift three-phase	3 to 30 °	8 °	
	Mains settling time	0- to 999 s	10 s	
	Batt.undervolt. U <	9.5 to 30.0 V	10.0 V	
	Batt.undervolt. delay	0 to 99 s	10 s	
	Horn self reset	1 to 9,999 s	180 s	

	Parameter	Setting range	Default value	Customer setting
<b>DISCRETE INPUTS CONFIGURATION</b>				
	Configure dig.inputs	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> N
	Dig.input 1234 function	E/D	DDDD	
	Dig.input 1234 delay	0 to 9	0000	
	Delayed by 1234 eng.speed	Y/N	NNNN	
	Dig.input 1234 error class	0 to 3	3210	
	Dig.input 5678 function	E/D	DDDD	
	Dig.input 5678 delay	0 to 9	0000	
	Delayed by 5678 eng.speed	Y/N	NNNN	
	Dig.input 5678 error class	0 to 3	3111	
	Dig.input 9ABC function	E/D	DDDD	
	Dig.input 9ABC delay	0 to 9	0000	
	Delayed by 9ABC eng.speed	Y/N	NNNN	
	Dig.input 9ABC error class	0 to 3	1111	
	Dig.input DEFG function	E/D	DDDD	
	Dig.input DEFG delay	0 to 9	0000	
	Delayed by DEFG eng.speed	Y/N	NNNN	
	Dig.input DEFG error class	0 to 3	1111	
L	Errortxt.term.34	any	EMERGENCY OFF	
L	Errortxt.term.35	any	terminal 35	
L	Errortxt.term.36	any	terminal 36	
L	Errortxt.term.61	any	terminal 61	
L	Errortxt.term.62	any	terminal 62	
L	Errortxt.term.63	any	terminal 63	
L	Errortxt.term.64	any	terminal 64	
L	Errortxt.term.65	any	terminal 65	
L	Errortxt.term.66	any	terminal 66	
L	Errortxt.term.67	any	terminal 67	
L	Errortxt.term.68	any	terminal 68	
L	Errortxt.term.69	any	terminal 69	
L	Errortxt.term.70	any	terminal 70	
L	Errortxt.term.71	any	terminal 71	
L	Errortxt.term.72	any	terminal 72	
L	Errortxt.term.73	any	terminal 73	
	Firing speed by Term. 62	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Op.mode blocked by Ter.63	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Breaker logic by Term64	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Breaker logic:	EXTERNAL [EXT] PARALLEL [PAR] OPEN TRANSIT [OPEN] CLOSED TRANSIT [CLOSE] INTERCHANGE [INCHG]	EXTERNAL	<input type="checkbox"/> EXT <input type="checkbox"/> EXT <input type="checkbox"/> PAR <input type="checkbox"/> PAR <input type="checkbox"/> OPEN <input type="checkbox"/> OPEN <input type="checkbox"/> CLOSE <input type="checkbox"/> CLOSE <input type="checkbox"/> INCHG <input type="checkbox"/> INCHG
RPQ	f/P setpoint by term.65/66	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Close GCB asap by Ter.67	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
RPQ	V/Q setpoint by term.67/69	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Emergency OFF by Ter.68	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Idle mode by Term.70	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Function term.6	Sprinkler operation [SO] Engine enabled [EE] ext.acknowledgment [ExA] STOP mode [SM] Engine blocked [EB] Start without CB [SwB]	ExA	<input type="checkbox"/> SO <input type="checkbox"/> SO <input type="checkbox"/> EE <input type="checkbox"/> EE <input type="checkbox"/> ExA <input type="checkbox"/> ExA <input type="checkbox"/> SM <input type="checkbox"/> SM <input type="checkbox"/> EB <input type="checkbox"/> EB <input type="checkbox"/> SwB <input type="checkbox"/> SwB
	Start withno GCB cool down	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Sprinkler shutd. Fl active	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off

	Parameter	Setting range	Default value	Customer setting
<b>ANALOG INPUTS CONFIGURATION</b>				
	Configure analog.inp.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
	Analog input 1 scalable	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
L	Name and unit	any	Analog 1	
L	Analog input 1	0 to 20 mA 4-20 mA	4 to 20 mA	<input type="checkbox"/> 0-20 mA <input type="checkbox"/> 0-20 mA <input type="checkbox"/> 4-20 mA <input type="checkbox"/> 4-20 mA
L	Value at 0%	-9999 to +9999	0	
L	Value at 100%	-9999 to +9999	100	
	Limit warning value	-9999 to +9999	80	
	Limit shutdown value	-9999 to +9999	90	
	Delay limit 1/2	0 to 650 s	1 s	
L	Monitoring for	High limit mon. [high] low limit mon. [low]	High limit mon.	<input type="checkbox"/> high <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> low
	Analog input 2 scalable	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
L	Name and unit	any	Analog 2	
L	Analog input 2	0 to 20 mA 4 to 20 mA	4 to 20 mA	<input type="checkbox"/> 0-20 mA <input type="checkbox"/> 0-20 mA <input type="checkbox"/> 4-20 mA <input type="checkbox"/> 4-20 mA
L	Value at 0%	-9999 to +9999	0	
L	Value at 100%	-9999 to +9999	100	
	Limit warning value	-9999 to +9999	80	
	Limit shutdown value	-9999 to +9999	90	
	Delay limit 1/2	0 to 650 s	1 s	
L	Monitoring for	High limit mon. [high] low limit mon. [low]	High limit mon.	<input type="checkbox"/> high <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> low
	Analog input 3 scalable	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
L	Name and unit	any	Analog 3	
L	Analog input 3	0 to 20 mA 4 to 20 mA	4 to 20 mA	<input type="checkbox"/> 0-20 mA <input type="checkbox"/> 0-20 mA <input type="checkbox"/> 4-20 mA <input type="checkbox"/> 4-20 mA
L	Value at 0%	-9999 to +9999	0	
L	Value at 100%	-9999 to +9999	100	
	Limit warning value	-9999 to +9999	80	
	Limit shutdown value	-9999 to +9999	90	
	Delay limit 1/2	0 to 650 s	1 s	
L	Monitoring for	High limit mon. [high] low limit mon. [low]	High limit mon.	<input type="checkbox"/> high <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> low
	Temperature 4 Pt100 ***name*** 000°C	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
L	Limit warning	0 to 200 °C	80 °C	
	Limit shutdown	0 to 200 °C	90 °C	
	Delay limit 1/2	0 to 650 s	1 s	
L	Monitoring for	High limit mon. [high] low limit mon. [low]	High limit mon.	<input type="checkbox"/> high <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> low
	Temperature 5 Pt100 ***name*** 000°C	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
L	Limit warning	0 to 200 °C	80 °C	
	Limit shutdown	0 to 200 °C	90 °C	
	Delay limit 1/2	0 to 650 s	1 s	
L	Monitoring for	High limit mon. [high] low limit mon. [low]	High limit mon.	<input type="checkbox"/> high <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> low
RPQ	Analog input 5 scalable	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
..	Name and unit	any	Analog 5	
..	Value at 0%	-9999 to +9999	0	
..	Value at 100%	-9999 to +9999	100	
..	Limit warning value	-9999 to +9999	80	
..	Limit shutdown value	-9999 to +9999	90	
..	Delay limit.1/2	0 to 650 s	1 s	
RPQ	Monitoring for	High limit mon. [high] low limit mon. [low]	High limit mon.	<input type="checkbox"/> high <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> low

	Parameter	Setting range	Default value	Customer setting
<b>ANALOG INPUTS CONFIGURATION</b>				
L	Analog input 6 VDO	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off
	Name and unit	any	Analog 6	
L	Analog input 6 VDO	0 to 5 bar 0 to 10 bar	0 to 5 bar	<input type="checkbox"/> 0-5 bar <input type="checkbox"/> 0-10 bar
	Limit warning value	0.0 to 10.0 bar	2.0 bar	
L	Limit shutdown value	0.0 to 10.0 bar	1.0 bar	
	Delay limit 1/2	0 to 650 s	1 s	
L	Monitoring for	High limit mon. [high] low limit mon. [low]	low limit mon.	<input type="checkbox"/> high <input type="checkbox"/> low
	Analog input 7 VDO	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off
L	Name and unit	any	Analog 7	
	Limit warning value	40 to 120 °C	80 °C	
L	Limit shutdown	40 to 120 °C	90 °C	
	Delay limit 1/2	0 to 650 s	1 s	
L	Monitoring for	High limit mon. [high] low limit mon. [low]	High limit mon.	<input type="checkbox"/> high <input type="checkbox"/> low
	Ana.in 12345678 SV.del.	Y/N	NNNNNYNN	
	Ana.in 12345678 control	Y/N	NNNNNNNN	
<b>OUTPUT CONFIGURATION</b>				
	Configure outputs	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
L	Analg.out.120121 Parameter	0 to 22	1	
L	Analg.out.120121 0-00 mA	OFF 0 to 20 mA 4 to 20 mA	0 to 20 mA	<input type="checkbox"/> OFF <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20 mA
	Analg.out.120121 0%	0 to 9,990	0	
L	Analg.out.120121 100%	0 to 9,990	200	
L	Analg.out.122123 Parameter	0 to 22	1	
L	Analg.out.122123 0-00 mA	OFF 0 to 20 mA 4 to 20 mA	0 to 20 mA	<input type="checkbox"/> OFF <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20 mA
	Analg.out.122123 0%	0 to 9,990	0	
L	Analg.out.122123 100%	0 to 9,990	200	
L	Assignm.relay 1	See table	1	
L	Assignm.relay 2	See table	2	
L	Assignm.relay 3	See table	3	
L	Assignm.relay 4	See table	4	
L	Assignm.relay 5	See table	5	
L	Assignm.relay 6	See table	84	
L	Assignm.relay 7	See table	85	

	Parameter	Setting range	Default value	Customer setting
--	-----------	---------------	---------------	------------------

ENGINE CONFIGURATION				
	Configure engine	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
L	Aux.services prerun	0 to 999 s	0 s	
L	Aux.services postrun	0 to 999 s	0 s	
L	Start-stop-logic for	DIESEL GAS EXTERNAL [EXT]	DIESEL	<input type="checkbox"/> DIESEL <input type="checkbox"/> DIESEL <input type="checkbox"/> GAS <input type="checkbox"/> GAS <input type="checkbox"/> EXT <input type="checkbox"/> EXT
L	Min.speed for ignit.	0 to 999 rpm	100 rpm	
Gas	Ignition delay	0 to 99 s	3 s	
..L	Gasvalve delay	0 to 99 s	5 s	
..	Max. attempts to start	1 to 6	3	
..	Starter time	2 to 99 s	10 s	
..	Start pause time	1 to 99 s	8 s	
..L	f lower before start	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
Gas L	time f lower bef.start	0 to 999 s	5 s	
Diesel	Preglow time	0 to 99 s	3 s	
..	Max. attempts to Start	1 to 6	3	
..	Starter time	2 to 99 s	10 s	
..	Start pause time	1 to 99 s	5 s	
L..	f lower before start	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
L..	time f lower bef.start	0 to 999 s	5 s	
Diesel L	Fuel relay logic	Open to stop [OPEN] Close to stop [STOP]	Open to stop	<input type="checkbox"/> OPEN <input type="checkbox"/> OPEN <input type="checkbox"/> STOP <input type="checkbox"/> STOP
	Cool down time	0 to 999 s	15 s	
	Delayed engine monitoring	1 to 99 s	8 s	
	Firing speed reached f>	5 to 70 Hz	15 Hz	
	Pickup input	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off <input type="checkbox"/> on <input type="checkbox"/> off
	Number of pickup teeth	30 to 280	160	
L	Gen. rated speed	0 to 3,000 rpm	1,500 rpm	
COUNTER CONFIGURATION				
	Configure counters	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
	Service interval in	0 to 9,999 h	300 h	
	Set oper.hours counter	0 to 65,000 h	0 h	
	Set start counter	0 to 32,000	0	
	kWh counter set in	kWh MWh	kWh	<input type="checkbox"/> kWh <input type="checkbox"/> kWh <input type="checkbox"/> MWh <input type="checkbox"/> MWh
	kWh counter set	0 to 65,500 kWh/MWh	0 kWh	
	Time	00:00 to 23:59	00:00	
	Year, month	00 to 99, 01 to 12	00, 00	
	Day/weekday	01 to 31/1 to 7	00, 0	
RPQ	Timer on at 00:00	00:00 to 23:59	00:00	
RPQ	Timer off at 00:00	00:00 to 23:59	00:00	
RPQ	Week M S days NNNNNNN	Y(es)/N(o)	NNNNNNN	

- RPQ This parameter is only available in the [RPQ Package](#) and may only be accessed via LeoPC1 depending on the unit
- B+X This parameter is only available in the [B+X Packages](#) and may only be accessed via LeoPC1 depending on the unit
- L This parameter may only be accessed via LeoPC1 depending on the unit

# Appendix E. Service Options



## Product Service Options



The following factory options are available for servicing Woodward equipment, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is purchased from Woodward or the service is performed. If you are experiencing problems with installation or unsatisfactory performance of an installed system, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact Woodward technical assistance (see "How to Contact Woodward" later in this chapter) and discuss your problem. In most cases, your problem can be resolved over the phone. If not, you can select which course of action you wish to pursue based on the available services listed in this section.

## Returning Equipment For Repair



If a control (or any part of an electronic control) is to be returned to Woodward for repair, please contact Woodward in advance to obtain a Return Authorization Number. When shipping the unit(s), attach a tag with the following information:

- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part numbers (P/N) and serial number (S/N);
- description of the problem;
- instructions describing the desired type of repair.



### CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

## Packing A Control

Use the following materials when returning a complete control:

- protective caps on any connectors;
- antistatic protective bags on all electronic modules;
- packing materials that will not damage the surface of the unit;
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material;
- a packing carton with double walls;
- a strong tape around the outside of the carton for increased strength.

## Return Authorization Number RAN

When returning equipment to Woodward, please telephone and ask for the Customer Service Department in Stuttgart, Germany [+49 (0) 711 789 54-0]. They will help expedite the processing of your order through our distributors or local service facility. To expedite the repair process, contact Woodward in advance to obtain a Return Authorization Number, and arrange for issue of a purchase order for the unit(s) to be repaired. No work will be started until a purchase order is received.



### NOTE

**We highly recommend that you make arrangement in advance for return shipments. Contact a Woodward customer service representative at +49 (0) 711 789 54-0 for instructions and for a Return Authorization Number.**

## Replacement Parts



When ordering replacement parts for controls, include the following information:

- the part numbers P/N (XXXX-XXX) that is on the enclosure nameplate;
- the unit serial number S/N, which is also on the nameplate.

## How To Contact Woodward



Please contact following address if you have questions or if you want to send a product for repair:

Woodward Governor Company  
Leonhard-Reglerbau GmbH  
Handwerkstrasse 29  
70565 Stuttgart - Germany

Phone: +49 (0) 711 789 54-0 (8.00 - 16.30 German time)  
Fax: +49 (0) 711 789 54-100  
eMail: sales-stuttgart@woodward.com

For assistance outside Germany, call one of the following international Woodward facilities to obtain the address and phone number of the facility nearest your location where you will be able to get information and service.

<b>Facility</b>	<b><u>Phone number</u></b>
USA	+1 (970) 482 5811
India	+91 (129) 230 7111
Brazil	+55 (19) 3708 4800
Japan	+81 (476) 93 4661
The Netherlands	+31 (23) 566 1111

You can also contact the Woodward Customer Service Department or consult our worldwide directory on Woodward’s website ([www.woodward.com](http://www.woodward.com)) for the name of your nearest Woodward distributor or service facility. [For worldwide directory information, go to [www.woodward.com/ic/locations](http://www.woodward.com/ic/locations).]

## Engineering Services



Woodward Industrial Controls Engineering Services offers the following after-sales support for Woodward products. For these services, you can contact us by telephone, by e-mail, or through the Woodward website.

- Technical support
- Product training
- Field service during commissioning

**Technical Support** is available through our many worldwide locations, through our authorized distributors, or through GE Global Controls Services, depending on the product. This service can assist you with technical questions or problem solving during normal business hours. Emergency assistance is also available during non-business hours by phoning our toll-free number and stating the urgency of your problem. For technical engineering support, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference technical support.

**Product Training** is available on-site from several of our worldwide facilities, at your location, or from GE Global Controls Services, depending on the product. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability. For information concerning training, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *customer training*.

**Field Service** engineering on-site support is available, depending on the product and location, from our facility in Colorado, or from one of many worldwide Woodward offices or authorized distributors. Field engineers are experienced on both Woodward products as well as on much of the non-Woodward equipment with which our products interface. For field service engineering assistance, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *field service*.

# Technical Assistance



If you need to telephone for technical assistance, you will need to provide the following information. Please write it down here before phoning:

## Contact

Your company \_\_\_\_\_

Your name \_\_\_\_\_

Phone number \_\_\_\_\_

Fax number \_\_\_\_\_

## Control (see name plate)

Unit no. and revision: P/N: \_\_\_\_\_ REV: \_\_\_\_\_

Unit type easYgen- \_\_\_\_\_

Serial number S/N \_\_\_\_\_

## Description of your problem

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Please be sure you have a list of all parameters available. You can print this using LeoPC1. Additionally you can save the complete set of parameters (standard values) and send them to our Service department via e-mail.

We appreciate your comments about the content of our publications.  
Please send comments to: [stgt-documentation@woodward.com](mailto:stgt-documentation@woodward.com)  
Please include the manual number from the front cover of this publication.



**Woodward Governor Company**  
**Leonhard-Reglerbau GmbH**  
Handwerkstrasse 29 - 70565 Stuttgart - Germany  
Phone +49 (0) 711 789 54-0 • Fax +49 (0) 711 789 54-100  
[sales-stuttgart@woodward.com](mailto:sales-stuttgart@woodward.com)

**Homepage**

<http://www.woodward.com/smart-power>

**Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.**

**Complete address/phone/fax/e-mail information  
for all locations is available on our website ([www.woodward.com](http://www.woodward.com)).**