




# MSLC-2XT

## Master Synchronizer and Load Control



**Manual**  
**Software Version 1.10**

**Document ID: 37947, Revision B**



**WARNING**

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage and (ii) invalidate product certifications or listings.

**CAUTION**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

**OUT-OF-DATE PUBLICATION**

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, be sure to check the Woodward website.

The revision level is shown at the bottom of the front cover after the publication number. The latest version of most publications is available at:

[http://wwdmanuals.com/DSLC\\_MSLC](http://wwdmanuals.com/DSLC_MSLC)

If your publication is not there, please contact your customer service representative to get the latest copy.

**Important definitions****WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a potentially hazardous situation that, if not avoided, could result in damage to equipment.

**NOTE**

Provides other helpful information that does not fall under the warning or caution categories.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, Woodward assumes no responsibility unless otherwise expressly undertaken.

© Woodward  
All Rights Reserved.



# Revision History

Rev.	Date	Editor	Changes
B	2024-01-29		<b>Technical Manual</b> <ul style="list-style-type: none"> <li>Appendix A: Deleted 'pending' at marine type approval</li> <li>Restructured Appendix</li> <li>Reworked title page</li> <li>Updated contact email addresses</li> </ul>
A	2022-10-30		<p>First release of MSLC-2-XT. MSLC-2-XT is the successor of the MSLC-2.</p> <p>Here is a rough list of the differences to the former MSLC-2 device:</p> <p><b>Hardware</b></p> <p><b>Housing</b></p> <ul style="list-style-type: none"> <li>The dimensions of the control remain the same.</li> <li>The silk screen of the housing is adapted according to the new hardware platform</li> <li>The labels are adapted according to the newest rules</li> </ul> <p><b>Terminals</b></p> <p>The phoenix plugs remain mainly the same with some slightly changes:</p> <ul style="list-style-type: none"> <li>The 100V AC measurement is connected on the 400V connection (the 100V AC connection does not exist anymore)</li> <li>The analog outputs 1 &amp; 2 are supported with two terminals now (the shunt for voltage output is internally populated)</li> <li>The communication 9-pin D-sub connectors are replaced by phoenix plugs with screw terminals</li> </ul> <p><b>I/O Features</b></p> <ul style="list-style-type: none"> <li>The AC voltage measurement capability is expanded to 690 Vrated</li> <li>PT inputs: 100V / 480V / 690V is handled by device configuration</li> <li>CT inputs: 1A and 5A secondary are provided by one P/N</li> <li>CT inputs: The linear measurement range is increased to 3 x Irated. (The MSLC-2 is 1.5 x Irated)</li> <li>Discrete Inputs: The minimum delay time of DIs on board are now 20ms (The MSLC-2 is 80ms)</li> <li>The connection of a 3-phase busbar measurement is performed differently in comparison to MSLC-2. (See wiring diagram)</li> </ul> <p><b>Communication Interfaces</b></p> <ul style="list-style-type: none"> <li>The RS232 is removed and exchanged by USB (slave) connection</li> <li>1 additional Ethernet connection (named C) is provided</li> </ul> <p><b>Communicating with legacy MSLC-2 (and DSLC-2)</b></p> <p>Woodward provides update files for legacy MSLC-2 (SW: 5418-7870-A) and DSLC-2 (SW: 5418-7869-A) devices in the field if there is a need to run a mixture of both MSLC-2 / DSLC-2 generations. The legacy device will then send their UDP message in a way the DSLC-2XT / MSLC-2XT can evaluate. If this update file is not loaded the system won't run.</p> <p><b>Functionality</b></p> <p><b>General</b></p> <p>The functionality is the same as the last published MSLC-2 (version 1.1511). Basically, the new generation is equipped with a more powerful CPU, memory, and communication. The device is more responsive in HMI and SCADA communication purposes. The important control functions are running on same task rates which ensures the same control and logic dynamic. The device is designed so that it behaves as good as possible like the original DSLC-2.</p> <p><b>Accepting wset configuration files from legacy MSLC-2 (and DSLC-2)</b></p> <p>Woodward provides a converting rule for ToolKit to make the configuration transfer as smooth as possible. Some minor parameters will be shown as to consider during this first process.</p>



Rev.	Date	Editor	Changes
			<p><b>The AC measurement of the MSLC-2XT (and DSLC-2XT)</b></p> <p>The measurement hardware and software is different in comparison to the legacy devices. But this is mainly the higher accuracy, the more flexible measurement range and the response characteristic. The earthing of the MSLC-2XT / DSLC-2XT devices becomes more important because of the higher impedance of the measurement circuits.</p> <p><b>ToolKit</b></p> <p>The ToolKit layout (wtool file) is in the same way designed like the original one of the legacy devices. There are only some less parameters to consider which have to do with the new AC measurement and communication purposes.</p>



# Content

<b>CHAPTER 1. GENERAL INFORMATION .....</b>	<b>13</b>
Document Overview .....	13
QR Code .....	13
Application .....	14
MSLC-2 function summary .....	14
Synchronizer .....	15
Load Control .....	15
Process Control .....	17
Var/PF Control .....	17
DSLC-2 / MSLC-2 Systems .....	18
Control Relationships in a MSLC-DSLC System .....	19
<b>CHAPTER 2. INSTALLATION .....</b>	<b>20</b>
Electrostatic Discharge Awareness .....	20
Unpacking .....	21
Location .....	21
Housing .....	22
Dimensions .....	22
Installation .....	23
Terminal Arrangement .....	24
LEDs .....	24
Wiring Diagrams .....	25
Connections .....	27
Power Supply .....	28
Voltage Measuring .....	30
Current Measuring .....	40
Power Factor Definition .....	43
Discrete Inputs .....	45
Relay Outputs .....	47
Analog Inputs .....	49
Interfaces .....	50
<b>CHAPTER 3. CONFIGURATION &amp; OPERATION .....</b>	<b>54</b>
Configuration via PC .....	54
Install ToolKit Configuration and Visualization Software .....	54
Install ToolKit Software .....	54
Install ToolKit Configuration Files .....	55
Starting ToolKit Software .....	56
Configure ToolKit Software .....	57
Connecting ToolKit and the MSLC-2 Unit .....	58
View MSLC-2XT Data with ToolKit .....	61
Configuring the MSLC-2XT with ToolKit .....	62
The MSLC-2XT Version Page .....	63
Menu (Setpoint) Description .....	64
MSLC-2XT – Homepage .....	64
Menu 1 – Synchronizer .....	69
Menu 2 – Load Control .....	73
Menu 3 – Process Control .....	80
Menu 4 – Voltage/Var/PF Control .....	82
Menu 5 – Configuration .....	86
Segment Connections .....	92
Menu 6 – Analog Inputs .....	119
Menu 7, 7.1 and 7.2 – Electrical Parameters .....	123
Menu 7.1 – System A .....	123
Menu 7.2 – System B .....	126



Menu 8 – Control Status Monitor.....	128
Menu 9 – Discrete Inputs / Discrete (Relay) Outputs.....	132
Menu 0 – Diagnostics.....	135
Overview Pages.....	138
Prestart Setup Procedure.....	141
Configuration Menu.....	141
Prestart Segmenting Setup.....	142
Prestart Synchronizer Setup.....	146
Prestart Load Control Setup.....	146
Prestart Process Control Setup.....	146
Prestart Var/Power Factor Control Setup.....	146
MSLC-2 Control Adjustments.....	147
Calibration Check.....	147
Synchronizer Adjustments.....	148
Preliminary Synchronizer Adjustments.....	148
Phase Matching Synchronizer.....	148
Slip Frequency Synchronizer.....	149
Final Synchronizer Setup.....	150
Voltage Matching Adjustments.....	151
Preliminary Voltage Matching Setup.....	151
Final Voltage Matching Setup.....	151
Load Control Adjustment.....	152
Base Load Mode Setup.....	152
Remote Base Load.....	152
Import/Export Mode Setup.....	153
Remote Import/Export Setup.....	153
Final Load Control Setup.....	154
Process Control Adjustment.....	155
Var/PF Control Adjustment.....	156
Constant Generator Power Factor Setup.....	156
PF Control at the Utility - Setup.....	157
Remote PF Control at the Utility - Setup.....	157
Var Control at the Utility - Setup.....	158
<b>CHAPTER 4. SYNCHRONIZER DESCRIPTION.....</b>	<b>159</b>
Introduction.....	159
Functional Description.....	159
Operating Modes.....	159
Measurement Connections (Examples).....	161
Dead Bus Closure – Multiple Units.....	173
Deadbus Closure Mismatch Alarm.....	174
Voltage Matching.....	175
Phase Matching Synchronizing.....	175
Slip Frequency Synchronizing.....	175
Permissive Mode / Synch-Check Function.....	175
GCB Maximum Closing Attempts.....	176
Auto re-synchronization.....	176
Reclose limit alarm.....	176
Synchronizer Timer.....	176
Logic Charter GCB Closure.....	177
Ramping.....	178
Manual Synchronizing.....	180
Frequency Setpoint.....	180
Voltage Setpoint.....	180
Breaker Close.....	181
Reset Frequency / Voltage Setpoints Back To Rated (50 Hz or 60 Hz).....	181
<b>CHAPTER 5. REAL POWER CONTROL DESCRIPTION.....</b>	<b>182</b>
Introduction.....	182
MSLC-2 / DSLC-2 Interface.....	182



Base Load Mode .....	182
Import / Export Mode.....	183
Process Control Mode.....	183
Remote Control .....	183
Automatic Power Transfer Control Functions .....	183
Ramping Between Modes.....	183
Utility Unload.....	183
Local Unload .....	184
<b>CHAPTER 6. VAR/POWER FACTOR CONTROL DESCRIPTION.....</b>	<b>185</b>
Introduction.....	185
Constant Generator Power Factor .....	185
Power Factor Control .....	186
Var Control .....	186
<b>CHAPTER 7. PROCESS CONTROL DESCRIPTION .....</b>	<b>187</b>
Introduction.....	187
Description .....	187
<b>CHAPTER 8. NETWORK / SYSTEM DESCRIPTION .....</b>	<b>190</b>
Introduction.....	190
Description .....	190
Applications without Segmenting .....	191
Applications with Segmenting.....	192
Not Supported Applications .....	195
Remote Control by PLC .....	196
Interface Connection via RS-485 with Modbus Protocol .....	197
Interface Connection via Ethernet by Modbus/TCP Stack .....	198
<b>CHAPTER 9. INTERFACE.....</b>	<b>199</b>
Interface Overview .....	199
Communication management.....	200
Commissioning of the Communication Network System.....	201
Ethernet Load Sharing .....	203
Multi-Master Principle .....	203
Load Share Monitoring.....	203
General Load Share Information .....	203
Modbus Communications.....	204
General Information .....	204
Address Range .....	204
Visualization .....	205
Configuration.....	206
MSLC-2 Interface Remote Control .....	207
Changing Parameter Settings via RS485 .....	214
Parameter Setting .....	214
Remotely Resetting the Default Values .....	216
Modbus Parameters .....	218
Serial Interface 2 (RS 485) .....	218
Network A, B, C – Modbus TCP .....	218
<b>CHAPTER 10. APPLICATION .....</b>	<b>219</b>
Phase Angle Compensation.....	219
<b>APPENDIX A TECHNICAL SPECIFICATIONS .....</b>	<b>220</b>
Technical Data .....	220
Environmental Data.....	223
Accuracy.....	225
<b>APPENDIX B USEFUL INFORMATION .....</b>	<b>227</b>
Connecting 24 V Relays.....	227
<b>APPENDIX C DATA PROTOCOLS .....</b>	<b>228</b>
Data Protocol 5200 .....	228



<b>APPENDIX D PARAMETER OVERVIEW .....</b>	<b>238</b>
Introduction .....	238
Parameter List Columns .....	238
Parameter List .....	239
<b>APPENDIX E SERVICE OPTIONS .....</b>	<b>249</b>
Product Service Options .....	249
Returning Equipment for Repair .....	249
Packing a Control .....	250
Return Authorization Number RAN .....	250
Replacement Parts .....	250
How to Contact Woodward .....	251
Engineering Services .....	251
Technical Assistance .....	252

## Figures and Tables

### Figures

Figure 1-2: MSLC-2 Load Control Overview .....	16
Figure 1-3: Multiple generators in isolated operation with tie-breaker .....	18
Figure 1-4: Multiple generators in isolated and utility parallel operation with utility- and tie-breaker .....	19
Figure 1-5: Control relationship in a MSLC-DSLC system .....	19
Figure 2-1: Housing MSLC-2 - dimensions .....	22
Figure 2-2: Housing - drill plan .....	23
Figure 2-4: Wiring diagram - MSLC-2 - 1/2 .....	25
Figure 2-5: Wiring diagram - MSLC-2 - 2/2 .....	26
Figure 2-6: Power supply .....	28
Figure 2-7: Power supply - crank waveform at maximum load .....	29
Figure 2-8: Voltage measuring – system A .....	30
Figure 2-9: Voltage measuring – system A windings, 3Ph 4W OD .....	31
Figure 2-10: Voltage measuring – system A measuring inputs, 3Ph 4W OD .....	31
Figure 2-11: Voltage measuring – system A windings, 3Ph 4W .....	32
Figure 2-12: Voltage measuring – system A measuring inputs, 3Ph 4W .....	32
Figure 2-13: Voltage measuring – system A windings, 3Ph 3W .....	33
Figure 2-14: Voltage measuring – system A measuring inputs, 3Ph 3W .....	33
Figure 2-15: Voltage measuring – system B .....	34
Figure 2-16: Voltage measuring – system B measuring inputs, 1Ph 2W (phase-neutral) .....	35
Figure 2-17: Voltage measuring – system B measuring inputs, 1Ph 2W (phase-phase) .....	35
Figure 2-18: Voltage measuring – auxiliary system B .....	37
Figure 2-19: Voltage measuring - auxiliary system B PT windings, 3Ph 4W .....	38
Figure 2-20: Voltage measuring - auxiliary system B measuring inputs, 3Ph 4W .....	38
Figure 2-21: Voltage measuring - auxiliary system B PT windings, 3Ph 3W .....	39
Figure 2-22: Voltage measuring - auxiliary system B measuring inputs, 3Ph 3W .....	39
Figure 2-23: Current measuring – system A .....	40
Figure 2-24: Current measuring – system A, L1 L2 L3 .....	41
Figure 2-25: Current measuring - system A, phase Lx .....	41
Figure 2-26: Power measuring - direction of power .....	42
Figure 2-27: Phasor diagram – inductive / capacitive .....	44
Figure 2-28: Discrete inputs - alarm/control input - positive signal .....	45
Figure 2-29: Discrete inputs - alarm/control input - negative signal .....	45
Figure 2-30: Relay outputs .....	47
Figure 2-31: Analog inputs - wiring two-pole senders using a voltage signal .....	49
Figure 2-32: Analog inputs - wiring two-pole senders (external jumper used for current signal) .....	49
Figure 2-33: screwable 6-terminal connector RS-485 .....	50
Figure 2-34: RS-485 Modbus - connection for half-duplex operation (120 Ohms termination resistor at both ends) .....	50
Figure 2-35: RS-485 Modbus - connection for full-duplex operation .....	50
Figure 2-36-1: Shielding preparation (internal RC element) .....	51
Figure 2-37: RJ-45 connector - Ethernet .....	52
Figure 3-1: ToolKit - visualization screen .....	61



Figure 3-2: ToolKit - analog value trending screen .....	61
Figure 3-3: ToolKit - configuration screen .....	62
Figure 3-4: ToolKit -version page.....	63
Figure 3-5: ToolKit - home page (MSLC-2 configured as utility breaker control).....	64
Figure 3-6: ToolKit - home page (MSLC-2 configured as tie-breaker control).....	65
Figure 3-7: ToolKit - home page - MSLC-2 configured as utility breaker control.....	67
Figure 3-8: ToolKit - home page - MSLC-2 configured as tie-breaker control.....	68
Figure 3-9: ToolKit - home page - segments.....	68
Figure 3-10: ToolKit – synchronizer .....	69
Figure 3-11: ToolKit – load control.....	73
Figure 3-12: ToolKit – process control .....	80
Figure 3-13: ToolKit – voltage/var/pf control .....	82
Figure 3-14: ToolKit – configuration .....	86
Figure 3-15: ToolKit – interfaces .....	96
Figure 3-16: ToolKit – system management .....	100
Figure 3-17: Access to the device – Overview.....	102
Figure 3-18: Password entry: ToolKit.....	102
Figure 3-19: ToolKit – configure counters .....	117
Figure 3-20: ToolKit – analog inputs .....	119
Figure 3-21: ToolKit – relevant fields for remote load reference input.....	119
Figure 3-22: ToolKit – relevant fields for remote process reference input.....	120
Figure 3-23: ToolKit – process signal input.....	121
Figure 3-24: ToolKit – reactive load input.....	122
Figure 3-25: ToolKit – electrical parameters .....	123
Figure 3-26: ToolKit – electrical parameters System A.....	123
Figure 3-27: ToolKit – electrical parameters System B.....	126
Figure 3-28: ToolKit – control status monitor .....	128
Figure 3-29: ToolKit – discrete inputs / relay outputs .....	132
Figure 3-30: ToolKit – diagnostics.....	135
Figure 3-31: ToolKit – MSLC-2 overview page .....	139
Figure 3-32: ToolKit – DSLC-2 overview page.....	140
Figure 3-33: Example of an online diagram – step 1.....	142
Figure 3-34: Example of an online diagram with segment numbers and segment connector feedbacks.....	143
Figure 3-35: Example of an online diagram with according network.....	144
Figure 3-36: Example of an online diagram with all required information to setup the units.....	145
Figure 3-37: Power measurement.....	147
Figure 4-1: Synchronizer block diagram.....	160
Figure 4-2: Low voltage system 480 V / 277 V – 3-phase with neutral .....	161
Figure 4-3: Low voltage system 480 V / 277 V – 3-phase with neutral .....	162
Figure 4-4: Low voltage system 480 V – 3-phase with neutral.....	163
Figure 4-5: Low voltage system 600 V / 346 V – 3-phase.....	164
Figure 4-6: Low voltage system 600 V / 346 V – 3-phase.....	165
Figure 4-7: Low voltage system 600 V / 346 V – 3-phase.....	166
Figure 4-8: Low voltage system 600 V / 346 V – 3-phase with neutral .....	167
Figure 4-9: Low voltage system 600 V / 346 V – 3-phase with neutral .....	168
Figure 4-10: Low voltage system 600 V / 346 V – 3-phase with neutral .....	169
Figure 4-11: Low voltage system 600 V / 346 V – 3-phase with neutral .....	170
Figure 4-12: Middle voltage system 20 kV – 3-phase without neutral .....	171
Figure 4-13: Middle voltage system 20 kV – 3-phase without neutral .....	172
Figure 4-14: Dead bus closing – Example of dead busbar closure arbitration .....	173
Figure 4-15: Logic charter CB closure .....	177
Figure 7-1: Diagram process control.....	189
Figure 8-1: Multiple generators in isolated operation without tie-breakers .....	191
Figure 8-2: Multiple generators in isolated / parallel to utility operation without tie-breakers.....	191
Figure 8-3: Isolated operation with multiple generator and tie-breaker .....	192
Figure 8-4: Isolated / utility parallel operation with multiple generator and tie-breaker.....	192
Figure 8-5: Isolated / utility parallel operation with multiple generator, tie-breaker and generator group breaker.....	193
Figure 8-6: Isolated operation with multiple generator and tie-breaker (ring option) .....	194
Figure 8-7: Not supported application .....	195
Figure 8-8: Not supported application .....	195
Figure 8-9: Visualization and remote control by PLC via RS-485 interface.....	197
Figure 9-1: MSLC-2 - interface overview (housing - side view).....	199
Figure 9-2: Modbus - visualization configurations .....	205
Figure 9-3: Modbus - sending binary digital orders over interface .....	209
Figure 9-4: Modbus – loss of connection .....	211
Figure 9-5: Modbus - configuration example 1 - active power.....	212



Figure 9-6: Modbus - configuration example 2 – power factor.....	213
Figure 9-7: Modbus - configuration example 2 .....	214
Figure 9-8: Modbus - configuration example 3 .....	215
Figure 9-9: Modbus - remote control parameter 1701 .....	216
Figure 9-10: Modbus - write register - enable the resetting procedure via USB or Modbus TCP/IP .....	216
Figure 9-11: Modbus - remote control parameter 1701 .....	217
Figure 9-12: Modbus - write register - resetting the default values .....	217
Fig. 201: Phase angle compensation MCB .....	219
Figure 0-1: Interference suppressing circuit - connection .....	227

## Tables

Table 1-1: Manual - overview .....	13
Table 2-1: Conversion chart - wire size .....	27
Table 2-2: Power supply - terminal assignment.....	28
Table 2-3: Voltage measuring – terminal assignment – System A voltage.....	30
Table 2-4: Voltage measuring - terminal assignment – System A, 3Ph 4W OD .....	31
Table 2-5: Voltage measuring – terminal assignment – system A, 3Ph 4W .....	32
Table 2-6: Voltage measuring - terminal assignment – system A, 3Ph 3W .....	33
Table 2-7: Voltage measuring - terminal assignment – system B voltage .....	34
Table 2-8: Voltage measuring - terminal assignment – system B, 1Ph 2W (phase-neutral).....	35
Table 2-9: Voltage measuring - terminal assignment – system B, 1Ph 2W (phase-phase).....	36
Table 2-10: Voltage measuring - terminal assignment - auxiliary system B voltage .....	37
Table 2-11: Voltage measuring - terminal assignment - auxiliary system B, 3Ph 4W.....	38
Table 2-12: Voltage measuring - terminal assignment - auxiliary system B, 3Ph 3W.....	39
Table 2-13: Current measuring - terminal assignment – system A current.....	40
Table 2-14: Current measuring - terminal assignment – system A, L1 L2 L3 .....	41
Table 2-15: Current measuring - terminal assignment - system A, phase Lx .....	41
Table 2-16: Power Measuring – sign displayed – Utility / Tie .....	42
Table 2-17: Power measuring - terminal assignment .....	42
Table 2-18: Discrete input - terminal assignment 1/2 .....	45
Table 2-19: Discrete input - terminal assignment 2/2 .....	46
Table 2-21: Relay outputs - terminal assignment .....	47
Table 2-22: Relay outputs driven by ... ..	48
Table 2-23: Analog inputs - terminal assignment - wiring two-pole senders.....	49
Table 2-24: RS-485 interface #1 - pin assignment .....	50
Table 2-26: RJ-45 interfaces - pin assignment .....	52
Table 3-1: Parameter – homepage - General.....	66
Table 3-2: Parameter – homepage - Setpoints.....	66
Table 3-3: Parameter – homepage – Process control.....	66
Table 3-4: Parameter – synchronizer – PID frequency control .....	70
Table 3-5: Parameter – synchronizer – PID voltage control .....	70
Table 3-6: Parameter – synchronizer – synchronizer control .....	72
Table 3-7: Parameter – load control – PID import/export control.....	73
Table 3-8: Parameter – load control – power control monitoring .....	74
Table 3-8: Parameter – load control – power control monitoring .....	75
Table 3-8: Parameter – load control – power control monitoring .....	75
Table 3-8: Parameter – load control – power control monitoring .....	77
Table 3-9: Parameter – load control – power control.....	78
Table 3-10: Parameter – load control – import/export level via interface.....	79
Table 3-11: Parameter – process control – PID process control .....	80
Table 3-12: Parameter – process control – process control .....	81
Table 3-13: Parameter – process control – process signal input monitoring .....	81
Table 3-14: Parameter – voltage/var/pf control – voltage control .....	82
Table 3-15: Parameter – voltage/var/pf control – voltage monitoring .....	83
Table 3-16: Parameter – voltage/var/pf control – PID VAR control.....	83
Table 3-17: Parameter – voltage/var/pf control – VAR control.....	85
Table 3-18: Parameter – configuration .....	88
Table 3-19: Parameter – configuration – transformer .....	89
Table 3-20: Parameter – configuration – operating ranges .....	90
Table 3-21: Parameter – configuration – system settings.....	91
Table 3-22: Parameter – configuration – tie breaker .....	91
Table 3-23: Parameter – configuration – communication .....	91
Table 3-24: Parameter – interfaces – serial 2 – RS485.....	97
Table 3-25: Parameter – interfaces – serial 2 – Modbus .....	97
Table 3-26: Parameter – interfaces – network A .....	97



Table 3-27: Parameter – interfaces – network B .....	98
Table 3-28: Parameter – interfaces – network C .....	98
Table 3-29: Parameter – interfaces – format Modbus protocol .....	99
Table 3-30: Parameter – system management – factory settings .....	116
Table 3-31: Parameter – system management – power supply .....	116
Table 3-32: Parameter – configure counters .....	118
Table 3-33: Parameter – analog inputs – reference input: remote load/process .....	121
Table 3-34: Parameter – analog inputs – process signal input .....	121
Table 3-35: Parameter – analog inputs – reactive load input .....	122
Table 3-36: Parameter – System A – active power .....	123
Table 3-37: Parameter – system A – reactive power .....	124
Table 3-38: Parameter – system A – apparent power .....	124
Table 3-39: Parameter – System A – voltage phase-phase .....	124
Table 3-40: Parameter – System A – voltage phase-neutral .....	124
Table 3-41: Parameter – system A – power factor .....	124
Table 3-42: Parameter – System A – current .....	125
Table 3-43: Parameter – System A – frequency .....	125
Table 3-44: Parameter – system A – phase rotation .....	125
Table 3-45: Parameter – system B – voltage .....	126
Table 3-46: Parameter – system B – frequency .....	126
Table 3-47: Parameter – system B – phase angle .....	126
Table 3-48: Parameter – System B – phase rotation .....	126
Table 3-49: Parameter – aux. system B – voltage phase-phase .....	127
Table 3-50: Parameter – aux. system B – voltage phase-neutral .....	127
Table 3-51: Parameter – aux. system B – frequency .....	127
Table 3-52: Parameter – auxiliary system B – phase rotation .....	127
Table 3-53: Parameter – control status monitor .....	129
Table 3-54: Parameter – control status monitor - alarms .....	130
Table 3-55: Parameter – control status monitor – System A energy counters .....	131
Table 3-56: Parameter – control status monitor – communication management .....	131
Table 3-57: Parameter – discrete inputs / outputs – discrete inputs .....	133
Table 3-58: Parameter – discrete inputs / outputs – discrete input source .....	134
Table 3-59: Parameter – discrete inputs / outputs – relay outputs .....	134
Table 3-60: Parameter – discrete inputs / outputs – segments .....	134
Table 3-61: Parameter – diagnostics .....	136
Table 3-62: System Status quick info at overview pages .....	138
Table 3-63: Parameter – MSLC-2 overview page .....	139
Table 3-64: Parameter – DSLC-2 overview page .....	140
Table 4-1: Low voltage system 480 V / 277 V – 3-phase with neutral .....	161
Table 4-2: Low voltage system 480 V / 277 V – 3-phase with neutral .....	162
Table 4-3: Low voltage system 480 V – 3-phase with neutral .....	163
Table 4-4: Low voltage system 600 V / 346 V – 3-phase .....	164
Table 4-5: Low voltage system 600 V / 346 V – 3-phase .....	165
Table 4-6: Low voltage system 600 V / 346 V – 3-phase .....	166
Table 4-7: Low voltage system 600 V / 346 V – 3-phase with neutral .....	167
Table 4-8: Low voltage system 600 V / 346 V – 3-phase with neutral .....	168
Table 4-9: Low voltage system 600 V / 346 V – 3-phase with neutral .....	169
Table 4-10: Low voltage system 600 V / 346 V – 3-phase with neutral .....	170
Table 4-11: Middle voltage system 20 kV – 3-phase without neutral .....	171
Table 4-12: Middle voltage system 20 kV – 3-phase without neutral .....	172
Table 4-13: Ramping overview .....	179
Table 9-1: MSLC-2 - Interfaces - overview .....	199
Table 9-2: Modbus - address range block read .....	205
Table 9-3: Modbus - address calculation .....	206
Table 9-4: Modbus - data types .....	206
Table 9-5: Modbus – sending setpoints over interface .....	207
Table 9-6: Modbus – sending binary digital orders over interface .....	208
Table 9-7: Modbus – sending binary digital orders over interface .....	210
Table 9-8: Modbus – password for serial interface 2 (RS 485) .....	214
Table 9-9: Modbus – generator rated voltage .....	214
Table 9-10: Modbus – generator voltage measuring .....	215
Table 9-11: Modbus – reset default values .....	216
Table 9-12: Modbus - serial interface 2 – parameters .....	218
Table 0-1: Technical Data .....	223
Table 0-2: Environmental data .....	224
Table 0-3: Accuracy .....	225



Table 0-1: Interference suppressing circuit for relays .....	227
Table 0-1: Data Protocol 5200.....	237
(Sequence following ID number) .....	239
Table 0-1: Parameter list .....	248



# Chapter 1.

## General Information

### Document Overview



This manual describes the Woodward MSLC-2-XT™ Master Synchronizer and Load Control. If there is no difference to MSLC-2, MSLC-2 and MSLC-2-XT are used synonymously in this document.

Type	English	German
<b>MSLC-2</b>		
DSLC-2 – User Manual	37948	-
MSLC-2 – User Manual	<a href="#">this manual</a> ⇨	37947

Table 1-1: Manual - overview

**Intended use:** The unit must only be operated in the manner described by this manual. The prerequisite for a proper and safe operation of the product is correct transportation, storage and installation as well as careful operation and maintenance.

### QR Code



To get access to the complete product documentation, scan this QR code or use the following link: [http://wwdmanuals.com/DSLC\\_MSLC](http://wwdmanuals.com/DSLC_MSLC)



#### NOTE

This manual has been developed for a unit fitted with all available options. Inputs/outputs, functions, configuration screens and other details described, which do not exist on your unit, may be ignored.

The present manual has been prepared to enable the installation and commissioning of the unit. Due to the large variety of parameter settings, it is not possible to cover every combination. The manual is therefore only a guide.



# Application



The Woodward MSLC-2XT™ control is the direct successor of the former MSLC™ master synchronizer and load control. The MSLC-2XT™ is a microprocessor-based overall plant load control designed for use in a system with Woodward DSLC-2XT™, DSLC-2™ (“Digital Synchronizer and Load Control”) controls on each generator to provide utility synchronizing, paralleling, loading and unloading of a three-phase generating system.

Applications allow up to 32 generators to be paralleled and controlled in conjunction with up to 16 MSLC-2XT™, MSLC-2™. A dedicated Ethernet system provides seamless communications between DSLC-2™ and MSLC-2™ units. A second Ethernet port is provided for customer remote control and monitoring capability using Modbus TCP allowing DCS and PLC interfacing. Both together can be used as a redundant Ethernet system. Modbus TCP is also available through additional Ethernet connection (named C). Modbus RTU is available through a separate RS-485 port.

## MSLC-2 function summary

### Original MSLC functions include:

- Selectable for phase matching or slip frequency synchronizing between the utility and a local bus with voltage matching
- Automatic system loading and unloading for bumpless load transfer
- Import/export level control capability
- Process control for cogeneration, pressure, maintenance or other process
- Proportional loading of associated DSLC-2 controls in isochronous load sharing
- Adjustable power factor control
- Built in diagnostics with relay output
- Multifunction adjustable high and low limit alarms and adjustable load switches with relay outputs
- Digital communications network to provide loading and power factor control of individual DSLC-2 equipped generators

### Additional MSLC-2 functions include:

- Automatic dead bus closure capability for tie-breakers
- Multiple utility breaker and tie-breaker MSLC-2s on the same bus segment
- One dedicated Ethernet line for precise system communications between all DSLC-2s and MSLC-2s on the system
- Ethernet Modbus/TCP for remote control and monitoring
- Serial Modbus RS-485 for remote control and monitoring
- Applications with up to 32 DSLC-2 and 16 MSLC-2
- Automatic segment control (self-recognizing of the segment)
- Full setup, metering and diagnostic capability through the PC program ToolKit



## Synchronizer



Either phase matching or slip frequency synchronizing may be selected. Phase matching provides rapid synchronizing for critical standby power applications. Slip frequency synchronizing ensures that the initial flow of power will be either out of the local system (export) or into the local system (import), depending on whether a positive or negative slip is chosen. For both synchronizing methods, the MSLC-2 uses actual slip frequency and breaker delay values to anticipate an adjustable minimum phase difference between the utility and the local bus. Additional synchronizer functions include voltage matching, time delayed automatic multi-shot reclosing, auto-resynchronizing and a synchronizer timeout alarm. Each of these features may be enabled or disabled during setup.

The MSLC-2 control provides a safe automatic dead bus closure function. Deadbus closing permission is granted to only one DSLC-2 or MSLC-2 control in the whole system through locking techniques done over the communications network.

The MSLC-2, configured as tie-breaker control, allows selecting different closure modes or all modes:

- Alive bus A -> dead bus B
- Dead bus A -> dead bus B
- Alive bus B -> dead bus A

## Load Control



The MSLC-2 has four load control modes available:

- Base load
- Import/export
- Process
- Utility unload

Load control begins with the breaker closure of the utility and another discrete input selecting the load control mode wanted. If no load control mode is selected the MSLC-2 will be in the offline mode. The system load immediately prior to breaker closure is used as the starting base load reference. On command, the adjustable ramp allows smooth, time controlled loading into a set import/export level. A ramp pause switch is provided to stop the ramp at any point.

The import/export control is an integrating control. It adjusts the percentage of rated load carried by the individual generators, operating in isochronous load sharing, in order to maintain a set import/export or base load level. The MSLC-2 will maintain a constant base load or import/export level even with changing utility frequencies. The MSLC-2 provides switch inputs to allow raising or lowering the internal digital base load or import/export reference. The control also provides a remote analog signal input for reference setting, if desired. (Signal variety: 0 to 20 mA, 4 to 20 mA, 0 to 5 V, 1 to 5 V and 0 to 10 V)

The MSLC-2 is equipped with a utility unload switch, which provides an adjustable time controlled ramp to lower the base load or import/export level. When the level is below an adjustable threshold, the MSLC-2 issues a breaker open command to separate the utility from the local bus. The ramp pause switch can be used to stop the utility unload at any point. The maximum load that the MSLC-2 can tell the individual generators to carry is their rated loads. So, in the event that the plant load is greater than the capacity of the operating generators, the utility unload will stop when 100% rated load is reached on each of the operating generators. This prevents accidental overloading of the local generators.

The MSLC-2 also includes two adjustable load switches which can be used for external functions or warnings when chosen system load levels are attained. The high and low limit switches may also be activated when 100% or 0% load signal to the generators is reached.






Figure 1-2: MSLC-2 Load Control Overview



## Process Control



A process controller is provided for cogeneration, fluid level maintenance, pressure control or other applications. An adjustable bandwidth signal input filter, flexible PID controller adjustments, selectable for direct or indirect action, allow the process control to be used in a wide variety of applications.

An analog signal input (signal variety: 0 to 20mA, 4 to 20mA, 0 to 5V, 1 to 5V and 0 to 10V) provides the process signal to the MSLC-2. The MSLC-2 includes an internal digital process reference, which may be controlled by the raise and lower switch contact inputs or by an external analog input signal as remote process reference. The MSLC-2 also has a Modbus address for process reference control. The output of the process control, like the import/export control, is the percentage of rated load setpoint to the individual generators in isochronous load sharing.

An adjustable ramp allows smooth entry and exit from the process control mode. When the process control mode is selected, the load reference is ramped in a direction to reduce the error between the process input and the process reference. When the error is minimized or the reference first reaches either the high or the low specified limits, the process controllers PID loop is activated. When the load reference output reaches either 100% or 0%, the control will maintain that load reference until process control is established.

The MSLC-2 is not capable of overloading or reverse powering the generators in an attempt to meet the process reference. The high and low limit switches mentioned above can be used to indicate that either too many or too few generators are online to maintain the process within its limits.

## Var/PF Control



The var/PF function controls the power factor on all of the DSLC-2 equipped machines operating in isochronous load sharing. The PF control begins on breaker closure. The MSLC-2 has three modes of Var/PF control (which are selected in Menu 4):

- Constant generator power factor – sets the power factor reference on all of the DSLC-2 controls to the internal reference chosen in the MSLC-2. The power factor can then be adjusted using the voltage raise and lower inputs. The voltage raise command will make the power factor more lagging. Conversely, the voltage lower command will make the power factor more leading.
- Utility tie power factor control – adjusts the power factor reference on all of the DSLC-2 controls in isochronous load sharing in order to maintain the power factor across the utility tie.
- Utility tie var control – adjusts the power factor reference on all of the DSLC-2 controls in isochronous load sharing in order to maintain the level of vars being imported or exported from the utility.

The var/PF control mode begins with the load control mode selected. The constant generator power factor and the utility tie power factor control can have the reference setting controlled by an analog input (see Menu 6). By closing the voltage raise and lower discrete inputs, you can select the analog remote input for reference control.



## DSL-2 / MSLC-2 Systems



The network addressing of the DSL-2 / MSLC-2 allows up to 32 DSL-2s and 16 MSLC-2s in an application. A DSL-2 and MSLC-2 application can handle 8 segments. Discrete inputs inform the DSL-2s and MSLC-2s which segments each generator and utilities are operating on. If a MSLC-2 receives a discrete input to activate segment 1 and 2, it will share this information with all controls over the Ethernet bus. It is not necessary to provide a segment activation discrete input to all controls. Segmenting allows the DSL-2s and MSLC-2s to remain connected thru the Ethernet bus, but be operating on separate load buses.

The DSL-2 / MSLC-2 system can be applied according to following rules:

- The maximum number of DSL-2s (Gen-CB) is 32.
- The maximum number of MSLC-2s (Utility- or Tie-CB) is 16.
- The maximum number of segments is 8.
- The segment numbers have to follow a line, which can finally be closed to a ring.
- For DSL-2 it can be selected between two segmenting modes:
  - Bus segmenting determining generators running together via an algorithm.
  - Device segmenting determining generators running together from outside.
- Only one MSLC-2 can be used as master control, when multiple MSLC-2 is resided in one segment.
  - The MSLC-2 with the lower device number will control if multiple Utility MSLC-2s are active on the same segment
- The generator is not counted as a segment.
- The utility is not counted as a segment.



### NOTE

If different MSLC-2s, located in different segments, are connected via a tie-MSLC-2, more than one MSLC-2 is now located in the same segment. The result is the MSLC-2 with the lowest device number becomes the master of all MSLC-2s located in this segment.

### Examples (DSL-2 with Bus Segmenting):




Figure 1-3: Multiple generators in isolated operation with tie-breaker






Figure 1-4: Multiple generators in isolated and utility parallel operation with utility- and tie-breaker

## Control Relationships in a MSLC-DSLC System

A MSLC / DSLC system is defined through minimum of one MSLC device and one DSLC device.

A DSLC is only controlled by a MSLC, if:

- The MSLC resides in the same segment
- The MSLC has got a master function, like:
  - DI Sync Run
  - DI Sync Check
  - DI Manual (DI Sync Check AND DI Sync Permissive)
  - DI Base Load Control
  - DI Import/Export Control
  - DI Process Control
  - DI Utility Unload
- The according DSLC is listening on the master MSLC, which means:
  - DI Base Load is not active
  - DI Process Control is not active
  - DI Load/Unload is active




Figure 1-5: Control relationship in a MSLC-DSLC system



## Chapter 2. Installation

### Electrostatic Discharge Awareness



All electronic equipment is static-sensitive, some components more than others. To protect these components from static damage, you must take special precautions to minimize or eliminate electrostatic discharges.

Follow these precautions when working with or near the control.

1. Before doing maintenance on the electronic control, discharge the static electricity on your body to ground by touching and holding a grounded metal object (pipes, cabinets, equipment, etc.).
2. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as easily as synthetics.
3. Keep plastic, vinyl and Styrofoam materials (such as plastic or Styrofoam cups, cigarette packages, cellophane wrappers, vinyl books or folders, plastic bottles, etc.) away from the control, modules and work area as much as possible.
4. **Opening the control cover may void the unit warranty.**  
Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
  - Ensure that the device is completely voltage-free (all connectors have to be disconnected).
  - Do not touch any part of the PCB except the edges.
  - Do not touch the electrical conductors, connectors, or components with conductive devices or with bare hands.
  - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.



#### CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards and Modules*.



## Unpacking



Before unpacking the control, refer to the inside front cover of this manual for WARNINGS and CAUTIONS. Be careful when unpacking the control. Check for signs of damage such as bent or dented panels, scratches, loose or broken parts. If any damage is found, immediately notify the shipper.

## Location



When selecting a location for mounting the MSLC-2 control, consider the following:

- Protect the unit from direct exposure to water or to a condensation-prone environment.
- The continuous operating range of the MSLC-2 control is  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$  ( $-40^{\circ}\text{F}$  to  $+158^{\circ}\text{F}$ ).
- Provide adequate ventilation for cooling. Shield the unit from radiant heat sources.
- Do not install near high-voltage, high-current devices.
- Allow adequate space in front of the unit for servicing.
- Do not install where objects can be dropped on the terminals.
- Ground the chassis for proper safety and shielding.
- The control must NOT be mounted on the engine.



## Housing



### Dimensions




Figure 2-1: Housing MSLC-2 - dimensions



## Installation

The unit is to be mounted to the switch cabinet back using four screws with a maximum diameter of 6 mm. Drill the holes according to the dimensions in Figure 2-2 (dimensions shown in mm).




Figure 2-2: Housing - drill plan



## Terminal Arrangement



### NOTE

The Protective Earth terminal 61 is not connected on the MSLC-2. The protective earth connection at the sheet metal housing must be used instead (refer to Figure 1-2).




Figure 2-3: MSLC-2 - terminal arrangement

## LEDs

### LED "Sync Enable"

Off	System A NOK (V, f) OR System B NOK (V, f)
Green	Ready for synchronization, CB Aux can be closed
Red	System A OK (V, f) AND System B OK (V, f), Synchronizer Voltage-Frequency Window = Not OK
Orange	Boot up or "Firmware Update Procedure" with ".Scp" file, phase 1 (file transfer)
Toggling red	"Firmware Update Procedure" with ".Scp" file, phase 2 (installing files)

### LED "CPU OK"

Off	The unit is not ready for operation. No supply voltage or hardware problem occurred.
Green	The unit is ready for operation
Toggling green	The process "System update" is active
Red	The unit is not ready for operation




\_\_\_\_\_



Page 25/253





© Woodward



## Connections



### WARNING

All technical data and ratings indicated in this chapter are not definite! Only the values indicated in paragraph Appendix A. Fehler! Verweisquelle konnte nicht gefunden werden. on page Fehler! Textmarke nicht definiert. are valid!

The following chart may be used to convert square millimeters [mm<sup>2</sup>] to AWG and vice versa:

AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>
30	0.05	21	0.38	14	2.5	4	25	3/0	95	600MCM	300
28	0.08	20	0.5	12	4	2	35	4/0	120	750MCM	400
26	0.14	18	0.75	10	6	1	50	300MCM	150	1000MCM	500
24	0.25	17	1.0	8	10	1/0	55	350MCM	185		
22	0.34	16	1.5	6	16	2/0	70	500MCM	240		

Table 2-1: Conversion chart - wire size



The Protective Earth terminal 61 is not connected on the sheet metal housing.

- Use the protective earth (PE) connector located at the bottom center of the sheet metal housing instead.



### **Common terminal for AC measurement voltages**

System A and System B voltage measuring terminals no longer differentiate with separate terminals for each voltage range.



### **General recommendations**

Ensure appropriate cable cross sections following the local standards and restrictions. The maximum cable cross section of the terminal blocks is 2.5 mm<sup>2</sup>.

For every type of signal lines like power supply, DI, DO, AI, AO:

- Return line has to be close to forward signal line.
- Use cables instead of single wires.
  - In case of using single wires please do at least one twist per meter to keep wires together closely.



## Power Supply



### WARNING – Protective Earth

Protective Earth (PE) must be connected to the unit to avoid the risk of electric shock. The conductor providing the connection must have a wire larger than or equal to 2.5 mm<sup>2</sup> (14 AWG). The connection must be performed properly.

Please use the protective earth connection at the sheet metal housing (refer to Figure 2-1 on page 22).



### WARNING – Permissible differential voltage

The maximum permissible differential voltage between terminal 64 (B-) and terminal 61 (PE) is 100 VRMS. On engines where a direct connection between battery minus and PE is not possible, it is recommended to use an isolated external power supply if the differential voltage between battery minus and PE exceeds 100 VRMS.



### NOTE

Woodward strictly recommends using a power supply that is fulfilling the SELV restrictions (SELV = separated or safety extra-low voltage, see IEC)



### NOTE

Woodward recommends using one of the following slow-acting protective devices in the supply line to terminal 63:

- Fuse NEOZED D01 6A or equivalent or
  - Miniature Circuit Breaker 6A / Type C
- (for example: ABB type: S271C6 or equivalent)




Figure 2-6: Power supply

Figure	Terminal	Description	A <sub>max</sub>
A	63	12/24Vdc (8 to 40.0 Vdc)	2.5 mm <sup>2</sup>
B	64	0 Vdc	2.5 mm <sup>2</sup>

Table 2-2: Power supply - terminal assignment






Figure 2-7: Power supply - crank waveform at maximum load



## Voltage Measuring



### WARNING – Protective Earth

The maximum permissible voltage against ground connected on the easYgen is 600 Volt. This is to consider if phase voltages are grounded.



### NOTE

Woodward recommends protecting the voltage measuring inputs with slow-acting fuses rated for 2 to 6 A.



### NOTE

The wide range terminals allow several voltages. The current voltage (range) of the application must be "told" to the genset controller device. Settings are described in chapter "Configure Measurement" .



### NOTE

The voltage measuring inputs for 120 V, 480 V, and 690 V are using the same terminals 30 to 36. The current voltage range must be selected by the corresponding settings via HMI and/or ToolKit. Parameter  $\mathbb{L} \rightarrow 1800$  ("Gen. PT secondary rated volt.") must be configured to the correct value to ensure proper measurement.

### Voltage Measuring: System A




Figure 2-8: Voltage measuring – system A

Figure	Terminal	Description	A <sub>max</sub>
A	30	System A Voltage AØ (L1)	2.5 mm <sup>2</sup>
B	32	System A Voltage BØ (L2)	2.5 mm <sup>2</sup>
C	34	System A Voltage CØ (L3)	2.5 mm <sup>2</sup>
D	36	System A Voltage N	2.5 mm <sup>2</sup>

Table 2-3: Voltage measuring – terminal assignment – System A voltage



## Voltage Measuring: System A

### Parameter Setting '3Ph 4W OD' (3-phase, 4-wire, Open delta)

System A that is connected to the load through a 3-phase, 4-wire connection but have the device wired for a 3-phase, 3-wire installation may have the L2 phase grounded on the secondary side. In this application the device will be configured for 3-phase, 4-wire open delta for correct power measurement.




Figure 2-9: Voltage measuring – system A windings, 3Ph 4W OD




Figure 2-10: Voltage measuring – system A measuring inputs, 3Ph 4W OD

Figure	Terminal	Description
A	30	System A Voltage AØ (L1)
B	32	System A Voltage BØ (L2)
C	34	System A Voltage CØ (L3)
D	36	Not connected

Table 2-4: Voltage measuring - terminal assignment – System A, 3Ph 4W OD

## Voltage Measuring: System A, Parameter Setting '3Ph 4W' (3-phase, 4-wire)






Figure 2-11: Voltage measuring – system A windings, 3Ph 4W




Figure 2-12: Voltage measuring – system A measuring inputs, 3Ph 4W

Figure	Terminal	Description
A	30	System A Voltage AØ (L1)
B	32	System A Voltage BØ (L2)
C	34	System A Voltage CØ (L3)
D	36	System A Voltage DØ (N)

Table 2-5: Voltage measuring – terminal assignment – system A, 3Ph 4W



## Voltage Measuring: System A, Parameter Setting '3Ph 3W' (3-phase, 3-wire)




Figure 2-13: Voltage measuring – system A windings, 3Ph 3W




Figure 2-14: Voltage measuring – system A measuring inputs, 3Ph 3W

Figure	Terminal	Description
A	30	System A Voltage AØ (L1)
B	32	System A Voltage BØ (L2)
C	34	System A Voltage CØ (L3)
D	36	Not connected

Table 2-6: Voltage measuring - terminal assignment – system A, 3Ph 3W



## Voltage Measuring: System B




Figure 2-15: Voltage measuring – system B

Figure	Terminal	Description	A <sub>max</sub>
A	38	System B Voltage AØ (L1)	2.5 mm <sup>2</sup>
B	40	System B Voltage BØ (L2)   N	2.5 mm <sup>2</sup>

Table 2-7: Voltage measuring - terminal assignment – system B voltage



### NOTE

Never configure the System B measurement for phase-neutral, if System A is configured as 3ph 3W without being the neutral in the middle of the triangle. The phase angle for synchronization would be incorrect.



## Voltage Measuring: System B, Parameter Setting '**1Ph 2W**' (1-phase, 2-wire)



### NOTE

The 1-phase, 2-wire measurement may be performed phase-neutral or phase-phase. Please note to configure and wire the MSLC-2 consistently. Refer to the chapter Configuration & Operation.

### '1Ph 2W' Phase-Neutral Measuring




Figure 2-16: Voltage measuring – system B measuring inputs, 1Ph 2W (phase-neutral)

Figure	Terminal	Description
A	38	System B Voltage AØ (L1)
B	40	System B Voltage BØ (N)

Table 2-8: Voltage measuring - terminal assignment – system B, 1Ph 2W (phase-neutral)

### '1Ph 2W' Phase-Phase Measuring




Figure 2-17: Voltage measuring – system B measuring inputs, 1Ph 2W (phase-phase)



Figure	Terminal	Description
A	38	System B Voltage AØ (L1)
B	40	System B Voltage BØ (L2)

Table 2-9: Voltage measuring - terminal assignment – system B, 1Ph 2W (phase-phase)



## Voltage Measuring: Auxiliary System B




Figure 2-18: Voltage measuring – auxiliary system B

Figure	Terminal	Description	A <sub>max</sub>
A	22	Auxiliary system B Voltage AØ (L1)	2.5 mm <sup>2</sup>
B	24	Auxiliary system B Voltage BØ (L2)	2.5 mm <sup>2</sup>
C	26	Auxiliary system B Voltage CØ (L3)	2.5 mm <sup>2</sup>
D	28	Auxiliary system B Voltage N	2.5 mm <sup>2</sup>

Table 2-10: Voltage measuring - terminal assignment - auxiliary system B voltage



### NOTE

Although Auxiliary System B measurement is used (connected to the device), System B measurement needs to be connected to the device.



### NOTE

- If Auxiliary System B is used, checking the plausibility between Auxiliary System B and System B is active.
- L1-L2 voltages in both systems are compared.
- Alarm ID 7770 "System B mismatch" does not occur if both L1-L2 voltages are in operating range or both dead.

The dead busbar closure is blocked, when this alarm occurs.



## Voltage Measuring: Auxiliary System B, Parameter Setting '3Ph 4W' (3-phase, 4-wire)




Figure 2-19: Voltage measuring - auxiliary system B PT windings, 3Ph 4W




Figure 2-20: Voltage measuring - auxiliary system B measuring inputs, 3Ph 4W

Figure	Terminal	Description
A	22	Auxiliary system B Voltage AØ (L1)
B	24	Auxiliary system B Voltage BØ (L2)
C	26	Auxiliary system B Voltage CØ (L3)
D	28	Auxiliary system B Voltage N

Table 2-11: Voltage measuring - terminal assignment - auxiliary system B, 3Ph 4W



## Voltage Measuring: Auxiliary System B, Parameter Setting '3Ph 3W' (3-phase, 3-wire)




Figure 2-21: Voltage measuring - auxiliary system B PT windings, 3Ph 3W




Figure 2-22: Voltage measuring - auxiliary system B measuring inputs, 3Ph 3W

Figure	Terminal	Description
A	22	Auxiliary system B Voltage AØ (L1)
B	24	Auxiliary system B Voltage BØ (L2)
C	26	Auxiliary system B Voltage CØ (L3)
D	28	Not connected

Table 2-12: Voltage measuring - terminal assignment - auxiliary system B, 3Ph 3W



## Current Measuring



### CAUTION

Before disconnecting the device, ensure that the current transformer/CT is short-circuited.

### System A Current



### NOTE

Generally, one line of the current transformers secondary is to be grounded close to the CT.




Figure 2-23: Current measuring – system A

Figure	Terminal	Description	A <sub>max</sub>
A	8	System A current C (L3) – X1	2.5 mm <sup>2</sup>
B	7	System A current C (L3) – X2	2.5 mm <sup>2</sup>
C	6	System A current B (L2) – X1	2.5 mm <sup>2</sup>
D	5	System A current B (L2) – X2	2.5 mm <sup>2</sup>
E	4	System A current A (L1) – X1	2.5 mm <sup>2</sup>
F	3	System A current A (L1) – X2	2.5 mm <sup>2</sup>

Table 2-13: Current measuring - terminal assignment – system A current



## Current Measuring: System A, Parameter Setting 'L1 L2 L3'




Figure 2-24: Current measuring – system A, L1 L2 L3

L1 L2 L3			Wiring terminals				Notes
MSLC-2 terminal	3	4	5	6	7	8	
Phase	X2 - A(L1)	X1 - A(L1)	X2 - B(L2)	X1 - B(L2)	X2 - C(L3)	X1 - C(L3)	

Table 2-14: Current measuring - terminal assignment – system A, L1 L2 L3

## Current Measuring: System A, Parameter Setting 'Phase L1', 'Phase L2' & 'Phase L3'




Figure 2-25: Current measuring - system A, phase Lx

Wiring terminals							Notes
Phase L1							
MSLC-2 terminal	3	4	5	6	7	8	
Phase	X2 - A(L1)	X1 - A(L1)	---	---	---	---	
Phase L2							
MSLC-2 terminal	3	4	5	6	7	8	
Phase	---	---	X2 - B(L2)	X1 - B(L2)	---	---	
Phase L3							
MSLC-2 terminal	3	4	5	6	7	8	
Phase	---	---	---	---	X2 - C(L3)	X1 - C(L3)	

Table 2-15: Current measuring - terminal assignment - system A, phase Lx



## Power Measuring

If the unit's current transformers are wired according to the diagram shown, the following values are displayed.

Utility Breaker MSLC-2		
Parameter	Description	Sign displayed
Mains real power	Importing KW (from Utility) Powerflow from System A to System B	+ Positive KW
Mains real power	Exporting KW (to Utility) Powerflow from System A to System B	- Negative KW
Mains power factor ( $\cos \phi$ )	Inductive / lagging	+ Positive
Mains power factor ( $\cos \phi$ )	Capacitive / leading	- Negative
Tie-Breaker MSLC-2		
Parameter	Description	Sign displayed
System A real power	Powerflow from System A to System B in kW	+ Positive
System A real power	Powerflow from System A to System B in kW	- Negative
System A power factor ( $\cos \phi$ )	Inductive / lagging reactive powerflow from System A to System B	+ Positive
System A power factor ( $\cos \phi$ )	Capacitive / leading reactive powerflow from System A to System B	- Negative

Table 2-16: Power Measuring – sign displayed – Utility / Tie




Figure 2-26: Power measuring - direction of power

Figure	Terminal	Description	A <sub>max</sub>
A	3	X2 A (L1) System A Current	2.5 mm <sup>2</sup>
B	4	X1 A (L1) System A Current	2.5 mm <sup>2</sup>

Table 2-17: Power measuring - terminal assignment



## Power Factor Definition

The phasor diagram is used from the generator's view. Power factor is defined as follows.

Power Factor is defined as a ratio of the real power to apparent power. In a purely resistive circuit, the voltage and current waveforms are in step resulting in a ratio or power factor of 1.00 (often referred to as unity). In an inductive circuit the current lags behind the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a positive ratio or lagging power factor (i.e. 0.85lagging). In a capacitive circuit the current waveform leads the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a negative ratio or a leading power factor (i.e. 0.85leading).

Inductive: Electrical load whose current waveform lags the voltage waveform thus having a lagging power factor. Some inductive loads such as electric motors have a large startup current requirement resulting in lagging power factors.	Capacitive: Electrical load whose current waveform leads the voltage waveform thus having a leading power factor. Some capacitive loads such as capacitor banks or buried cable result in leading power factors.
---	--

Different power factor displays at the unit:

i0.91 (inductive) lg.91 (lagging)	c0.93 (capacitive) ld.93 (leading)
--------------------------------------	---------------------------------------

Reactive power display at the unit:

70 kvar (positive)	-60 kvar (negative)
--------------------	---------------------

Output at the interface:

+ (positive)	- (negative)
--------------	--------------

In relation to the voltage, the current is

lagging	leading
---------	---------

The generator is

over excited	under excited
--------------	---------------

Control: If the control unit is equipped with a power factor controller while in parallel with the utility:

A voltage lower "-" signal is output as long as the measured value is "more inductive" than the reference setpoint Example: measured = i0.91; setpoint = i0.95	A voltage raise "+" signal is output as long as the measured value is "more capacitive" than the reference setpoint Example: measured = c0.91; setpoint = c0.95
---	--



Phasor diagram:




Figure 2-27: Phasor diagram – inductive / capacitive



## Discrete Inputs

### Discrete Inputs: Signal Polarity

The discrete inputs are electrically isolated which permits the polarity of the connections to be either positive or negative.



#### NOTE

All discrete inputs must use the same polarity, either positive or negative signals, due to the common ground.

### Discrete Inputs: Positive Polarity Signal




Figure 2-28: Discrete inputs - alarm/control input - positive signal

### Discrete Inputs: Negative Polarity Signal




Figure 2-29: Discrete inputs - alarm/control input - negative signal

Terminal		Description			A <sub>max</sub>
Term.	Com.				
A	B				
66 GND com- mon ground	67	Discrete input [DI 01]	{all}	Check	2.5 mm <sup>2</sup>
	68	Discrete input [DI 02]	{all}	Permissive	2.5 mm <sup>2</sup>
	69	Discrete input [DI 03]	{all}	Run	2.5 mm <sup>2</sup>
	70	Discrete input [DI 04]	{all}	CB Aux	2.5 mm <sup>2</sup>
	71	Discrete input [DI 05]	{all}	Voltage Raise	2.5 mm <sup>2</sup>
	72	Discrete input [DI 06]	{all}	Voltage Lower	2.5 mm <sup>2</sup>
	73	Discrete input [DI 07]	{all}	Base Load	2.5 mm <sup>2</sup>
	74	Discrete input [DI 08]	{all}	Utility Unload	2.5 mm <sup>2</sup>
	75	Discrete input [DI 09]	{all}	Ramp Pause	2.5 mm <sup>2</sup>
	76	Discrete input [DI 10]	{all}	Setpoint Raise	2.5 mm <sup>2</sup>
	77	Discrete input [DI 11]	{all}	Setpoint Lower	2.5 mm <sup>2</sup>
	78	Discrete input [DI 12]	{all}	Process Control	2.5 mm <sup>2</sup>

Table 2-18: Discrete input - terminal assignment 1/2



Terminal Term.	Com.	Description	A <sub>max</sub>
A	B		
152 GND com- mon ground	141	Discrete input [DI 13] {all} Segment No. 12 Act.	2.5 mm <sup>2</sup>
	142	Discrete input [DI 14] {all} Segment No. 23 Act.	2.5 mm <sup>2</sup>
	143	Discrete input [DI 15] {all} Segment No. 34 Act.	2.5 mm <sup>2</sup>
	144	Discrete input [DI 16] {all} Segment No. 45 Act.	2.5 mm <sup>2</sup>
	145	Discrete input [DI 17] {all} Segment No. 56 Act.	2.5 mm <sup>2</sup>
	146	Discrete input [DI 18] {all} Segment No. 67 Act.	2.5 mm <sup>2</sup>
	147	Discrete input [DI 19] {all} Segment No. 78 Act.	2.5 mm <sup>2</sup>
	148	Discrete input [DI 20] {all} Segment No. 81 Act.	2.5 mm <sup>2</sup>
	149	Discrete input [DI 21] {all} Imp./Exp. control	2.5 mm <sup>2</sup>
	150	Discrete input [DI 22] {all} Modbus Reset	2.5 mm <sup>2</sup>
	151	Discrete input [DI 23] {all} System update	2.5 mm <sup>2</sup>

Table 2-19: Discrete input - terminal assignment 2/2

	DI CB AUX	DI Utility Unload	DI Base Load	DI Imp/Exp Control	DI Process Control	DI Ramp Pause	DI Setpoint Raise	DI Setpoint Lower
Off Line	0	x	x	x	x	x	x	x
Base Load	1	0	1	0	0	0	0	0
Base Load Raise	1	0	1	0	0	0	1	0
Base Load Lower	1	0	1	0	0	0	0	1
Base Load <sup>1</sup> Remote	1	0	1	0	0	0	1	1
Utility Unload <sup>2</sup>	1	1	x	x	x	0	x	x
Local Unload <sup>3</sup>	1	0	1	0	0	0	0	1
Ramp Pause <sup>4</sup>	1	x	x	x	x	1	x	x
Import/ Export mode	1	0	x	1	0	0	0	0
I/E Raise	1	0	x	1	0	0	1	0
I/E Lower	1	0	x	1	0	0	0	1
I/E Remote <sup>1</sup>	1	0	x	1	0	0	1	1
Process Control	1	0	x	x	1	0	0	0
Process Raise	1	0	x	x	1	0	1	0
Process Lower	1	0	x	x	1	0	0	1
Process Remote <sup>1</sup>	1	0	x	x	1	0	1	1

Table 2-20: Load control modes MSLC-2

<sup>1</sup> Remote reference is activated by closing both setpoint raise and setpoint lower switches at the same time.

<sup>2</sup> The MSLC-2 can only load the associated generators to 100%. If this is not enough capacity to unload the utility, the unload ramps stops at 100% rated load on the associated generators. The generator high limit alarm, if enabled, will activate at this time.

<sup>3</sup> The local plant unload is accomplished by switching to base load mode and supplying a continuous setpoint lower command.

<sup>4</sup> The ramp pause command will pause all ramps in any mode.



## Relay Outputs



Figure 2-30: Relay outputs

Terminal Term.	Com.	Description	$A_{max}$			
A	B	Form A, N.O. make contact	Type ↓			
42	41	Relay output [R 01] {all}	Alarm (Self-Test OK)	N.O.	2.5 mm <sup>2</sup>	
43	46	Relay output [R 02] {all}	Reserve	N.O.	2.5 mm <sup>2</sup>	
44		Relay output [R 03] {all}	High Limit	N.O.	2.5 mm <sup>2</sup>	
45		Relay output [R 04] {all}	Low Limit	N.O.	2.5 mm <sup>2</sup>	
48	47	Relay output [R 05] {all}	Breaker Open	N.O.	2.5 mm <sup>2</sup>	
50	49	Relay output [R 06] {all}	Breaker Close	N.O.	2.5 mm <sup>2</sup>	
52	51	Relay output [R 07] {all}	Lcl./Gen. Breaker Open	N.O.	2.5 mm <sup>2</sup>	
54	53	Relay output [R 08] {all}	Alarm 1	N.O.	2.5 mm <sup>2</sup>	
56	55	Relay output [R 09] {all}	Alarm 2	N.O.	2.5 mm <sup>2</sup>	
57	60	Relay output [R 10] {all}	Alarm 3	N.O.	2.5 mm <sup>2</sup>	
58		Relay output [R 11] {all}	Load Switch 1	N.O.	2.5 mm <sup>2</sup>	
59		Relay output [R 12] {all}	Load Switch 2	N.O.	2.5 mm <sup>2</sup>	

N.O.-normally open (make) contact

Table 2-21: Relay outputs - terminal assignment



### CAUTION

The discrete output "Alarm (Self-Test OK)" can be wired in series with an emergency stop function. This means that it must be ensured that the generator circuit breaker can be opened, if this discrete output is de-energized. We recommend signaling this fault independently from the unit if the availability of the plant is important.



### NOTE

Alarms 1, 2, and 3 can be used for monitoring only.  
Don't use alarm messages for protection control!



	DO Alarm	DO Reserve	DO High Limit	DO Low Limit	DO Breaker Open	DO Breaker Close	DO LCL/ Gen Breaker Open	DO Alarm 1	DO Alarm 2	DO Alarm 3	DO Load switch 1	DO Load switch 2
Self-Test	x											
Reserve		x										
High load limit												
High process limit			x									
High voltage limit												
Low load limit												
Low process limit				x								
Low voltage limit												
Utility Unload (DI 8)					x							
Synchronization deadbus closure						x						
Local Generator Breaker open (DI 11)							x					
Synchronizer timeout												
Reclose limit												
High load limit												
Low load limit												
High process limit												
Low process limit												
Low voltage limit												
High voltage limit												
Voltage range limit												
Communication error								x	x	x		
Missing member												
Centralized alarm												
CB open fail												
Deadbus closure mismatch												
System B mis- match												
Rotation mis- match												
Load switch 1											x	
Load switch 2												x

Table 2-22: Relay outputs driven by ...

**NOTE**

Refer to Fehler! Verweisquelle konnte nicht gefunden werden.: **Connecting 24 V Relays on page 227 for interference suppressing circuits when connecting 24 V relays.**



## Analog Inputs

The following senders may be used for the analog inputs:

- 0 to 20mA
- 4 to 20mA
- 0 to 10V
- 0 to 5V
- 1 to 5V

## Wiring Examples




Figure 2-31: Analog inputs - wiring two-pole senders using a voltage signal




Figure 2-32: Analog inputs - wiring two-pole senders (external jumper used for current signal)

Figure	Terminal	Description	A <sub>max</sub>
A	83	<b>Analog input [AI 01]</b> Remote Load Reference Input	2.5 mm <sup>2</sup>
B	84		2.5 mm <sup>2</sup>
C	85 +		2.5 mm <sup>2</sup>
A	86	<b>Analog input [AI 02]</b> Process Signal Input	2.5 mm <sup>2</sup>
B	87		2.5 mm <sup>2</sup>
C	88 +		2.5 mm <sup>2</sup>
A	89	<b>Analog input [AI 03]</b> Reactive Load Input	2.5 mm <sup>2</sup>
B	90		2.5 mm <sup>2</sup>
C	91 +		2.5 mm <sup>2</sup>

Table 2-23: Analog inputs - terminal assignment - wiring two-pole senders



## Interfaces

### RS-485 Serial Interface (Serial Interface #2)




Figure 2-33: screwable 6-terminal connector RS-485

Terminal	Description	.. used for FULL duplex mode	... used for HALF duplex mode	A <sub>max</sub>
1	A	A (RxD+)	N/A	N/A
2	B	B (RxD-)	N/A	N/A
3	GND	GND - local galvanically isolated	N/A	N/A
4	SHLD	Shield connected to earth via RC element	N/A	N/A
5	Y	Y (TxD+)	Y (TxD+ / RxD+)	N/A
6	Z	Z (TxD-)	Z (TxD- / RxD-)	N/A

Table 2-24: RS-485 interface #1 - pin assignment

### Half-Duplex with Modbus on RS-485




Figure 2-34: RS-485 Modbus - connection for half-duplex operation (120 Ohms termination resistor at both ends)

### Full-Duplex with Modbus on RS-485




Figure 2-35: RS-485 Modbus - connection for full-duplex operation



**NOTE**

Please note that the MSLC-2 must be configured for half- or full-duplex configuration (parameter 3173).

**Shielding**

MSLC-2 is prepared for shielding: Terminal 4 and the connector housing are internally grounded via an RC element. Therefore, they may either be grounded directly (recommended) or also via an RC element on the opposite connection.




Figure 2-36-1: Shielding preparation (internal RC element)



## Serial Interface USB (2.0 slave) interface – Service Port



### NOTE

- **Avoid electrostatic discharge!**  
Avoid electrostatic discharge during USB cable connection to the unit.
- To connect this USB 2.0 (slave) device a USB cable with USB Type A (PC/laptop side) and Type B (Woodward device side) connectors is necessary.
- USB cable length shall be limited up to 3 m. It is recommended to use professional (high quality) USB cable: 28AWG/1P+24AWG/2C with good shielding.

### Use USB service port for ToolKit connection.

The USB interface is a service port and the preferred for ToolKit connection!

'Read only' USB interface

For others than ToolKit connection the USB interface is read-only!

It can be used for further service tasks from manufacturer's side.

Connecting it to a PC/laptop will display the USB interface available and all files prepared from Woodward manufacturing side. Read/write attributes of this service port are restricted to read only.

## RJ-45 Ethernet Interfaces (Network A, Network B, Network C)

This Ethernet interface 10/100Base-T/-XT complies with the IEEE 802.3 specifications.



### NOTE

**Avoid electrostatic discharge!**

**Avoid electrostatic discharge during Ethernet cable connection to the unit.**

Pin assignment




Figure 2-37: RJ-45 connector - Ethernet

Table 25: Pin assignment

Pin	Description	10Base-T	100Base-T
1	Transmit Data+	TX+	TX+
2	Transmit Data-	TX-	TX-
3	Receive Data+	RX+	RX+
4	not connected	NC	NC
5	not connected	NC	NC
6	Receive Data-	RX-	RX-
7	not connected	NC	NC
8	not connected	NC	NC

Table 2-26: RJ-45 interfaces - pin assignment



## Visualization

Two LEDs (green and yellow) indicate communication status as well known by the standard.

- The green LED indicates the link activity: blinking during data transmission.
- The yellow LED indicates the link (speed) status:
  - 10MB – LED switched-OFF
  - 100MB – LED switched-ON

## General notes

Ethernet category 5 (STP CAT 5) shielded cable is required with shielded plug RJ45. The chosen switch shall support a transmission speed of 10/100 Mb/s with a network segment expansion capability of 100 m.

**NOTE****Flexibility**

**All Ethernet ports have auto MDI/MDI-X functionality what allows to connect straight-through or cross-over Ethernet cable.**

**The Ethernet ports are named twice but mean the same: Ethernet #1 or Ethernet A; Ethernet #2 or Ethernet B; and Ethernet #3 or Ethernet C .**

## Cable length / distance

The maximum length from connection to connection is 100 m. Some third-party suppliers offer technology to expand the connection.

## Troubleshooting

- Check first the power supply of the switches
- Check the IP addressed of the single devices
- Take care that principlly each port is running in an own network IP address range.



## Chapter 3. Configuration & Operation

### Configuration via PC



#### Install ToolKit Configuration and Visualization Software




#### NOTE

Woodward's ToolKit software is required to configure the unit via PC.

**ToolKit Version 6.4 or higher**

#### Install ToolKit Software

1. Please scan the QR code or use the link.
2. Go to the section "Software".



Alternatively ToolKit can be downloaded from our Website. Please proceed as follows:

1. Go to <http://www.woodward.com/software>
2. Select ToolKit in the list and click the "Go" button
3. Click "More Info" to get further information about ToolKit
4. Choose the preferred software version and click "Download"
5. Now you need to login with your e-mail address or register first
6. The download will start immediately

Minimum system requirements for ToolKit:

- Microsoft Windows® 10, 8.1, 7, Vista (32- & 64-bit
- Microsoft .NET Framework version 4.5.1 or higher
- 1 GHz or faster x86 or x64 processor
- 1 GB of RAM
- Minimum 800 by 600 pixel screen with 256 colors
- Serial Port and Serial Extension Cable
- CD-ROM drive



**NOTE**

Required version or higher of Microsoft .NET Framework must be installed on your computer to be able to install ToolKit. If not already installed, Microsoft .NET Framework will be installed automatically, if internet access is given.

## Install ToolKit Configuration Files

1. Please scan the QR code or use the link.
2. Please go to the section "Configuration Files" and select the part number (P/N) and revision of your device

Alternatively ToolKit configuration files can be downloaded from our Website. Please proceed as follows:

1. Go to <https://www.woodward.com/en/support/industrial/technical-help-desk/control-configuration-files>
2. Please insert the part number (P/N) and revision of your device into the corresponding fields
3. Select ToolKit in the application type list
4. Click "Search"

**NOTE**

ToolKit is using the following files:

**\*.WTOOL**

File name composition: [P/N1]\*1-[Revision]\_[Language ID]\_[P/N2]\*2-[Revision]\_[# of visualized gens].WTOOL

Example file name: 8440-1234-NEW\_US\_5418-1234-NEW.WTOOL

Content of the file: Display screens and pages for online configuration, which are associated with the respective \*.SID file

**\*.SID**

File name composition: [P/N2]\*2-[Revision].SID

Example file name: 5418-1234-NEW.SID

Content of the file: All display and configuration parameters available in ToolKit

**\*.WSET**

File name composition: [user defined].WSET

Example file name: MSLC\_settings.WSET

Content of the file: Default settings of the ToolKit configuration parameters provided by the SID file or user-defined settings read out of the unit.


\*1 P/N1 = Part number of the unit

\*2 P/N2 = Part number of the software in the unit




## Starting ToolKit Software

1. Start ToolKit via Windows Start menu -> Programs -> Woodward -> ToolKit 4.x
2. Please press the button “Open Tool”




3. Go to the “Application” folder and open then the folder equal to the part number (P/N) of your device (e.g. 8440-1234). Select the wtool file (e.g. 8440-1234-NEW\_US\_5418-1234-NEW.wtool) and click “Open” to start the configuration file
4. Now the home page of the ToolKit configuration screen appears






## Configure ToolKit Software

1. Start the configuration by using the toolbar. Please go to Tools -> Options



2. The options window will be displayed



- a. Adjust the default locations of the configuration files
  - b. The displayed language can be selected here
3. The changes become effective after clicking "OK"



### NOTE

Please use the ToolKit online help for further information.



## Connecting ToolKit and the MSLC-2 Unit

For configuration of the unit via ToolKit two communication paths are possible:

### 1. Via USB

This is the easiest way to connect one ToolKit running @ one PC/laptop with one device each. Refer to *Connect ToolKit via USB* for details.

### 2. Via Ethernet

This configuration allows to use the already installed Ethernet connection for communication of the DSLC-2 units itself and the configuration of all units in the network with one ToolKit running @ one PC. This configuration needs more preparation. Refer to *Connect ToolKit via Ethernet* for details.

## Connect ToolKit via USB

For configuration of the unit with ToolKit via USB, please proceed as follows:

1. Connect this USB 2.0 (slave) device a USB cable with USB Type A (PC/laptop side) and Type B (Woodward device side).
2. Open ToolKit via Windows Start menu -> Programs -> Woodward -> ToolKit version 6.4 or higher.
3. Connect ToolKit by selected the corresponding COM Port.  
For more details see ToolKit Manual.



## Connect ToolKit via Ethernet




### NOTE

**It is recommended to connect ToolKit via Network A.  
Firewall settings must allow ToolKit to interact.**

For configuration of the unit via ToolKit please proceed as follows:

1. Connect your PC and the control unit via the Ethernet communications cable.
2. Open ToolKit via Windows Start *menu* -> *Programs* -> *Woodward* -> *ToolKit 4.x*
3. From the main ToolKit window, click File then select "Open Tool"... or click the Open Tool icon  on the tool bar.
4. Locate and select the desired tool file (\*.WTOOL) in the ToolKit data file directory and click Open.
5. From the main ToolKit window, click the icon  Connect on the toolbar.



The connect dialog window will open if the option is enabled.



**Adding Devices:**

- In the field Host Name/Address an IP Address can be entered - for example for Device ID = 33 - and then pressing the “Add Button”,

Select a network:

Network

COM5  
COM6  
COM1  
TCP/IP  
USB-to-CAN II 34315748-3130-3137-0000-00000...  
USB-to-CAN II 34315748-3130-3137-0000-00000...

Protocol: Servlink

Check the devices to connect to:

Alias	Host Name	Port
<input checked="" type="checkbox"/>	192.168.0.33	192.168.0.33 666

Host Name/Address: 192.168.0.33 Port: 666 Add

☐ Always connect to my last selected network.

Connect

**NOTE**

Please take care that the IP address is correct. It must fit to the device settings and not be used twice!

- Devices 34, 35, and 36 can be added accordingly:

Protocol: Servlink

Check the devices to connect to:

Alias	Host Name	Port
<input checked="" type="checkbox"/>	192.168.0.36	192.168.0.36 666
<input checked="" type="checkbox"/>	192.168.0.35	192.168.0.35 666
<input checked="" type="checkbox"/>	192.168.0.34	192.168.0.34 666
<input checked="" type="checkbox"/>	192.168.0.33	192.168.0.33 666

**Deleting/Renaming Devices:**

Mouse right click on a selected IP Address, then “Delete” or “Rename” is possible.

**NOTE**

If one ToolKit is connected to a device all (!) other ToolKit access in this system is disabled for both Networks A and B. The number of the connected device will be displayed on the top of the ToolKit screen left beside the Menu number.

How to connect to a certain device and to swap control from one to another device is described below:




## Selecting devices for ToolKit communication


- Click on “Connect”:




- Click on „Details“:




- In row of device 35 click on <None> pull-down button and select „ToolConfigurator“:



- Device 35 is selected:



- To select another device e.g., device 37, first deselect device 35:  
In row of device 35 click on < ToolConfigurator> pull-down button and select „ None “



- Then in row of device 37 click on <None> pull-down button and select „ToolConfigurator“ as described above. Selection works with one of the connected devices so deselect the other first!



### NOTE

The Device ID is important for system management. Device ID and/or other IP address mismatch can cause reduced functionality of missing member alarm or even loss of control. Use System update (parameter 7789) for changing device ID! See chapter on page 91 for more details.



### NOTE

Device access always is depending on the device's current password level. Be aware of each device's password level—especially if connecting to several devices as described above! E.g., loading .wset files is depending on the password level. Only parameters with the device's current password level or lower will be loaded:  
Different password levels = different load results!



## View MSLC-2XT Data with ToolKit

The following figure shows an example visualization screen of ToolKit:




Figure 3-1: ToolKit - visualization screen

Navigation through the various visualization and configuration screens is performed by clicking on the and icons, by selecting a navigation button (e.g. ), or by selecting a screen from the drop-down list to the right of the arrow icons.

It is possible to view a trend chart of up to eight values with the trending tool utility of ToolKit. The following figure shows a trending screen of the measured power supply value:




Figure 3-2: ToolKit - analog value trending screen

Each visualization screen provides trending of monitored values by right-clicking on a value and select-



ing the "Add to trend" function. Trending is initiated by clicking on the Start button. Clicking the Export... button will save the trend data to a Comma Separated Values (CSV) file for viewing, editing or printing with office software, like Microsoft Excel, etc. The Properties... button is used to define high and low limits of the scale, sample rate, displayed time span and color of the graph.

## Configuring the MSLC-2XT with ToolKit

The following figure shows an example configuration screen of ToolKit:







Figure 3-3: ToolKit - configuration screen

Entering a new value or selecting a value from a defined list will change the value in a field. The new value is written to the controller memory by changing to a new field or pressing the Enter key.

Navigation through the various configuration and visualization screens is performed by clicking on the  and  icons, by selecting a navigation button (e.g. ), or by selecting a screen from the drop-down list to the right of the arrow icons.



## The MSLC-2XT Version Page

The ToolKit version page allows you to check the serial number of the unit and versions of the boot-loader, operating system and GAP application.




Figure 3-4: ToolKit -version page



## Menu (Setpoint) Description



All parameters are assigned a unique parameter identification number (ID). The parameter identification number may be used to reference individual parameters listed in this manual. This parameter identification number is also displayed in the ToolKit configuration screens next to the respective parameter.

### MSLC-2XT – Homepage

The appearance of the MSLC-2 Homepage depends on the configuration. If the MSLC-2 type is configured as “Utility” MSLC-2 (parameter 7628), values and pictures are displayed in the sense being located at the utility. On the other side, the “Tie” configured MSLC-2 shows values and pictures related to a tie-breaker sense.

This is the basic page of the MSLC-2. It gives general information, such as:

- The system A condition
- The system B (busbar) condition
- The condition of the breaker
- The current operating action
- The load and reactive load output to the DSLC-2
- The segment breaker state




Figure 3-5: ToolKit - home page (MSLC-2 configured as utility breaker control)






Figure 3-6: ToolKit - home page (MSLC-2 configured as tie-breaker control)

## General

ID	Parameter	CL	Setting range	Format	Description
4602	<b>Synchronizer mode</b>	-	Off / Check / Permissive / Run / Close Timer/ Sync Timer / Synchronized / Auto-Off / Manual	-	Display of the different <i>Synchronizer modes</i> : <b>Off</b> : The synchronizer is not active. <b>Check</b> : The synchronizer runs in check mode. <b>Permissive</b> : The synchronizer runs in permissive mode. <b>Run</b> : The synchronizer is full active. <b>Close Timer</b> : This is the CB close command. <b>Sync Timer</b> : The synchronizer is stopped, because of a sync time-out. <b>Synchronized</b> : The CB is closed. <b>Auto-Off</b> : The synchronizer is stopped, because of an unsuccessful closure of the CB. (Resync is disabled). <b>Manual</b> : manual synchronization
7672	<b>Reactive load control mode</b>	-	Off / Inactive / Voltage Control / VAR Control / Power Factor Control / Const Gen PF Control /	-	Display of the different <i>Reactive load control modes</i> : <b>Off</b> : The reactive load control mode is disabled. <b>Inactive</b> : The reactive load control is not active. <b>Voltage Control</b> : The voltage control is active. <b>VAR Control</b> : The reactive load control with kvar reference is active. <b>Power Factor Control</b> : Power factor control is active. <b>Const Gen PF Control</b> : The reactive load control with a constant power factor reference is active.
4603	<b>Load control mode</b>	-	Off Line / Inactive / Base Load / Base Load Lower / Base Load Raise / Base Load Remote /	-	Display of the different <i>Load control modes</i> : <b>Off Line</b> : The load control mode is disabled. <b>Inactive</b> : The load control mode is inactive. <b>Base Load</b> : The Load control is in base load. <b>Base Load Lower</b> : A base load lower command is active. <b>Base Load Raise</b> : A base load raise command is active. <b>Base Load Remote</b> : The load reference is controlled by an analog remote input. <b>Process Control</b> : The process control is full active



ID	Parameter	CL	Setting range	Format	Description
			Process Control / Process Lower / Process Raise / Process Remote / Process Ramp / Import Export Control / Import Export Ramp / Import Export Remote / Imp Exp Lower / Imp Exp Raise / Utility Unload		<b>Process Lower:</b> A process reference lower command is active. <b>Process Raise:</b> A process reference raise command is active. <b>Process Remote:</b> The process reference is controlled by an analog remote input <b>Process Ramp:</b> The generators are ramped into process control <b>Import Export Control:</b> The Import Export control is active. <b>Import Export Ramp:</b> The generators are being ramped into Im / Ex control <b>Import Export Remote:</b> The Import Export reference is controlled by an analog remote input <b>Imp Exp Lower:</b> An Import Export lower command is active. <b>Imp Exp Raise:</b> An Import Export raise command is active. <b>Utility Unload:</b> The utility or tie-breaker is being unloaded.

Table 3-1: Parameter – homepage - General

## Setpoints

ID	Parameter	CL	Setting range	Format	Description
4627	Setpoint frequency	-	Info	0.00 Hz	The field indicates the current <i>Setpoint Frequency</i> in Hz.
4628	Setpoint voltage	-	Info	0.00%	The field indicates the current <i>Setpoint Voltage</i> in percentage.
4629	Setpoint load level	-	Info	0.00%	Indicates the load level setpoint in percentage.
4630	Setpoint re-active power	-	Info	0.00%	Indicates the reactive load level setpoint in percentage.
4631	Setpoint constant generator PF	-	Info	0.00	The field indicates the constant generator power factor setpoint sent to the DSLC-2. <b>NOTE:</b> This field only indicates values if "VAR PF control mode" (parameter 7558) is configured to "Constant Generator PF".
7721	Import / export reference		Info	0.0 kW	The field indicates the current import / export setpoint for the MSLC-2 in kW.
7722	Reactive load reference	-	Info	0.0 kvar	The field indicates the current reactive load setpoint for the MSLC-2 in kvar.

Table 3-2: Parameter – homepage - Setpoints

## Process control

ID	Parameter	CL	Setting range	Format	Description
4605	Process reference	-	Info	0.0%	The field indicates the current <i>Process reference</i> value of the MSLC-2 process control in percentage.
7726	Process reference	-	Info	0.0 kW	The field indicates the current <i>Process reference</i> value of the MSLC-2 process control in engineering units.
4600	Process signal input	-	Info	0.0%	The field indicates the real <i>Process signal input</i> value of the MSLC-2 process control in percentage.
7727	Process signal input	-	Info	0.0 kW	The field indicates the real <i>Process signal input</i> value of the MSLC-2 process control in engineering units.
5535	Load level		Info	0.00%	The gage indicates the load setpoint going to the DSLC-2.
5635	Reactive load level		Info	0.00%	The gage indicates the reactive load setpoint going to the DSLC-2.
4639	Synchroscope	-	Info	0°	The gage illustrates a <i>Synchroscope</i> for the relation system A voltage to system B voltage in degrees.
4637	Automatic segment allocation	-	Info	0	The field indicates the segment number for this unit.

Table 3-3: Parameter – homepage – Process control






Figure 3-7: ToolKit - home page - MSLC-2 configured as utility breaker control

If the electrical diagram is shown in “Red” the electrical bar is live. Respectively an electrical diagram shown in “Green” means a dead bar. \*<sup>1</sup>

<p><b>1</b></p> <p><b>Q Sum:</b> Sum of all real reactive loads in the same segment in kVar.  <b>P Sum:</b> Sum of all real loads in the same segment in kW.  <b>Q:</b> Real reactive load of this path in kVar.  <b>P:</b> Real load of this path in kW.  <b>PF:</b> Power factor in this path.  <b>I:</b> Average current of this path in A.  <b>Ph-N:</b> Average Phase-neutral voltage of System A in Volt.  <b>Ph-Ph:</b> Average Phase-phase voltage of System A in Volt.  <b>f:</b> Real frequency of System A in Hz.</p>	<p><b>2</b></p> <p><b>V:</b> System B voltage Volt.  <b>f:</b> Real frequency of System B in Hz.</p>
	<p><b>3</b></p> <p><b>7726 Process reference:</b> kW - Example of a configurable engineering unit.  <b>7727 Process signal input:</b> kW - Example of a configurable engineering unit.</p>
	<p><b>4</b></p> <p><b>LED: Process PID active</b> – Indicates that the process control PID is activated.  <b>LED: Remote Reference</b> – Indicates that the load control or the reactive load control setpoint comes by analog input.</p>

\*<sup>1</sup> The parameter *Dead bus detection max. volt.* (parameter 5820) defines the dead bus condition.







Figure 3-8: ToolKit - home page - MSLC-2 configured as tie-breaker control

If the electrical diagram is shown in “Red” the electrical bar is live. Respectively an electrical diagram shown in “Green” means a dead bar. \*1



\*1 The parameter *Dead bus detection max. volt.* (parameter 5820) defines the dead bus condition.





Figure 3-9: ToolKit - home page - segments

This figure indicates which segments in the DSLC-2 / MSLC-2 system are interconnected.





## Menu 1 – Synchronizer

This menu contains the adjustments of the synchronizer.




Figure 3-10: ToolKit – synchronizer

### PID Frequency Control

ID	Parameter	CL	Setting range	Default	Description
4539	<b>Frequency synchronizer proportional gain</b>	2	0.01 to 100.00	0.80	Frequency sync gain determines how fast the synchronizer responds to an error in speed or phase. Adjust gain to provide stable control during synchronizing. Lower value to slow response.
4540	<b>Frequency synchronizer integral gain</b>	2	0.00 to 20.00	0.50	Frequency sync integral gain compensates for delay in the synchronizer control loop. Prevents low frequency hunting and damping (overshoot or undershoot). Lower value to slow response.
5505	<b>Phase matching gain</b>	2	1 to 99	5	The <i>Phase matching gain</i> increases or decreases the influence of the phase angle deviation to the frequency control. Prevents frequency hunting and damping (overshoot or undershoot) when the synchronizer is enabled with phase matching function.
5506	<b>Phase matching df-start</b>	2	0.02 to 0.25 Hz	0.05 Hz	Phase matching is started if the frequency difference between the systems to be synchronized is below the configured value.
5707	<b>Phase matching CB dwell time</b>	2	0 to 60.0 s	0.5 s	Dwell Time: This is the minimum time that the system A voltage, frequency and phase angle must be within the configured limits before the breaker will be closed. Set to lower time for quicker breaker closure commands.
5516	<b>Start frequency control level</b>	1	0.00 to 70.00 Hz	55.00 Hz	The frequency controller is activated when the monitored system B frequency has exceeded the value configured in this parameter. This prevents the MSLC-2 from attempting to control the frequency while the engine is completing its start sequence.



ID	Parameter	CL	Setting range	Default	Description
5517	Start frequency control delay	1	0 to 999 s	1 s	The frequency controller is enabled after the configured time for this parameter expires.
7783	Freq. Control setpoint source		Internal / Interface	Internal	This setting determines from which source the Frequency control setpoint comes:  <b>Internal:</b> The setpoint parameter 1750 System rated frequency is valid. <b>Interface:</b> The setpoint comes via RS-485 Modbus or TCP/IP Modbus Interface with parameter 7641.

Table 3-4: Parameter – synchronizer – PID frequency control

## PID Voltage Control

ID	Parameter	CL	Setting range	Default	Description
5610	Voltage synchronizer proportional gain	2	0.01 to 100.00	1.00	Voltage sync gain determines how fast the synchronizer responds to a voltage deviation. Adjust gain to provide stable control during synchronizing. Lower value to slow response.
5611	Voltage synchronizer integral gain	2	0.01 to 100.00	0.50	Voltage sync integral gain compensates for delay in the synchronizer voltage control loop. Prevents low voltage hunting and damping (overshoot or undershoot) when the synchronizer is enabled. Lower value to slow response.

Table 3-5: Parameter – synchronizer – PID voltage control

## Synchronizer Control

ID	Parameter	CL	Setting range	Default	Description
5730	Synchronization CB	2	Slip frequency./. Phase matching	Slip frequency	<b>Slip frequency:</b> The frequency controller adjusts the frequency in a way, that the frequency of the variable system is marginal greater than the fixed system. When the synchronizing conditions are reached, a close command will be issued. The slipping frequency depends on the setting of <i>Slip frequency setpoint offset</i> (parameter 5502). <b>Phase matching:</b> The frequency controller adjusts the phase angle of the system B to that of the system A. <b>NOTE:</b> In the Permissive mode, phase matching is internally switched.
4712	Slip frequency setpoint offset	2	-0.50 to 0.50 Hz	0.10 Hz	This value is the offset for the synchronization to the variable system to the fixed system. With this offset, the unit synchronizes with a positive or negative slip.  <b>Example:</b> If this parameter is configured to 0.10 Hz and the busbar/mains frequency is 60.00 Hz, the synchronization setpoint is 60.10 Hz. If this parameter is configured to -0.10 Hz and the busbar/mains frequency is 60.00 Hz, the synchronization setpoint is 59.90 Hz.
5701	Positive frequency differential CB	2	0.02 to 0.49 Hz	0.18 Hz	The prerequisite for a close command being issued for the CB is that the differential frequency is below the configured differential frequency. This value specifies the upper frequency (positive value corresponds to positive slip > system B frequency is higher than system A frequency).
5702	Negative frequency differential CB	2	-0.49 to 0.00 Hz	-0.10 Hz	The prerequisite for a close command being issued for the CB is that the differential frequency is above the configured differential frequency. This value specifies the lower frequency limit (negative value corresponds to negative slip > system B frequency is less than system A frequency).
4717	Phase window extended maximum	2	0.0 to 60.0 °	10.0 °	When closing the last breaker in a ring structure, the phase window for the synchronizer is extended by this value



ID	Parameter	CL	Setting range	Default	Description
7513	Voltage matching	2	Disabled / Enabled	Enabled	Enables or disables the synchronizer voltage matching function. Independent on this setting the voltage control is still executed but the synchronizer does not care about the voltage matching.
4541	Voltage window	2	0.50 to 10.00%	0.50%	The maximum permissible voltage differential for closing the breaker is configured here. If the difference between system A and system B voltage does not exceed the value configured here and the system A/B voltages are within the according operating voltage windows, the "Command: Breaker Close" may be issued.  <b>NOTE:</b> When Voltage matching (parameter 7513) is "Disabled", the voltage window is set to the maximum value of 10%.
4718	Voltage window extended max.	2	0.50 to 20.00%	10.0%	When closing the last breaker in a ring structure, the voltage window for the synchronizer is extended by this value  <b>NOTE:</b> In Menu 5, the Upper and Lower Voltage limit must be adapted (Parameter 5800 and 5801)
5705	Breaker delay	2	40 to 300 ms	80 ms	The inherent closing time of the CB corresponds to the lead-time of the close command. The close command will be issued independent of the differential frequency at the entered time before the synchronous point.
3417	CB close hold time	2	0.10 to 1.0 s	0.50 s	The time of the pulse output may be adjusted to the breaker being closed. <b>NOTE: Higher settings than the default value need attention in case of black busbar closing! It must be ensured that no other MSLC/DSLC tries to close to the dead busbar during this time is running.</b>
3421	CB open monitoring	2	0.10 to 5.00 s	2.00 s	If the "Reply: Breaker Open" is not detected as energized once this timer expires, a "CB fail to open" alarm is issued. This timer initiates as soon as the "Open breaker" sequence begins.
7514	Auto resynchronization	2	Disabled / Enabled	Enabled	Switch for automatic GCB close attempts. <b>Disabled:</b> The device executes one close attempt, no automatic retry. <i>Synchronizer mode</i> parameter 4602 displays "auto-off" at the home page. For a new retry RUN order must be cycled. <b>Enabled:</b> The device automatically retries closing CB. If the <i>Reclose limit alarm</i> parameter 7556 is enabled, and the number of <i>CB maximum close attempts</i> parameter 3419 is expired the automatic retries will be stopped. <b>NOTE: As long as the device is executing retries due to dead busbar closure the other controls in the system are blocked in dead busbar closure.</b>
3419	CB maximum closing attempts	2	1 to 10	5	The maximum number of breaker closing attempts. <b>NOTE: Not valid in the Permissive mode. Close attempt counter is reset after new RUN order or if GCB close time expired 5 s.</b>
4534	Reclose delay	2	1 to 1000 s	2 s	The time between attempts to close the circuit breaker.
7556	Reclose limit alarm	2	Disabled / Enabled	Disabled	Switch for an alarm to be generated when reaching the maximum number of (automatic) close attempts. <b>Disabled:</b> Automatic re-synchronization (reclose) is not monitored. No alarm is caused to stop close attempts. <b>Enabled:</b> Reclose attempts are counted and compared with <i>CB maximum closing attempts</i> parameter 3419. If maximum is reached, the alarm stops further close attempts. <b>NOTE: Not valid in the Permissive mode.</b>
7557	Synchronizer timeout alarm	2	Disabled / Enabled	Disabled	This setting enables or disables the alarm generated by exceeding the synch timeout interval without achieving synchronization. <b>NOTE: Not valid in the Permissive mode.</b>
3063	Synchronizer timeout	2	3 to 999 s	60 s	This is the interval over which the synchronizer will attempt to achieve synchronization. The interval begins when system A voltage is in operating range and the run mode is activated. Failure to get a "CB Aux" contact closure within the specified time will result in a synch timeout alarm. The synchronizer must be set to "Off" mode to clear the interval timer and alarm.



ID	Parameter	CL	Setting range	Default	Description
5503	Freq. control setpoint ramp	2	0.10 to 60.00 Hz/s	2.50 Hz/s	The slope of the ramp is used to alter the rate at which the controller modifies the setpoint value. The greater the value, the faster the change.
Phase matching					
5703	Max. positive phase window CB	2	0.0 to 60.0 °	5.0 °	The prerequisite for a close command being issued for the CB is that the leading phase angle between system B and system A is below the configured maximum permissible angle.
5704	Max. negative phase window CB	2	-60.0 to 0.0 °	-5.0 °	The prerequisite for a close command being issued for the CB is that the lagging phase angle between system B and system A is above the configured minimum permissible angle.
Manual synchronizer					
4713	DI raise frequency ramp	2	0.01 to 100,00% rated/s	0,04% rated/s	Digital Input: Raise frequency ramp as percentage rated delta frequency per second
4714	DI lower frequency ramp	2	0.01 to 100,00% rated/s	0,04% rated/s	Digital Input: Lower frequency ramp as percentage rated delta frequency per second
Phase angle compensation					
8841	Phase angle compensation MCB	2	On / Off	Off	The phase angle between busbar voltage and mains voltage can be compensated according to an installed power transformer between busbar and mains. On: The compensation is active. The phase will be compensated according the value configured in parameter 8842 config. Off: The compensation is inactive. The phase angle is directly taken from the measurement. Notes WARNING: Ensure the following parameters are configured correctly to prevent erroneous synchronization settings. Incorrect wiring of the system cannot be compensated for with this parameter! Please check during initial commissioning the phase angle and the synchronization with a zero voltmeter. Recommendation: For safety reasons, please mark the MSLC2 with a label showing the configured phase angle compensation. Refer to the configured phase angle compensation.ase on page 217 for details.
8842	Phase angle MCB	2	-180 to 180°	0°	The phase angle compensation corrects the degree between busbar voltage and mains voltage. The configured degree is added to the real measured phase angle.
Dead bus closure					
7555	Dead bus closure	2	Disabled / Enabled	Enabled	Enables or disables the synchronizer's automatic deadbus detection and breaker closure functions. When enabled, the synchronizer will insure a breaker closure signal when a dead-bus is detected. (This incorporates the dead busbar closure negotiation to potential other DSLC-2 or MSLC-2 devices)  <b>NOTE:</b> In Menu 1 you find more settings related to the dead busbar closure.
5820	Deadbus detection max. volt.	2	0 to 30%	10%	Adjustable voltage in percentage of system A or B rated voltage for deadbus detection.

Table 3-6: Parameter – synchronizer – synchronizer control



## CAUTION

Ensure the previous parameters are configured correctly to prevent erroneous synchronization settings. Incorrect wiring of the system cannot be compensated for with these parameters!



## Menu 2 – Load Control

This menu contains the adjustments for load control.

File View Device Settings Tools Help

Active code level 0 Device 33 MENU 2 - LOAD CONTROL

**PID import/export control**

5510 Import/export control proportional gain 1.00

5511 Import/export control integral gain 0.50

5512 Import/export control derivative ratio 0.01

**Power control monitoring**

7504 High load limit alarm Disabled

4709 High load limit PU 100 %

4526 High load limit DO 90 %

7505 Low load limit alarm Disabled

4710 Low load limit PU 0 %

4528 Low load limit DO 5 %

7506 Load limit switch Disabled

7616 Gen load high limit alarm Disabled

7617 Gen load low limit alarm Disabled

7618 Gen load limit switch Disabled

4529 Gen load switch 1 PU 0 %

4530 Gen load switch 1 DO 10 %

4538 Gen load switch 2 PU 100 %

4543 Gen load switch 2 DO 90 %

**Power control**

7634 Load control setpoint source Internal

1752 System A rated load 1600.0 kW

7717 Import / export level 50.0 kW

3125 Generator unload trip 5.0 %

4506 Utility unload trip 75 kW

3123 Utility unload trip time 20 s

4524 Unload ramp rate 3.00 %/s

4700 Load ramp rate 3.00 %/s

4515 Raise load rate 1.00 %/s

4516 Lower load rate 1.00 %/s

4523 Import/export droop 0.0 %

**Import / export level via interface**

7755 Interface switch Import Export Export

Connected on COM2 Details...

Figure 3-11: ToolKit – load control

### PID Import/Export Control

ID	Parameter	CL	Setting range	Default	Description
5510	Import/export control proportional gain	2	0.01 to 100.00	1.00	Import/export control proportional gain determines how fast the load control responds to an import/export load error. Gain is set to provide stable control. Lower the value for slower response.
5511	Import/export control integral gain	2	0.01 to 100.00	0.50	Import/export control integral gain compensates for lags in the load control loop. It prevents slow hunting and controls damping (overshoot or undershoot) after a load disturbance. Lower the value for slower response.
5512	Import/export control derivative ratio	2	0.01 to 100.00	0.01	Import/export control derivative ratio adjusts the rate of change in the load command during a load transient.


Table 3-7: Parameter – load control – PID import/export control



## Power Control Monitoring

### High Load Monitoring

This monitoring function observes if the system A power exceeds either an export power or an import power. In other words an alarm can be raised if either an export or import load is higher than a configurable limit. So the monitor checks if in both power directions a high limit is exceeded.



ID	Parameter	CL	Setting range	Default	Description
7504	High load limit alarm	2	Disabled / Enabled	Disabled	The <i>High load limit alarm</i> enables the high load limit alarm output caused by the high load monitor. Additionally if the Load limit switch ID7506 is enabled the relay 3 (terminal 44) is energized.
4709	High load limit PU	2	-150 to 150%	100%	The <i>High load limit PU</i> (pickup) is the import/export load level where (if enabled) the "High Limit" relay is energized and the high limit alarm is activated. The percentage value relates to system A rated load (parameter 1752).
4526	High load limit DO	2	-150 to 150%	90%	The <i>High load limit DO</i> (dropout) is the import/export load level where (if enabled) the "High Limit" relay is de-energized and the high limit alarm is deactivated. The percentage value relates to system A rated load (parameter 1752).

Table 3-8: Parameter – load control – power control monitoring




### NOTE

A negative percentage value of parameter ID4709 High Load Limit PU and ID4526 High Load Limit DO has no influence in the functionality.



## Low Load Monitoring

This monitoring function observes if the system A power fall below either an export power or an import power. In other words an alarm can be raised if either an export or import load is lower than a configurable limit. So the monitor checks if for both power directions a low limit is underrun.



ID	Parameter	CL	Setting range	Default	Description
7505	<b>Low load limit alarm</b>	2	Disabled / Enabled	Disabled	The <i>Low load limit alarm</i> enables the low load limit alarm output caused by the low load monitor. Additionally if the Load limit switch ID7506 is enabled the relay 4 (terminal 45) is energized.
4710	<b>Low load limit PU</b>	2	0 to 100%	0%	The <i>Low load limit PU</i> (pickup) is the import/export load level where (if enabled) the "Low Limit" relay is energized and the low limit alarm is activated. The percentage value relates to system A rated load (parameter 1752).
4528	<b>Low load limit DO</b>	2	2 to 100%	5%	The <i>Low load limit DO</i> (dropout) is the import/export load level where (if enabled) the "Low Limit" relay is deenergized and the low limit alarm is deactivated. The percentage value relates to system A rated load (parameter 1752).

Table 3-8: Parameter – load control – power control monitoring

## Load Limit Switch

The load limit switch function can transfer the expired High and Low limits trips to the according high and low limit alarms and relays.

ID	Parameter	CL	Setting range	Default	Description
7506	<b>Load limit switch</b>	2	Disabled / Enabled	Disabled	<i>Load limit switch</i> specifies if the "High Limit" and "Low Limit" trigger shall activate the high and low limit relays.

Table 3-8: Parameter – load control – power control monitoring



## Gen Load Monitoring

### Generator Load High Limit Alarm

With this alarm function a high limit alarm is issued if not enough generator power in the own segment is available. The Gen load high limit alarm is triggered if the setpoint sent to the generators reaches 100%. Additionally if the Gen load limit switch ID7618 is enabled the relay 3 "High Limit" (terminal 44) is energized.

### Generator Load Low Limit Alarm

With this alarm function a low limit alarm is issued if no generator power in the own segment is required. The Gen load low limit alarm is triggered if the setpoint sent to the generators reaches 0% level. Additionally if the Gen load limit switch ID7618 is enabled the relay 4 "Low Limit" (terminal 45) is energized.

ID	Parameter	CL	Setting range	Default	Description
7616	<b>Gen load high limit alarm</b>	2	Disabled / Enabled	Disabled	<i>Generator load high limit alarm</i> enables the generator high limit alarm and activates (if enabled) the "High Limit" relay (Terminal 44). The generator high limit alarm is activated when the MSLC-2 is required to output a system load of 100% to the DSLC-2 controls in order to meet its reference.
7617	<b>Gen load low limit alarm</b>	2	Disabled / Enabled	Disabled	<i>Generator load low limit alarm</i> enables the generator low limit alarm and activates (if enabled) the "Low Limit" relay (Terminal 45). The generator low limit alarm is activated when the MSLC-2 is required to output a system load of 0% to the DSLC-2 controls in order to meet its reference.

Table 3-8: Parameter – load control – power control monitoring

### Generator Load Limit Switch

The Generator load limit switch function puts the generator load switch 1 flag on relay 11 and the generator load switch 2 flag on relay 12. Refer to Generator Load Switch 1 + 2 for more details.

ID	Parameter	CL	Setting range	Default	Description
7618	<b>Gen load limit switch</b>	2	Disabled / Enabled	Disabled	<i>Generator load limit switch</i> specifies if the high and low limit alarms will activate the "Load Switch 1" or "Load Switch 2" relay when the system load setpoint reaches 100% or respectively 0%.

Table 3-8: Parameter – load control – power control monitoring


### Generator Load Switch 1 + 2

The generator load switches 1 + 2 monitors the DSLC-2 system load in the own segment with a limit and a hysteresis. According to the configuration of "Gen load switch PU" and "Gen load switch DO" the value is monitored on a lower limit or an higher limit. Each monitor sets a tripping flag.

### Low Limit Monitoring

If the pickup (PU) entry is lower or equal as the dropout (DO) entry a flag is set if the system load underruns the PU limit. If then the system load is equal or overruns the DO entry the flag will be reset.






Example underrun: With decreasing load the flag is set.

### High Limit Monitoring

If the pickup (PU) entry is higher or equal as the dropout (DO) entry a flag is set if the system load overruns the PU limit. If then the system load is equal or underruns the DO entry the flag will be reset.



Example overrun: With increasing load the flag is set.

ID	Parameter	CL	Setting range	Default	Description
4529	Gen Load switch 1 PU	2	0 to 100%	0%	Generator Load switch 1 PU (pickup) is the system load level where the "Load Switch1" relay is energized.
4530	Gen Load switch 1 DO	2	0 to 100%	10%	Generator Load switch 1 DO (dropout) is the system load level where the "Load Switch1" relay is de-energized.
4538	Gen Load switch 2 PU	2	0 to 100%	100%	Generator Load switch 2 PU (pickup) is the system load level where the "Load Switch2" relay is energized.
4543	Gen Load switch 2 DO	2	0 to 100%	90%	Generator Load switch 2 DO (dropout) is the system load level where the "Load Switch2" relay is de-energized.

Table 3-8: Parameter – load control – power control monitoring



## Power Control

ID	Parameter	CL	Setting range	Default	Description
7634	Load control setpoint source	2	Internal / Interface	Internal	This setting determines from which source the load reference for the import / export power control comes:  <b>Internal:</b> The setpoint parameter 7717 is valid or the analog input. The analog remote load reference input is valid, when DI "Load Raise" and DI "Load Lower" are closed. <b>Interface:</b> The setpoint comes via RS-485 Modbus or TCP/IP Modbus Interface.
1752	System A rated load	2	1 to 999999.9 kW	250.0 kW	This value specifies a rated power at the interchange point or over the tie-breaker. This real power rating is the reference for several functions, like power control monitoring or ramp scaling.  <b>NOTE:</b> During active power control, the System A rated load value (parameter 1752) may not be changed. The power plant has to be shut down and the MCB has to be opened.
7717	Import / export level	0	-999999.9 to 999999.9 kW	20.0 kW	This value is the load setpoint for the import export control. The value gets active when the load control setpoint source (parameter 7634) is configured for "Internal".  <b>Note:</b> This value is bypassed in the moment of using the raise / lower setpoint function by DI. The value is triggered, if the "CB Aux" goes open and close or another load setting is configured.
3125	Generator unload trip	2	0.5 to 99.9%	3.0%	Generator unload trip is the percentage limit of the system load level sent to the DSLC-2s, which must be reached before issuing the local/gen bus breaker open command.  <b>NOTE:</b> The local/gen bus unload mode will be activated, if the "Load Lower" DI is given continuously while in the base load control mode.
4506	Utility unload trip	2	0 to 30000 kW	5 kW	Utility unload trip is the load level that the MSLC-2 must be below before issuing the utility breaker open command during a utility unload.
3123	Utility unload trip time	2	3 to 999 s	60 s	If the monitored system A power does not fall below the limit configured in parameter 3125 before the time configured here expires, a "Breaker open" command will be issued together with an alarm.
4524	Unload ramp rate	2	0.01 to 100.00%/s	3.00%/s	Unload ramp rate is the rate at which the control ramps between modes in%/sec. Remember, this refers to unloading the utility, which is then loading the generator set.
4700	Load ramp rate	2	0.01 to 100.00%/s	3.00%/s	Load ramp rate is the rate at which the control ramps between modes in%/sec. Remember; this refers to loading the utility, which is then unloading the generator set.
4515	Raise load rate	2	0.01 to 100.00%ss	1.00%/s	This is the rate the internal load reference increases, when the discrete input raise load command is activated.  <b>NOTE:</b> Modbus reference changes will follow this value.
4516	Lower load rate	2	0.01 to 100.00%ss	1.00%/s	This is the rate the internal load reference decreases, when the discrete input lower load command is activated.  <b>NOTE:</b> Modbus reference changes will follow this value.
4523	Import / export droop	2	0.0 to 100.0%	0.0%	Import / export droop is the droop setting for the import/export controller. The effect of droop is to make the control more resistant to variations from the import/export reference. This droop has the effect of causing the target import/export level to go towards a zero power transfer situation with increasing load. When set to the default value of zero the import/export control has no droop.

Table 3-9: Parameter – load control – power control



**Import / Export Level via Interface**

ID	Parameter	CL	Setting range	Default	Description
7755	<b>Interface switch import export</b>	2	Export / Import	Export	<p>This setting defines the setpoint argument for the power control setpoint transferred by interface. This setting gets active when the <i>Load control setpoint source</i> (parameter 7634) is configured to "Interface".</p> <p><b>Export:</b> The value send by interface is an export kW setpoint.  <b>Import:</b> The value send by interface is an import kW setpoint.</p>

Table 3-10: Parameter – load control – import/export level via interface



## Menu 3 – Process Control

This menu contains the adjustments for process control.




Figure 3-12: ToolKit – process control

### PID Process Control

ID	Parameter	CL	Setting range	Default	Description
4500	<b>Process control proportional gain</b>	2	0.01 to 100.00	3.00	The <i>Process control proportional gain</i> determines how fast the process control responds to an error between the process variable and reference. The gain is set to provide stable control of the process. Lower the value to slow the response.
4501	<b>Process control integral gain</b>	2	0.01 s to 100.00 s	3.00 s	The <i>Process control integral gain</i> compensates for delay in the process control loop. It prevents low frequency hunting and damping (overshoot or undershoot) when a process disturbance occurs. Lower the value to slow the response.
4502	<b>Process control derivative ratio</b>	2	0.01 to 100.00 s	0.01 s	The <i>Process control derivative ratio</i> adjusts the rate of change in speed bias output during a process level transient. Lower the value to slow the response.

Table 3-11: Parameter – process control – PID process control



## Process Control

ID	Parameter	CL	Setting range	Default	Description
7559	<b>Process control action</b>	2	Direct / Indirect	Indirect	The <i>Process control action</i> specifies if the process variable is direct or indirect acting.  <b>Direct:</b> If the process variable increases when generator load increases. <b>Indirect:</b> If the process variable decreases when generator load increases.
4508	<b>Process droop</b>	2	0.0 to 100.0%	0.0%	The <i>Process droop</i> is the load droop desired based on process level.
4509	<b>Process filter</b>	2	0 to 8	0	The <i>Process filter</i> adjusts the bandwidth of the filter on the process input. Higher frequency settings result in faster control response, but also more response to process noise.
7737	<b>Process reference</b>	0	-999999.9 to 999999.9	0.0	The <i>Process reference</i> is the internal reference for the process control. The process engineering units are determined by the selection and settings in Menu 6.1.
4504	<b>Raise reference rate</b>	2	0.01 to 20.00%/s	0.10%/s	The <i>Raise reference rate</i> is the rate at which the process reference is increased when the DI "Load Raise" command is activated.
4505	<b>Lower reference rate</b>	2	0.01 to 20.00%/s	0.10%/s	The <i>Lower reference rate</i> is the rate at which the process reference is decreased when the DI "Load Lower" command is activated.

Table 3-12: Parameter – process control – process control

## Process Signal Input Monitoring

ID	Parameter	CL	Setting range	Default	Description
7500	<b>Process high limit alarm</b>	2	Disabled / Enabled	Disabled	The <i>Process high limit alarm</i> specifies if the high process limit alarm is activated.
4510	<b>Process high limit PU</b>	2	0.0 to 150.0%	75.0%	The <i>Process high limit PU</i> is the process input level where (if enabled) the "High Limit" relay output is energized and the high limit alarm is activated.
4511	<b>Process high limit DO</b>	2	0.0 to 150.0%	75.0%	The <i>Process high limit DO</i> is the process input level where (if enabled) the "High Limit" relay output is de-energized and the high limit alarm is deactivated.
7501	<b>Process low limit alarm</b>	2	Disabled / Enabled	Disabled	The <i>Process low limit alarm</i> specifies if the low process limit alarm is activated.
4513	<b>Process low limit PU</b>	2	0.0 to 150.0%	50.0%	The <i>Process low limit PU</i> is the process input level where (if enabled) the "Low Limit" relay output is energized and the low limit alarm is activated.
4514	<b>Process low limit DO</b>	2	0.0 to 150.0%	50.0%	The <i>Process low limit DO</i> is the process input level where (if enabled) the "Low Limit" relay output is de-energized and the low limit alarm is deactivated.
7502	<b>Process switches</b>	2	Disabled / Enabled	Disabled	The <i>Process switch</i> specifies if the process high and low limits will activate the "High Limit" and "Low Limit" relay outputs.

Table 3-13: Parameter – process control – process signal input monitoring



## Menu 4 – Voltage/Var/PF Control

This menu contains the adjustments for reactive load control.

File View Device Settings Tools Help

Active code level: 0 Device: 33 MENU 4 - VAR / PF CONTROL

**Voltage control**

7784 Volt. control setpoint source: Internal

5600 Voltage control setpoint: 2400 V

5603 Voltage control setpoint ramp: 1.00 %/s

Manual synchronizer

4715 DI raise voltage ramp: 0.00 %rated/s

4716 DI lower voltage ramp: 0.00 %rated/s

**Voltage monitoring**

1770 System A voltage monitoring: Phase - phase

7510 Voltage high alarm: Disabled

4537 Voltage high limit: 110 %

7509 Voltage low alarm: Disabled

4536 Voltage low limit: 90 %

7511 Voltage switches: Disabled

7512 Voltage range alarm: Disabled

**PID VAR control**

5613 VAR control proportional gain: 0.50

5614 VAR control integral gain: 1.00

5615 VAR control derivative ratio: 0.01

**VAR control**

7558 VAR PF control mode: VAR Control

1758 System A rated react. power: 1200.0 kvar

7723 KVAR reference: 10.0 kvar

4690 Rated appar. power: 2000.0 kVA

5622 Reactive power setpoint ramp: 1.00 %/s

5620 Power factor reference: 1.000

5621 Constant gen. PF reference: 0.950

Interface: only for Power Factor control mode

7635 VAR control setpoint source: Internal

Figure 3-13: ToolKit – voltage/var/pf control

### Voltage Control

ID	Parameter	CL	Setting range	Default	Description
7784	<b>Voltage control setpoint source</b>		Internal / Interface	Internal	This setting determines from which source the Voltage control setpoint comes:  <b>Internal:</b> The setpoint parameter 5600 Voltage control setpoint is valid. <b>Interface:</b> The setpoint comes via RS-485 Modbus or TCP/IP Modbus Interface with parameter 7780.
5600	<b>Voltage control setpoint</b>	1	50 to 650.000 V	480 V	This value is the reference for the voltage controller when performing isolated and/or no-load operations. Usually the voltage control setpoint is the same like the rated voltage setting. In some cases it could be desired to have another setpoint in isolation operation.
5603	<b>Voltage control setpoint ramp</b>	2	1.00 to 300.00%/s	5.00%/s	The different setpoint values are supplied to the controller via this ramp. The slope of the ramp is used to alter the rate at which the controller modifies the setpoint value. A greater value will create a faster change in the setpoint.
<b>Manual synchronizer</b>					
4715	<b>DI raise voltage ramp</b>	2	000.01 to 100.00%/rated/s	000.05%/rated/s	Digital Input: Raise voltage ramp as percentage rated delta voltage per second
4716	<b>DI lower voltage ramp</b>	2	000.01 to 100.00%/rated/s	000.05%/rated/s	Digital Input: Lower voltage ramp as percentage rated delta voltage per second

Table 3-14: Parameter – voltage/var/pf control – voltage control



## Voltage Monitoring

ID	Parameter	CL	Setting range	Default	Description
1770	<b>System A voltage monitoring</b>	2	Phase - phase / Phase - neutral	Phase - phase	This configuration determines the monitored voltage type.  <b>Phase – phase:</b> Only the phase - phase voltages VL12, VL23 and VL31 are monitored. <b>Phase – neutral:</b> Only the phase - neutral voltages VL1N, VL2N and VL3N are monitored.
7510	<b>Voltage high alarm</b>	2	Disabled / Enabled	Disabled	The <i>Voltage high alarm</i> specifies if the high voltage limit alarm is activated.
4537	<b>Voltage high limit</b>	2	0 to 150%	110%	The <i>Voltage high limit</i> setting specifies the voltage high limit alarm trip point. The input is related to the rated voltage input configurable in Menu 5 (parameter 1766). (Hysteresis 2 %)
7509	<b>Voltage low alarm</b>	2	Disabled / Enabled	Disabled	The <i>Voltage low alarm</i> specifies if the low voltage limit alarm is activated.
4536	<b>Voltage low limit</b>	2	0 to 150%	90%	The <i>Voltage low limit</i> specifies the voltage low limit alarm trip point. The input is related to the rated voltage input configurable in Menu 5 (parameter 1766). (Hysteresis 2 %)
7511	<b>Voltage switch</b>	2	Disabled / Enabled	Enabled	The <i>Voltage switch</i> specifies if the voltage high and low limits will activate the “High Limit” and “Low Limit” relays.
7512	<b>Voltage range alarm</b>	2	Disabled / Enabled	Disabled	Enables or disables the voltage regulator bias output limit alarm. The alarm voltage range limit will be activated as soon as the value is outside the range 80-101 %.

Table 3-15: Parameter – voltage/var/pf control – voltage monitoring

## PID VAR Control

ID	Parameter	CL	Setting range	Default	Description
5613	<b>VAR control proportional gain</b>	2	0.01 to 100.00	1.00	Var/PF proportional gain determines how fast the var/PF control responds to an error signal between kvar/PF reference and kvar/PF actual measurement. The gain is set to provide stable control of kvars or power factor. Lower value to slow response. <b>PID var control loop is active:</b> <i>VAR PF control mode</i> (parameter 7558) <ul style="list-style-type: none"> <li>Var control</li> <li>PF control</li> </ul> Utility MSLC-2 is operating in <ul style="list-style-type: none"> <li>Import/export control</li> <li>Process control mode</li> </ul>
5614	<b>VAR control integral gain</b>	2	0.01 to 100.00	0.50	Var/PF integral gain compensates for delay in the reactive power control loop. This prevents low frequency overshoot or undershoot when a change in reactive power occurs. Lower value to slow response. <b>PID var control loop is active:</b> <i>VAR PF control mode</i> (parameter 7558) <ul style="list-style-type: none"> <li>Var control</li> <li>PF control</li> </ul> Utility MSLC-2 is operating in <ul style="list-style-type: none"> <li>Import/export control</li> <li>Process control mode</li> </ul>
5615	<b>VAR control derivative ratio</b>	2	0.01 to 100.00	0.01	Var/PF derivative ratio adjusts the rate of change of the voltage bias output during a load transient. Lower value to slow response. <b>PID var control loop is active:</b> <i>VAR PF control mode</i> (parameter 7558) <ul style="list-style-type: none"> <li>Var control</li> <li>PF control</li> </ul> Utility MSLC-2 is operating in <ul style="list-style-type: none"> <li>Import/export control</li> <li>Process control mode</li> </ul>

Table 3-16: Parameter – voltage/var/pf control – PID VAR control



## Var Control

ID	Parameter	CL	Setting range	Default	Description
7558	<b>VAR PF control mode</b>	2	PF Control / VAR Control / Constant Generator PF	VAR Control	<p>This setting specifies the reactive load controller:</p> <p><b>PF Control:</b> If the DI process control or DI import/export control is active, the control will maintain a constant PF across the utility tie (ID 5620). Otherwise the DSLC's are forced for a constant generator PF (ID 5621).</p> <p><b>VAR Control:</b> If the DI process control or DI import/export control is active, the control will maintain a constant var load level across the utility tie (ID 7723). Otherwise the DSLC's are forced for a constant generator PF (ID 5621).</p> <p><b>Constant Generator PF:</b> The control will always send a constant generator PF (ID 5621) to the DSLC-2.</p>
1758	<b>System A rated react. power</b>	2	0.1 to 999999.9 kvar	190.0 kvar	<p>This value specifies the system A reactive power rating, which is used as a reference figure for related functions.</p> <p>If unknown, set to 60% of the kVA or 80% of the kW rating, which is the kvar load at 0.8 lagging power factor.</p>
7723	<b>KVAR reference</b>	2	-999999.9 to 999999.9 kvar	10.0 kvar	This is the setpoint for the reactive load control when the <i>VAR PF control mode</i> is configured for "VAR control".
4690	<b>Rated appar. power</b>	-	Info	kVA	This field indicates the internal calculated appearance power which is calculated out of the kW and kvar rating.
5622	<b>Reactive power setpoint ramp</b>	2	0.01 to 100.00%/s	10.00%/s	When issuing of different setpoints or during ramp up and ramp down of the reactive load. The ramp setting is related to rated reactive power (parameter 1758).
5620	<b>Power factor reference</b>	1	- 0.5 to 0.5*  Displayed text in case of wrong input: "min -0.999, max 1.000"	1.000	<p>This is the setpoint for the reactive load control when the <i>VAR PF control mode</i> (parameter 7558) is configured for "PF control". The designations "-" and "+" stand for:</p> <ul style="list-style-type: none"> <li>Inductive/lagging (+) - generator supplying vars</li> <li>Capacitive/leading (-) - generator absorbing vars</li> </ul> <p><b>*NOTE:</b> ToolKit works fine but input error messaging has no adequate standard text available.</p>
5621	<b>Constant gen. PF reference</b>	1	-0.999 to 1.000	0.950	<p>This is the constant reference the MSLC-2 sends to the DSLC-2 controls (the reference level at which to maintain each DSLC-2 controls generator) when in constant generator power factor control mode. In this mode the DSLC-2 control will maintain a constant generator PF level regardless of the amount of vars being absorbed / generated across the utility tie. This setpoint is active when the <i>VAR PF control mode</i> (parameter 7558) is configured on "Constant Generator PF".</p> <p><b>NOTE:</b> The designations "+" stands for generate inductive/lagging reactive power with the generator. The designations "-" stands for absorb capacitive/leading reactive power with the generator.</p> <p><b>NOTE:</b> It is recommended that the constant generator power factor control mode be used in applications where the total generator kvar capacity is less than the kvar load of the system.</p>
Interface: only for Power factor control mode					
7635	<b>VAR control setpoint source</b>	2	Internal / Interface	Internal	<p>This parameter determines the reactive load control setpoint source:</p> <p><b>Internal</b></p> <p>The setpoint comes from:</p> <ul style="list-style-type: none"> <li><i>KVAR reference</i> (parameter 7723) at the interchange point when <i>VAR PF control mode</i> (parameter 7558) is configured on "VAR control".</li> <li><i>Power factor reference</i> (parameter 5620) at the interchange point when <i>VAR PF control mode</i> (parameter 7558) is configured on "PF control".</li> <li>Power factor reference at the interchange point over analog input (parameter 7718) when <i>VAR PF control mode</i> (parameter 7558) is configured on "PF control" and the remote</li> </ul>



ID	Parameter	CL	Setting range	Default	Description
					<p>function is activated. (DI "Voltage Raise" / "Voltage Lower" set).</p> <p><b>Interface</b> The setpoint comes from the interface (via RS-485 Modbus or TCP/IP Modbus, Address 7640). The setpoint is a power factor setpoint. Therefore the <i>VAR PF control mode</i> (parameter 7558) has to be configured to one of the PF settings.</p> <ul style="list-style-type: none"> <li>• "PF Control": The Modbus parameter 7640 will be the power factor reference value at the interchange point.</li> <li>• "Constant Generator PF": The Modbus parameter 7640 will be the power factor reference for a constant power factor reference sent to the DSLC-2s.</li> </ul>

Table 3-17: Parameter – voltage/var/pf control – VAR control



## Menu 5 – Configuration

This menu contains system rated frequency, generator rated voltage, PT and CT settings, with operating range and device number for the configuration of the MSLC-2.

MSLC2XT.wtool - Woodward ToolKit

Main View Settings Tools

Menu 5 - CONFIGURATION

Tool: Device: 33

HOME PAGE

MENU 1 SYNCHRONIZER

MENU 2 LOAD CONTROL

MENU 3 PROCESS CONTROL

MENU 4 VAR/PF CONTROL

MENU 5 CONFIGURATION

MENU 6 ANALOG INPUTS

MENU 7 ELECTRICAL PARAMETERS

MENU 8 CONTROL STATUS MONITOR

MENU 9 DISCRETE INPUTS/OUTPUTS

MENU 0 DIAGNOSTICS

OVERVIEW PAGES

VERSION PAGE

MENU 5.1 INTERFACES

MENU 5.2 SYSTEM MANAGEMENT

MENU 5.3 CONFIGURE COUNTERS

1750 System rated frequency 60Hz

1766 System A rated voltage 480 V

1754 System A rated current 500 A

1850 System A current input L1 L2 L3

1851 System A voltage measuring 3Ph 3W

1781 System B rated voltage 480 V

1858 1Ph2W voltage input Phase - phase

1859 1Ph2W phase rotation CW

1853 Aux system B voltage meas. 3Ph 3W

7649 Auxiliary system B available No

Operating ranges

5800 Upper voltage limit 110 %

5801 Lower voltage limit 90 %

5802 Upper frequency limit 110 %

5803 Lower frequency limit 90 %

System

1702 Device number 33

4544 Basic segment number 1

7786 Basic segment number source Internal

7628 Type of MSLC breaker Utility

7626 Switch alive bus A -> dead bus B Yes

Transformer

1801 System A PT primary rated voltage 480 V

1800 System A PT secondary rated voltage 120 V

1806 System A CT primary rated current 500 A/x

1830 System A current range 5A

1804 System B PT primary rated voltage 480 V

1803 System B PT secondary rated voltage 120 V

Tie

7625 Switch dead bus A -> dead bus B Yes

7627 Switch alive bus B -> dead bus A Yes

Communication

7809 Ethernet communication mode Single

7789 System update Off

Connected on TCP/IP Details...

Figure 3-14: ToolKit – configuration

### General



#### NOTE

Beside the System A 3-phase or 1-phase measurement the MSLC-2 provides a busbar 1-phase measurements and an auxiliary busbar 3-phase measurement. The busbar 1-phase measurement at the terminals 37-40 is obligatory and has to be connected in each application. The auxiliary busbar 3-phase AC measurement at the terminals 21-28 can additionally be used. When both measurements are used the busbar voltage has to be connected to both inputs. With the parallel use of the auxiliary busbar measurement, the MSLC-2 can determine correct voltages on all 3 phases and becomes a part of the operating range- and the phase rotation monitoring.



#### NOTE

Connection plausibility is checked: If the Busbar is not connected but Auxiliary Busbar is connected the "Busbar mismatch" Alarm ID 7770 occurs. This alarm is triggered when either the L1-L2 phase-phase voltage of the Aux busbar or the original busbar is lower or higher than the operation ranges (but higher than dead bus closure limit).



Dependent on the configuration "auxiliary busbar measurement" it will be checked when

- Auxiliary system available = "No"  
then the auxiliary busbar has no influence and therefore an alarm is never triggered
- Auxiliary system available = "Yes" then the auxiliary busbar with L1-L2 and the original busbar L1-L2 is checked if lower or higher than operating ranges

The dead busbar closure shall be blocked, when this alarm occurs.

ID	Parameter	CL	Setting range	Default	Description
1750	System rated frequency	2	50 / 60 Hz	60 Hz	The rated frequency of the system is used as a reference figure for all frequency related functions. This is used for operating range limits and frequency monitoring.
1766	System A rated voltage	2	50 to 650000 V	480 V	This voltage is always entered as a "Phase - phase" value. The rated system A potential transformer primary voltage is used as a reference figure for all system A voltage related functions, which use a percentage value, like operating range limits and voltage monitoring.  <b>NOTE:</b> This value refers to the rated voltage of the system A (system A voltage on data plate) and is the voltage measured on the potential transformer primary.
1754	System A rated current	2	1 to 32000 A	500 A	This value specifies the System A rated current.
1850	System A current input	2	L1 L2 L3 / Phase L1 / Phase L2 / Phase L3	L1 L2 L3	<b>L1 L2 L3:</b> All three phases are monitored. Measurement, display and protection are adjusted according to the rules for 3-phase measurement. <b>Phase L {1/2/3}:</b> Only one phase is monitored. Measurement, display and protection are adjusted according to the rules for single-phase measurement. Monitoring refers to the selected phase.  <b>NOTE:</b> Please refer to the comments on measuring principles in the installation chapter. This parameter is only effective if System A voltage measuring (parameter 1851) is configured to "3Ph 4W", "3Ph 3W" or "3Ph 4W OD".
1851	System A voltage measuring	2	3Ph 4W / 3Ph 3W / 1Ph 2W / 3Ph 4W OD	3Ph 3W	<b>3Ph 4W: Wye connected voltages</b> System A voltage is connected using all 3 phases and a neutral. This measurement can be directly connected or through potential transformers (PTs). Voltage monitoring is configured in the "Voltage/VAR/PF Menu 4", parameter 1770. This setting determines if the MSLC-2 uses "Phase - phase" or "Phase - neutral" voltage for protection. <b>3Ph 3W: Delta connected voltages</b> System A voltage is connected using all 3 phases. This measurement can be directly connected or through potential transformers (PTs). This configuration is used when: <ul style="list-style-type: none"> <li>• The system A is connected to the load using 3-phase and neutral</li> <li>• The system A voltage is connected to the MSLC-2 using 3-wire, "Phase - phase"</li> <li>• The L2 phase is <b>not</b> grounded on the input of the MSLC-2</li> </ul> And when: <ul style="list-style-type: none"> <li>• The system A is connected to the load using 3 phases and <b>no</b> neutral</li> <li>• The system A voltage is connected to the MSLC-2 using 3 wire, "Phase - phase"</li> <li>• The L2 phase can be grounded or left ungrounded</li> </ul> <b>1Ph 2W: Wye or delta connected system</b> System A is connected using L1 phase and neutral or L1 phase and L2. This selection should be used when the MSLC-2 will function only as a synchronizer, such as an MSLC-2 in the tie-breaker mode. <b>3Ph 4W OD: Delta connected voltages</b> System A voltage is connected using all 3 phases without a neutral connection. This measurement can be directly connected or through potential transformers (PTs). This configuration is used when: <ul style="list-style-type: none"> <li>• The system A is connected to the load using 3-phase and neutral</li> </ul>



ID	Parameter	CL	Setting range	Default	Description
					<ul style="list-style-type: none"> <li>The system A voltage is connected to the MSLC-2 using 3 wire, "Phase - phase"</li> <li>The L2 phase is <b>grounded</b> on the input of the MSLC-2</li> </ul> <p><b>NOTE:</b> Please refer to the comments on measuring principles in the installation chapter ("Voltage Measuring: System A" on page 30)</p>
1781	<b>System B rated voltage</b>	2	50 to 650000 V	480 V	<p>The system B potential transformer primary voltage is entered in this parameter.</p> <p>This value can be:</p> <ul style="list-style-type: none"> <li>Phase - phase</li> <li>Phase - neutral</li> </ul> <p>They dependent on the <i>1Ph 2W voltage input</i> (parameter 1858) setting. The system B rated voltage is used as a reference figure for all system B voltage related functions.</p> <p><b>NOTE:</b> This value refers to the rated voltage of system B and is the voltage measured on the potential transformer primary.</p>
1858	<b>1Ph2W voltage input</b>	2	Phase – phase / Phase – neutral	Phase – phase	<p><b>Phase – phase:</b> The unit is configured for measuring phase-phase voltages, if 1Ph 2W measuring is selected.</p> <p><b>Phase – neutral:</b> The unit is configured for measuring phase-neutral voltages, if 1Ph 2W measuring is selected.</p> <p><b>NOTE:</b> When this parameter is configured wrong the synchronization phase angle system A &lt;-&gt; Bus would be wrong calculated.</p>
1859	<b>1Ph2W phase rotation</b>	2	CW / CCW	CW	<p><b>CW:</b> A clockwise rotation field is considered for 1Ph 2W measuring.</p> <p><b>CCW:</b> A counter-clockwise rotation field is considered for 1Ph 2W measuring.</p>
1853	<b>Aux system B voltage meas.</b>	2	3Ph 4W / 3Ph 3W /	3Ph 3W	<p>In case of a 3-phase measurement connection of auxiliary system B, the connection has to be defined.</p> <p><b>3Ph 4W: Wye connected voltages</b> Auxiliary system B voltage is connected using all 3 phases and neutral. This measurement can be directly connected or through potential transformers (PTs). Voltage monitoring is configured in the "Voltage/VAR/PF Control Menu 4", parameter 1770. This setting determines if the MSLC-2 uses the "Phase - phase" or "Phase - neutral" voltage measurement for protection.</p> <p><b>3Ph 3W: Delta connected voltages</b> Auxiliary system B voltage is connected using all 3 phases. This measurement can be directly connected or through potential transformers (PTs). Voltage monitoring is configured in the "Voltage/VAR/PF Control Menu 4", parameter 1770. This settings must be configured for "Phase - phase".</p>
7649	<b>Auxiliary system B available</b>	2	No / Yes	No	<p><b>No:</b> The auxiliary system B measurement is not used.</p> <p><b>Yes:</b> The auxiliary system B measurement is used and becomes a part of the operating range- and the phase rotation monitoring. The auxiliary system B measurement is displayed in Menu 7.</p>

Table 3-18: Parameter – configuration

## Transformer

ID	Parameter	CL	Setting range	Default	Description
1801	<b>System A PT primary rated voltage</b>	2	50 to 650000 V	480 V	<p>The value is always entered as the "Phase - phase" measurement. Some System A applications may require the use of potential transformers to facilitate measuring the voltages produced by the system A. The rating of the primary side of the potential transformer must be entered into this parameter.</p> <p>If the application does not require potential transformers (i.e. the measured voltage is 690 V or less), then the measured voltage will be entered into this parameter.</p>
1800	<b>System A PT secondary rated voltage</b>	2	50 to 480 V	120 V	<p>The value is always entered as the "Phase - phase" measurement. Some System A applications may require the use of potential transformers to facilitate measuring the voltages produced by the system A. The rating of the secondary side of the potential</p>



ID	Parameter	CL	Setting range	Default	Description
					transformer must be entered into this parameter. If the System A application does not require potential transformers (i.e. the generated voltage is 690 V or less), then the generated voltage will be entered into this parameter.
1806	<b>System A CT primary rated current</b>	2	1 to 32000 A/x	500 A/x	The input of the current transformer ratio is necessary for the indication and control of the actual monitored value. The current transformers ratio should be selected so that at least 60% of the secondary current rating can be measured when the monitored system is at 100% of operating capacity (i.e. at 100% of system capacity a 5 A CT should output 3 A). If the current transformers are sized so that the percentage of the output is lower, the loss of resolution may cause inaccuracies in the monitoring and control functions and affect the functionality of the control.
1804	<b>System B PT primary rated voltage</b>	2	50 to 650000 V	480 V	The value is always entered as the "Phase - phase" measurement. Some applications may require the use of potential transformers to facilitate measuring the voltages to be monitored. The rating of the primary side of the potential transformer must be entered into this parameter.  If the application does not require potential transformers (i.e. the measured voltage is 690 V or less), then the measured voltage will be entered into this parameter.
1803	<b>System B PT second- ary rated voltage</b>	2	50 to 480 V	120 V	This voltage is always entered as a "Phase – phase" measurement. Some applications may require the use of potential transformers to facilitate measuring the system B voltages. The rating of the secondary side of the potential transformer must be entered into this parameter.  If the application does not require potential transformers (i.e. the measured voltage is 690 V or less), then the measured voltage will be entered into this parameter.

Table 3-19: Parameter – configuration – transformer



## Operating Ranges



### NOTE

The operating ranges are settings, which are used for determining the generator is operating at the correct voltage and frequency. Drop out of the operating range is not monitored with an alarm. The operating ranges are valid for generator, busbar and auxiliary busbar measurement, if used. It is recommended to configure the operating limits within the monitoring limits.



### NOTE

For monitoring the operating ranges respectively, the information can be read by interface or the Home page in ToolKit and is also displayed by the LEDs conditions.

ID	Parameter	CL	Setting range	Default	Description
5800	Upper voltage limit	2	100 to 150%	110%	The maximum permissible positive deviation of the voltage from the <i>System B rated voltage</i> (parameter 1768) is configured here. (Hysteresis 1 %)
5801	Lower voltage limit	2	50 to 100%	90%	The maximum permissible negative deviation of the voltage from the <i>System B rated voltage</i> (parameter 1768) is configured here. (Hysteresis 1 %)
5802	Upper frequency limit	2	100.0 to 150.0%	110.0%	The maximum permissible positive deviation of the frequency from the rated system frequency (parameter 1750) is configured here. (Hysteresis 0.05 Hz)
5803	Lower frequency limit	2	50.0 to 100.0%	90.0%	The maximum permissible negative deviation of the frequency from the rated system frequency (parameter 1750) is configured here. (Hysteresis 0.05 Hz)

Table 3-20: Parameter – configuration – operating ranges

## System



### NOTE

To configure a device in a running system please use *System update* parameter 7789 or DI 23 (see page 91).

ID	Parameter	CL	Setting range	Default	Description
1702	Device Number	2	33 to 48	33	A unique address is assigned to the control though this parameter. This unique address permits the controller to be correctly identified on the network. The address assigned to the controller may only be used once. All other network addresses are calculated on the number entered in this parameter. The device number is also important for the device assignment in load sharing.
4544	Basic segment number	2	1 to 8	1	The <i>Basic segment number</i> describes where the MSLC-2 is placed in relation to other DSLC-2 or MSLC-2. As long as no tie-breaker is located between the busbar voltage measurements of multiple MSLC-2s, the parameter can be remain on "1". Tie-breaker MSLC-2s should have the basic segment number that is on the system A side.  <b>NOTE:</b> In case there are different segments available in the application please follow the rules on page 141.
7786	Basic segment number source		Internal / Interface	Internal	This setting determines from which source the Basic segment number comes: <b>Internal:</b> The Basic segment number parameter 4544 Basic segment number is valid. <b>Interface:</b> The setpoint comes via RS-485 Modbus or TCP/IP Modbus Interface with parameter 7785.
7628	Type of MSLC breaker	2	Utility / Tie	Utility	Specifies the type of MSLC-2. <b>Utility:</b> The MSLC-2 controls the utility breaker. The parameters 7625 and 7627 are ignored. <b>Tie:</b> The MSLC-2 controls a tie-breaker (no direct segment connection to utility). The parameters 7625 and 7627 are active.



ID	Parameter	CL	Setting range	Default	Description
7626	Switch alive bus A -> dead bus B	2	Yes / No	Yes	<p>There could come up a situation that a live busbar at measurement A shall be closed on a dead busbar at measurement B. This configuration is allowing the closure in such a case. If this closure is not allowed, the MSLC-2 would not close the breaker in this case.</p> <p><b>Yes:</b> The closure is allowed in such a situation, if:</p> <ul style="list-style-type: none"> <li>• <i>Dead busbar closure</i> is enabled (Menu 1, parameter 7555) AND</li> <li>• The live busbar A is within the operating ranges (parameter 5800 to parameter 5803) AND</li> <li>• The busbar B is dead in the sense of the parameter <i>Dead bus detection max. volt.</i> (Menu 5, parameter 5820).</li> </ul> <p><b>No:</b> The closure is not allowed in such a situation.</p> <p><b>NOTE:</b> This parameter is only effective, if parameter 7628 is configured to "Tie".</p>

Table 3-21: Parameter – configuration – system settings

### Tie (Breaker)

ID	Parameter	CL	Setting range	Default	Description
7625	Switch deadbus A -> dead bus B	2	Yes / No	Yes	<p>There could come up a situation that both sides of the breaker are dead and a close command is given to the tie MSLC-2. This configuration is allowing the closure in such a case. If this closure is not allowed, the MSLC-2 would not close the breaker in this case.</p> <p><b>Yes:</b> The closure is allowed in such a situation, if:</p> <ul style="list-style-type: none"> <li>• <i>Dead busbar closure</i> is enabled (Menu 1, parameter 7555) AND</li> <li>• Both busbars are dead in the sense of the parameter <i>Dead bus detection max. volt.</i> (Menu 5, parameter 5820).</li> </ul> <p><b>No:</b> The closure is not allowed in such a situation.</p> <p><b>NOTE:</b> This parameter is only effective, if parameter 7628 is configured to "Tie".</p>
7627	Switch alive bus B -> dead bus A	2	Yes / No	Yes	<p>There could come up a situation that a live busbar at measurement B shall be closed on a dead busbar at measurement A. This configuration is allowing the closure in such a case. If this closure is not allowed, the MSLC-2 would not close the breaker in this case.</p> <p><b>Yes:</b> The closure is allowed in such a situation, if:</p> <ul style="list-style-type: none"> <li>• <i>Dead busbar closure</i> is enabled (Menu 1, parameter 7555) AND</li> <li>• The a live busbar B is within the operating ranges (parameter 5800 to parameter 5803) AND</li> <li>• The dead busbar A is dead in the sense of the parameter <i>Dead bus detection max. volt.</i> (Menu 5, parameter 5820).</li> </ul> <p><b>No:</b> The closure is not allowed in such a situation.</p> <p><b>NOTE:</b> This parameter is only effective, if parameter 7628 is configured to "Tie".</p>

Table 3-22: Parameter – configuration – tie breaker

### Communication

ID	Parameter	CL	Setting range	Default	Description
7809	Ethernet communication mode	2	Single / Redundant	Single	<p><b>Single:</b> Network A for UDP messages and Network B for TCP/IP communication</p> <p><b>Redundant:</b> Network A and Network B are for UDP messages and for TCP/IP communication. If one network fails an alarm will be initiated.</p>
7789	System update	2	Off / On	Off	Adding or removing the device can be started

Table 3-23: Parameter – configuration – communication



## Segment Connections

### Utility mode

The MSLC-2s “Basic Segment number” (4544) in menu 5 will be set for the Segment number that the System B PT is connected to.

### Tie Breaker mode

The MSLC-2s “Basic Segment number” (4544) in menu 5 will be set for the Segment number that the System A PT is connected to. The System A PT is normally connected to the Lowest Segment number and only at segment connection 81 the System B PT has the lower segment number (System A = 8 and System B = 1).

### Example

39

MENU 5 - CONFIGURATION

MENU 5.3  
CONFIGURE  
COUNTERS

### Operating ranges


60Hz ▾	5800 Upper voltage limit	110 %
480 V	5801 Lower voltage limit	90 %
500 A	5802 Upper frequency limit	110 %
L1 L2 L3 ▾	5803 Lower frequency limit	90 %

### System

3Ph 3W ▾	1702 Device number	39
480 V	4544 Basic segment number	8
Phase - phase ▾	7786 Basic segment number source	Internal ▾
CW ▾	7628 Type of MSLC breaker	Tie ▾
3Ph 3W ▾	7626 Switch alive bus A -> dead bus B	Yes ▾
No ▾		




## Dual Generator source





## Single Generator power source



The application drawings show that the MSLC-2 Tie Breaker mode will have:

1. System A PT connected to the lower segment side
2. The MSLC-2 connecting **segments 8 and 1 together**, the System A PT will connect to the Segment 8 side of the breaker.
3. This MSLC-2 will be configured for the "Basic Segment number" of 8

The Basic Segment Number of 8 is used to handle the correct information for an 8 to 1 segment connection and it also verifies if the Segment 1 side is connected to the Utility. With this information it will drive the generator sets correctly into synchronization across this breaker.


The MSLC-2 Tie Breaker mode will want to steer the System B PT signal into synchronization with the System A PT signal. If the System B PT is determined to be connected to a Utility, then System PT A will be driven into synchronization with Systems B PT signal. An MSLC-2 across the Utility breaker is how this information is passed to the Tie breaker MSLC-2.



The MSLC-2 Tie breaker unit should receive the feedback of the breaker closing, using this information to also tell the system what segments got connected. The MSLC-2 will inform all DSLC-2s and MSLC-2s on the system that you activated a segment connection. Say you connected "Segment 1 / 2", this is terminal 141 on all MSLC-2s. It is critical that you only tell the system that segments have been activated if the breaker is closed. Do not trick yourself into thinking that because all segments are closed except 3 / 4, that you should steer your PLC to close the 3 / 4 discrete input. **The rules are simple**, if the breaker is closed, the MSLC-2 should be informed so it can share this information with everyone else on the system.

80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61
NC		Process Control	Setpoint Lower	Setpoint Raise	Ramp Pause	Utility Unload	Base Load	Volt Lower	Volt Raise	CB Aux	Run	Perm	Check	Common DI	NC	- + Power Supply 12/24 Vdc		NC	Do Not Use
		Discrete Inputs																	
160	159	158	157	156	155	154	153	152	151	150	149	148	147	146	145	144	143	142	141
NC						NC		Common DI	System Update	Modbus Reset	Imp / Exp Control	Seg. No. 81 Act	Seg. No. 78 Act	Seg. No. 67 Act	Seg. No. 56 Act	Seg. No. 45 Act	Seg. No. 34 Act	Seg. No. 23 Act	Seg. No. 12 Act
Discrete Inputs																			

### Example of Ring bus with 2 Utility feeds using all 8 segments:





## Menu 5.1 – Interfaces

This menu contains the parameters for the configuration of the interfaces of the MSLC-2.




Figure 3-15: ToolKit – interfaces

### USB (Service Port) Interface

If the MSLC-2XT is connected to a PC via USB port, the device appears as an USB drive. The drive contains e.g. the technical manual, appropriate configuration files and the virtual COM port driver to connect to the MSLC-2 using ToolKit. If the PC does not install the COM port automatically, then the installer in folder "Driver" must be executed before starting ToolKit

There is no configuration to do for the USB Service Port.

#### Note:

The USB service port is restricted for ToolKit communication, Woodward service communication, and - if provided by factory side - read only files.

The »Automatic Reconnection« over USB is not possible.

If connection over USB is lost, please reconnect manually:

- 1. Wait until the MSLC is recognized again through the PC (as an external hard drive)
- 2. Start via ToolKit at new by "Disconnect" and then "Connect" again



## Serial Interface 2 – RS-485

The serial interface 2 – RS-485 allows exclusively access by Modbus protocol with configurable parity, stop bits and full-, halfduplex mode. The unit acts here as a RTU slave.

ID	Parameter	CL	Setting range	Default	Description
3170	<b>Baudrate</b>	2	2.4 / 4.8 / 9.6 19.2 / 38.4 / 56.0 / 115.0 kBaud	19.2 kBd	This parameter defines the baud rate for communications. Please note, that all participants on the bus must use the same baud rate.
3171	<b>Parity</b>	2	No / Even / Odd	No	The used parity of the interface is set here.
3172	<b>Stop bits</b>	2	One / Two	One	The number of stop bits is set here.
3173	<b>Full-, halfduplex mode</b>	2	Fullduplex / Halfduplex	Fullduplex	<b>Fullduplex:</b> Fullduplex mode is enabled. <b>Halfduplex:</b> Halfduplex mode is enabled.

Table 3-24: Parameter – interfaces – serial 2 – RS485

## Modbus Serial Interface 2

ID	Parameter	CL	Setting range	Default	Description
3188	<b>Modbus slave ID</b>	2	0 to 255	33	The Modbus device address, which is used to identify the device via Modbus, is entered here. If "0" is configured here, the Modbus is disabled.
3189	<b>Reply delay time</b>	2	0.00 to 2.55 s	0.00 s	This is the minimum delay time between a request from the Modbus master and the set response of the slave. This time is required in halfduplex mode.

Table 3-25: Parameter – interfaces – serial 2 – Modbus

## Network A – UDP / Modbus (Ethernet Channel #1)

The network A – UDP Ethernet bus is reserved for internal communication between all MSLC-2 and DSLC-2 in one system independent on the busbar segment. Up to 32 DSLC-2 and up to 16 MSLC-2 can communicate over the 100 ms – UDP messages.

Additionally, the network A – Modbus/TCP Ethernet bus is provided for external communication purposes with all MSLC-2 and DSLC-2 in one system and a PLC.

ID	Parameter	CL	Setting range [Default]	Description
5330	<b>IP address</b>	2	[192, 168, 50, 100]	Field 1,2,3,4 for IP address Ethernet port A. This setting will be not valid automatically. The »Set IP address« parameter must be set to »ON« for enabling.  <b>Notes:</b> Device part bits are not allowed to be either <b>all 00...2</b> or <b>all 11...2</b> (broadcast).
7412	<b>Set IP address</b>	2	Off	Set IP-Address Ethernet port A.
5334	<b>Subnet mask</b>	2	[255, 255, 255, 0]	Set byte 1,2,3,4 of the subnet mask Ethernet port A. This setting will be not valid automatically. The »Set subnet mask« parameter must be set to »ON« for enabling.
7413	<b>Set subnet mask</b>	2	Off	Set subnet mask Ethernet port A.

Table 3-26: Parameter – interfaces – network A



### Network B – UDP / Modbus (Ethernet Channel #2)

The network B – UDP / Modbus/TCP Ethernet bus is provided for external communication purposes with all MSLC-2 and DSLC-2 in one system and a PLC.

Additionally—if *Ethernet communication mode* (ID 7809) is “Redundant”—the network B – UDP Ethernet bus is reserved for internal communication between all MSLC-2 and DSLC-2 in one system independent on the busbar segment. Up to 32 DSLC-2 and up to 16 MSLC-2 can communicate over the 100 ms – UDP messages.

ID	Parameter	CL	Setting range [Default]	Description
5430	IP address	2	[192, 168, 50, 101]	Field 1,2,3,4 for IP address Ethernet port B. This setting will be not valid automatically. The »Set IP address« parameter must be set to »ON« for enabling.  <b>Notes:</b> Device part bits are not allowed to be either <b>all 00...2</b> or <b>all 11...2</b> (broadcast).
7414	Set IP address	2	Off	Set IP-Address Ethernet port B.
5434	Subnet mask	2	[255, 255, 255, 0]	Set byte 1,2,3,4 of the subnet mask Ethernet port B. This setting will be not valid automatically. The »Set subnet mask« parameter must be set to »ON« for enabling.
7415	Set subnet mask	2	Off	Set subnet mask Ethernet port B.

Table 3-27: Parameter – interfaces – network B

### Network C Modbus (Ethernet Channel #3)

The network C Modbus/TCP Ethernet bus is provided for external communication purposes with a PLC.

ID	Parameter	CL	Setting range [Default]	Description
7418	IP address	2	[192, 168, 52, 102]	Field 1,2,3,4 for IP address Ethernet port C. This setting will be not valid automatically. The »Set IP address« parameter must be set to »ON« for enabling.  <b>Notes:</b> Device part bits are not allowed to be either <b>all 00...2</b> or <b>all 11...2</b> (broadcast).
7416	Set IP address	2	Off	Set IP-Address Ethernet port C.
7422	Subnet mask	2	[255, 255, 255, 0]	Set byte 1,2,3,4 of the subnet mask Ethernet port B. This setting will be not valid automatically. The »Set subnet mask« parameter must be set to »ON« for enabling.
7417	Set subnet mask	2	Off	Set subnet mask Ethernet port C.

Table 3-28: Parameter – interfaces – network C



#### NOTE

Generally, up to 10 TCP/IP Ethernet stacks are provided per device.



## Format Modbus Protocol (Interface Definitions)

The unit offers a Modbus address table with for visualizing systems. The table contains 16bit integer (short) and 32bit integer (long) variables. The contents of some measurement long variables are also available as short variables. To cover all measurement ranges in a satisfying resolution, the engineering unit “Watt”, “Volt” and “Ampere” can be adjusted according to the application.

ID	Parameter	CL	Setting range	Default	Description																									
3181	Power [W] exponent 10^x	2	2 to 5	3	<p>This setting adjusts the format of the 16 bit power values in the data telegram.</p> <p><b>Example power measurement:</b> The measurement range is 0 to 250 kW. Momentarily measurement value = 198.5 kW (198.500 W)</p> <table><thead><tr><th>Setting</th><th>Meaning</th><th>Calculation</th><th>Transfer value (16Bit, max. 32767)</th><th>Possible Display Format</th></tr></thead><tbody><tr><td>2</td><td>10<sup>2</sup></td><td><math>\frac{198500\text{ W}}{10^2\text{ W}}</math></td><td>1985</td><td>198.5 kW</td></tr><tr><td>3</td><td>10<sup>3</sup></td><td><math>\frac{198500\text{ W}}{10^3\text{ W}}</math></td><td>198</td><td>198 kW</td></tr><tr><td>4</td><td>10<sup>4</sup></td><td><math>\frac{198500\text{ W}}{10^4\text{ W}}</math></td><td>19</td><td>N/A</td></tr><tr><td>5</td><td>10<sup>5</sup></td><td><math>\frac{198500\text{ W}}{10^5\text{ W}}</math></td><td>1</td><td>N/A</td></tr></tbody></table>	Setting	Meaning	Calculation	Transfer value (16Bit, max. 32767)	Possible Display Format	2	10 <sup>2</sup>	$\frac{198500\text{ W}}{10^2\text{ W}}$	1985	198.5 kW	3	10 <sup>3</sup>	$\frac{198500\text{ W}}{10^3\text{ W}}$	198	198 kW	4	10 <sup>4</sup>	$\frac{198500\text{ W}}{10^4\text{ W}}$	19	N/A	5	10 <sup>5</sup>	$\frac{198500\text{ W}}{10^5\text{ W}}$	1	N/A
Setting	Meaning	Calculation	Transfer value (16Bit, max. 32767)	Possible Display Format																										
2	10 <sup>2</sup>	$\frac{198500\text{ W}}{10^2\text{ W}}$	1985	198.5 kW																										
3	10 <sup>3</sup>	$\frac{198500\text{ W}}{10^3\text{ W}}$	198	198 kW																										
4	10 <sup>4</sup>	$\frac{198500\text{ W}}{10^4\text{ W}}$	19	N/A																										
5	10 <sup>5</sup>	$\frac{198500\text{ W}}{10^5\text{ W}}$	1	N/A																										
3182	Volts [V] exponent 10^x	2	-1 to 2	0	<p>This setting adjusts the format of the 16 bit voltage values in the data telegram.</p> <p><b>Example voltage measurement:</b> The measurement range is 0 to 480 V. Momentarily measurement value = 477.8 V</p> <table><thead><tr><th>Setting</th><th>Meaning</th><th>Calculation</th><th>Transfer value (16Bit, max. 32767)</th><th>Possible Display Format</th></tr></thead><tbody><tr><td>-1</td><td>10<sup>-1</sup></td><td><math>\frac{477.8\text{ V}}{10^{-1}\text{ V}}</math></td><td>4778</td><td>477.8 V</td></tr><tr><td>0</td><td>10<sup>0</sup></td><td><math>\frac{477.8\text{ V}}{10^0\text{ V}}</math></td><td>477</td><td>477 V</td></tr><tr><td>1</td><td>10<sup>1</sup></td><td><math>\frac{477.8\text{ V}}{10^1\text{ V}}</math></td><td>47</td><td>N/A</td></tr><tr><td>2</td><td>10<sup>2</sup></td><td><math>\frac{477.8\text{ V}}{10^2\text{ V}}</math></td><td>4</td><td>N/A</td></tr></tbody></table>	Setting	Meaning	Calculation	Transfer value (16Bit, max. 32767)	Possible Display Format	-1	10 <sup>-1</sup>	$\frac{477.8\text{ V}}{10^{-1}\text{ V}}$	4778	477.8 V	0	10 <sup>0</sup>	$\frac{477.8\text{ V}}{10^0\text{ V}}$	477	477 V	1	10 <sup>1</sup>	$\frac{477.8\text{ V}}{10^1\text{ V}}$	47	N/A	2	10 <sup>2</sup>	$\frac{477.8\text{ V}}{10^2\text{ V}}$	4	N/A
Setting	Meaning	Calculation	Transfer value (16Bit, max. 32767)	Possible Display Format																										
-1	10 <sup>-1</sup>	$\frac{477.8\text{ V}}{10^{-1}\text{ V}}$	4778	477.8 V																										
0	10 <sup>0</sup>	$\frac{477.8\text{ V}}{10^0\text{ V}}$	477	477 V																										
1	10 <sup>1</sup>	$\frac{477.8\text{ V}}{10^1\text{ V}}$	47	N/A																										
2	10 <sup>2</sup>	$\frac{477.8\text{ V}}{10^2\text{ V}}$	4	N/A																										
3183	Current [A] exponent 10^x	2	-1 to 0	0	<p>This setting adjusts the format of the 16 bit current values in the data telegram.</p> <p><b>Example current measurement:</b> The measurement range is 0 to 500 A Momentarily measurement value = 345.4 A</p> <table><thead><tr><th>Setting</th><th>Meaning</th><th>Calculation</th><th>Transfer value (16Bit, max. 32767)</th><th>Possible Display Format</th></tr></thead><tbody><tr><td>-1</td><td>10<sup>-1</sup></td><td><math>\frac{345.4\text{ A}}{10^{-1}\text{ V}}</math></td><td>3454</td><td>345.4 A</td></tr><tr><td>0</td><td>10<sup>0</sup></td><td><math>\frac{345.4\text{ V}}{10^0\text{ V}}</math></td><td>345</td><td>345 A</td></tr></tbody></table>	Setting	Meaning	Calculation	Transfer value (16Bit, max. 32767)	Possible Display Format	-1	10 <sup>-1</sup>	$\frac{345.4\text{ A}}{10^{-1}\text{ V}}$	3454	345.4 A	0	10 <sup>0</sup>	$\frac{345.4\text{ V}}{10^0\text{ V}}$	345	345 A										
Setting	Meaning	Calculation	Transfer value (16Bit, max. 32767)	Possible Display Format																										
-1	10 <sup>-1</sup>	$\frac{345.4\text{ A}}{10^{-1}\text{ V}}$	3454	345.4 A																										
0	10 <sup>0</sup>	$\frac{345.4\text{ V}}{10^0\text{ V}}$	345	345 A																										

Table 3-29: Parameter – interfaces – format Modbus protocol



## Menu 5.2 System Management

This menu contains the parameters for the system management of the MSLC-2XT.

MSLC2XT.wttool - Woodward ToolKit

Main View Settings Tools

Menu 5.2 - SYSTEM MANAGEMENT

Tool: Device: 33

### MENU 5.2 - SYSTEM MANAGEMENT

HOME PAGE

GO BACK TO MENU 5 CONFIGURATION

#### Factory settings

10417 Factory default settings: No

10110 Power supply: 23,1 V

Lamp test

#### Password system

Password basic

10415 Password basic: 1

Password commissioning

10413 Password commissioning: 3

Code temp. commissioning

10414 Code temp. commissioning: 200

10412 Code temp. super commissioning: 400

Password super commissioning

10411 Password super commissioning: 500

10437 Alphanumeric code temp. comm.: a9t5

10438 Alphan. code temp. super comm.: xk38

#### Alphanumeric password

Change password basic level

10439 Old password basic level:

10440 New password basic level:

10441 Confirm password basic level:

10442 Change password basic level: No

10443 Change passw.error basic level:

10428 Reset password basic level: No

Change password commiss. level

10444 Old password commiss. level:

10445 New password commiss. level:

10446 Confirm password commiss.level:

10447 Change password commiss. level: No

10448 Change passw. error comm.level:

10429 Reset password commiss. level: No

Change passw.super comm. level

10449 Old passw. super comm. level:

10450 New passw. super comm. level:

10451 Confirm passw.super comm.level:

10452 Change passw.super comm. level: No

10453 Change passw. error super comm.level:

10436 Reset passw. super comm. level: Not

Random number for password

10416 Random number for password: 3907

Connected on TCP/IP Details...

Figure 3-16: ToolKit – system management

## Password System

### General notes

The controller utilizes a password protected multi-level access hierarchy to prevent unauthorized access to parameters, configuration and calibration items. This permits varying degrees of access to the parameters being granted by assigning unique passwords to designated personnel.

Password protection covers direct and remote access through all methods and interfaces of inter-connectivity of the device.





### **Personal security**

Configure password security before handing over the device to the customer!

Note your password on a secure location. The next higher password level (2 and 4) allows to reset the password of the level below (1 and 3).

To restore the according User Name Account needs support from Woodward (authorized partner).

## **Access via channel ...**

The following table and drawing provide an overview about the possible access channels to the MSLC-2XT.

Access to the MSLC-2XT by	# used in figure "Overview: Access Rights – Use Cases" below
PC running ToolKit servlink, connected over USB	①
PLC running Modbus TCP	②
PC running ToolKit servlink, connected over Ethernet	③
PLC running Modbus RTU via RS-485	④
Netbiter® Easy Connect gateway running Servlink TCP (ToolKit via internet)	③



Each channel has its own independent access level.

The according password handling for each of this access is defined afterwards.

Two login procedures cover all access channel variants: The ...

- Basic Code Entry
- User Account Entry



### **Hidden entry for more security**

The currently selected entry number is visible only - all other numbers are hidden and a "\*" asterisk is displayed instead.






Figure 3-17: Access to the device – Overview

## LOGIN procedure "Basic Code Entry"

The Basic Code Entry is valid for access ② and ④

The Basic Code Entry asks for four numbers to open the related password level. It starts with the default value of parameter 10416 »Random number for password«.

## LOGIN procedure "User Account Entry"

The User Account Entry is valid for access ① and ③.




Figure 3-18: Password entry: ToolKit

The User Account Entry comes with more security as requested for internet access. It asks for »Username:« **and** »Password:« ("Alphanumeric Password"). To open the related password level, both rows entries need the correct alphanumeric strings.




The already existing User names cannot be changed. They are fixed for the desired code level, which shall be entered.





### Check you Password entry

View hidden password entry by pushing the the  symbol on the right side of »Password:« box.

## Enter Password for level ... (Overview)

A distinction is made between the access levels as follows:

Code Level	User Account Entry		Basic Code Entry	Comment
	User Name (fix)	Password (default)	Password (default)	
5	CL05	CL0500	500	<b>The Super Commissioning Level</b>  Access to nearly all parameters and configurations, except calibration and super user items.  The firmware updating is released.  The own code level and the levels below can be indicated and configured.
4	AC04	Algorithm Code	Algorithm Code	<b>The temporary Super Commissioning Level</b>  The same access rights like in the Super Commissioning Level but with the following exceptions: <ul style="list-style-type: none"> <li>• The password for this level is not visible.</li> <li>• The access is dismissed afterwards.</li> </ul>
3	CL03	CL0003	3	<b>The Commissioning Level</b>  Access to well defined parameters and configurations, which are usually needed on a commissioning level.  The own code level and the levels below can be indicated and configured.
2	AC02	Algorithm Code	Algorithm Code	<b>The temporary Commissioning Level</b>  The same access rights like in the Commission Level.  The Code level is entered in an algorithm code. The access is dismissed afterwards.  Only the code levels below can be indicated and configured.



1	CL01	CL0001	1	<b>The Basic Level</b>  Access to a limited number of parameters and configurations.  The own code level can be indicated and configured.
0				No access rights to change, even viewed information is restricted.



#### **Active Code Level**

A code level always belongs to an access channel. Each access channel has its own password level. This password level can be different to others (other channels) at the same time.

The access related code level is available and visible beside the access related interface settings.

## **The Algorithm Code**

The "Algorithm Code" is an implemented procedure to give an external user temporarily access to the device but without being able to see or change the according passwords. This temporary access needs a random number produced by the device. The actual password then is calculated from this random number using a secret formula. The secret formula is provided by a higher instance.

## **Access Channels**



#### **Maximum Security**

Each of these channels have their own independent access level. That has the advantage that e.g. a ToolKit channel password level opens not automatically the access rights for the other channels.

The device provides different access channels via ...	Remarks
USB	ToolKit Servlink
RS485	Modbus RTU
Ethernet	Modbus TCP
	ToolKit Servlink TCP, 8 sub channels are possible
	<b>Note:</b> Each of the 8 sub channels has its own independent password access level!



## Code Level 1 - The Basic Level CL01

- **General:**

This level releases the access to a limited number of parameters and configurations

- **Basic Code entry:**

In this and higher levels the password for the Basic Code Level CL01 can be changed

- **User Account Entry:**

This level is selected with the User Name CL01 and the according password can only be changed being in code level CL01.


Being in code level AC02 or higher the password of the Basic Level CL01 can be reset to its default by the Yes/No parameter 10428.

Code Level	User Account Entry		Basic Code Entry
	User Name (fix)	Password (default)	Password (default)
1	CL01	CL0001	0001

## Code Level 2 - The temporary Commissioning Level AC02

- **General:**

This Level allows temporary access to parameters of the Commission Level.

The access is dismissed automatically (see  “Automatic Logout from Password level (Fall into level 0)”).

- **Basic Code Entry:**


In this and higher Levels, the password for the Basic Code Level CL01 can be changed.

- **User Account Entry:**

This level is selected with the User Name AC02 and the according algorithm for the password can only be changed being in the Commissioning code level CL03.

Being in code level AC02 or higher the password of the Basic Level CL01 can be reset to its default by the Yes/No parameter 10428.



Code Level	User Account Entry		Basic Code Entry
	User Name (fix)	Password	Password
2	AC02	<p>The entry procedure:</p> <p>The operator connects ToolKit with the device and closes the upcoming security login window <b>without entering</b> username and password (Code level 0). The operator navigates with ToolKit to the page [Parameter / Configure system management].</p> <p>The operator reads on that page  10416 »Random number for password«. He tells it to a higher instance.</p> <p>The higher instance calculates: (10414 »Code temp. commissioning« + 10416 »Random Number«) x 3.</p> <p>The higher instance takes the lower four digits of the result and puts the according algorithm string 10437 »Alphanumeric code temp. comm.« as prefix in front.</p> <p>The higher instance tells the result to the operator, who enters the result as password into the control.</p>	<p>The entry procedure:</p> <p>The operator navigates on ToolKit to MENU 5.2 SYSTEM MANAGEMENT.</p> <p>The operator reads the indicated random number. He tells it to a higher instance.</p> <p>The higher instance calculates: (10414 »Code temp. commissioning« + 10416 »Random Number«) x 3.</p> <p>The higher instance takes the lower four digits of the result and tells it the operator. The operator enters the result as password into the control.</p>

### Code Level 3 - The Commissioning Level CL03

- **General:**

In this Level, the operator has access to all parameters and configurations, which are usually needed on a commissioning level

- **Basic Code Entry:**

In this and higher levels the password for the Commissioning Level CL03 can be changed

- **User Account Entry:**

This level is selected with the User name CL03 and the according password can only be changed being in the Commissioning Level CL03

Being in code level AC04 or higher the password of the Commissioning Level CL03 can be reset to its default by the Yes/No parameter ID 10429.



Level	User Account Entry		Basic Code Entry
	User Name (fix)	Password (default)	Password (default)
3	CL03	CL0003	0003

### Code Level 4 - The temporary Super Commissioning Level

- **General:**

This Level allows temporary access to nearly all parameters and configurations, except calibration and super user items.

The access is dismissed automatically

- **Basic Code Entry:**

In this and higher levels the passwords for the Commissioning Level CL04 can be changed

- **User Account Entry:**

This level is selected with the User name AC03 and the according algorithm for the password can only be changed being in the Super Commissioning Level CL05

Being in code level AC04 or higher the password of the Commissioning Level CL03 can be reset to its default by the Yes/No parameter ID 10429.

Level	User Account Entry		Basic Code Entry
	User Name	Password	Password
4	AC04	<p>The entry procedure:</p> <p>The operator connects ToolKit with the device and closes the upcoming security login window <b>without entering</b> username and password (Code level 0). The operator navigates with ToolKit to the page [Parameter / Configure system management].</p> <p>The operator reads on that page 10416 »Random number for password«.</p>	<p>The entry procedure:</p> <p>The operator navigates on ToolKit to MENU 5.2 SYSTEM MANAGEMENT</p> <p>The operator reads the indicated random number. He tells it to a higher instance.</p>



		<p>He tells it to a higher instance.</p> <p>The higher instance calculates: (10412 »Code temp. commissioning« + 10416 »Random Number«) x 5.</p> <p>The higher instance takes the lower four digits of the result and puts the according algorithm string 10438 »Alphanumeric code super temp. comm.« as prefix in front.</p> <p>The higher instance tells the result to the operator, who enters the result as password into the control.</p>	<p>The higher instance calculates: (10412 »Code temp. commissioning« + 10416 »Random Number«) x 5.</p> <p>The higher instance takes the lower four digits of the result and tells it the operator. The operator enters the result as password into the control.</p>
--	--	---	---

## Code Level 5 - The Super Commissioning Level CL05

- **General:**

In this Level, the operator has access to nearly all parameters and configurations, except calibration items

The firmware updating is released

- **Basic Code Entry:**

In this and higher Levels the password from the Super Commissioning Level CL05 can be changed

- **User Account Entry:**

This level is selected with the User name CL05 and the according password can only be changed being in the Super Commissioning Level CL05

Being in a higher level as CL05 the password of the Super Commissioning Level CL05 can be reset to its default by the Yes/No parameter ID 10436.



If you have forgotten your password for the Super Commissioning Level, please contact Woodward or a representative for help.

Level	User Account Entry		Basic Code Entry
	User Name (fix)	Password (default)	Password (default)
5	CL05	CL0500	0500



## Automatic Logout from Password level (Fall into level 0)

All basic code entry channels deny after 2h

The Modbus TCP access channel denies after 2h

Generally with power supply cycling the password level is denied. The ToolKit Servlink access never logout

### ***What forces the Logout from Password levels (Fall into level 0)***

All basic code entry channels with »0« as password or a wrong password The ToolKit Servlink access with logout function

The Modbus TCP (in all channels) with wrong password

## Definition of the password

Numeric Password of the Basic Code entry

- The range of possible passwords is 1 to 9999

Alpha numeric Password of the User Account entry

- The maximum length of the alpha numeric password is 20 characters
- The maximum length of the alpha numeric prefix (ID 10437, 10438) is 6

## The Random Number

Each time a password is entered, the random number is calculated at new. This guarantees max. security.

## Password handling via Modbus using RS-485

The device must be a member of a RS-485 network and the password has to be transferred (from PLC) to the device.

### **Set the device to code level 5 via Modbus RS-485**

With factory settings the password is expected to be "500" for code level 5.

- Modbus address = 400000 + Par. ID= 410430
- Modbus length = 1 (UNSIGNED 16)

Code level state can be read with index 10420 localized in ToolKit: [MENU 0 - DIAGNOSTICS]



## Password handling via Modbus using Modbus TCP

The device must be a member of an Ethernet network (A, B, or C) and the password has to be transferred (from PLC) to the device.

### Set the device to code level 5 via Modbus TCP

With factory settings the password is expected to be "500" for code level 5.

- Modbus address = 400000 + Par. ID = 410434
- Modbus length = 1 (UNSIGNED 16)
- or
- Modbus address = 400000 + Par. ID = 410435
- Modbus length = 1 (UNSIGNED 16)

(To be backwards compatible to MSLC-2 the parameter ID 10434 or ID 10435 can be used. Regardless which of the two IDs is used, it is valid for all 3 Ethernet ports.)

Code level state can be read with index 10427 localized in ToolKit: [MENU 0 - DIAGNOSTICS].




#### Notes

Generally, up to 10 TCP/IP Ethernet stacks are provided per device. (The splitting to the 3 Ethernet ports does not matter.)

Only one code level is used at a time. The highest code level is valid.

### Password expiry



The figure above shows an example of password expiration.

If code level 5 is set via 10434 at 2 pm and code level 3 is set via 10435 at 3 pm, code level 5 expires at 4 pm code level 3 expires at 5 pm.

### Code level interfaces

ID	Parameter	CL	Setting range [Default]	Description
10430	<b>Password for serial interface</b>	0	0000 to 9999 [random number]	The password for configuring the control via the RS485 interface must be entered here.  Not visible but can be accessed by interface!
10420	<b>Code level</b>	0	[0]	This value displays the code level, which is currently enabled for access via the RS485 interface.



10427	Code level	0	[0]	This value displays the code level, which is currently enabled for access via the Modbus TCP/IP interface.
-------	------------	---	-----	--



## Password System - Parameter Overview

### General notes



The following passwords grant varying levels of access to the parameters.

ID	Parameter	CL	Setting range [Default]	Description
10415	<b>Password basic</b>	1	1 to 9999 [-]	The password for the code level "Basic" is defined in this parameter.  Refer to "Enter Password" for default values.
10413	<b>Password commissioning</b>	3	1 to 9999 [-]	The password for the code level "Commissioning" is defined in this parameter.  Refer to "Enter Password" for default values.

ID	Parameter	CL	Setting range [Default]	Description
10414	<b>Code temp. commissioning</b>	3	1 to 9999 [200]	The algorithm for calculating the password for the code level "Temporary Commissioning" is defined in this parameter.
10412	<b>Code temp. super commissioning</b>	5	1 to 9999 [400]	The algorithm for calculating the password for the code level "Temporary Super commissioning" is defined in this parameter.
10411	<b>Password super commissioning</b>	5	1 to 9999 [500]	The password for the code level "Super commissioning" is defined in this parameter.  Refer to "Enter Password" for default values.



10437	<b>Alphanumeric code temp. comm.</b>	3	(up tp 6 characters)  [a9t5]	Alphanumeric code for temporary commissioning level.  This is the alphanumeric algorithm value for the formula to reach the temporary commissioning code level (Level 02), entered as string here.
10438	<b>Alphan. code temp. super comm.</b>	5	(up tp 6 characters)  [xk38]	Alphanumeric code for temporary super commissioning level  This is the alphanumeric algorithm value for the formula to reach the temporary commissioning code level (Level 04), entered as string here.

## Random Number for Password

ID	Parameter	CL	Setting range [Default]	Description
10416	<b>Random number for password</b>		[(random four letters number)]	Random number generated by the device. Needed to get an alphanumeric password by Woodward support.



## Change/Reset Alphanumeric Password

ID	Parameter	CL	Setting range [Default]	Description
Change password basic level				
10439	Old password basic level	1	((empty))	Enter here your old alphanumeric password to release the password change for the basic code level (CL01)
10440	New password basic level	1	((empty))	Enter here your new alphanumeric password string for the basic code level (CL01)

ID	Parameter	CL	Setting range [Default]	Description
10441	Confirm password basic level	1	((empty))	Repeat here your new alphanumeric password string for the basic code level (CL01)
10442	Change password basic level	1	[No]  Yes	With switching this parameter to yes, the control checks the entries for changing the password and executes the password change, if the entries are correct. The visualization 10443 indicates the successful execution.  <b>Notes</b>  If the parameters 10439, 10440, and 10441 are not correct, the password change is not executed.
10443	Change passw.error basic level	0		Flag: illuminated LED
			[green]	Password was not changed or successfully changed
			red	Error: password could not be changed
10428	Reset password basic level	2	Yes	The control resets the password of the basic level to "CL0001".
			[No]	
Change password commissioning level				
10444	Old password commiss. level	3	((empty))	Enter here your old alphanumeric password to release the password change for the commissioning code level (CL03)
10445	New password commiss. level	3	((empty))	Enter here your new alphanumeric password string for the commissioning code level (CL03)
10446	Confirm password commiss.level	3	((empty))	Repeat here your new alphanumeric password string for the commiss. code level (CL03)



10447	<b>Change password commiss. level</b>	3	[No]	With switching this parameter to »Yes«, the control checks the entries for changing the password and executes the password change, if the entries are correct. The visualization 1048 indicates the successful execution.
			Yes	
10448	<b>Change passw. error comm.level</b>	0		Flag: illuminated LED
			[green]	Password was not changed or successfully changed
			red	Error: password could not be changed

ID	Parameter	CL	Setting range [Default]	Description
10441	Confirm password basic level	1	((empty))	Repeat here your new alphanumeric password string for the basic code level (CL01)
10442	Change password basic level	1	[No]  Yes	With switching this parameter to yes, the control checks the entries for changing the password and executes the password change, if the entries are correct. The visualization 10443 indicates the successful execution.
				Notes  If the parameters 10439, 10440, and 10441 are not correct, the password change is not executed.
10443	Change passw.error basic level	0		Flag: illuminated LED
			[green]	Password was not changed or successfully changed
			red	Error: password could not be changed
10428	Reset password basic level	2	Yes	The control resets the password of the basic level to "CL0001".
			[No]	
Change password commissioning level				
10444	Old password commiss. level	3	((empty))	Enter here your old alphanumeric password to release the password change for the commissioning code level (CL03)
10445	New password commiss. level	3	((empty))	Enter here your new alphanumeric password string for the commissioning code level (CL03)



10446	Confirm password commiss.level	3	((empty))	Repeat here your new alphanumeric password string for the commiss. code level (CL03)
10447	Change password commiss. level	3	[No]  Yes	<p>With switching this parameter to »Yes«, the control checks the entries for changing the password and executes the password change, if the entries are correct. The visualization 1048 indicates the successful execution.</p> <p><b>Notes</b></p> <p>If the parameters 10444, 10445, and 10446 are not correct, the password change is not executed.</p>
10448	Change passw. error comm.level	0		Flag: illuminated LED
			[green]	Password was not changed or successfully changed
			red	Error: password could not be changed

## Factory Settings

ID	Parameter	CL	Setting range	Default	Description
10417	Factory default settings	0	No / Yes	No	Selecting "Yes" will allow the reset back to <i>Factory default settings</i> by selecting "Yes" for the <i>Reset factory default values</i> parameter (parameter 1701).
1701	Reset factory default values	0	No / Yes	No	<b>No:</b> All parameters will remain as currently configured. <b>Yes:</b> All parameters, which the enabled access code grants privileges to, will be restored to factory default values. This value returns to "No" when factory defaults are set.

Table 3-30: Parameter – system management – factory settings

## Lamp Test (Button)

Push this button to illuminate all lights on the controller. Correct LED operation can be checked.

## Power Supply

ID	Parameter	CL	Setting range	Default	Description
10110	Power supply	0	-	-	Display of the measured supply voltage in V

Table 3-31: Parameter – system management – power supply



## Menu 5.3 – Configure Counters

This menu contains the parameters for the Configuration of the Counters of the MSLC-2.

The screenshot shows a web-based configuration interface for the MSLC-2. The browser address bar displays 'MENU 5.3 - CONFIGURE COUNTERS'. The interface includes a top navigation bar with 'HOME PAGE MSLC-2' and 'GO BACK TO MENU 5 CONFIGURATION' buttons. The main content area is titled 'MENU 5.3 - CONFIGURE COUNTERS' and features a 'Device 33' indicator. The 'Active code level' is set to '0'. The configuration is for 'System A energy counter' and includes the following parameters:

Parameter	Value
2515 Counter value preset	0
2510 Syst. A active energy [0.00MWh]	No
2515 Counter value preset	0
2512 Syst. A active energy -[0.00MWh]	No
2515 Counter value preset	0
2511 Syst. A react. energy [0.00Mvarh]	No
2515 Counter value preset	0
2513 Syst. A react. energy -[0.00Mvarh]	No

Figure 3-19: ToolKit – configure counters



## System A reset values

ID	Parameter	CL	Setting range	Default	Description
2515	Counter value pre-set	2	0 to 999,999,99	[0]	This value is utilized to set the following counters: <ul style="list-style-type: none"> <li>kWh counter</li> <li>kvarh counter</li> </ul> The number entered into this parameter is the number that will be set to the parameters listed above when they are enabled.
2510	Syst. A active power [0.00 MWh]	2	Yes / No	[No]	<p><b>Yes:</b> The current value of this counter is overwritten with the value configured in "Counter value preset" (parameter 2515). After the counter has been (re)set, this parameter changes back to "No" automatically.</p> <p><b>No:</b> The value of this counter is not changed.</p> <p><b>Example</b></p> <ul style="list-style-type: none"> <li>The counter value preset (parameter 2515) is configured to "3456".</li> <li>If this parameter is set to "Yes", the "System A active power" counter will be set to 34.56 MWh.</li> </ul>
2511	Syst. A react. power [0.00 Mvarh]	2	Yes / No	[No]	<p><b>Yes:</b> The current value of this counter is overwritten with the value configured in "Counter value preset" (parameter 2515). After the counter has been (re)set, this parameter changes back to "No" automatically.</p> <p><b>No:</b> The value of this counter is not changed.</p> <p><b>Example</b></p> <ul style="list-style-type: none"> <li>The counter value preset (parameter 2515) is configured to "3456".</li> </ul> <p>If this parameter is set to "Yes", the "System A reactive power" counter will be set to 34.56 Mvarh.</p>
2512	Syst. A -active power [0.00 MWh]	2	Yes / No	[No]	<p><b>Yes:</b> The current value of this counter is overwritten with the value configured in "Counter value preset" (parameter 2515). After the counter has been (re)set, this parameter changes back to "No" automatically.</p> <p><b>No:</b> The value of this counter is not changed.</p> <p><b>Example</b></p> <ul style="list-style-type: none"> <li>The counter value preset (parameter 2515) is configured to "3456".</li> </ul> <p>If this parameter is set to "Yes", the "System A -active power" counter will be set to 34.56 MWh.</p>
2513	Syst. A -react. power [0.00 Mvarh]	2	Yes / No	[No]	<p><b>Yes:</b> The current value of this counter is overwritten with the value configured in "Counter value preset" (parameter 2515). After the counter has been (re)set, this parameter changes back to "No" automatically.</p> <p><b>No:</b> The value of this counter is not changed.</p> <p><b>Example</b></p> <ul style="list-style-type: none"> <li>The counter value preset (parameter 2515) is configured to "3456".</li> </ul> <p>If this parameter is set to "Yes", the "System A -reactive power" counter will be set to 34.56 Mvarh.</p>

Table 3-32: Parameter – configure counters



## Menu 6 – Analog Inputs

This menu contains the parameters for the configuration of the analog inputs of the MSLC-2.

File View Device Settings Tools Help

Active code level: 0 Device: 33 MENU 6 - ANALOG INPUTS

### Remote load reference input / Process reference input

7673 HW signal	0 - 5V	7735 Remote load ref min value	0,0 kW
Linear		7736 Remote load ref max value	500,0 kW
4311 User defined min display value	0,0 %	7738 Remote load reference input	1,0 kW
4312 User defined max display value	100,0 %		
10117 Remote reference input	0,2 %	7726 Process reference	0,0 kW

### Process signal input

7674 HW signal	1 - 5V	7732 Process engineering unit	kW
Linear			
4322 User defined min display value	0 %	7733 Process min value	-500,0
4323 User defined max display value	100 %	7734 Process max value	500,0
10151 Process signal input	0,0 %	7727 Process signal input	-500,0 kW

### Reactive load input

7675 HW signal	0 - 5V		
Linear			
4333 User defined min display value	-0,99 PF		
4334 User defined max display value	0,71 PF		
7718 Reactive load input	-0,990 PF		

Connected on COM2 Details...

Figure 3-20: ToolKit – analog inputs

### Remote Load Reference Input / Process Reference Input

This analog input can be used for two functionalities:

1. Remote load reference input. The input becomes active, if the DI “Setpoint Raise” / “Setpoint Lower” (remote) are closed and the DI “Base Load” or “Imp/Exp Control” is closed.

### Remote load reference input / Process reference input

7673 HW signal	0 - 5V	7735 Remote load ref min value	0,0 kW
Linear		7736 Remote load ref max value	500,0 kW
4311 User defined min display value	0,0 %	7738 Remote load reference input	1,0 kW
4312 User defined max display value	100,0 %		
10117 Remote reference input	0,2 %	7726 Process reference	0,0 kW

Figure 3-21: ToolKit – relevant fields for remote load reference input

The load control interacts with the percentage input value shown in field *Remote reference input* (parameter 10177). The setting on the right side is the scaling for a minimum and maximum load value while displaying the actual kW setting, which is shown in the field *Remote load reference input* (parameter 7738).



2. Process reference input. The input becomes active, if the DI “Setpoint Raise” / “Setpoint Lower” (remote) are closed and the DI “Process Control” is closed.

Active code level: 5

Device: 33

## MENU 6 - ANALOG INPUTS

### Remote load reference input / Process reference input

7673 HW signal: 0 - 5V

Linear

4311 User defined min display value: 0.0 %

4312 User defined max display value: 100.0 %

10117 Remote reference input: 0.2 %

7735 Remote load ref min value: 0.0 kW

7736 Remote load ref max value: 500.0 kW

7738 Remote load reference input: 1.0 kW

### Process signal input

7674 HW signal: 1 - 5V

Linear

4322 User defined min display value: 0 %

4323 User defined max display value: 100 %

10151 Process signal input: 0.0 %

7732 Process engineering unit: kW

7733 Process min value: -500.0

7734 Process max value: 500.0

7727 Process signal input: -500.0 kW

Figure 3-22: ToolKit – relevant fields for remote process reference input

The process control interacts with the percentage input value shown in field *Remote reference input* (parameter 10117). The setting on the right side will display the actual *Process reference* (parameter 7726). The process engineering unit will allow you to display a 4 to 20 mA input as a kW value (Example, there are many engineering units to select). The process signal input and the process reference (remote) will both display the engineering units selected.

ID	Parameter	CL	Setting range	Default	Description
7673	<b>HW signal</b>	2	0 to 20 mA./ 4 to 20 mA./ 0 to 10 V./ 0 to 5 V./ 1 to 5 V	0 to 5 V	Selection of hardware signal range.
Linear					
4311	<b>User defined min display value</b>	2	-100.0 to 100.0%	0.0%	Remote load reference input / process reference input. Linear scaling: This is the percentage value according to the lowest hardware signal.
4312	<b>User defined max display value</b>	2	-100.0 to 100.0%	100.0%	Remote load reference input / process reference input. Linear scaling: This is the percentage value according to the highest hardware signal.
10117	<b>Remote reference input</b>	-	Info	-	This is the resulting percentage value calculated out of the minimum and maximum scaling as to what the remote input actually has connected.
7735	<b>Remote load ref min value</b>	2	-999999.9 to 999999.9 kW	0.0 kW	This setting is only in use, if the remote load reference input is in use (see description above). This value is the according kW value to the percentage value according to the lowest hardware signal (parameter 4311). This setting is used to display the analog input reference in kW.
7736	<b>Remote load ref max value</b>	2	-999999.9 to 999999.9 kW	500.0 kW	This setting is only in use, if the remote load reference input is in use (see description above). This value is the according kW value to the percentage value according to the highest hardware signal (parameter 4312). This setting is used to display the analog input reference in kW.



ID	Parameter	CL	Setting range	Default	Description
7738	Remote load reference input	-	Info	-	This is the resulting kW value calculated out of the minimum and maximum scaling.
7726	Process reference	-	Info	-	This is the resulting <i>Process reference</i> value calculated out of the minimum and maximum scaling, adjusted in parameter 7733 and parameter 7734.

Table 3-33: Parameter – analog inputs – reference input: remote load/process

## Process Signal Input

This analog input stands for the process control real signal. The input comes as a hardware signal but the engineering values can be selected here. The process engineering units are adjustable and used for visualizing purposes. The regulation of the process is done with the percentage value.

**Process signal input**

7674 HW signal  7732 Process engineering unit

Linear

4322 User defined min display value  % 7733 Process min value

4323 User defined max display value  % 7734 Process max value

10151 Process signal input  % 7727 Process signal input

Figure 3-23: ToolKit – process signal input

ID	Parameter	CL	Setting range	Default	Description
7674	HW signal	2	0 to 20 mA./ 4 to 20 mA./ 0 to 10 V./ 0 to 5 V./ 1 to 5 V	1 to 5 V	Selection of hardware signal range.
Linear					
4322	User defined min display value	2	-100.0 to 100.0%	0.0%	Process signal input (real value). Linear scaling: This is the percentage value according to the lowest hardware signal.
4323	User defined max display value	2	0.0 to 100.0%	100.0%	Process signal input (real value). Linear scaling: This is the percentage value according to the lowest hardware signal.
10151	Process signal input	-	Info	-	This is the resulting percentage value calculated out of the minimum and maximum scaling.
7732	Process engineering unit	2	kW / °C / kPa / bar / V / mA	kW	The process control engineering units can be determined here. With this input the reference and the real value can be defined in engineering units.
7733	Process min value	2	-999999.9 to 999999.9	-500.0	This value is the engineering unit value to the percentage value according to the lowest hardware signal (parameter 4322).
7734	Process max value	2	-999999.9 to 999999.9	500.0	This value is the engineering unit value to the percentage value according to the highest hardware signal (parameter 4323).
7727	Process signal input	-	Info	-	This is the resulting process signal input value calculated out of the minimum and maximum scaling, adjusted in parameter 7733 and parameter 7734.

Table 3-34: Parameter – analog inputs – process signal input



## Reactive Load Input

This analog input stands for the power factor reference signal. Remote var reference control is not available at this time. To activate the remote reactive load input, the discrete inputs “Voltage raise” and “Voltage lower” must be closed.

Figure 3-24: ToolKit – reactive load input

ID	Parameter	CL	Setting range	Default	Description
7675	<b>HW signal</b>	2	0 to 20 mA./ 4 to 20 mA./ 0 to 10 V./ 0 to 5 V./ 1 to 5 V	0 to 5 V	Selection of hardware signal range.
Linear					
4333	<b>User defined min display value</b>	2	-0.999 to 0.999 PF	-0.990 PF	Power factor reference signal input. Linear scaling: This is the power factor value according to the lowest hardware signal.
4334	<b>User defined max display value</b>	2	-0.999 to 0.999 PF	0.710 PF	Power factor reference signal input. Linear scaling: This is the power factor value according to the highest hardware signal.
7718	<b>Reactive load input</b>	-	Info	-	This is the resulting power factor reference calculated out of the minimum and maximum scaling, adjusted in parameter 4333 and parameter 4334.

Table 3-35: Parameter – analog inputs – reactive load input



## Menu 7, 7.1 and 7.2 – Electrical Parameters

This menu contains the general electrical parameters of the MSLC-2.



Figure 3-25: ToolKit – electrical parameters

Menu 7, 7.1, and 7.2 provide all the AC measurement, voltage, current, power and reactive power. The System A (menu 7.1) is always a 3-phase measurement and the System B (menu 7.2) is measured as a single phase. A configuration in Menu 5, *Auxiliary system B available* (parameter 7649), allows additionally the measurement of the system B with 3 phases. The option of the 3-phase system B measurement allows the monitoring of all 3 phases and detection of the system B phase rotation. Menu 7 will display the auxiliary system B measurement values when parameter 7649 is configured to “Yes”.

### Menu 7.1 – System A




Figure 3-26: ToolKit – electrical parameters System A

### Active Power

ID	Parameter	CL	Setting range	Format	Description
135	<b>System A active power</b>	-	Info	0.0 kW	Display of <i>System A active power</i> in kW.
4622	<b>System A active power</b>	-	Info	0%	Display of <i>System A active power</i> in%.

Table 3-36: Parameter – System A – active power



**Reactive Power**

ID	Parameter	CL	Setting range	Format	Description
136	<b>System A reactive power</b>	-	Info	0.0 kvar	Display of <i>System A reactive power</i> in kvar.

Table 3-37: Parameter – system A – reactive power

**Apparent Power**

ID	Parameter	CL	Setting range	Format	Description
137	<b>System A apparent power</b>	-	Info	0.0 kVA	Display of <i>System A apparent power</i> in kVA.

Table 3-38: Parameter – system A – apparent power

**Voltage phase-phase**

ID	Parameter	CL	Setting range	Format	Description
108	<b>System A Voltage L1-L2</b>	-	Info	0.0 V	Display of <i>System A voltage L1-L2</i> in V.
109	<b>System A Voltage L2-L3</b>	-	Info	0.0 V	Display of <i>System A voltage L2-L3</i> in V.
110	<b>System A Voltage L3-L1</b>	-	Info	0.0 V	Display of <i>System A voltage L3-L1</i> in V.

Table 3-39: Parameter – System A – voltage phase-phase

**Voltage phase-neutral**

ID	Parameter	CL	Setting range	Format	Description
114	<b>System A voltage L1-N</b>	-	Info	0.0 V	Display of <i>System A voltage L1-N</i> in V.
115	<b>System A voltage L2-N</b>	-	Info	0.0 V	Display of <i>System A voltage L2-N</i> in V.
116	<b>System A voltage L3-N</b>	-	Info	0.0 V	Display of <i>System A voltage L3-N</i> in V.

Table 3-40: Parameter – System A – voltage phase-neutral

**Power Factor**

ID	Parameter	CL	Setting range	Format	Description
160	<b>System A power factor</b>	-	Info	1.00	Display of <i>System A power factor</i> .
139	<b>System A power factor L1</b>	-	Info	1.00	Display of <i>System A power factor L1</i> .
203	<b>System A power factor L2</b>	-	Info	1.00	Display of <i>System A power factor L2</i> .
204	<b>System A power factor L3</b>	-	Info	1.00	Display of <i>System A power factor L3</i> .

Table 3-41: Parameter – system A – power factor

**Current**

ID	Parameter	CL	Setting range	Format	Description
111	<b>System A current L1</b>	-	Info	0.0 A	Display of <i>System A current L1</i> in A.
112	<b>System A current L2</b>	-	Info	0.0 A	Display of <i>System A current L2</i> in A.



ID	Parameter	CL	Setting range	Format	Description
113	<b>System A current L3</b>	-	Info	0.0 A	Display of <i>System A current L3</i> in A.

Table 3-42: Parameter – System A – current

## Frequency

ID	Parameter	CL	Setting range	Format	Description
144	<b>System A frequency</b>	-	Info	0.00 Hz	Display of <i>System A frequency</i> in Hz.

Table 3-43: Parameter – System A – frequency

## Phase Rotation

ID	Parameter	CL	Setting range	Format	Description
4152	<b>System A phase rotation</b>	-	Info	- / CW / CCW	Display of <i>System A phase rotation</i> : -: The phase rotation is not measurable <b>CW</b> : Clock Wise = phase rotation right <b>CCW</b> : Counter Clock Wise = phase rotation left

Table 3-44: Parameter – system A – phase rotation



## Menu 7.2 – System B

File View Device Settings Tools Help

MSLC-2XT MENU 7.2 - SYSTEM B

Active code level: 0

Device: 33

### MENU 7.2 - SYSTEM B

**Voltage**

216 System B average volt: 0.0 V

**Frequency**

209 System B frequency: 0.00 Hz

4640 Delta frequency System B-A: 0.00 Hz

**Phase angle**

181 Phase angle system B-A: 180.0 °

**Phase rotation**

4152 Configured system B phase rotation: CW

**Auxiliary system B**

**Voltage phase-phase**

118 Aux System B voltage L1-L2: 0.0 V

119 Aux System B voltage L2-L3: 0.0 V

120 Aux System B voltage L3-L1: 0.0 V

**Voltage phase-neutral**

121 Aux System B voltage L1-N: 0.0 V

122 Aux System B voltage L2-N: 0.0 V

123 Aux System B voltage L3-N: 0.0 V

**Frequency**

147 Aux System B frequency: 0.00 Hz

**Phase rotation**

4152 Aux System B phase rotation: -

Only shown, if auxiliary system B is enabled (parameter 7649)

Figure 3-27: ToolKit – electrical parameters System B

### Voltage

ID	Parameter	CL	Setting range	Format	Description
216	<b>System B average volt</b>	-	Info	0.0 V	Display of <i>System B average voltage</i> in V. (If auxiliary System B is available, average Ph-Ph, if not L1-L2 or L1-N depending on "1858 1Ph2W voltage measuring".)

Table 3-45: Parameter – system B – voltage

### Frequency

ID	Parameter	CL	Setting range	Format	Description
209	<b>System B frequency</b>	-	Info	0.00 Hz	Display of <i>System B frequency</i> in Hz.
4640	<b>Delta frequency system B-A</b>	-	Info	0.00 Hz	Display of <i>Delta frequency system B-A</i> in Hz.

Table 3-46: Parameter – system B – frequency

### Phase Angle

ID	Parameter	CL	Setting range	Format	Description
181	<b>Phase angle system B-A</b>	-	Info	180.0°	Display of <i>Phase angle system B-A</i> in degrees.

Table 3-47: Parameter – system B – phase angle

### Phase Rotation

ID	Parameter	CL	Setting range	Format	Description
4152	<b>Configured system B phase rotation</b>	-	Info	CW / CCW	<p>Display of the <i>Configured system B phase rotation</i>:</p> <p><b>CW</b>: Clock Wise = phase rotation right</p> <p><b>CCW</b>: Counter Clock Wise = phase rotation left</p> <p><b>NOTE</b>: This is no measurement displaying. This field shows the configuration of the 1Ph 2W phase rotation (parameter 1859) in Menu 5.</p>

Table 3-48: Parameter – System B – phase rotation



## Auxiliary System B Measurement

(depends on parameter 7649 Auxiliary System B available)

### Voltage phase-phase (Aux. System B)

ID	Parameter	CL	Setting range	Format	Description
118	Aux System B voltage L1-L2	-	Info	0.0 V	Display of <i>Auxiliary System B</i> voltage L1-L2 in V.
119	Aux System B voltage L2-L3	-	Info	0.0 V	Display of <i>Auxiliary System B</i> voltage L2-L3 in V.
120	Aux System B voltage L3-L1	-	Info	0.0 V	Display of <i>Auxiliary System B</i> voltage L3-L1 in V.

Table 3-49: Parameter – aux. system B – voltage phase-phase

### Voltage phase-neutral (Aux. System B)

ID	Parameter	CL	Setting range	Format	Description
121	Aux System B voltage L1-N	-	Info	0.0 V	Display of <i>Auxiliary System B</i> voltage L1-N in V.
122	Aux System B voltage L2-N	-	Info	0.0 V	Display of <i>Auxiliary System B</i> voltage L2-N in V.
123	Aux System B voltage L3-N	-	Info	0.0 V	Display of <i>Auxiliary System B</i> voltage L3-N in V.

Table 3-50: Parameter – aux. system B – voltage phase-neutral

### Frequency (Aux. System B)

ID	Parameter	CL	Setting range	Format	Description
147	Aux System B frequency	-	Info	0.00 Hz	Display of <i>Auxiliary System B</i> frequency in Hz.

Table 3-51: Parameter – aux. system B – frequency

### Phase Rotation (Aux. System B)

ID	Parameter	CL	Setting range	Format	Description
4152	Aux System B phase rotation	-	Info	- / CW / CCW	Display of <i>Auxiliary System B</i> phase rotation: -: The phase rotation is not measurable <b>CW</b> : Clock Wise = phase rotation right <b>CCW</b> : Counter Clock Wise = phase rotation left

Table 3-52: Parameter – auxiliary system B – phase rotation



## Menu 8 – Control Status Monitor

This menu contains the parameters of the control status monitor of the MSLC-2 showing the actual modes, references and alarms.




Figure 3-28: ToolKit – control status monitor

ID	Parameter	CL	Setting range	Format	Description
4602	<b>Synchronizer mode</b>	-	Off / Synchronized / Permissive / Check / Run / Sync Timer / Auto-Off / Close Timer/ Manual	-	<p>Display of the different <i>Synchronizer modes</i>:</p> <p><b>Off:</b> The synchronizer is not active.</p> <p><b>Synchronized:</b> The CB is closed.</p> <p><b>Permissive:</b> The synchronizer runs in permissive mode.</p> <p><b>Check:</b> The synchronizer runs in check mode.</p> <p><b>Run:</b> The synchronizer is full active.</p> <p><b>Sync Timer:</b> The synchronizer is stopped, because of a sync time-out.</p> <p><b>Auto-Off:</b> The synchronizer is stopped, because of an unsuccessful closure of the CB. (resync is disabled).</p> <p><b>Close Timer:</b> This is the CB close command.</p> <p>Manual: manual synchronization</p>



ID	Parameter	CL	Setting range	Format	Description
7672	<b>Reactive load control mode</b>	-	Off / Inactive / Voltage Control / VAR Control / Power Factor Control / Const Gen PF Control /	-	Display of the different <i>Reactive load control modes</i> :  <b>Off:</b> The reactive load control mode is disabled. <b>Inactive:</b> The reactive load control is not active. <b>Voltage Control:</b> The voltage control is active. <b>VAR Control:</b> The reactive load control with kvar reference is active. <b>Power Factor Control:</b> Power factor control is active. <b>Const Gen PF Control:</b> The reactive load control with a constant power factor reference is active.
4603	<b>Load control mode</b>	-	Off Line / Inactive / Base Load / Base Load Lower / Base Load Raise / Base Load Remote / Process Control / Process Lower / Process Raise / Process Remote / Process Ramp / Import Export Control / Import Export Ramp / Import Export Remote / Imp Exp Lower / Imp Exp Raise / Utility Unload	-	Display of the different <i>Load control modes</i> :  <b>Off Line:</b> The load control mode is disabled. <b>Inactive:</b> The load control mode is inactive. <b>Base Load:</b> The Load control operates in base load. <b>Base Load Lower:</b> A base load lower command is active. <b>Base Load Raise:</b> A base load raise command is active. <b>Base Load Remote:</b> The load control setpoint comes remotely. <b>Process Control:</b> The process control is full active <b>Process Lower:</b> A process reference lower command is active. <b>Process Raise:</b> A process reference raise command is active. <b>Process Remote:</b> The process reference comes remotely <b>Process Ramp:</b> The Process ramps toward the reference setting before it hands off to the Process Control. <b>Import Export Control:</b> The Import Export control is active. <b>Import Export Ramp:</b> A ramp to a new Import Export reference is active. <b>Import Export Remote:</b> The Import Export reference value comes remotely <b>Imp Exp Lower:</b> The Import Export lower command is active. <b>Imp Exp Raise:</b> The Import Export raise command is active. <b>Utility Unload:</b> The utility (tie-breaker) is unloaded.
7721	<b>Import / export reference</b>	-	Info	0.0 kW	Display of Import / export load control reference in kW. This field indicates the momentarily load control setpoint.
4605	<b>Process reference</b>	-	Info	0.0%	Display of process control reference in percentage. This field indicates the momentarily process control setpoint.
7722	<b>Reactive load reference</b>	-	Info	0.0 kvar	Display of <i>Reactive load reference</i> in kvar. This field indicates the momentarily reactive load control setpoint.
7708	<b>Power factor reference</b>	-	Info	0.00	Display of the <i>Power factor reference</i> .

Table 3-53: Parameter – control status monitor

## Alarms



### NOTE

All alarms are self-acknowledged!

Alarm states are not stored.

ID	Parameter	CL	Setting range	Format	Description
4606	<b>Synchronizer timeout</b>	-	Info	- / Alarm	Display of Alarm: <i>Synchronizer timeout</i> .
4607	<b>Sync reclose limit</b>	-	Info	- / Alarm	Display of Alarm: <i>Synchronizer reclose limit</i> .
4608	<b>High load limit</b>	-	Info	- / Alarm	Display of Alarm: <i>High load limit</i> .
4609	<b>Low load limit</b>	-	Info	- / Alarm	Display of Alarm: <i>Low load limit</i> .



ID	Parameter	CL	Setting range	Format	Description
7753	Generator high limit	-	Info	- / Alarm	Display of Alarm: <i>Generator high limit.</i>
7754	Generator low limit	-	Info	- / Alarm	Display of Alarm: <i>Generator low limit.</i>
4610	High process limit	-	Info	- / Alarm	Display of Alarm: <i>High process limit.</i>
4611	Low process limit	-	Info	- / Alarm	Display of Alarm: <i>Low process limit.</i>
4613	High voltage limit	-	Info	- / Alarm	Display of Alarm: <i>High voltage limit.</i>
4612	Low voltage limit	-	Info	- / Alarm	Display of Alarm: <i>Low voltage limit.</i>
4614	Voltage range limit	-	Info	- / Alarm	Display of Alarm: <i>Voltage range limit.</i>
10093	System A AC wiring		Info	- / Alarm	Display of Alarm: <i>System A AC wiring.</i>
4615	Communication error NW A	-	Info	- / Alarm	Display of Alarm: <i>Communication error NW A.</i>
4617	Missing member	-	Info	- / Alarm	Display of Alarm: Missing loadshare member.
4618	Centralized alarm	-	Info	- / Alarm	Display of Alarm: <i>Centralized alarm.</i>
4619	GCB open failure	-	Info	- / Alarm	Display of Alarm: <i>GCB open failure.</i>
4620	Deadbus closure mismatch	-	Info	- / Alarm	Display of Alarm: <i>Deadbus closure mismatch.</i>
7770	System B mismatch	-	Info	- / Alarm	Display of Alarm: System B mismatch (connection plausibility check).
7777	Phase rotation mismatch	-	Info	- / Alarm	Display of Alarm: Phase rotation mismatch.
7787	Communication error NW B	-	Info	- / Alarm	Display of Alarm: <i>Communication error NW B</i>
7792	Network A error		Info	- / Alarm	Display of Alarm: <i>Network A error</i>
7793	Network B error		Info	- / Alarm	Display of Alarm: <i>Network B error</i>
7794	Devices not matched		Info	- / Alarm	Display of Alarm: Devices do not matched
10093	Aux. Syst. B AC wiring		Info	- / Alarm	Display of Alarm: <i>Auxiliary System B AC wiring.</i>

Table 3-54: Parameter – control status monitor - alarms

## System A Energy Counters

ID	Parameter	CL	Setting range	Format	Description
2520	Syst. A pos. act. energy	-	Info	0.00 MWh	Counter for: System A positive active energy
2524	Syst. A neg. act. energy	-	Info	0.00 MWh	Counter for: System A negative active energy
2522	Syst. A pos. react. energy	-	Info	0.00 Mvarh	Counter for: System A positive reactive energy



2526	<b>Syst. A neg. react. energy</b>	-	Info	0.00 Mvarh	Counter for: System A negative reactive energy
------	---------------------------------------	---	------	---------------	--

Table 3-55: Parameter – control status monitor – System A energy counters

## Communication Management

ID	Parameter	CL	Setting range	Format	Description
7791	<b>Number of devices in system</b>	-	Info	-	Counter for: Number of devices in the system

Table 3-56: Parameter – control status monitor – communication management



## Menu 9 – Discrete Inputs / Discrete (Relay) Outputs

This menu contains the parameters for the discrete inputs, the discrete input source (hardware or communication interface) and the discrete outputs (relays) of the MSLC-2.




Figure 3-29: ToolKit – discrete inputs / relay outputs

### Discrete Inputs

Parameter 7671 is bit masked starting with 1<sup>st</sup> bit (mask: 0001h) “Check switch”, 2<sup>nd</sup> bit “Permissive switch”, ...

ID	Parameter	CL	Setting range	Default	Description
7671	<b>Check switch</b>	-	Open / Closed	Open	Display of discrete input state for [DI 01]: Check.
7671	<b>Permissive switch</b>	-	Open / Closed	Open	Display of discrete input state for [DI 02]: Permissive.
7671	<b>Run switch</b>	-	Open / Closed	Open	Display of discrete input state for [DI 03]: Run.
7671	<b>CB Aux contact</b>	-	Open / Closed	Open	Display of discrete input state for [DI 04]: CB Aux.
7671	<b>Voltage raise switch</b>	-	Open / Closed	Open	Display of discrete input state for [DI 05]: Voltage raise
7671	<b>Voltage lower switch</b>	-	Open / Closed	Open	Display of discrete input state for [DI 06]: Voltage lower
7671	<b>Base load switch</b>	-	Open / Closed	Open	Display of discrete input state for [DI 07]: Base load.
7671	<b>Utility unload</b>	-	Open / Closed	Open	Display of discrete input state for [DI 08]: Utility unload.
7671	<b>Ramp pause switch</b>	-	Open / Closed	Open	Display of discrete input state for [DI 09]: Ramp pause.



ID	Parameter	CL	Setting range	Default	Description
7671	Setpoint raise switch	-	Open / Closed	Open	Display of discrete input state for [DI 10]: Setpoint raise
7671	Setpoint lower switch	-	Open / Closed	Open	Display of discrete input state for [DI 11]: Setpoint lower
7671	Process control switch	-	Open / Closed	Open	Display of discrete input state for [DI 12]: Process control
7671	Import/ Export switch	-	Open / Closed	Open	Display of discrete input state for [DI 21]: Imp./Exp. control
7671	Modbus re-set switch	-	Open / Closed	Open	Display of discrete input state for [DI 22]: Reset Modbus
7671	System update switch	-	Open / Closed	Open	Display of discrete input state for [DI 23]: System update switch

Table 3-57: Parameter – discrete inputs / outputs – discrete inputs

### Discrete Input Source

Parameter 4157 is bit masked starting with 1<sup>st</sup> bit (mask: 0001h) “Source Check switch”, 2<sup>nd</sup> bit “Source Permissive switch”, ...

ID	Parameter	CL	Setting range	Default	Description
4157	Source-Check switch	-	DI / COM	DI	Indicates the source of “Check” switch either DI or communication interface.
4157	Source-Permissive switch	-	DI / COM	DI	Indicates the source of “Permissive” switch either DI or communication interface.
4157	Source-Run switch	-	DI / COM	DI	Indicates the source of “Run” switch either DI or communication interface.
4157	Source-CB Aux contact	-	DI	DI	“CB Aux” fixed to DI 4.
4157	Source-Voltage raise switch	-	DI / COM	DI	Indicates the source of “Voltage Raise” switch either DI or communication interface.
4157	Source-Voltage lower switch	-	DI / COM	DI	Indicates the source of “Voltage Lower” switch either DI or communication interface.
4157	Source-Base load switch	-	DI / COM	DI	Indicates the source of “Base Load” switch either DI or communication interface.
4157	Source-Utility unload switch	-	DI / COM	DI	Indicates the source of “Utility Unload” switch either DI or communication interface.
4157	Source Ramp pause switch	-	DI / COM	DI	Indicates the source of “Ramp Pause” switch either DI or communication interface.
4157	Source-Setpoint raise switch	-	DI / COM	DI	Indicates the source of “Setpoint Raise” switch either DI or communication interface.
4157	Source-Setpoint lower switch	-	DI / COM	DI	Indicates the source of “Setpoint Lower” switch either DI or communication interface.
4157	Source-Process control switch	-	DI / COM	DI	Indicates the source of “Process Control” switch either DI or communication interface.
4157	Source-Import/Export switch	-	DI / COM	DI	Indicates the source of “Imp./Exp. Control” switch either DI or communication interface.



ID	Parameter	CL	Setting range	Default	Description
4157	Source Modbus re-set switch	-	DI	DI	Modbus reset fixed to DI 22.
4157	Source System update switch	-	DI / COM	DI	Indicates the source of "System update" switch either DI or communication interface.

Table 3-58: Parameter – discrete inputs / outputs – discrete input source

## Discrete (Relay) Outputs

ID	Parameter	CL	Setting range	Default	Description
7572	Alarm	-	Open / Closed	Closed	Display of relay output state for [R 01]: Alarm.
7574	High limit	-	Open / Closed	Open	Display of relay output state for [R 03]: High limit.
7575	Low limit	-	Open / Closed	Open	Display of relay output state for [R 04]: Low limit.
7576	Breaker open	-	Open / Closed	Open	Display of relay output state for [R 05]: Breaker open.
7577	Breaker close	-	Open / Closed	Open	Display of relay output state for [R 06]: Breaker close.
7578	LCL/Gen breaker open	-	Open / Closed	Open	Display of relay output state for [R 07]: LCL/Gen breaker open.
7579	Alarm 1	-	Open / Closed	Open	Display of relay output state for [R 08]: Alarm 1
7580	Alarm 2	-	Open / Closed	Open	Display of relay output state for [R 09]: Alarm 2
7581	Alarm 3	-	Open / Closed	Open	Display of relay output state for [R 10]: Alarm 3.
7582	Load switch 1	-	Open / Closed	Open	Display of relay output state for [R 11]: Load switch 1.
7583	Load switch 2	-	Open / Closed	Open	Display of relay output state for [R 12]: Load switch 2.

Table 3-59: Parameter – discrete inputs / outputs – relay outputs

## Segments

ID	Parameter	CL	Setting range	Default	Description
7604	Segment no .12 active	-	Open / Closed	Open	Display of discrete input state for [DI 13]: Segment no 12 active.
7605	Segment no .23 active	-	Open / Closed	Open	Display of discrete input state for [DI 14]: Segment no 23 active.
7606	Segment no .34 active	-	Open / Closed	Open	Display of discrete input state for [DI 15]: Segment no 34 active.
7607	Segment no .45 active	-	Open / Closed	Open	Display of discrete input state for [DI 16]: Segment no 45 active.
7608	Segment no .56 active	-	Open / Closed	Open	Display of discrete input state for [DI 17]: Segment no 56 active.
7609	Segment no .67 active	-	Open / Closed	Open	Display of discrete input state for [DI 18]: Segment no 67 active.
7610	Segment no .78 active	-	Open / Closed	Open	Display of discrete input state for [DI 19]: Segment no 78 active.
7611	Segment no .81 active	-	Open / Closed	Open	Display of discrete input state for [DI 20]: Segment no 81 active.
7671	Import /Export switch	-	Open / Closed	Open	Display of discrete input state for [DI 21]: Import/Export control.

Table 3-60: Parameter – discrete inputs / outputs – segments



## Menu 0 – Diagnostics

This menu contains the alarms that can be connected to output either for relays 8, 9 or 10.




Figure 3-30: ToolKit – diagnostics

### Set Alarm to Off / Alarm1 / Alarm2 / Alarm3

Each alarm can be set on relay 8 (Alarm 1), relay 9 (Alarm 2) or relay 10 (Alarm 3). Multiple parameters can be selected for the same alarm.



### NOTE

Alarms 1, 2, and 3 can be used for monitoring only.

Don't use alarm messages for protection control!

ID	Parameter	CL	Setting range	Default	Description
7584	<b>Synchronizer timeout alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7585	<b>Reclose limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7586	<b>High load limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7587	<b>Low load limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.



ID	Parameter	CL	Setting range	Default	Description
7588	<b>High process limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7589	<b>Low process limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7590	<b>Low voltage limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7591	<b>High voltage limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7592	<b>Voltage range limit alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7593	<b>Communication error alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7595	<b>Missing member alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7596	<b>Centralized alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7597	<b>CB open fail</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7598	<b>Deadbus closure mismatch</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7771	<b>System B mismatch alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7779	<b>Phase rotation mismatch alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7824	<b>Communication error NW B alarm</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7825	<b>Network A system error</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7826	<b>Network B system error</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
7827	<b>Devices not match</b>	2	Off / Alarm1 / Alarm2 / Alarm3	Off	Passing the alarm to relay Alarm 1, Alarm 2 or Alarm 3.
1964	<b>Plausibility AC Wiring</b>	2	On / Off	On	On: AC wiring monitoring is active Off: AC wiring monitoring not active (For details see "Plausibility check of AC Wiring".)

Table 3-61: Parameter – diagnostics

## Plausibility check of AC Wiring

The MSLC-2XT detects the frequency out of up to six voltages (L1-N, L2-N, L3-N, L1-L2, L2-L3 and L3-L1). The frequency measurement (of all System A and auxiliary System B) additionally checks the values on plausibility. With this monitoring the device can detect wrong wiring issues.



**Wrong Wiring Issue**

It might occur that for example a generator frequency is measured even if the generator is not running. This can happen e.g. if PE (terminal 61) is not connected, the System A neutral connection is broken, and System B (terminals 38/40) is energized (with 1Ph2W connection). In this case a potential shift occurs which could lead to "ghostly" voltages at the System A (or System B, or Auxiliary system B) phase-neutral system. These voltages lead to a frequency measurement even if no voltage is detected in the generator phase-phase system.

The »Plausibility AC wiring « monitoring is introduced to indicate such situations at System A, and auxiliary System B measurement. These alarms are tripping if only "Phase- Phase" or only "Phase-Neutral" frequency is detected. If such an alarm ("System A AC wiring", or " Aux. Syst. B wiring" has tripped please check all "Phase-Phase" and "Phase-Neutral" voltages via Toolkit to get more information and check the AC wiring.



This »Plausibility AC wiring « monitoring function is only active if the wiring can provide "Phase-Phase" and "Phase-Neutral" values.

The plausibility monitoring offers one setting "1964 Plausibility AC Wiring" for System A and auxiliary System B measurement.

If at least one of these monitors has tripped, "4618 Centralized alarm" will become active and the corresponding dedicated alarm "10093 System A AC wiring" or "10095 Aux. Syst. B AC wiring" indicates "Alarm" at Menu 8.



## Overview Pages

The MSLC-2 provides 2 overview pages showing information from up to 32 DSLC-2 and up to 16 MSLC-2.

### LED Display for „System Status“

The system status of each device is displayed by a combination of LED color and the additional text beside „System status“. Both together give the quick status overview of each device; the own device and all another devices in the network. In single mode network information comes from Network A only; using a redundant network system status display takes care for both networks Network A and Network B:

LED color	Displayed text	Explanation	
		Single mode	Redundant mode
GREEN	Unit available	Network A is <b>working</b> accordingly to the latest System Update.	Both networks A and B are <b>working</b> accordingly to the latest System Update.
Twinkling			
YELLOW	BLACK	Only NW A	-/-
Twinkling			
YELLOW	BLACK	Only NW B	-/-
YELLOW	Add device	The device is No Member according to the latest System Update. <b>System update is required!</b>	The device is no member according to the latest System Update. <b>System update is required!</b>
YELLOW	Only NW A	-/-	Only Network A is working, <b>Network B fails.</b>
YELLOW	Only NW B	-/-	Only Network B is working, <b>Network A fails.</b>
Twinkling			
RED	BLACK	Unit not recognized	Communication error on Network A. This unit is <b>suspected</b> .
RED	Unit not recognized	Network A is not working according to the latest System Update. <b>(“Missing Member”)</b>	Communication error on both Networks A and B. This unit is <b>suspected</b> .
RED	Unit not recognized	Network A is not working according to the latest System Update. <b>(“Missing Member”)</b>	Networks A and B are not working. But the latest System Update registered this device as a member. <b>(“Missing Member”)</b>
BLACK	Not installed	Network A is not working. The latest System Update registered this device as No Member. So the device is <b>not installed</b> .	Networks A and B are not working. The latest System Update registered this device as No Member. So the device is <b>not installed</b> .

Table 3-62: System Status quick info at overview pages

See page 200 for more details.



## MSLC-2 Overview Page

The MSLC-2 overview informs about the conditions of the MSLC-2 number 33 to 48 connected to the network. This helps for commissioning a DSLC-2 / MSLC-2 system.




Figure 3-31: ToolKit – MSLC-2 overview page

ID	Parameter	CL	Setting range	Default	Description
	<b>Auto segment number</b>	-	1 to 8	-	This field indicates what each MSLC-2 recognizes to which segment number it is accorded to.
	<b>System status</b>	-	Unit available / Add device / Only NW A / Only NW B / Unit not recognized / Not installed	Not installed	Display if MSLC-2 unit 33 to 48 is available. This text and the illumination of the related LED together describe the device's status in the system. Refer to page 138 for details.

Table 3-63: Parameter – MSLC-2 overview page



## DSL-2 Overview Page

The DSL-2 overview page 1 informs about the conditions of the DSL-2 number 1 to 32 connected to the network. This helps for commissioning a DSL-2 / MSLC-2 system.




Figure 3-32: ToolKit – DSL-2 overview page

ID	Parameter	CL	Setting range	Default	Description
	<b>Auto segment number</b>	-	1 to 8	-	This field indicates what each DSL-2 recognizes to which segment number it is accorded to.
	<b>System status</b>	-	Unit available / Add device / Only NW A / Only NW B / Unit not recognized / Not installed	Not installed	Display if DSL-2 unit 1 to 32 is available. This text and the illumination of the related LED together describe the device's status in the system. Refer to page 138 for details.

Table 3-64: Parameter – DSL-2 overview page



## Prestart Setup Procedure



Apply power to the MSLC-2 control. Verify that the MSLC-2 control passes its power up diagnostics by checking that self-test relay (terminal 41 / 42) is energized. If the unit fails see **Fehler! Verweisquelle konnte nicht gefunden werden. Fehler! Verweisquelle konnte nicht gefunden werden.** for instructions on getting service for the control. Connect the PC configuration software ToolKit via USB connection to the MSLC-2.

### Configuration Menu

Select Menu 5 and adjust all measurement and system relevant configuration items. Set the following setpoints to their appropriate value as described in menu (setpoint) descriptions.

1. Operating Ranges
2. Transformer
3. System Settings

If you have an application with multiple units please check the device number (parameter 1702) of each device:

- The DSLC-2s getting device numbers from 1 to 32
- The MSLC-2s getting device numbers from 33 to 48



## Prestart Segmenting Setup

The Menu 5 contains a configuration named *Basic Segment Number* (parameter 4544).

In the following cases the basic segment number is configured to the default value (1):

- There is only one single DSLC-2 in use
- There are several DSLC-2 / MSLC-2 installed, which work on a common bus, which cannot be separated. (only one segment available)

When the application contains switching elements between DSLC-2s and/or MSLC-2s proceed with following rules:

1. Draw an online diagram of your application with all generators, breakers and utility inputs. Then arrange the DSLC-2 (and MSLC-2) at the according breaker. Refer to Figure 3-33.




Figure 3-33: Example of an online diagram – step 1

2. Draw the measurement systems arrows between unit and bars (refer to Figure 3-34). Please consider following rules:
  - The DSLC-2 is placed at the generator breaker.
  - The MSLC-2 can be placed at the tie-breaker and at the utility breaker.
  - The MSLC-2 at the utility is doing the utility voltage measurement with System A measurement always.  
The system B/Busbar measurement is connected to the busbar (no Aux. measurement in this sample).
  - The MSLC-2 at the tie-breaker usually has the system A on the left side and the system B on the right side.



3. Draw the segment numbers into your online diagram (refer to Figure 3-34).  
Please consider following rules:
  - Begin on the left side with segment number 1.
  - The utility and the generators are not segments in sense of the DSLC-2 / MSLC-2 system.
  - The segment numbers have to follow a line and shall not branch. (Please refer there for to the chapter Network/System) for a better understanding.
4. Draw the device numbers of your units in your online diagram (refer to Figure 3-34).  
Please consider following rules (for a better overview and understanding):
  - The DSLC-2 on the left side should begin with device number 1.
  - The DSLC-2s getting device numbers between 1 and 32.
  - The MSLC-2 on the left side should begin with device number 33.
  - The MSLC-2s getting device numbers between 33 and 48.
5. Draw the “CB Aux” feedbacks and segment connection feedbacks in your online diagram (refer to Figure 3-34).  
Please consider following rules (for a better overview and understanding):
  - The DSLC-2 getting usually only their generator breaker feedback.
  - The MSLC-2 at the utility breaker getting usually only their utility breaker feedback.
  - The MSLC-2 at the tie-breaker getting usually their tie-breaker feedback and parallel the according segment connector feedback.




Figure 3-34: Example of an online diagram with segment numbers and segment connector feedbacks



6. Draw the switches and its networks for Ethernet channel A and B, if used; in your online diagram (refer to Figure 3-35).

Please consider the following rules (for a better overview and understanding):

- Ethernet A is for the device interconnection. Each Ethernet channel A connection gets an own individual UDP TCP/IP address.
- Ethernet B is for the PLC connection. Each Ethernet channel B connection gets an own individual Modbus TCP/IP address.




Figure 3-35: Example of an online diagram with according network

7. You can optionally draw the current measurement and the amount of phases in your online diagram (refer to Figure 3-36).

Please consider following rules (for a better overview and understanding):

- The current measurement is always on system A.
- The positive power flow for MSLC-2 power measurement is defined from A to B.
- The busbar measurement can be 1-phase or 3-phase executed. Please remark this (not shown in diagram below) with one or three lines over the busbar / system B measurement.





8. With the information out of the online diagram, following parameters shall be configurable now:
- Menu 5 *Device number* (parameter 1702):
    - Enter the according device number in the particular units
  - Menu 5 *Basic segment number* (parameter 4544):
    - DSLC-2: Enter the according segment number of the particular unit.
    - MSLC-2 at the utility breaker: Enter the according segment number of the particular unit.
    - MSLC-2 at the tie-breaker: Enter the according segment number which is resided on the left side (System A).
  - Setting in MSLC-2 Menu 5 *Type of MSLC breaker* (parameter 7628):
    - Enter “Utility” or “Tie”.

Page 145/253



## Prestart Synchronizer Setup

Set all synchronizer (Menu 1) setpoints according to the descriptions above and the work sheet. Leave unknown values, such as gain and stability, at their default values.

## Prestart Load Control Setup

Set all load control (Menu 2) setpoints according to the descriptions above and the work sheet. Proportional load control mode should be used during initial setup of the DSLC-2 control. Set the unload trip setpoint to approximately 10% of rated load.

## Prestart Process Control Setup

Set all process control (Menu 3) setpoints according to the descriptions above and the work sheet. If gain and stability values (process control integral gain / ... derivative ratio) are unknown, leave at their default values.

## Prestart Var/Power Factor Control Setup

Set all var/power factor control (Menu 4) setpoints according to the descriptions above and the work sheet. Set *VAR PF control mode* (parameter 7558) to "Disabled" until doing the var/PF control adjustment section on page 156.



## MSLC-2 Control Adjustments



When the prestart setup procedures above have been completed, the MSLC-2 may be installed into the system and the following adjustment procedures must be followed. After the unit has been installed and before applying power to the PT and CT inputs, verify the following:

1. The MSLC-2s see the proper number of DSLC-2 and MSLC-2 controls on the network (see overview page DSLC-2 and MSLC-2 in ToolKit).
2. The DSLC-2s see the proper number of DSLC-2 and MSLC-2 controls on the network (see overview page DSLC-2 and MSLC-2 in ToolKit).
3. The MSLC-2 recognizes the synchronizer switch inputs (see Menu 9).
4. The synchronizer is in the "OFF" mode.

## Calibration Check



Load the system up to a typical import/export level. Check Menu 7 to ensure that the MSLC-2 is sensing the proper voltages, currents, power levels and power factor. Power must measure positive when being imported from the utility. Use Figure 3- to help verify all measurements.

- Ensure that the MSLC-2 synchronizer mode is "Off" (Menu 8).
- Verify that the MSLC-2 sees the proper number of MSLC-2 / DSLC-2 controls (overview pages).
- Verify that the MSLC-2 shows active and reactive power flow in the right signing (Homepage).




Figure 3-37: Power measurement



# Synchronizer Adjustments



This section is for adjusting the synchronizer functions including procedures for phase matching and slip frequency synchronization. Note that dynamic adjustments for gain and stability will be different for each method. To assist in setup and adjustments, you can monitor synchronizer mode of operation on Homepage or Menu 8 and synchronizer mode and slip frequency and synchronoscope values on Menu 7.

## Preliminary Synchronizer Adjustments

1. Set the *Voltage matching* setpoint (parameter 7513) to "Disabled".
2. Select Menu 1 and verify that the *Frequency synchronizer proportional gain* (parameter 4539) and *Frequency synchronizer integral gain* (parameter 4540) setpoints are set to their default values.
3. Set the maximum phase window (parameter 5703, parameter 5704) and maximum slip window (parameter 5701, parameter 5702) setpoints to the desired values or use the default values if unknown.
4. Set the ramp rate for the Digital Input Frequency setpoint raise and lower ( parameter 4713, parameter 4714)
5. Set *Breaker delay* (parameter 5705) to the closure time specified by the breaker manufacturer. Add delay time for any interposing relays if required.
6. Set *CB close hold time* (parameter 3417) to the time desired for the MSLC-2 control to hold the breaker closure signal. This time should at least exceed the breaker delay time.
7. Set the close attempts (parameter 3419) setpoint to "1".
8. Set the *Synchronizer timeout* (parameter 3063) setpoint to "0".
9. Set *Auto re-synchronize* (parameter 7514) to "Disabled".

Proceed to the phase matching synchronizer or slip frequency synchronizer section as required.

## Phase Matching Synchronizer

Do the following steps to setup the synchronizer dynamics for use as a phase matching synchronizer. For slip frequency synchronizing, see the procedure below. The MSLC-2 control indicates the phase angle with the Synchronoscope on the ToolKit Homepage (parameter 4639).



### NOTE

The synchronoscope on the Homepage will show the right phase angle, when all electrical settings are correctly done and the wire connections to the unit are correct. Double check the phase angle across the breaker with a voltmeter or other phase testing device.

1. Set the *Synchronization CB* (parameter 5730) to "Phase matching".
2. Close the synchronizer "Check" mode switch.
3. With System A active (mainly utility) system B active (mainly generator bus), adjust the synchronizer proportional gain setpoint for stable control of the utility frequency as indicated by synchronoscope holding steady at zero phase.



### NOTE

If the system (not the MSLC-2 control) synchronoscope does not lock close to zero phase, but at some other value (such as 30, 60, 180, 210, etc. degrees), verify system A and system B potential wiring to either the synchronoscope or MSLC-2 control.

**DO NOT PROCEED WITH ANY ACTION RESULTING IN BREAKER CLOSURE UNTIL THE PROBLEM IS DETERMINED AND CORRECTED.**

4. Turn the synchronizer mode to "Off" (open discrete inputs). Allow the phase to drift until the synchronoscope indicates approximately 150 degrees fast. It may be necessary to adjust the engine speed setting slightly fast to achieve the desired phase drift.
5. Turn the synchronizer mode to "Check". The synchronizer should pull the generator smoothly



into phase lock. If the synchronizer action is too slow, increase *Frequency synchronizer proportional gain* (parameter 4539) by a factor of two. If increasing sync gain results in unstable operation, reduce the value by at least one-half and proceed to step 6. Otherwise, repeat steps 4 and 5.

6. Do step 4 and then turn the synchronizer mode to "Check". The synchronizer should pull the generator smoothly into phase lock. If the synchronizer is too slow or "over-damped", increase integral gain (parameter 4540) by a factor of two to decrease damping and increase sync proportional gain by a factor of two. If the synchronizer is too fast or "under-damped" as indicated by excessive overshoot of zero phase when pulling in, decrease sync proportional gain by a factor of two and decrease integral gain by a factor of two to increase damping.
7. Repeat steps 4, 5 and 6, with smaller adjustment steps until satisfactory performance is obtained.
8. Turn the synchronizer mode to "Off". Allow the phase to drift until the synchronoscope indicates approximately 150 degrees slow. It may be necessary to adjust the engine speed setting slightly slow to achieve the phase drift. Repeat steps 5 and 6 if necessary to get the desired performance.
9. Verify synchronizer performance under all expected operating conditions, such as synchronizing at higher or lower speeds.
10. If voltage matching is to be used, do the setup in the voltage matching section below.

Proceed to final synchronizer setup.

## Slip Frequency Synchronizer

Do the following steps to setup the synchronizer dynamics for use as a slip frequency synchronizer.

1. Complete the phase matching synchronizer setup before continuing.
2. Turn the synchronizer mode to "Off". Set the *Slip frequency setpoint offset* (parameter 4712) to the desired slip rate. Set engine speed slightly slow.
3. Turn the synchronizer mode to "Check". The synchronizer should drive engine speed so that phase rotation is smooth and at the correct rate as indicated on a synchronoscope or by observing the slip frequency value on Menu 7 (parameter 4640). If the synchronizer is too slow to react when switched from off to check mode, increase *Frequency synchronizer proportional gain* (parameter 4539) by a factor of two. If the synchronizer action is too aggressive when switched to check mode, reduce the sync proportional gain by half of what your last adjustment.

### Example:

If you moved from a proportional gain of 1 to 2, reduce to 1.5. Repeat until the synchronizer controls the system A at your desired rate.

4. Observe the smoothness of phase rotation. If a slow hunt is observed, as indicated by slowing and speeding up of the synchronoscope during rotation, increase *Frequency synchronizer integral gain* (parameter 4540) by a factor of two and repeat step 3. If rapid changes in slip frequency occur, decrease sync integral gain.
5. Repeat steps 3 and 4 with smaller adjustment steps until satisfactory performance is obtained. Note that it may not be possible to remove all slow hunting in slip frequency and this will not adversely affect synchronization.
6. Verify synchronizer performance under all expected operating conditions, such as synchronizing from higher or lower speeds.
7. If voltage matching or the var/PF control is to be used, do the setup in the voltage matching adjustment section below.

Proceed with final synchronizer setup.



## Final Synchronizer Setup

1. Open the circuit breaker to disconnect the system A (usually mains) from system B.
2. Set close attempts (parameter 3419) to the desired number of times the synchronizer should attempt to close the circuit breaker. Set to "1" if only one close attempt should be made.
3. Set *Reclose delay* (parameter 4534) to the desired interval between close attempts. This should be greater than the time required to recharge the circuit breaker arming mechanism.
4. If an alarm is desired when the maximum close attempts has been reached, set sync reclose alarm to "Enabled".
5. Set the *Synchronizer timeout* (parameter 3063) to the maximum number of seconds the synchronizer should attempt to achieve synchronization. Set to "0" for no timeout.
6. If an alarm is desired when the sync timeout interval expires, set the *Synchronizer timeout alarm* (parameter 7557) setpoint to "Enabled".
7. If it is desired to automatically attempt to reclose the circuit breaker on loss of synchronization (CB Aux opens after a successful closure has been accomplished), set the *Auto re-synchronize* (parameter 7514) setpoint to "Enabled". If set to "Disabled", the synchronizer will enter an auto-off mode when synchronization is obtained. It will be necessary to set the synchronizer mode switch to "Off" and back to the desired operating mode to restart the synchronizer.

This completes the MSLC-2 control synchronizer setup.



# Voltage Matching Adjustments



The following steps will verify the correct operation of the synchronizer voltage matching function. With the breaker open and at least one generator on line, momentarily raise and lower the voltage on the local generator bus.



## NOTE

Individual DSLC-2 controls must be setup for proper voltage regulator control prior to adjusting the MSLC-2 control (See the DSLC-2 manual).

## Preliminary Voltage Matching Setup

1. Select Menu 1 and set the *Voltage matching* (parameter 7513) setpoint to “Enabled”.
2. Select Menu 7 and display both system A and system B voltages.
3. With the synchronizer “Off”, manually raise the local bus (system B) voltage until it is approximately 5% higher than the utility voltage.
4. Set the synchronizer mode to “Check”. The MSLC-2 should adjust the local bus voltage until it is within the voltage window selected in Menu 1.
5. If the voltage cycles through the window without settling into it, use the *Voltage synchronizer proportional gain* (parameter 5610) and integral gain to obtain the response you want. Lowering these values will slow the response. It might be that the DSLC-2s will have to be adjusted to obtain the response needed.
6. Set the synchronizer to “Off”, manually lower the local bus voltage until it is approximately 5% lower than the utility voltage.
7. Set the synchronizer mode to “Check”. The MSLC-2 should adjust the local bus voltage until it is within the voltage window selected in Menu 1.



## NOTE

If the slip frequency reference is set to zero, the voltage window is  $\pm$  the setpoint chosen in Menu 1. If the slip frequency reference is set to a negative or slow slip, the voltage window is such that the local bus voltage must be less than the utility voltage. Conversely, if the slip frequency reference is set to a positive or fast slip, the voltage window is such that the local bus voltage must be greater than the utility voltage. This ensures that the initial flow of reactive power is in the same direction as the initial flow of real power.

## Final Voltage Matching Setup

1. Set the voltage high/low limits in Menu 4 to their desired values.
2. Enable the voltage alarms and voltage switches in Menu 4 if it is desired to activate the alarm or the high/low limit relay drivers upon exceeding a setpoint.



## Load Control Adjustment



This section contains the instructions for setup of the MSLC-2 load control. Set all load control setpoints (Menu 2) according to the descriptions above and the work sheet. The Homepage or Menu 8 displays the load control mode, import/export reference and load command outputs are provided to assist in setup and verification of correct operation.



### NOTE

The load control is only possible if the DSLCs can listen to the MSLC and does not operate in Droop mode (DI Droop switch or Droop Missing member).

## Base Load Mode Setup

The base load mode is used when manual control of the operating generators is required, or whenever the generators are desired to be maintained at a set percentage of their rated load without regard to plant loading or import/export levels.

1. Adjust the setpoints in Menu 2 as described above. Set the parameter *Load control setpoint source* (parameter 7634) to "Internal". Check that the DIs setpoint raise and lower are not energized.
2. Switch the MSLC-2 in base load master control. This is done by energizing the DI "Base Load" and the "CB Aux".
3. Break the parallel between the local bus (system A) and the utility (system B). Place at least one generator in isochronous load sharing (isolated run).
4. Watch the *Load control mode* field (parameter 4603) in the Homepage. Re-synchronize and parallel the local bus (system B) to the utility (system A). Verify that, when the breaker at the MSLC-2 closes, the load command assumes the value of system load immediately prior to paralleling.
5. Temporarily issue a lower setpoint command and then a raise setpoint command. Verify that the load command changes appropriately and that the engines running in base load respond appropriately. You can watch in the Homepage the setpoint load level going down to the DSLC-2s (parameter 4629).

## Remote Base Load

Do the following steps if the analog *Remote load reference input* (parameter 7738) is used in base load control.

1. As a basic do the base load mode setup described above.
2. The value of the remote input is to configure and can be viewed in Menu 6. Before you start the engine check over the displaying field in Menu 6 (parameter 7738) if the analog input is right transformed in a base load reference value in kW.
3. Switch the MSLC-2 in base load master control. This is done by energizing the DI "Base Load".
4. Synchronize and parallel the local bus (system B) to the utility (system A) in the base load mode. Adjust the signal input to a level different from the present base load level.
5. Close both the raise and lower setpoint contacts to select the remote mode. The *Load control mode* (parameter 4603) in Menu 8 or in the Homepage should indicate base load and the load command should ramp to the specified level.
6. Raise and lower the analog signal. The load will ramp at the rates chosen in Menu 2 load and unload ramp rates. These rates may be adjusted to achieve satisfactory performance.
7. Open the raise and lower setpoint contacts. The *Load control mode* (parameter 4603) should indicate base load and the control remains at the last base load level chosen by the analog input.

This completes the remote base load reference setup procedure.



## Import/Export Mode Setup

1. As a basic do the base load mode setup described above.
2. An important assumption for setup this mode is the right connection of the CT's of the MSLC-2. Be sure that incoming real power (power flow from system A to system B) is displayed positive (see Homepage) and incoming lagging reactive power is displayed positive as well. Do not proceed if you have not clarified the right measurement.
3. Check Menu 2 setpoints for *Import/export control proportional gain* (parameter 5510), *Import/export control integral gain* (parameter 5511), and *Import/export control derivative ratio* (parameter 5512) whether they are adjusted to their default values.
4. Adjust the setpoints in Menu 2 as described in the parameter setup chapter above. Set the parameter *Load control setpoint source* (parameter 7634) to "Internal". Check that the DI's setpoint raise and lower are not energized. Configure an import/export reference (parameter 7717), positive value is importing power from mains, negative value is exporting power to mains.



### NOTE

**Do not chose an export level if it is not allowed by the utility.**

5. Switch the MSLC-2 in import/export load master control. This is done by energizing the DI "Import/Export Control".
6. Break the parallel between the local bus (system A) and the utility (system B). Place at least one generator in isochronous load sharing.
7. Re-synchronize and parallel the local bus (system B) to the utility (system A). Verify that, when the breaker at the MSLC-2 closes, the load command assumes the value of system load immediately prior to paralleling. The control will ramp the *Setpoint load level* (parameter 4629) output until the import/export level is within its target.
8. If the import/export control is unstable when taking control, decrease the import/export proportional gain to achieve stability. If the chosen import/export level is not obtainable within the 0 to 100% load command range, the control will stop at 0% or 100%. If a slow hunt is observed or excessive overshoot of the export/import value occurs, decrease the process integral gain.
9. Temporarily issue a lower setpoint command and then a raise setpoint command. Verify that the import/export reference changes appropriately and that the running engines respond appropriately. You can watch in the Homepage the *Setpoint load level* (parameter 4629) decreasing to the DSLC-2s.

This completes the import/export setup.

## Remote Import/Export Setup

Do the following steps if analog remote load reference input is to be used. The value of the remote input is configured and viewed in Menu 6.

1. As a basic do the import/export load mode setup described above.
2. Set the scaling of the analog signal according to the instructions of the Menu 6. The remote load reference signal will be interpreted as an import/export load reference when the DI import/export control is given.
3. Close both the raise and lower setpoint contacts to select the remote mode. The load control mode in Menu 8 or the Homepage should indicate import/export remote and the load command of the MSLC-2 to DSLC-2 ramps to the needed level.
4. Raise and lower the analog signal. The load will ramp at the rates chosen in Menu 2 load and unload ramp rates. These rates may be adjusted to achieve satisfactory performance. Open the raise and lower setpoint contacts the load control mode indicates import/export control and the control keeps the last import/export level.

This completes the remote import/export reference setup procedure.



## Final Load Control Setup

1. Set Menu 2 Load ramp rate (parameter 4700) and *Unload ramp rate* (parameter 4524) to desired values.
2. Set *Raise load rate* (parameter 4515) and *Lower load rate* (parameter 4516) to desired values.
3. Set the *Utility unload trip* (parameter 4506) and *Generator unload trip* (parameter 3125) levels to their desired values.
4. The import real load can be monitored by the high load Limit PU (pick up) and DO (drop out) setpoints. The settings are related on a rated power System A (parameter 1752).
5. The export real load can be monitored by the low load limit PU (pick up) and DO (drop out) setpoints. The settings are related on a rated power at the interchange point (parameter 1752).
6. If it is desired that the alarm output *High load limit* (parameter 4608) alarm is activated when load reaches the high limit PU, set the high load limit alarm setpoint to "Enabled". The alarm will be automatically cleared when load drops below the high load limit DO switch point.
7. If it is desired that the alarm output *Low load limit* (parameter 4609) alarm is activated when load reaches the low limit PU, set the low load limit alarm setpoint to "Enabled". The alarm will be automatically cleared when load increases to above the low load limit DO switch point.
8. If it is desired that the high and low limit switches also activate the "High Limit" and "Low Limit" relays, set the *Load limit switch* (parameter 7506) setpoint to "Enabled".
9. Set the load switch PU and load switch DO setpoints to their desired operating levels.



## Process Control Adjustment



This section contains instructions for setup of the MSLC-2 process control. Menu 6 provides the setting for the process input signal and the according engineering units. Menu 6 and the Homepage displays the resulting real signal in percentage and in engineering units. Menu 8 shows the process control setpoint in percentage. The Homepage displays the setpoint process control in percentage and engineering units.

1. Configure in Menu 6 the *Process signal input* (parameter 7727) according to the chapter setup description Menu 6 in this manual. Don't forget to scale engineering units according to the real process signal. This is the base that the process control reference signal can be interpreted.
2. Check Menu 3 setpoints for *Process control proportional gain* (parameter 4500), *Process control integral gain* (parameter 4501), *Process control derivative ratio* (parameter 4502) and *Process filter* (parameter 4509) whether they are adjusted to their default values.
3. Set Menu 3 *Process control action* (parameter 7559) to "Direct" or "Indirect" as required for the process. If increasing load also increases the process input signal level, use "Direct". If increasing load decreases the process input signal level, use "Indirect".
4. Set the internal *Process reference* (parameter 7737) setpoint Menu 3 to a value requiring approximately 50% load to maintain the process signal level. If the required process reference is not known at start-up, operate the MSLC-2 in base load mode. Use the raise and lower setpoint inputs to adjust the load until the desired process level is obtained. Observe the process input in Menu 6 or the Homepage to determine the required process reference value.
5. Close the process switch. Select "Run" on the MSLC-2 to parallel the local bus with the utility. The MSLC-2 will ramp into process control.
6. If the process control is unstable when taking control, decrease the *Process control proportional gain* to achieve stability. If decreasing *Process control proportional gain* (parameter 4500) increases instability, increase *Process control integral gain* (parameter 4501). If the process control gain is too slow, increase the *Process control proportional gain* (parameter 4500) by a factor of two. If a slow hunt is observed or excessive overshoot of the process reference settings occurs, increase the process integral gain by a factor of two.
7. In systems experiencing rapid fluctuations of the process input, increasing the process filter will provide a slower but more stable response.
8. Introduce *Process droop* (parameter 4508) if required.
9. The real process value can be monitored by the *Process high limit PU* (parameter 4510) and DO setpoints to issue an alarm.
10. The real process value can be monitored by the *Process low limit PU* (parameter 4513) and DO setpoints to issue an alarm.
11. If it is desired that the alarm output *High process limit* (parameter 4610) alarm is set when the process input reaches the *Process high limit PU* (parameter 4510), set the *Process high limit alarm* (parameter 7500) setpoint to "Enabled". The alarm will be automatically cleared when the process input level drops below the *Process high limit DO* (parameter 4511) switch point.
12. If it is desired that the alarm output *Low process limit alarm* (parameter 7589) is set when the process input reaches the *Process low limit PU* (parameter 4513), set the *Process low limit alarm* (parameter 7501) setpoint to "Enabled". The alarm will be automatically cleared when the process input increases to a level above the *Process low limit DO* (parameter 4514) switch point.
13. If it is desired that the high and low limit switches also activate the "High Limit" and "Low Limit" relays, set the *Process switches* (parameter 7502) setpoint to "Enabled".

This completes setup and adjustment of the MSLC-2 process control function.



## Var/PF Control Adjustment



This section describes the setup and adjustment of the MSLC-2 voltage/var/PF control functions. The voltage control is used in case of voltage matching for the synchronizer. The var/PF control is used, if the DSLC- 2 / MSLC-2 system runs parallel to the utility. The values of kvars and average power factor are available in Menu 7 or the Homepage.



### NOTE

The VAR/PF control is only possible if the DSLCs can listen to the MSLC and does not operate in Droop mode (DI Droop switch or Droop Missing member).



### NOTE

Var/PF control effectiveness depends on var/PF control in the DSLC-2s. Because of that commission the DSLC-2 var/PF control first.

1. Verify that the voltage matching adjustments above have been done.
2. Select Menu 4 and set *VAR control proportional gain* (parameter 5613), *VAR control integral gain* (parameter 5614) and *VAR control derivative ratio* (parameter 5615) to their default values.

## Constant Generator Power Factor Setup

The MSLC-2 can send a constant generator power factor setpoint to the DSLC-2s. The power factor reference is configured in Menu 4 (parameter 5621). The constant generator power factor will be executed, if:

- The MSLC-2 runs in base load mode OR
    - When in Base load mode, the MSLC-2 can only operate in the constant generator PF mode.
  - The MSLC-2 runs in export/import mode and the *VAR PF control mode* (parameter 7558) in Menu 4 is configured to “Constant Generator PF”.
1. Set the *VAR control setpoint source* (parameter 7635) to “Internal”. Set the desired constant generator power factor reference in Menu 4 (parameter 5621).
  2. Run the DSLC-2 / MSLC-2 system parallel to the utility. For test purposes change between different constant generator power factors to validate the functionality. When the power factor at the DSLC-2 begins to swing check the settings at the DSLC-2s.

This completes setup of the MSLC-2 constant generator power factor function.



## PF Control at the Utility - Setup

The MSLC-2 can regulate a power factor at the interchange point. A PID control compares the power factor reference with the real value and sends a reactive load setpoint to the DSLC-2 to run the error signal to zero. Whatever is sent for reactive load level to the DSLC-2s, the DSLC-2 allows not more than 10% rated vars for leading and do not allow more than 100% rated vars for lagging.

1. Set the *VAR control setpoint source* (parameter 7635) to "Internal". Set the *VAR PF control mode* (parameter 7558) to "PF Control". Set the desired *Power factor reference* (parameter 5620) in Menu 4.
2. An important assumption for setup is the right connection of the CTs of the MSLC-2. Be sure that incoming power is displayed positive (refer to ToolKit Homepage) and incoming lagging reactive power is displayed positive as well. Do not proceed if you have not clarified the right measurement.
3. Check Menu 4 setpoints for *VAR control proportional gain* (parameter 5613), *VAR control integral gain* (parameter 5614), and *VAR control derivative ratio* (parameter 5615) whether they are adjusted to their default values.
4. Switch to base load at the MSLC-2.
5. Run the DSLC-2 / MSLC-2 system parallel to the utility. For test purposes change between different setpoints for the constant generator power factor reference. When the power factor at the DSLC-2 begins to swing check the settings at the DSLC-2s.
6. Run a base load and a generator constant power factor with the DSLC-2 which gives the generators the capability to run the desired power factor at the interchange point. Prepare an import/export control reference which can be maintained by the engines.



### NOTE

**Do not chose a power factor level if it is not allowed by the utility.**

7. Check that the DIs "Voltage Lower" and "Voltage Raise" are not energized and switch the MSLC-2 in import/export load master control. This is actively done by energizing the DI "Imp./Exp. Control".
8. The MSLC-2 should influence the reactive load of the DSLC-2 so that the desired power factor is matched at the utility. If the control action is too fast decrease *VAR control proportional gain* (parameter 5613). If the control action is too slow to bring the PF into control, increase the *VAR control proportional gain* (parameter 5613). If overshoot of the setpoint occurs, decrease *VAR control integral gain* (parameter 5614).
9. Check the regulating behavior by switching several times between base load mode and import/export control mode and watch the guidance of the power factor by the MSLC-2.

This completes setup of the PF control at the interchange point.

## Remote PF Control at the Utility - Setup

Do the following steps if the analog "Reactive Load" input signal is used. The analog signal can only be used for the power factor setpoint at the utility.

1. First do the "PF Control at the Utility – Setup", before you proceed with this topic.
2. The value of the remote input needs to be configured and can be viewed in Menu 6. Before you start the engine check over the displaying field in Menu 6 (parameter 7718) if the analog input is right transformed in a power factor reference value.
3. Set the *VAR control setpoint source* (parameter 7635) to "Internal".
4. The power factor reference will be accepted from the MSLC-2 when the "Voltage raise" and "Voltage lower" commands are given and the MSLC-2 runs in export/import mode and the *VAR PF control mode* (parameter 7558) in Menu 4 is configured to "PF Control".
5. Run the DSLC-2 / MSLC-2 system parallel to the utility. For test purposes change the setpoint over the analog input to validate the functionality. When the power factor at the utility begins to swing check the PID settings in the MSLC-2.

This completes setup of the remote PF control at the interchange point.



## Var Control at the Utility - Setup

The MSLC-2 can regulate kvars at the interchange point. A PID control compares the kvar reference with the real value and sends a reactive load setpoint to the DSLC-2 to run the error signal to zero. Whatever is sent for reactive load level to the DSLC-2s, the DSLC-2 allows not more than 10% rated vars for leading and do not allow more than 100% rated vars for lagging.

1. First do the “PF Control at the Utility – Setup”, before you proceed with the vars.
2. Set the *VAR control setpoint source* (parameter 7635) to “Internal”. Set the *VAR PF control mode* (parameter 7558) to “VAR Control”.
3. Set the desired *KVAR reference* (parameter 7723) in Menu 4. For a correct and universal regulating configure the rated kvar for the MSLC-2 system. If unknown take the same amount as for the rated active power (parameter 1752).
4. An important assumption for setup this mode is the right connection of the CTs of the MSLC-2. Be sure that incoming power is displayed positive (refer to ToolKit Homepage) and incoming lagging reactive power is displayed positive as well. Do not proceed if you have not clarified the right measurement.
5. Check Menu 4 setpoints for *VAR control proportional gain* (parameter 5613), *VAR control integral gain* (parameter 5614), and *VAR control derivative ratio* (parameter 5615) whether they are adjusted to their default values.
6. Switch to base load at the MSLC-2. Run the DSLC-2 / MSLC-2 system parallel to the utility. For test purposes change between different setpoints for the constant generator power factor reference. When the power factor at the DSLC-2 begins to swing check the settings at the DSLC-2s.
7. Run a base load and a generator constant power factor with the DSLC-2 which gives the generators the capability to run the desired kvars at the interchange point. Prepare an import/export control reference which can be maintained by the engines.



### NOTE

**Do not chose a var level if it is not allowed by the utility.**

8. Check that the DIs “Voltage Lower” and “Voltage Raise” are not energized and switch the MSLC-2 in import/export load master control. This is actively done by energizing the DI “Imp./Exp. Control”.
9. At next the MSLC-2 influences the reactive load of the DSLC-2 so that the desired kvars are matched at the utility. If the control action is too fast decrease *VAR control proportional gain* (parameter 5613). If the control action is too slow to bring the var into control, increase the *VAR control proportional gain* (parameter 5613). If overshoot of the setpoint occurs, decrease *VAR control integral gain* (parameter 5614).
10. Check the regulating behavior by switching several times between base load mode and import/export control mode and watch the guidance of the kvars by the MSLC-2.

This completes var control adjustments.



# Chapter 4.

## Synchronizer Description

### Introduction



Synchronization is the matching of the output voltage wave form of one synchronous alternating current electrical generator with the voltage wave form of another alternating current electrical system. For the two systems to be synchronized and connected in parallel, five conditions must be considered:

- The number of phases in each system
- The direction of rotation of the phases
- The voltage amplitudes of the two systems
- The frequencies of the two systems
- The phase angle of the voltage of the two systems

The first two conditions are determined when the equipment is specified, installed and wired. The synchronizer matches the remaining conditions (voltage, frequency and phase) before the paralleling breakers are closed.

### Functional Description



This section describes how generator and bus matching occurs and how all conditions are verified by the synchronizer functions. The examples shown in chapter "Measurement Connections (Examples)" on page 161 demonstrate the AC measurement connection and configuration of the MSLC-2 system.

### Operating Modes

The operation of the synchronizer is determined by the discrete inputs shown in Figure 4-1. The synchronizer modes are *Off*, *Check*, *Permissive*, *Run*, and *Manual*. When all 3 discrete inputs are open (De-Energized) you are in the *Off* mode. *Manual* mode is achieved by selecting both the Check and Permissive inputs. In *Manual* mode you will use the setpoint raise and lower inputs to affect the *frequency control setpoint* (5500) in the DSLC-2. The voltage raise and lower inputs will affect the *voltage control setpoint* (5600) in the DSLC-2.

**Run mode** allows normal synchronizer operation and breaker closure signals. When the specified closure signal time has elapsed or the CB (circuit breaker) aux contact closure signal is received at DI 4 (terminal 70), the synchronizer is disabled. The synchronizer may optionally be reset automatically when the generator is disconnected from the bus.

The breaker close command follows the *CB close hold time* (3417) setting. It does not stay closed for the complete time you are within the proper limits.

**Check mode** allows normal synchronizing and voltage matching, but does not issue a breaker closure signal.

**Permissive mode** enables the synch-check function for proper synchronization, but synchronizer operation does not affect the engine's speed or generator voltage. If phase, frequency and voltage are within proper limits, the synchronizer issues the breaker closure command.

The breaker close command is always a "Constant" signal:

The breaker close command remains enabled as long as the synchronization conditions are matched.



#### NOTE

In case of power loss, the MCB breaker must be opened manually, because the MSLC-2s output cannot be energized.



The MSLC-2 is no protective device. In case of overvoltage the breaker has to be opened externally.




Figure 4-1: Synchronizer block diagram



## Measurement Connections (Examples)

### Low Voltage System 480 V / 277 V - 3-Phase with Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase with neutral
- System B measurement : L1-L2 (“Phase – phase”)




Figure 4-2: Low voltage system 480 V / 277 V – 3-phase with neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “480 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 4W”</li> <li>• System B rated voltage (parameter 1781): “480 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – phase”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “No”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “480 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “480 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “480 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “480 V”</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1</li> <li>• System A [V] L2</li> <li>• System A [V] L3</li> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1-L2</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1</li> <li>• System A [V] L2</li> <li>• System A [V] L3</li> </ul> <p>OR</p> <ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-1: Low voltage system 480 V / 277 V – 3-phase with neutral



## Low Voltage System 480 V / 277 V - 3-Phase with Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase with neutral
- System B measurement : **L1-N** ("**Phase – neutral**")




Figure 4-3: Low voltage system 480 V / 277 V – 3-phase with neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• <i>System A rated voltage</i> (parameter 1766): "480 V"</li> <li>• <i>System A current input</i> (parameter 1850): "L1 L2 L3"</li> <li>• <i>System A voltage measuring</i> (parameter 1851): "3Ph 4W"</li> <li>• <i>System B rated voltage</i> (parameter 1781): "277 V"</li> <li>• <i>1Ph2W voltage input</i> (parameter 1858): "Phase – neutral"</li> <li>• <i>1Ph2W phase rotation</i> (parameter 1859): "CW"</li> <li>• <i>Auxiliary System B available</i> (parameter 7629): "No"</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• <i>System A PT primary rated voltage</i> (parameter 1801): "480 V"</li> <li>• <i>System A PT secondary rated volt.</i> (parameter 1800): "480 V"</li> <li>• <i>System B PT primary rated voltage</i> (parameter 1804): "480 V"</li> <li>• <i>System B PT secondary rated volt.</i> (parameter 1803): "480 V"</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1</li> <li>• System A [V] L2</li> <li>• System A [V] L3</li> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1</li> <li>• System A [V] L2</li> <li>• System A [V] L3</li> </ul> <p>OR</p> <ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-2: Low voltage system 480 V / 277 V – 3-phase with neutral



## Low Voltage System 480 V - 3-Phase with Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase with neutral
- System B measurement : **L1-N ("Phase – neutral")**
- Auxiliary system B busbar measurement: 3-Phase with neutral (connection plausibility checked, see page 37)




Figure 4-4: Low voltage system 480 V – 3-phase with neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): "480 V"</li> <li>• System A current input (parameter 1850): "L1 L2 L3"</li> <li>• System A voltage measuring (parameter 1851): "3Ph 4W"</li> <li>• System B rated voltage (parameter 1781): "277 V"</li> <li>• 1Ph2W voltage input (parameter 1858): "Phase – neutral"</li> <li>• 1Ph2W phase rotation (parameter 1859): "CW"</li> <li>• Auxiliary System B available (parameter 7629): "Yes"</li> <li>• Aux System B voltage measuring (parameter 1853): "3Ph 4W"</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): "480 V"</li> <li>• System A PT secondary rated volt. (parameter 1800): "480 V"</li> <li>• System B PT primary rated voltage (parameter 1804): "480 V"</li> <li>• System B PT secondary rated volt. (parameter 1803): "480 V"</li> </ul> <div style="display: flex; align-items: center;"> <div style="border: 2px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"> <b>i</b> </div> <div> <b>NOTE</b>            Connection plausibility is checked: "System B mismatch" Alarm ID 7770. See page 37 for details.         </div> </div>	<ul style="list-style-type: none"> <li>• System A [V] L1</li> <li>• System A [V] L2</li> <li>• System A [V] L3</li> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> <li>• Aux System B [V] L1</li> <li>• Aux System B [V] L2</li> <li>• Aux System B [V] L3</li> <li>• Aux System B [V] L1-L2</li> <li>• Aux System B [V] L2-L3</li> <li>• Aux System B [V] L3-L1</li> <li>• Aux System B phase rotation</li> <li>• Aux System B [Hz]</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1</li> <li>• System A [V] L2</li> <li>• System A [V] L3</li> </ul> <p>OR</p> <ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-3: Low voltage system 480 V – 3-phase with neutral



## Low Voltage System 600 V / 346 V - 3-Phase

- Phase rotation clockwise
- System A measurement: 3-Phase PT “Open Delta” (Phase L2 (B) is grounded at the MSLC-2 connection)
- System B measurement: 1-Phase PT **L1-L2 (“Phase – phase”)**




Figure 4-5: Low voltage system 600 V / 346 V – 3-phase

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “600 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 4W OD”</li> <li>• System B rated voltage (parameter 1781): “600 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – phase”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “No”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “600 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “120 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “600 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “120 V”</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1-L2</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-4: Low voltage system 600 V / 346 V – 3-phase



## Low Voltage System 600 V / 346 V - 3-Phase

- Phase rotation clockwise
- System A measurement: 3-Phase PT “Open Delta” (Phase L2 (B) is grounded at the MSLC-2 connection)
- System B measurement: 1-Phase PT L1-N (“Phase – neutral”)




Figure 4-6: Low voltage system 600 V / 346 V – 3-phase

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “600 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 4W OD”</li> <li>• System B rated voltage (parameter 1781): “346 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – neutral”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “No”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “600 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “120 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “600 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “120 V”</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-5: Low voltage system 600 V / 346 V – 3-phase



## Low Voltage System 600 V / 346 V - 3-Phase

- Phase rotation clockwise
- System A measurement: 3-Phase PT “Open Delta” (Phase L2 (B) is grounded at the MSLC-2 connection)
- System B measurement: 1-Phase PT **L1-L2 (“Phase – phase”)**
- Auxiliary system B measurement: 3-Phase “Open Delta”




Figure 4-7: Low voltage system 600 V / 346 V – 3-phase

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “600 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 4W OD”</li> <li>• System B rated voltage (parameter 1781): “600 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – phase”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “Yes”</li> <li>• Aux System B voltage measuring (parameter 1853): “3Ph 3W”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “600 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “120 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “600 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “120 V”</li> </ul> <div style="display: flex; align-items: center;"> <div> <p><b>NOTE</b></p> <p>Connection plausibility is checked: “System B mismatch” Alarm ID 7770. See page 37 for details.</p> </div> </div>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> </ul> <ul style="list-style-type: none"> <li>• System B [V] L1-L2</li> <li>• System B [Hz]</li> </ul> <ul style="list-style-type: none"> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-6: Low voltage system 600 V / 346 V – 3-phase



## Low Voltage System 600 V / 346 V - 3-Phase with Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase PT “wye” (Phase L2 (B) is grounded at the MSLC-2 connection)
- System B measurement: 1-Phase PT L1-L2 (“Phase – phase”)




Figure 4-8: Low voltage system 600 V / 346 V – 3-phase with neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• <i>System A rated voltage</i> (parameter 1766): “600 V”</li> <li>• <i>System A current input</i> (parameter 1850): “L1 L2 L3”</li> <li>• <i>System A voltage measuring</i> (parameter 1851): “3Ph 4W”</li> <li>• <i>System B rated voltage</i> (parameter 1781): “600 V”</li> <li>• <i>1Ph2W voltage input</i> (parameter 1858): “Phase – phase”</li> <li>• <i>1Ph2W phase rotation</i> (parameter 1859): “CW”</li> <li>• <i>Auxiliary System B available</i> (parameter 7629): “No”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• <i>System A PT primary rated voltage</i> (parameter 1801): “600 V”</li> <li>• <i>System A PT secondary rated volt.</i> (parameter 1800): “120 V”</li> <li>• <i>System B PT primary rated voltage</i> (parameter 1804): “600 V”</li> <li>• <i>System B PT secondary rated volt.</i> (parameter 1803): “120 V”</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1-L2</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-7: Low voltage system 600 V / 346 V – 3-phase with neutral



## Low Voltage System 600 V / 346 V - 3-Phase with Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase PT “wye” (Phase L2 (B) is grounded at the MSLC-2 connection)
- System B measurement: 1-Phase PT L1-N (“Phase – neutral”)




Figure 4-9: Low voltage system 600 V / 346 V – 3-phase with neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “600 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 4W”</li> <li>• System B rated voltage (parameter 1781): “346 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – neutral”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “No”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “600 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “120 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “600 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “120 V”</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-8: Low voltage system 600 V / 346 V – 3-phase with neutral



## Low Voltage System 600 V / 346 V - 3-Phase with Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase PT “wye”
- System B measurement: 1-Phase PT L1-L2 (“Phase – phase”)
- Auxiliary system B measurement: 3-Phase PT “wye”




Figure 4-10: Low voltage system 600 V / 346 V – 3-phase with neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “600 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 4W”</li> <li>• System B rated voltage (parameter 1781): “600 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – phase”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “Yes”</li> <li>• Aux System B voltage measuring (parameter 1853): “3Ph 4W”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “600 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “120 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “600 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “120 V”</li> </ul> <div style="display: flex; align-items: center;"> <div> <b>NOTE</b>            Connection plausibility is checked: “System B mismatch” Alarm ID 7770. See page 37 for details.         </div> </div>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1-L2</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-9: Low voltage system 600 V / 346 V – 3-phase with neutral



## Low Voltage System 600 V / 346 V - 3-Phase with Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase PT “wye”
- System B measurement: 1-Phase PT **L1-N** (“Phase – neutral”)
- Auxiliary system B measurement: 3-Phase PT “wye”




Figure 4-11: Low voltage system 600 V / 346 V – 3-phase with neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “600 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 4W”</li> <li>• System B rated voltage (parameter 1781): “346 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – neutral”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “Yes”</li> <li>• Aux System B voltage measuring (parameter 1853): “3Ph 4W”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “600 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “120 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “600 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “120 V”</li> </ul> <div style="display: flex; align-items: center;"> <div> <p><b>NOTE</b></p> <p>Connection plausibility is checked: “System B mismatch” Alarm ID 7770. See page 37 for details.</p> </div> </div>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-10: Low voltage system 600 V / 346 V – 3-phase with neutral



## Middle Voltage System 20 kV - 3-Phase without Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase PT “Open Delta”
- System B measurement: 1-Phase PT L1-L2




Figure 4-12: Middle voltage system 20 kV – 3-phase without neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “20000 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 3W”</li> <li>• System B rated voltage (parameter 1781): “20000 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – phase”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “No”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “20000 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “115 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “20000 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “115 V”</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1-L2</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-11: Middle voltage system 20 kV – 3-phase without neutral



## Middle Voltage System 20 kV - 3-Phase without Neutral

- Phase rotation clockwise
- System A measurement: 3-Phase PT “Open Delta”
- System B measurement: 1-Phase PT **L1-L2**
- Auxiliary system B measurement: 3-Phase PT “Open Delta”




Figure 4-13: Middle voltage system 20 kV – 3-phase without neutral

Configuration	Measurement	Voltage Monitoring
<b>Menu 5</b> <ul style="list-style-type: none"> <li>• System A rated voltage (parameter 1766): “20000 V”</li> <li>• System A current input (parameter 1850): “L1 L2 L3”</li> <li>• System A voltage measuring (parameter 1851): “3Ph 3W”</li> <li>• System B rated voltage (parameter 1781): “20000 V”</li> <li>• 1Ph2W voltage input (parameter 1858): “Phase – phase”</li> <li>• 1Ph2W phase rotation (parameter 1859): “CW”</li> <li>• Auxiliary System B available (parameter 7629): “Yes”</li> <li>• Aux System B voltage measuring (parameter 1853): “3Ph 3W”</li> </ul> <b>Transformer</b> <ul style="list-style-type: none"> <li>• System A PT primary rated voltage (parameter 1801): “20000 V”</li> <li>• System A PT secondary rated volt. (parameter 1800): “115 V”</li> <li>• System B PT primary rated voltage (parameter 1804): “20000 V”</li> <li>• System B PT secondary rated volt. (parameter 1803): “115 V”</li> </ul> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"> <b>i</b> </div> <div> <b>NOTE</b>            Connection plausibility is checked: “System B mismatch” Alarm ID 7770. See page 37 for details.         </div> </div>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> <li>• System A [A] L1</li> <li>• System A [A] L2</li> <li>• System A [A] L3</li> <li>• System A [kW]</li> <li>• System A [KVA]</li> <li>• System A [kvar]</li> <li>• System A [PF] L1</li> <li>• System A [PF] L2</li> <li>• System A [PF] L3</li> <li>• System A [Hz]</li> <li>• System A Phase rotation</li> <li>• System B [V] L1-L2</li> <li>• System B [Hz]</li> <li>• Phase-Angle</li> <li>• System B-A</li> <li>• Aux System B [V] L1-L2</li> <li>• Aux System B [V] L2-L3</li> <li>• Aux System B [V] L3-L1</li> <li>• Aux System B phase rotation</li> <li>• Aux System B [Hz]</li> </ul>	<ul style="list-style-type: none"> <li>• System A [V] L1-L2</li> <li>• System A [V] L2-L3</li> <li>• System A [V] L3-L1</li> </ul>

Table 4-12: Middle voltage system 20 kV – 3-phase without neutral



## Dead Bus Closure – Multiple Units

When a dead bus is detected and dead bus closing mode is “Enabled”, the MSLC-2 is doing a security check before issuing a breaker closure command. This security is required to prevent two or more units from closing their breakers at the same time.

To provide this security, the active MSLC-2 is listening on the network, if any other DSLC-2 or MSLC-2 wants already close its breaker:

- If any DSLC-2 wants to close its breaker, the active MSLC-2 cancels the wish for breaker closure, remains passive and still listen on the network, if the situation changes
- If no DSLC-2 wants to close its breaker, the active MSLC-2 publish a close wish on the network and listen, if there is any other control wish to close its breaker. Three scenarios are now possible:
  - **Scenario 1:** No other control announces a close desire within the next 500 ms. After that the MSLC-2 closes its breaker.
  - **Scenario 2:** No other control with a smaller Device-ID announces a desire for dead bus closure within the next 500 ms. After that the MSLC-2 closes its breaker.
  - **Scenario 3:** Another control with a smaller Device-ID announces a desire for dead bus closure, so the MSLC-2 cancels the wish for breaker closure, remains passive and still listen on the network, if the situation changes.



### NOTE

The DSLC-2s have a higher priority for dead bus closure than the MSLC-2s. In other words: If a DSLC-2 wishes to close the GCB on a dead busbar the MSLC-2s are blocked.




Figure 4-14: Dead bus closing – Example of dead busbar closure arbitration



## Deadbus Closure Mismatch Alarm

When a deadbus is detected and dead bus closing mode is activated by a *Run* or *Permissive* command, the MSLC-2 is doing an additional security check before issuing a breaker closure command.

If the MSLC detects a closed breaker (GCB or MCB) at System A or System B then the alarm "Deadbus closure mismatch" is set and the MSLC-2 will not close to a deadbus.

The alarm "Deadbus closure mismatch" (parameter 4620) shows the deadbus plausibility in ToolKit Menu 8. Additionally, a Relay output: Alarm1, Alarm2 or Alarm3 can be assigned within ID 7598 in ToolKit Menu 0. Finally the deadbus closure mismatch alarm is added internally to the "Centralized Alarm" and can be first detected therefore in the ToolKit Homepage with the LED "Centralized Alarm".

The Deadbus closure mismatch **alarm is set** with following detailed conditions:

### Utility MSLC2:

- Precondition: Start Deadbus closure with energizing DI "Run" or DI "Permissive"
- A GCB in the own segment is closed and the busbar is dead
- Another MCB in the own segment is closed and the busbar is dead

### Tie MSLC2:

- Precondition: Activate Deadbus closure by a *Run* or *Permissive* command
- GCB closed and busbar is dead on system A
- GCB closed and busbar is dead on system B
- MCB closed and busbar is dead on system A
- MCB closed and busbar is dead on system B

The deadbus closure mismatch **alarm is reset** (self-acknowledge) with following conditions:

- Still deadbus but **no closed breaker** in the same segment (via breaker open feedback received)
- **Deadbus changes to "Voltage ok"** on busbar in the detected segment with the closed breaker
- De energize DI "Run" or DI "Permissive"



## Voltage Matching

The voltages of two systems in parallel must be matched within a small percentage to minimize the reactive power flow in the system. If a local plant is paralleled to the main grid with unequal voltages, the local plant will, in most cases, follow the utility voltage. The difference in voltages results in reactive currents flowing in the system with subsequent lowered system efficiency.

If the system is initially at a lower voltage than the utility, reactive power will be absorbed by the system. If the system voltage was initially higher, the local plant will provide extra reactive power to the utility. In either case the breaker across which the parallel is made will experience unnecessary wear and tear created by the arcing across different voltages.

The MSLC-2 measures the RMS values of the voltages. The synchronizer issues appropriate raise or lower commands, or voltage bias adjustment to all of the DSLC-2 controls over the Ethernet network. The MSLC-2 will continue this process until the difference between System B and System A voltage is within a specified window. The automatic voltage matching function may be enabled or disabled with a configuration setpoint. When enabled, voltage matching will occur in both the “Check” and “Run” modes and is verified to be within the window in the “Permissive” mode.

## Phase Matching Synchronizing

The phase matching synchronizer mode corrects the frequency and phase of system A to lock it to system B frequency and phase. Phase matching synchronizing can be configured (parameter 5730) in the unit. With activation of the synchronizer the MSLC-2 begins to control at first the frequency to minimize the frequency difference between system B and system A. When the frequency window comes into the range of phase matching start, see configuration *Phase matching df-start* (parameter 5506), the synchronizer watches the phase relation. Therefore the frequency setpoint to the DSLC-2 increases or decreases and result in speed biasing to the engine depending on whether the slip is faster or slower than the system A. Proportional and integral gain adjustments are provided to allow stable operation of the automatic synchronizer over a wide range of system dynamics.

## Slip Frequency Synchronizing

In certain applications the initial power flow can be either from or to the utility. Depending on the requirement, the local bus can be brought into parallel with a slightly higher or lower frequency than the mains. This can be provided by the parameter *Slip frequency setpoint offset* (parameter 4712). The slip frequency method is configured using *Synchronization CB* (parameter 5730). The synchronizer automatically controls the connected generator at the specified slip frequency. The MSLC-2 outputs an error signal over the network to the DSLC-2 controls to change their bias on the speed controls. Gain and stability adjustments for the slip frequency proportional and integral gain controller are provided to allow stable operation of the automatic synchronizer function over a wide range of system dynamics (parameter 4539, parameter 4540).

## Permissive Mode / Synch-Check Function

The synch-check function determines when frequency, phase and voltage are within the configured settings for proper synchronization before issuing a breaker closure command. The *Setpoint frequency* (parameter 4627) and *Setpoint voltage* (parameter 4628) are not used to drive system B into synchronization. The MSLC-2 can be manually controlled using the setpoint raise/ lower and voltage raise/ lower discrete inputs. The system A and system B voltage comparison is made independent of the voltage matching function being enabled. When all conditions of voltage and phase are met, then a constant breaker closure command is given.



## GCB Maximum Closing Attempts

The synchronizer allows multiple breaker closure attempts to an active or dead bus. The control provides setpoints for the number of close attempts (parameter 3419) and the reclosure delay timing (parameter 4534). The synchronizer feature has 2 alarms, *Reclose limit alarm* (parameter 7556) and the *Synchronizer timeout alarm* (parameter 7557). These alarms will affect the synchronizer differently between an active or dead bus.

### Dead bus closing

If both alarms are disabled, you will receive infinite breaker closure attempts. If one or both alarms are enabled, when that alarm setting is reached, an alarm is received and no more breaker close attempts will be given. This is important when you have multiple utilities attempting to close to a dead bus. The MSLC-2 that receives the dead bus token will not pass the dead bus token until it receives an alarm. So having 1 or 2 close attempts is preferred in a multiple utility application.

### Active bus closing

If both alarms are disabled, you will receive infinite breaker closure attempts. If one or both alarms are enabled, when that alarm setting is reached, an alarm is received but the synchronizer will keep providing breaker closure commands until a “CB Aux” feedback is received or the “Run” or “Permissive” input is removed.

## Auto re-synchronization

The *Auto re-synchronization* feature (parameter 7514), when enabled, allows the MSLC-2 to attempt to reclose the breaker if the “CB Aux” feedback is opened and the MSLC-2 still has a “Run” or “Permissive” input closed. The auto re-synchronizer feature becomes active after a successful breaker closure is received. Then if the breaker feedback (CB Aux) is opened and the “Run” or “Permissive” input is still closed, the MSLC-2 will attempt to close the breaker when in the synchronizer specifications. If configured for “Disabled”, no attempt at synchronization will be made until the “Run” input is then opened and reclosed. This is active even when a utility unload command is given and the MSLC-2 opens the breaker. With auto re-synchronization “Enabled”, the synchronizer will become active.



### NOTE

Woodward suggest to remove the “Run” or “Permissive” input after a successful breaker closure has been received and have the “Run” or “Permissive” input reclosed if the breaker opens and it is safe to reclose it.

## Reclose limit alarm

When the *Reclose limit alarm* (parameter 7556) is “Enabled” an independent monitor counts in the background the number of close attempts. When the number of close attempts matches the configurable number of closing attempts (parameter 3419) an alarm flag will be issued. This alarm flag is automatically considered when a dead busbar closure is executed. When during the dead busbar closure, the reclose limit alarm becomes active; the dead busbar closure permission will be passed to another MSLC-2. If the *Reclose limit alarm* (parameter 7556) is “Disabled”, the MSLC-2 will have an infinite number of attempts to close the breaker.

## Synchronizer Timer

The synchronizer function is equipped with three adjustable timers.

1. The *CB close hold time* (parameter 3417) determines the amount of time the control maintains the breaker close command.
2. The *Synchronizer timeout* (parameter 3063) when the *Synchronizer timeout alarm* (parameter 7557) is “Enabled”. The alarm is removable by de-energized run signal.
3. The *Reclose delay* (parameter 4534) which is the time delay between the single close commands.

When “Enabled” the synchronizer timer starts when the “Run” switch is closed. It is not active in the check or permissive modes. If no breaker closure is received by the end of the timer, a synchronizer timeout alarm is received and the MSLC-2 will stop the synchronizing process. If the “Run” input is removed, the alarm is reset and when the “Run” input is closed the synchronizer process will be active.



## Logic Charter GCB Closure




Figure 4-15: Logic charter CB closure



## Ramping

The MSLC-2 is providing some intelligent ramps for controlled „move“ from current to requested status. Because of the number of ramps and conditions, please find below an overview below what ramp rate is used in case ...

The MSLC-2 ramps its setpoints before sending to the DSLCs. The DSLC-2 accepts these setpoints, if:

1. The DSLC-2 and MSLC-2 reside in the same segment.
2. The DSLC-2 is neither switched in Base Load nor Process Control
3. The DSLC-2 is not in Unload Mode

The DSLC-2 is usually accepting setpoints from the MSLC-2 directly into its PIDs with some exceptions:

- Each time a DSLC-2 closes its breaker, it ramps first with its own load ramp rate onto the busbar.
- Each time a DSLC-2 recognizes being mains parallel, it ramps first with its own load ramp rate onto the busbar.

With reaching the MSLC-2 setpoint, the DSLC-2 disables the ramp and channels the setpoint through to the load PID.

The behavior with the kvar setpoint is the same as long kvar—or PF—control is done over the MSLC-2 interchange point (Kvar Import/Export Control).

Mode	Function	Related ramp rate (Parameter)
<b>Manual Permissive</b>	<b>DSLC Isolated Operation, MCB open:</b> Apply a new frequency setpoint by Raise/Lower commands.	ID 4713 DI raise frequency ramp ID 4714 DI lower frequency ramp
<b>Manual Permissive</b>	<b>DSLC Isolated Operation, MCB open:</b> Apply a new voltage setpoint by raise/lower commands.	ID 4715 DI raise voltage ramp ID 4716 DI lower voltage ramp
<b>Base Load</b>	<b>Mains Parallel Operation (kW):</b> Apply a new Base Load setpoint by Raise/Lower commands. In this case the load ramp and the respectively Raise/Lower ramp rate are incorporated.  <b>Note:</b> If the raise/lower ramp rate value is larger than the load ramp rate value, the load ramp determines the overall ramp rate. If the Raise/Lower ramp rate is smaller than the load ramp rate, the Raise/Lower ramp rate determines the overall ramp.	ID 4700 Load ramp rate ID 4713 DI raise frequency ramp ID 4714 DI lower frequency ramp
<b>Base Load</b>	<b>Mains Parallel Operation (kW):</b> A new Base Load setpoint is applied by Remote Input (AI).	ID 4549 Load ramp rate
<b>Base Load</b>	<b>Mains Parallel Operation (PF):</b> A new Constant Generator Power Factor (ID5621) is applied by Toolkit.	ID 5622 Reactive power setpoint ramp
<b>Imp/Exp Control</b>	<b>Mains Parallel Operation:</b> First ramping into Import/Export control window.	ID 4549 Load ramp rate



Mode	Function	Related ramp rate (Parameter)
Imp/Exp Control	<b>Mains Parallel Operation (I/E kW):</b> A new Export/Import Load setpoint (ID7717) is applied by Toolkit.  Note: The output of the PID is sent to the DSLC as setpoint load level.	ID 4549 Load ramp rate
Imp/Exp Control	<b>Mains Parallel Operation (I/E kW):</b> A new Export/Import Load setpoint is applied by Remote Input (AI).  <b>Note:</b> The output of the PID is sent to the DSLC as setpoint load level.	ID 4549 Load ramp rate
Imp/Exp Control	<b>Mains Parallel Operation (I/E kW):</b> Apply a new Import/Export setpoint by Raise/Lower commands. In this case the load ramp and the respectively Raise/Lower ramp rate are incorporated.  <b>Note:</b> The output of the PID is sent to the DSLC as setpoint load level.	ID 4549 Load ramp rate
Imp/Exp Control	<b>Mains Parallel Operation (I/E kW):</b> A new Export/Import setpoint (ID7642) is applied by communication interface.	ID 4549 Load ramp rate
Imp/Exp Control	<b>Mains Parallel Operation (I/E kvar):</b> A new Export/Import reactive load setpoint (ID7723) is applied by Toolkit.  <b>Note:</b> The output of the PID is sent to the DSLC as setpoint reactive load level.	ID 5622 Reactive power setpoint ramp
Imp/Exp Control	<b>Mains Parallel Operation (I/E PF):</b> A new Export/Import Power Factor setpoint (ID5620) is applied by Toolkit.  <b>Note:</b> The output of the PID is sent to the DSLC as setpoint reactive load level.	ID 5622 Reactive power setpoint ramp
Imp/Exp Control	<b>Mains Parallel Operation (I/E PF):</b> A new Power factor setpoint (ID7640) is applied by communication interface.	ID 5622 Reactive power setpoint ramp
Process Control	<b>Mains Parallel Operation:</b> First ramping into process control window.	ID 4549 Load ramp rate
Utility Un-load	<b>Mains Parallel Operation:</b> The utility is unloaded. The reactive power is unloaded accordingly.	ID 4524 Unload ramp rate ID 5622 Reactive power setpoint ramp

Table 4-13: Ramping overview



# Manual Synchronizing



The manual synchronizer is activated / deactivated under the following conditions.

## Activated

- MCB/tie-breaker = open
- AND
- DI "Check" (active)
- AND
- DI "Permissive" (active)

## Deactivated

- Breaker feedback DI "CB Aux" = closed
- OR
- DI "Check" (not active)
- AND
- DI "Permissive" (not active)

The MSLC-2 is before and during the manual synchronization in *Load control mode* (parameter 4603) "Off Line", and in the *Synchronizer mode* (parameter 4602) "Off", independent if the MSLC-2 is configured to utility or tie.

## Frequency Setpoint

It is possible with discrete input "Setpoint Raise" or discrete input "Setpoint Lower" to adjust the *Setpoint frequency* (parameter 4627) of connected DSLCs, which are in the same segment, up and down (ramp rate adjustable from 0,01%rated/s to 100,00%rated/s (0.01%rated/s) with parameter 4713, parameter 4714). The setpoint frequency is the direct output of the parameter *Setpoint frequency* (parameter 4627) is transferred in Hz to the DSLCs. The setpoint frequency is limited due to the parameters *Upper frequency limit* (parameter 5802) and *Lower frequency limit* (parameter 5803). The operating ranges of these parameters are adjustable in Menu 5.

- *Upper frequency limit* (parameter 5802) | Range: 100 to 150% | Default: 110% = 66 Hz (with rated frequency = 60 Hz)
- *Lower frequency limit* (parameter 5803) | Range: 50 to 100% | Default: 90% = 54 Hz (with rated frequency = 60 Hz)



### NOTE

Frequency setpoint DSLC-2:

Received via parameter *Setpoint frequency* (parameter 4627) | Range: 54 to 66 Hz (limited 90 to 110% from rated frequency, for example 60 Hz)

## Voltage Setpoint

It is possible with discrete input "Voltage Raise" or discrete input "Voltage Lower" to adjust the *Setpoint voltage* (parameter 4628) of connected DSLCs, which are in the same segment, up and down (ramp rate adjustable from 0,01%rated/s to 100,00%rated/s (0.05%rated/s) with parameter 4715, parameter 4716) t. The setpoint voltage is the direct output of the parameter *Setpoint voltage* (parameter 4628) is transferred in % to the DSLCs. The setpoint frequency is limited due to the parameters *Upper voltage limit* (parameter 5800) and *Lower voltage limit* (parameter 5801). The operating ranges of these parameters are adjustable in Menu 5.

- *Upper voltage limit* (parameter 5800) | Range: 100 to 150% | Default: 110% = 440 V (of rated voltage = 400 V)
- *Lower voltage limit* (parameter 5801) | Range: 50 to 100% | Default: 90% = 360 V (of rated voltage = 400 V)



### NOTE

Voltage setpoint DSLC-2:

Received via parameter *Setpoint voltage* (parameter 4628) | Range: 90 to 110% (limited 80 to 120% from rated voltage)



## Breaker Close

The MCB/tie-breaker can be closed manually when system B frequency and voltage are in range.



### CAUTION

The rotation field of system A and system B must be measured. They must have the same direction – CW or CCW.

## Reset Frequency / Voltage Setpoints Back To Rated (50 Hz or 60 Hz)

- **MSLC-2 configured as utility breaker control:** MCB/tie-breaker = closed and breaker feed-back mains parallel operation
- **MSLC-2 configured as tie-breaker control:** Manual synchronizer = off and MCB/tie-breaker = closed



# Chapter 5.

## Real Power Control Description

### Introduction



The MSLC-2 control provides several modes of generator load operation. These are:

- Base loading
  - Automatic control of generators kW and constant generator PF control
- Import/export level control
  - Automatic control of the systems import or export power and either var or power factor control or constant generator PF control
- Process control
  - Automatic control of a process signal with either var or power factor control or constant generator PF control
- Utility unload
  - The ability to transfer the system load from the utility to the generators with the utility breaker being opened at the *Utility unload trip* (parameter 4506) level

### MSLC-2 / DSLC-2 Interface



The MSLC-2 is able to control load and reactive load with only active DSLC-2 controls which are connected to the same bus segment and are in the load sharing mode. DSLC-2s that are in base load or process control cannot be controlled by a MSLC-2. The MSLC-2 can synchronize multiple DSLC-2s to the utility. Once the utility breaker is closed, the MSLC-2 must be placed in a load control mode. These are base load, import/export, process control or utility unload. MSLC-2s in the tie-breaker mode will synchronize and close the tie-breaker to connect different bus segments but will not have any load control capabilities.



#### NOTE

The DSLC-2 will show it is in the base load mode (parameter 4603) when being controlled by a MSLC-2.

### Base Load Mode



The MSLC-2 takes the system load percentage immediately upon entering the base load mode for the initial base load reference setting. This is true when synchronizing to the utility or transferring from import/export mode to base load. The base load reference can be moved by using the setpoint “Raise” or “Lower” discrete inputs with an option to use the remote analog input to control the reference. The DSLC-2 controls will maintain the system load percentage being provided by the MSLC-2 with the utility picking up all load swings. Using the setpoint lower input will decrease the system load percentage, thus unloading the generators and transferring the load to the utility. The MSLC-2 has a *Generator unload trip* (parameter 3125) level that activates the Lcl. / generator breaker open relay. This output can be used to open a group breaker or to signal the DSLC-2s to open the generator breaker. This breaker stays active for 400 milliseconds. When in base load control the reactive power control will automatically be the constant generator PF mode. While unloading the kW of the generators you will need to unload the reactive power. The MSLC-2 will change the constant generator PF control reference to 1.0 when the system load percentage reaches the *Generator unload trip* (parameter 3125) setpoint.



## Import / Export Mode



The MSLC-2 measures the real power flow to or from the main power grid. It then controls all active DSLC-2s by controlling the system load percentage signal. The individual DSLC-2 controls will control to this percentage of their rated loads and the MSLC-2 will adjust this system load up or down to achieve the proper import/export level. The system load percentage is limited to a 0 to 100% signal so that overload or reverse power of the generators will never occur. When in import / export mode the PID control is located in Menu 2. The DSLC-2 controls are using the base load PID (Menu 2) to control at the reference signal being sent from the MSLC-2. The reactive power can be configured for var, PF, or constant generator PF control.



### NOTE

Any DSLC-2 set for base loading will maintain its individually set base load, regardless of the MSLC-2 signal. Therefore, a sufficient number of generators must be in isochronous load sharing in order to handle plant load swings and still maintain the import/export level. The DSLC-2s *Load control mode* (parameter 4603) will indicate base load mode when being controlled by the MSLC-2.

## Process Control Mode



The MSLC-2 controls the DSLC-2 equipped generators by adjusting the system load. The MSLC-2 will control the system load to maintain the process input signal is equal to the process reference. The MSLC-2 is limited to changing the reference signal to the DSLC-2 controls between 0 and 100%. The reactive power can be configured for var, PF, or constant generator PF control.

## Remote Control



In any of the above modes, the reference can be determined by an analog signal input at terminals 83 to 85. The remote mode is selected by activating both the setpoint raise and lower at the same time. Menu 6 determines the scaling and the engineering units. The remote load reference signal can be a base load, import / export or a process control value.

The reactive load analog input at terminals 89 to 91 can be used for a power factor setpoint control or a constant generator power factor control reference. Menu 6 determines the scaling.

## Automatic Power Transfer Control Functions



### Ramping Between Modes

Whenever the mode of load control is changed, the MSLC-2 will ramp at a user chosen rate until it is within 5% of its new reference. Then, it will begin dynamic control. This provides smooth (bumpless) transitions between all modes.

### Utility Unload

The utility unload feature is available with the MSLC-2 in base load, import / export or process mode. When the utility unload command is issued, the MSLC-2 will adjust the *Setpoint load level* (parameter 4629) until a specified level around the zero power transfer point is obtained. It will then issue a utility breaker open command. The *Utility unload trip* (parameter 4506) determines at which power value the tolerance for opening the breaker is reached. If the local plant is initially operating at some export level,



supplying power to the utility, the MSLC-2 will lower the system load setpoint to obtain a zero power transfer condition. If the local plant is initially operating at some import level, absorbing power from the utility, the MSLC-2 will raise the system load setpoint to obtain a zero power transfer condition. If the MSLC-2 cannot bring the import/export level within the chosen band prior to reaching a system load setpoint of 0% or 100%, the unload will stop and if enabled the appropriate high/low limit alarms will activate. When the *Utility unload trip time* (parameter 3123) is reached the breaker will be opened independent on the trip level.

## Local Unload

When the MSLC-2 is in base load mode and the setpoint lower command is continuously activated, the control will lower the *Setpoint load level* (parameter 4629), which is sent to the DSLC-2s. When the system level reaches the *Generator unload trip* (parameter 3125) level, the Lcl. / generator breaker open relay will energize. This relay will energize for 400 milliseconds. This will transfer the plant load back to the utility power grid. During unloading, the MSLC-2 is in the constant generator PF mode. When the *Generator unload trip* (parameter 3125) level is reached, the MSLC-2 will change the constant generator PF level to 1.0.

	DI CB AUX	DI Utility Unload	DI Base Load	DI Imp/Exp Control	DI Process Control	DI Ramp Pause	DI Setpoint Raise	DI Setpoint Lower
Off Line	0	x	x	x	x	x	x	x
Base Load	1	0	1	0	0	0	0	0
Base Load Raise	1	0	1	0	0	0	1	0
Base Load Lower	1	0	1	0	0	0	0	1
Base Load <sup>1</sup> Remote	1	0	1	0	0	0	1	1
Utility Unload <sup>2</sup>	1	1	x	x	x	0	x	x
Local Unload <sup>3</sup>	1	0	1	0	0	0	0	1
Ramp Pause <sup>4</sup>	1	x	x	x	x	1	x	x
Import/ Export mode	1	0	x	1	0	0	0	0
I/E Raise	1	0	x	1	0	0	1	0
I/E Lower	1	0	x	1	0	0	0	1
I/E Remote <sup>1</sup>	1	0	x	1	0	0	1	1
Process Control	1	0	x	x	1	0	0	0
Process Raise	1	0	x	x	1	0	1	0
Process Lower	1	0	x	x	1	0	0	1
Process Remote <sup>1</sup>	1	0	x	x	1	0	1	1

Table 5-1: Load control modes MSLC-2



### NOTE

<sup>1</sup> Remote reference is activated by closing both setpoint raise and setpoint lower switches at the same time.

<sup>2</sup> The MSLC-2 can only load the associated generators to 100%. If this is not enough capacity to unload the utility, the unload ramps stops at 100% rated load on the associated generators. The generator high limit alarm, if enabled, will activate at this time.

<sup>3</sup> The local plant unload is accomplished by switching to base load mode and supplying a continuous setpoint lower command.

<sup>4</sup> The ramp pause command will pause all ramps in any mode.



## Chapter 6.

# Var/Power Factor Control Description

### Introduction



The MSLC-2 offers 3 modes of reactive power control. Var or power factor modes will control the reactive power at the utility breaker while constant generator PF control will provide a power factor setpoint to all DSLC-2 controls on the system.

When an utility unload command is issued, the control automatically shifts from var control to power factor control in order to ensure a minimum amount of current flow across the utility tie when it is opened. It is important to note that, as with the real load functions, the var/PF control in the MSLC-2 controls only those DSLC-2 controls which are in isochronous load sharing. Any DSLC-2 controls which are in base load mode will control the reactive power on their associated generators in accordance with their own internal reference and chosen mode of var/PF control.

### Constant Generator Power Factor



The MSLC-2 sets the power factor reference of the generators according to the value chosen by:

- **Base Configuration:** *VAR PF control mode* (parameter 7558) configured to “Constant Generator PF” and reference value *Constant gen. PF reference* (parameter 5621).
- **ToolKit:** Changing the *Constant gen. PF reference* (parameter 5621) in ToolKit will change the reference value being controlled.
- **Adaptation:** With the settings of the base configuration the constant gen PF reference can be influenced by voltage raise and voltage lower commands.
- **Remote:** With the settings of the base configuration the *Constant gen PF reference* (parameter 5621) can be influenced by an analog signal (“Reactive Load Input”). The voltage raise and voltage lower signal must be energized simultaneously.
- **Interface:** With the settings of the base configuration the *Constant gen PF reference* (parameter 5621) can be influenced by interface, when the configuration *VAR control setpoint source* (parameter 7635) is set to “Interface”.
- **Control:** The DSLC-2s PID var control will affect the stability of the power factor control.



## Power Factor Control



The MSLC-2 adjusts the power factor references of the generators in order to maintain a chosen power factor level across the utility tie. The MSLC-2 sends a system reactive power percentage value to the DSLC-2s. Following procedures are possible:

- **Base Configuration:** *VAR PF control mode* (parameter 7558) configured to “PF Control” and *Power factor reference* (parameter 5620) is configured.
- **ToolKit:** Changing the *Power factor reference* (parameter 5620) in ToolKit will change the reference value being controlled.
- **Remote:** With the settings of the base configuration the *Power factor reference* (parameter 5620) at the MSLC-2 can be influenced by an analog signal (“Reactive Load Input”). The voltage raise and voltage lower signal must be energized simultaneously.
- **Interface:** With the settings of the base configuration the *Power factor reference* (parameter 5620) at the MSLC-2 can be influenced by interface, when the configuration *VAR control set-point source* (parameter 7635) is set to “Interface”.
- **Control:** The PID var control setting in the MSLC-2, Menu 4 will affect the stability of the power factor control.

## Var Control



The MSLC-2 adjusts the power factor reference of the generators in order to maintain a chosen var level across the utility tie. The MSLC-2 sends a system reactive power percentage value to the DSLC-2s. The unit allows only one basic setting:

- **Base Configuration:** *VAR PF control mode* (parameter 7558) configured to “VAR Control” and *KVAR reference* (parameter 7723) is configured.
- **ToolKit:** Changing the *KVAR reference* (parameter 7723) in ToolKit will change the reference value being controlled.
- **Control:** The PID var control settings in the MSLC-2, Menu 4, will affect the stability of the var control.



# Chapter 7.

## Process Control Description

### Introduction



The process control function of the MSLC-2 will control any process where the controlled parameter is determined by the load on the local generators and the controlled parameter can be monitored as an analog input signal (process input). The control compares the input signal to the process reference setpoint, or the remote reference if used and adjusts the local generator loading to maintain the desired setpoint.



#### NOTE

The MSLC-2 system load command is obeyed only by the associated DSLC-2 controls which are in isochronous load sharing. DSLC-2s in Base load or process control mode will ignore the MSLC-2 load command signal and maintain its set load reference. The DSLC-2s *Load Control mode* (parameter 4603) will display Base load mode when being controlled by a MSLC-2.

### Description



Figure 7-1 shows a block diagram of the process control function. The process control mode is selected when the "Process Control" and "CB Aux" switch contacts are closed. The process input signal is compared with the process reference, which may be either the internal *Process reference* (parameter 4605) or the analog remote process reference input (Configurable in Menu 6). In process control mode, the "Load Raise" and "Load Lower" contact inputs operate on the process control reference. When the internal reference is used, the "Load Raise" and "Load Lower" contacts raise and lower the process reference based on the internal *Process reference* (parameter 4605). The analog remote reference input becomes active on the process reference, when both the "Load Raise" and "Load Lower" contacts are closed.

Each time a new process control begins, the first error signal is checked. If the process error signal is higher than 5% or lower than -5% the generator load is guided over a ramp function to leveling the error signal. This shall be a relatively smooth process. When the error signal resides within +/-5% the Process PID function becomes active. The process PID function also becomes active, if the ramp function has reached the minimum or the maximum gen load level (0 to 100%). If the process PID is one time activated, it remains active until the process control is switched off or the CB gets open.

When the process control is enabled, the PID controller operates in cascade with the load control. The output of the controller is a generator load reference within the range 0 to 100% rated power to prevent overload or reverse power on the generator. The load setting signal is output from the load control to the speed control to set control at the required load to maintain the desired process level. An additional feature of the process control is the adjustable process input signal filter. The adjustable *Process filter*, Menu 3 (parameter 4509) allows reducing bandwidth when controlling a noisy process such as experienced in digester gas fuel applications. The process control function is configurable for direct and inverse action. Direct process control is where the sensed input signal increases as the load increases (such as where the sensed input is exhaust pressure or export power). An inverse action control is where the sensed input signal decreases as the load increases (such as when controlling import power where the import power will decrease as the generating system picks up more of the local load).

The process error is the difference between process signal input and process reference. The controller in the MSLC-2 regulates the percentage values. For a better understanding the engineering unit can be



displayed according to the percentage value. Therefore the scaling of the percentage value is to make with according engineering units (parameter 7732, parameter 7733 and parameter 7734). The units are then displayed in field parameter 7726 and in field parameter 7727 in Menu 6 or the Homepage.

The *Process signal input* (parameter 10151) and the *Remote reference input* (parameter 10117) is displayed in Menu 6 in%.

The resulting *Process reference* (parameter 4605) and the resulting *Process signal input* (parameter 4600) is displayed in the Homepage in%.






Figure 7-1: Diagram process control



# Chapter 8.

## Network / System Description

### Introduction



The new DSLC-2 / MSLC-2 system provides within one network following features:

- The maximum number of DSLC-2s (Generator) can go up to 32.
- The maximum number of MSLC-2s (Utility- or Tie-breaker) can go up to 16.
- The maximum number of segments is 8.

The DSLC-2 still cares about the generator breaker and the MSLC-2 cares about utility breaker or a tie-breaker. The DSLC-2 and MSLC-2 can reside at different segments. A segment is defined as the smallest undividable bar in a system. Segment connectors inform the DSLC-2s and MSLC-2s which generators and utilities are connected. Through the segmenting the DSLC-2 / MSLC-2 can recognize all the time with which other units they are interconnected. So the DSLC-2s in the same segment are load share together or doing an independent load control.

The MSLC-2 can be configured to utility breaker mode or to tie-breaker mode. In each case it is only allowed to have one MSLC-2 in one segment running as master control. A MSLC-2 gets a master control when base load control, export/import control or process control is activated. If multiple MSLC-2s are in the same segment, the control with the lowest device number will be master.

### Description



Beside the upper described restrictions there are existing additional rules for the successful operation of the DSLC-2 / MSLC-2 system. Please read this rules and compare it with your planned application.

- The segment numbers have to follow a line, which can finally be closed to a ring. A segment branch is not allowed.
- There can be placed several MSLC-2 in one segment, but only one MSLC-2 can run as Master control.
- The generator is not counted as a segment.
- The utility is not counted as a segment.

The intention of the following application examples is to provide a better understanding of the philosophy of segmenting:



## Applications without Segmenting

In some applications there is no segmenting to make because the common busbar of DSLC-2 and MSLC-2 cannot be separated. In this case in Menu 5, *Basic segment number* (parameter 4544) is configured to 1 at each unit. The *Device number* (parameter 1702) needs still to be different because it determines the network addressing. See Figure 8-1 and Figure 8-2 for examples which need no segmenting.




Figure 8-1: Multiple generators in isolated operation without tie-breakers




Figure 8-2: Multiple generators in isolated / parallel to utility operation without tie-breakers



## Applications with Segmenting

The segmenting is to make in each application where the common busbar can be separated into two or more segments. The segment numbers have to follow a line and shall not branch. The information which segments are connected coming by discrete inputs terminals 141 to 148. All DSLC-2 and MSLC-2 have the same discrete inputs to control the segmenting. The 8 segment connection feedbacks are over-all the same and are linked by logic 'OR'. The information is exchanged over network. In all these cases in Menu 5, *Basic segment number* (parameter 4544) of each unit is configured according to the location of the unit. The rules for setting up the segment numbers are shown in chapter "Prestart Setup Procedure" on page 141.

At next are shown some examples which are covered by the DSLC-2 / MSLC-2 system.




Figure 8-3: Isolated operation with multiple generator and tie-breaker




Figure 8-4: Isolated / utility parallel operation with multiple generator and tie-breaker






Figure 8-5: Isolated / utility parallel operation with multiple generator, tie-breaker and generator group breaker

Figure 8-5 shows an application with 2 utility feeder breakers, 2 load segments and 2 generator group breakers. The segment line begins at the left side with the load A segment (segment no.1) and ends with the load B segment (segment no.4) at the right side.



## Isolated Operation (ring topology)




Figure 8-6: Isolated operation with multiple generator and tie-breaker (ring option)

Figure 8-6 shows an application with multiple generators connectable to a ring with tie-breaker. However segments are in use, the last not used segment connectors are be bridged as closed at one of the units.

### Special Function - Synchronizing the last breaker in a ring structure

For the case the last tie breaker shall be closed in a ring structure the respectively MSLC-2 synchronizes the breaker without guiding voltage and frequency. But the tolerances for voltage and phase angle must be extended.

1. Extend the *voltage window* to the value, given with parameter 4718
2. Extend the *phase angle window* to the value, given with parameter 4717 for phase window positive and phase window negative



## Not Supported Applications

A main rule in the segmenting is that segment numbers have to follow a line without branches. At next are shown some application examples which are not covered by the DSLC-2 / MSLC-2 system. The application in Figure 8-7 and Figure 8-8 shows how the segment number line can branch. Another indication is the need for a segment breaker between segment 3 and 5, which does not exist.




Figure 8-7: Not supported application




Figure 8-8: Not supported application



## Remote Control by PLC



The DSLC-2XT / MSLC-2XT system offers three Ethernet network and one serial interface RS-485. Ethernet network A and network B are the dedicated communication busses for the Woodward own UDP message system, which is used to exchange information between all units in the network. In Menu 5.1 the “Network A –UDP TCP/IP address” (parameter 5330) must be configured accordingly. Each unit gets its own address usually related to the own *Device number* (parameter 1702).

Ethernet network A and Ethernet network B can be used for visualization and remote control of all units. The protocol here used is Modbus TCP. In Menu 5.1 the “Network B – Modbus TCP/IP address” (parameter 5430) must be configured accordingly. Each unit gets its own address usually related to the own *Device number* (parameter 1702).

The DSLC-2XT / MSLC-2XT provides additionally in comparison to the former DSLC-2 / MSLC-2 system a network Ethernet C. This network can now be used for ToolKit or further Modbus TCP access.

Please note that the Ethernet C network is not independent and needs an own network mask to be configured.



### NOTE

Because the device has 3 Ethernet ports internally operated with a switch (A , B and C) it is important to make sure that the network addresses of all ports are different!



### NOTE

IP address range 224.0.0.0 to 239.255.255.255

This address range is restricted for specific use (multicast class D addresses) and not usable for the Ethernet IP configuration from network A, B and C.



### NOTE

The device can support up to 10 Modbus TCP connections independent on the port at one time.

*The former DSLC-2 / MSLC-2 supports max. 5 Modbus TCP connections per port.*



### NOTE

The device closes its Modbus TCP connection after 2 seconds if no communication activity is detected anymore.

*The former DSLC-2 / MSLC-2 close their port after 20 seconds inactivity.*



The device offers furthermore a serial RS-485 connection for visualization and remote control. The visualization can be done simultaneously by Ethernet and RS-485. In Menu 5.1 the “Modbus Serial Interface 2 Modbus slave ID” (parameter 3188) must be configured accordingly. Each unit gets its own slave ID usually related to the own *Device number* (parameter 1702).



### NOTE

The remote control must be configured for either RS-485 or Ethernet. The DSLC-2 / MSLC-2 allow distribute functions to discrete inputs and to protocol bits.

## Interface Connection via RS-485 with Modbus Protocol

The DSLC-2 / MSLC-2 system provides a RS-485 Modbus connection. Each unit gets an own Modbus slave address. The DSLC-2 as the MSLC-2 allows to configure each parameter or to inform about each measurement value and binary information. For visualization the unit offers a special mapped Modbus table with all important values refer to “Data Protocol 5200” on page 228.




Figure 8-9: Visualization and remote control by PLC via RS-485 interface



## Interface Connection via Ethernet by Modbus/TCP Stack

The MSLC-2XT / DSLC-2XT system provides the Ethernet channels A, B or C for Modbus/TCP connection. Each unit gets an own Modbus slave address. The DSLC-2 as the MSLC-2 allows to configure each parameter or to inform about each measure.




Figure 8-10: Visualization and remote control by PLC via Ethernet Modbus/TCP interface



## Chapter 9. Interface

### Interface Overview



The device has several communication interfaces which are described below.




Figure 9-1: MSLC-2 - interface overview (housing - side view)

Number	Labeled	Interface / Protocol
1	LAN A (Ethernet Network A)	UDP protocol ToolKit (ServLink) Modbus (Protocol 5200)
2	LAN B (Ethernet Network B)	UDP protocol (redundant) ToolKit (ServLink) Modbus (Protocol 5200)
3	LAN C (Ethernet Network C)	ToolKit (ServLink) Modbus (Protocol 5200)
4	SERVICE (USB)	ToolKit (ServLink)
5	CAN #3	Not used
6	CAN #1	Not used
7	RS-485 #1	Modbus (Protocol 5200)
8	CAN #2	Not used

Table 9-1: MSLC-2 - Interfaces - overview

#### RJ-45 Ethernet Interfaces (Network A, Interface **1**; Network B, Interface **2**, Network C, Interface **3**))

Redundant Standard Ethernet ports Network A and Network B for device interconnection (UDP Protocol) and PLC connection (TCP/IP Protocol). ). The redundancy is configurable with parameter 7809 Ethernet communication mode = single or redundant.

#### RS-485 Serial Interface **3** (Interface #7)

A freely configurable RS-485 Modbus RTU Slave interface is provided to add PLC connectivity. It is also possible to configure the unit, visualize measured data and alarm messages and control the unit remotely.



## Communication management

### Redundant Bus topology

In general: if a bus fails, it shall be switched automatically to the other bus and an alarm shall be activated.

Each unit in the network system is displayed in the overview screen. The status of each unit can be recognized. The display "Unit ID available" (see OVERVIEW PAGE screens) helps the operator to detect, where a defect unit or wire is located.

#### ***What happens if only Network A fails?***

All functions are fully maintained. The alarm "7792 Network A error" is triggered on all devices. The device, which cannot successfully send data over the Network A, sets in addition the alarm "4615 Communication error network A". In the ToolKit overview diagram DSLC2 and MSLC2 it can be detected via the information "Unit ID available", which device is down.

#### ***What happens if only Network B fails?***

All functions are fully maintained. The alarm "7793 Network B error" is triggered on all devices. The device, which cannot successfully send data over the Network B, sets in addition the alarm "7787 Communication error network B". In the ToolKit overview diagram DSLC2 and MSLC2 it can be detected via the information "Unit ID available", which device is down.

#### ***What happens if both Network A and Network B are down to one device?***

The alarm "Missing member" is triggered on all devices. In addition, alarms, as described subsequently are issued.

#### ***What happens if both Network A and Network B fail?***

The alarms "7792 Network A error" and "7793 Network B error" are triggered on each device. The device, which no longer can successfully send data over the Network A and / or Network B, sets in addition the alarms "4615 Communication error network A" and / or "7787 Communication error network B". In the ToolKit overview pages DSLC2 and MSLC2 it can be detected via the information "Unit ID available", which device is down.

### Single Bus topology

In general: if a network (Network A) fails, it shall be switched automatically to droop if configured and an alarm shall be activated.

Each unit in the network system is displayed in the overview screen. The status of each unit can be recognized. The display "Unit ID available" (see OVERVIEW PAGE screens and tables below) helps the operator to detect, where a defect unit or wire is located.

#### ***What happens if Network A fails***

The alarm "4617 Missing member" is triggered on each device. The device, which can no longer successfully send data over the Network A, sets in addition the alarm "4615 Communication error network A". In the overview diagram DSLC2 and MSLC2 it can be detected via the information "Unit ID available", which device is down.



## Visualization of the Bus System

### **ToolKit Overview pages DSLC2 / MSLC2**

The overview pages from DSLC2 and MSLC2 are showing the state of the networks in the field "Unit ID available" in the view of a single unit. The dedicated description is shown in the previous chapters.

### **ToolKit Homepage**

In the ToolKit Home page the actual number of teach units is shown in a field. A red LED still indicates "Missing member alarm like it is in Release 1.

### **ToolKit - Status Control Monitoring of Alarms**

On the page Menu 8, the following Alarms are displayed:

- Communication error Network A
- Communication error Network B
- Network A Error
- Network B Error
- Devices not matched

## Commissioning of the Communication Network System

### **Precondition:**

- All interfaces are wired.
- The correct equipment configuration is installed.
- All single overview pages (page 138ff) display the corresponding status.

If not:

- Check the configuration of the device
- Check and repair wiring
- Check and update configuration(s)
- Go for *System update* parameter 7789 to teach the correct system status.



### **NOTE**

The system update process described below can be executed on each of the devices recognized under each other.

## System update process

The System update process can be started by

- energizing DI 23 "System update" or
- using the parameter 7789 *System update* in ToolKit or
- sending the *System update* signal by communication interface (see page 208 for details)



### **NOTE**

The DI 23 e.g., can be handled by a push button. The unit reacts on a rising edge.

With this command the according device sends a system update signal for 30 seconds to all connected devices on the network. During this time the DSLC / MSLC Ethernet network system will be updated on the current network constellation. Single Bus or redundant bus will be incorporated. During the system update process, the CPU OK LED on cover of the DSLC-2 is flashing.

After this procedure all corresponding alarms should disappear and the correct number of participants is recognized, displayed, and stored in parameter 7791 *Number of devices in system*. In case Network A and/or Network B are not available the according alarms are (still) activated.



### Changing a device in a running system

First it is to check whether there is not yet a "Missing member" alarm active on the Ethernet network. If this alarm is active the reason for this is to clarify first. Otherwise the system update procedure would fade out this alarm situation.

1. The operator sends a system update command to the whole system by DI23 "System update". Then within the next 30 seconds he powers-off the particular device. After these 30 seconds the other controls are accepting the new constellation and monitor the network with one device lesser. No missing member alarm will occur!
2. The operator changes now the device and takes care that the communication network is not reconnected as long he has not configured the device correctly. If the device is configured correctly, he can reconnect the network.
3. After repowering and reconnecting the device, the system will automatically report that the system is over determined (by this changed device). It requests a new system update through the information "Add device" in the overview page. After checking this, the operator executes a new system update command. The alarm will disappear, if all works correct. The missing device monitor will take from now on this additional member into account.

### Switching off a device in a running system (i.e. servicing the engine)

First it is to check whether there is not yet a "Missing member" alarm active on the Ethernet network. If this alarm is active the reason for this is to clarify first. Otherwise the system update procedure would fade out this alarm situation.

1. The operator sends a system update command to the whole system by DI23 "System update". Then within the next 30 seconds he powers-off the particular device. After these 30 seconds the other controls are accepting the new constellation and monitor the network with one device lesser. No missing member alarm will occur!

### Adding a device to a running system (i.e. Commissioning new Genset)

First it is to check whether there is not yet a "Missing member" alarm active on the Ethernet network. If this alarm is active the reason for this is to clarify first. Otherwise the system update procedure would fade out this alarm situation.

After configuration, connecting and powering the device, the system will automatically report that the system is over determined. It requests a new system update through the information "Add device" in the overview page. After checking this, the operator executes a new system update command. The alarm will disappear, if all works correct. The missing device monitor will take from now on this additional member into account.



# Ethernet Load Sharing



## Multi-Master Principle

It is important to know that the load share and load-dependent start/stop functionality is subject to a multi-master principle. This means that there is no dedicated master and slave function. Each MSLC-2 decides for itself how it has to behave. The benefit is that there is no master control, which may cause a complete loss of this functionality in case it fails. Each control is also responsible for controlling common breakers like a mains circuit or generator group breaker.

## Load Share Monitoring

The MSLC-2 provides the following monitoring function for load sharing:

## Multi-Unit Missing Members

The multi-unit missing members monitoring function checks whether all participating units are available (sending data on the Ethernet line).

## Switches

Please use a 10/100 Mbit/s Ethernet switch if more than two devices should be connected.

## General Load Share Information

The maximum number of participating DSLC-2 devices for load sharing is 32. The maximum number of MSLC-2 devices is 16.

The following parameters affect the bus load:

- Baud rate
- Transfer rate of load share messages
- Visualization



# Modbus Communications



## General Information

Modbus is a serial communications protocol published by Modicon in 1979 for use with its programmable logic controllers (PLCs). It has become a de facto standard communications protocol in industry and is now the most commonly available means of connecting industrial electronic devices. The DSLC-2 / MSLC-2 support a Modbus RTU Slave module. This means that a Master node needs to poll the slave node. Modbus RTU can also be multi-dropped, or in other words, multiple Slave devices can exist on one Modbus RTU network, assuming that the serial interface is a RS-485. Detailed Information about the Modbus protocol is available on the following website:


<https://www.modbus.org/specs.php>

There are also various tools available on the internet. We recommend using ModScan32 which is a Windows application designed to operate as a Modbus Master device for accessing data points in a connected Modbus Slave device. It is designed primarily as a testing device for verification of correct protocol operation in new or existing systems. It is possible to download a trial version from the following website:

<http://www.win-tech.com/html/modscan32.htm>

## Address Range

The DSLC-2 / MSLC-2 Modbus Slave module distinguishes between visualization data and configuration & remote control data. The different data is accessible over a split address range and can be read via the "Read Holding Register" function. Furthermore, the parameters and remote control data can be written with the "Preset Single Registers" function or "Preset Multiple Registers".



### NOTE

All addresses in this document comply with the Modicon address convention. Some PLCs or PC programs use different address conventions depending on their implementation. Then the address must be increased and the leading 4 may be omitted.

Please refer to your PLC or program manual for more information. This determines the address sent over the bus in the Modbus telegram. The Modbus starting address 450001 of the visualization data may become bus address 50000 for example.



## Visualization

The visualization over Modbus is provided in a very fast data protocol where important system data like alarm states, AC measurement data, switch states and various other information may be polled. According to the DSLC-2 / MSCL-2 Modbus addressing range, the visualization protocol can be reached on addresses starting at 450001. On this address range it is possible to do block reads from 1 up to 128 Modbus registers at a time.

Modbus Read Addresses	Description	Multiplier	Units
450001	Protocol-ID, always 5200		--
450002	Scaling power		--
.....	.....	.....	.....
.....	.....	.....	.....
.....	.....	.....	.....
.....	.....	.....	.....
450171	Remote load reference input	0.1	kW

Table 9-2: Modbus - address range block read



### NOTE

Table 9-2 is only an excerpt of the data protocol. It conforms to the data protocol 5200 that is also used by Ethernet. Refer to “Data Protocol 5200” on page 228 for the complete protocol.

The following ModScan32 screenshot shows the configurations made to read the visualization protocol with a block read of 128 registers.




Figure 9-2: Modbus - visualization configurations



## Configuration

The Modbus interface can be used to read/write parameters of the DSLC-2 / MSLC-2. According to the DSLC-2 / MSLC-2 Modbus addressing range for the configuration addresses, the range starts at 40001 and ends at 450000. You can always access only one parameter of the system in this address range. The Modbus address can be calculated depending on the parameter ID as illustrated below:

	Parameter ID < 10000	Parameter ID >= 10000
Modbus address =	40000 + (Par. ID+1)	400000 + (Par. ID+1)

Table 9-3: Modbus - address calculation

Block reads in this address range depend on the data type of the parameter. This makes it important to set the correct length in Modbus registers which depends on the data type (UNSIGNED 8, INTEGER 16, etc.). Refer to Table 9-4 for more information.

Device types	Modbus registers
UNSIGNED 8	1
UNSIGNED 16	1
INTEGER 16	1
UNSIGNED 32	2
INTEGER 32	2
LOGMAN	7
TEXT/X	X/2

Table 9-4: Modbus - data types

If Modbus commands are sent via TCP/IP packages in Network A or B, dedicated Modbus slave addresses are configurable for Network A as well as for Network B.

The default slave addresses for Network A and B are 255.



## MSLC-2 Interface Remote Control

For a remote setting of the control setpoints, it is necessary to use the interface setpoints instead of the internal setpoints. No password is required to write this value. All other setpoint sources are configured accordingly. Control orders can be sent via Ethernet (Modbus/TCP) or RS-485 Modbus RTU.

### Sending Setpoints Over Interface

Some setpoints can be sent over the communication interface.

ID	Parameter	CL	Setting range	Default	Description
7642	Active power setpoint for import/export control	-	1 kW to 999999,9 kW	-	<p>Setpoint for the active power control. The setpoint is a long integer 32 to provide a wide range from 1 kW to 999999.9 kW. Negative values are not allowed.</p> <p><b>Example:</b> 1000 kW = 1000 = 3E8Hex</p> <p><b>Note:</b> This setpoint will be only accepted when the parameter Load control setpoint source (parameter 7634) is configured to "Interface".</p>
7640	Setpoint power factor import/export	-	-500 to 1000 to 500	-	<p>The power factor is set as a value (integer 16) between -500to 1000 to 500. A negative value is capacitive, a positive value is inductive, 1000 = <math>\cos \varphi</math> 1. Other values are not accepted by the unit.</p> <p><b>Example:</b>  <math>\cos \varphi = c0.71 \text{ cap.}</math>      -710 FD3AHex  <math>\cos \varphi = 1.00 \text{ 1000}</math>      03E8Hex  <math>\cos \varphi = i 0.71 \text{ ind.}</math>      710 02C6Hex</p> <p><b>Note:</b> This setpoint will be only accepted when the parameter VAR control setpoint source (parameter 7635) is configured to "Interface".</p>
7641	Frequency Setpoint		0 to 7000 1/100 Hz		<p>Setpoint Generator Frequency Control [Hz*100]</p> <p><b>Example:</b> 50.00Hz = 5000 = 1388Hex</p> <p><b>Note:</b> This setpoint will be only accepted when the parameter Freq. control setpoint source (parameter 7783) is configured to "Interface".</p>
7780	Voltage Setpoint		50 to 650000 V		<p>Voltage Setpoint for voltage control [V]</p> <p><b>Example:</b> 400V = 400 = 190Hex 10000V = 10000 = 2710Hex</p> <p><b>Note:</b> This setpoint will be only accepted when the parameter Voltage control setpoint source (parameter 7784) is configured to "Interface".</p>
7785	Basic Segment number		1 to 8		<p>Basic segment number</p> <p><b>Example:</b> Range:1 to 8</p> <p><b>Note:</b> The Basic segment number will be only accepted when the parameter Basic segment number source (parameter 7786) is configured to "Interface".</p>

Table 9-5: Modbus – sending setpoints over interface



## Sending Binary Digital Orders over Interface

Some single functions can be passed over from discrete inputs to the communication interface.

Function	Terminal	Controllable by
Check	67	Discrete input DI 01 or communication interface
Permissive	68	Discrete input DI 02 or communication interface
Run	69	Discrete input DI 03 or communication interface
CB Aux	70	Discrete input DI 04 fixed to DI
Voltage Raise	71	Discrete input DI 05 or communication interface
Voltage Lower	72	Discrete input DI 06 or communication interface
Base Load	73	Discrete input DI 07 or communication interface
Utility Unload	74	Discrete input DI 08 or communication interface
Ramp Pause	75	Discrete input DI 09 or communication interface
Setpoint Raise	76	Discrete input DI 10 or communication interface
Setpoint Lower	77	Discrete input DI 11 or communication interface
Process Control	78	Discrete input DI 12 or communication interface
Segment Connection 12/23/ ... Act.	141/142/ ... / 148	Discrete input DI 13/14/ ... /18
Imp./Exp. Control	149	Discrete input DI 21 or communication interface
Modbus Reset	150	Discrete input DI 22 fixed to DI
System Update	151	Discrete input DI 23 or communication interface

Table 9-6: Modbus – sending binary digital orders over interface






Figure 9-3: Modbus - sending binary digital orders over interface

ID	Parameter	CL	Setting range	Default	Description
7645	<b>Release discrete inputs over communication interface</b>	-	-	-	<p>These single bits control if a function shall be switched by discrete input or communication interface.</p> <p>Bit 01 = 1 Check            Bit 02 = 1 Permissive            Bit 03 = 1 Run            Bit 04 = 1 N/A            Bit 05 = 1 Voltage Raise            Bit 06 = 1 Voltage Lower            Bit 07 = 1 Base Load            Bit 08 = 1 Utility Unload            Bit 09 = 1 Ramp Pause            Bit 10 = 1 Setpoint Raise            Bit 11 = 1 Setpoint Lower            Bit 12 = 1 Process            Bit 13 = 1 Imp./Exp. control            Bit 14 = 1 N/A            Bit 15 = 1 system update            Bit 16 = 1 N/A</p> <p><b>Note:</b>            Bit {x} = 0 -&gt; DI interface = hardware controlled            Bit {x} = 1 -&gt; DI interface = interface controlled</p>
7644	<b>Discrete inputs over communication interface</b>	-	-	-	<p>These single bits switch the single functions if they are released by parameter 7645.</p> <p>Bit 01 = 1 Check            Bit 02 = 1 Permissive            Bit 03 = 1 Run            Bit 04 = 1 N/A            Bit 05 = 1 Voltage Raise            Bit 06 = 1 Voltage Lower            Bit 07 = 1 Base Load            Bit 08 = 1 Utility Unload            Bit 09 = 1 Ramp Pause</p>



ID	Parameter	CL	Setting range	Default	Description
					Bit 10 = 1 Setpoint Raise Bit 11 = 1 Setpoint Lower Bit 12 = 1 Process Bit 13 = 1 Imp./Exp. Control Bit 14 = 1 N/A Bit 15 = 1 System update Bit 16 = 1 N/A  <b>Note:</b> Bit {x} = 0 -> DI interface = switched "Off" Bit {x} = 1 -> DI interface = switched "On"

Table 9-7: Modbus – sending binary digital orders over interface

## Loss of Connection

The device sends Modbus binary digital orders via interface. The function *Release discrete inputs over communication interface* (parameter 7645) takes care if the DI interfaces are "Hardware" or "Interface" controlled. The parameter *Discrete inputs over communication interface* (parameter 7644) switches the DI interfaces to "On" or "Off". In case of a connection loss (RS-485 or Network B) the device can be controlled via "Hardware" control and overrides the original setting of parameter 7645. The following paragraph describes the function in detail.

### Interface Control Fails

1. Interface connection loss (RS-485 or Network B).
2. The conditions of the discrete inputs (DI) will remain in their current settings, even in the case of interface connection loss.
3. Please configure the discrete inputs via hardware switches to the desired settings.
4. To regain system control, please energize DI 22 "Modbus Reset" via hardware switch (overrides the original settings of parameter 7645; the control bits will reset to value "0").
5. Now all discrete inputs are "Hardware" controlled.

### Switch Back To Interface Control

1. The discrete inputs (DI) are currently "Hardware" controlled.
2. The interface connection is working again.
3. Please de-energize DI 22 "Modbus Reset" via hardware switch to be able to configure parameter 7645 to "Interface" control.
4. The settings of parameter 7644 remain in their last configuration if there was no interrupt of the power supply. We highly recommend double-checking the settings. Please check the conditions of the DIs in Menu 9 (Notification: DI = "Hardware" controlled; Notification: Com = "Interface" controlled).
5. Now you must configure the discrete inputs in parameter 7645 to "Interface" control.
6. Now the discrete inputs are again "Interface" controlled.



### NOTE

The DI's „CB Aux“ and „Modbus Reset“ are in general hardware controlled and cannot be changed via interface.






Figure 9-4: Modbus – loss of connection

### Example 1: Active Power Interface Setpoint Baseload

The setpoint for active power control is a long integer to provide a wide range from 1 to 999999.9 kW. Negative values are not allowed. This setpoint will be accepted, if the power setpoint manager of the unit passes the setpoint through.

The active power setpoint value must be written to parameter 7642.

#### Example:


A power value of 500 kW = 500 (dec) = 01F4 (hex) is to be transmitted.

Modbus address = 40000 + (Par. ID + 1) = 407642.

Modbus length = 2 (INTEGER 32).


The high word is to be written to the lower address and the low word is to be written to the higher address.

The following ModScan32 screenshots show how to set the parameter address 7642 in ModScan32.





Open the preset multiple registers window by selecting Setup > Extended > Preset Regs from the menu.



16: PRESET MULTIPLE REGISTERS


Slave Device: 255

Address: 7643

Number of Points: 2

OK Cancel

Select OK and enter the desired values.



16: PRESET MULTIPLE REGISTERS


Address: 7643  
Length: 0002

7643:	0000	(HEX)
7644:	01F4	(HEX)

From File To File

Update Cancel

Select Update to take over the entered values.



ModScan32 - [ModSca1]

File Connection Setup View Window Help

Address: 7643 Device Id: 255 Number of Polls: 23469  
Length: 2 MODBUS Point Type Valid Slave Responses: 23140  
03: HOLDING REGISTER Reset Ctrs

47643: <0000H>  
47644: <01F4H>

For Help, press F1 Polls: 23469 Resps: 23140

Figure 9-5: Modbus - configuration example 1 - active power



## Example 2: Power Factor Interface Setpoint

The setpoint for the power factor control is set as a value between -500 to -999, 1000, 999 to 500. A negative value is capacitive, a positive value is inductive, 1000 = cosphi 1. Other values are not accepted by the unit. This setpoint will be accepted, if the power factor setpoint is selected via ToolKit.

The power factor setpoint value must be written to parameter 7640.

### Example:

A power factor of 1 = 1000 (dec) = 03E8 (hex) is to be transmitted.

Modbus address = 40000 + (Par. ID + 1) = 40509.

Modbus length = 1 (UNSIGNED 16).

The following Modscan32 screenshot shows the settings made to parameter address 7640 in ModScan32.




Figure 9-6: Modbus - configuration example 2 – power factor



## Changing Parameter Settings via RS485



### Parameter Setting



#### NOTE

The example tables below are excerpts of the parameter list in Chapter: “Configuration & Operation”.



#### NOTE

Be sure to enter the password for code level 2 or higher for the corresponding interface to get access for changing parameter settings.



#### NOTE

The new entered value must comply with the parameter setting range when changing the parameter setting.

**Example 1:** Addressing the password for RS 485:

Par. ID.	Parameter	Setting range	Data type
10430	Password for serial interface1	0000 to 9999	UNSIGNED 16

Table 9-8: Modbus – password for serial interface 2 (RS 485)

Modbus address =  $400000 + (\text{Par. ID} + 1) = 410431$   
 Modbus length = 1 (UNSIGNED 16)

**Example 2:** Addressing the generator rated voltage:

Par. ID.	Parameter	Setting range	Data type
1766	Generator rated voltage	50 to 650000 V	UNSIGNED 32

Table 9-9: Modbus – generator rated voltage

Modbus address =  $40000 + (\text{Par. ID} + 1) = 41767$   
 Modbus length = 2 (UNSIGNED 32)

The following Modscan32 screenshot shows the configurations made to address parameter 1766.




Figure 9-7: Modbus - configuration example 2

**Example 3:** Addressing the generator voltage measuring:



Par. ID.	Parameter	Setting range	Data type
1851	Generator voltage measuring	3Ph 4W 3Ph 3W n/a n/a 3Ph 4WOD	UNSIGNED 16

Table 9-10: Modbus – generator voltage measuring

Modbus address = 40000 + (Par. ID + 1) = 41852

Modbus length = 1 (UNSIGNED 16)

**NOTE**

If the setting range contains a list of parameter settings like in this example, the parameter settings are numbered and start with 0 for the first parameter setting. The number corresponding with the respective parameter setting must be configured.

The following Modscan32 screenshot shows the configurations made to address parameter 1851, which is configured to "3Ph 4W".




Figure 9-8: Modbus - configuration example 3



## Remotely Resetting the Default Values

### Modbus via RS-485 or Modbus TCP/IP

It is possible to remotely reset the unit to its default values through Modbus (via RS-485) or Modbus TCP/IP using the parameter 10417 and 1701. The required procedure is detailed in the following steps.

Par. ID.	Parameter	Setting range	Data type
10417	Factory default settings	Yes / No	UNSIGNED 16
1701	Reset factory default values	Yes / No	UNSIGNED 16

Table 9-11: Modbus – reset default values

In order to enable the resetting procedure, parameter 10417 must be enabled.

#### Example:

The resetting procedure has to be enabled.

Modbus address =  $40000 + (\text{Par. ID} + 1) = 410418$

Modbus length = 1 (UNSIGNED 16)

The following Modscan32 screenshot shows the settings made to parameter 10417 in ModScan32. It is possible to set the format to decimal to view the value using the "display options".




Figure 9-9: Modbus - remote control parameter 1701

By double-clicking the address, a Write Register command is issued. The following screenshot shows how the parameter is enabled using the ModScan32 Software. The value must be set to "1" to enable the parameter.




Figure 9-10: Modbus - write register - enable the resetting procedure via USB or Modbus TCP/IP



In order to reset the default values, parameter 1701 must be enabled.

**Example:**

The default values are to be reset.

Modbus address =  $40000 + (\text{Par. ID} + 1) = 41702$

Modbus length = 1 (UNSIGNED 16)

The following Modscan32 screenshot shows the settings made to parameter 1701 in ModScan32. It is possible to set the format to decimal to view the value using the "display options".




Figure 9-11: Modbus - remote control parameter 1701

By double-clicking the address, a Write Register command may be issued. The following screenshot shows how the parameter is enabled using the ModScan32 Software. The value must be set to "1" to enable the parameter.



Figure 9-12: Modbus - write register - resetting the default values



# Modbus Parameters



## NOTE

The following parameters are available for configuring the Modbus modules on the Serial Interfaces. Refer to Chapter: “Configuration & Operation” for detailed information about all parameters.

## Serial Interface 2 (RS 485)

Parameter table

ID	Text	Setting range	Default value
<b>Configure RS-485 interfaces: serial interface 2</b>			
3188	Modbus Slave ID	0 to 255	33
3189	Reply delay time	0.00 to 2.55 s	0.00 s

Table 9-12: Modbus - serial interface 2 – parameters

## Network A, B, C – Modbus TCP

For Modbus TCP parameters refer to

- Network A – UDP / Modbus
- Network B – UDP / Modbus
- Network C Modbus



## Chapter 10. Application

### Phase Angle Compensation



This feature allows the MSLC-2 to adapt the phase angle measurement system according to the transformer type. The phase angle of the "System B to System A" measurement can be compensated.

The controller provides an adjustment for a phase angle deviation in a range of  $\pm 180.0$ : "Phase angle MCB" (parameter 8842). This parameters compensate the phase angle deviation, which can be caused by transformers (i.e. a delta to wye transformer) located within the electrical system. The phase angle compensation is activated with the parameter "Phase angle compensation MCB" (parameter 8841).



#### WARNING

Ensure the parameters are configured correctly to prevent erroneous synchronization settings. Incorrect wiring of the system cannot be compensated with this parameter!





Fig. 201: Phase angle compensation MCB

#### Example

Using the vector group 11 (Yd11) it counts  $\alpha = 11 \times 30^\circ = 330^\circ$ . Because  $330^\circ > 180^\circ$  and MSLC mains measurement is connected to the high voltage side this results into  $(-360^\circ + \alpha)$  to be used as phase difference. Enter  $-30^\circ$  into as parameter for the phase difference Mains/Busbar.



## Technical Data



## Measuring Values

Measuring values (voltages) – wye/delta voltage	
Measuring voltages	398/690 VAC
• Rated value ( $V_{LLrated}$ )	100 VAC up to 690 VAC
• Maximum value ( $V_{LLmax}$ )	max. 897 VAC
• Rated voltage phase – ground	600 VAC
• Rated surge voltage	6.0 kV
Linear measuring range	$1.3 \times V_{rated}$
Measuring frequency	50/60 Hz (30.0 to 85.0 Hz)
Accuracy	Class 0.5
Input Resistance per path	2.5 MΩ
Maximum power consumption per path	< 0.15 W

## Currents



### With External CT

**For correct measuring with external CT the input must be one side grounded by the customer.**

Measuring values (currents) – galvanically isolated		
Measuring current	Rated value ( $I_{rated}$ )	.../1 A or .../5 A
Accuracy	Class 0.5	
Linear measuring range	$1.5 \times I_{rated}$	
Maximum power consumption per path	< 0.10 VA	
Rated short-time current (1 s)		50.0 A



## Ambient Variables

Ambient variables	
Power supply	12/24 VDC (8 to 40.0 VDC), SELV
Intrinsic consumption	max. 32 W
Insulation voltage	Marine applications 40 Vdc
Insulation test voltage (1 s)	100 Vdc
Overvoltage ( $\leq 2$ min)	80 Vdc
Reverse voltage protection	Over the full supply range
Input capacitance	5,000 $\mu$ F
Unit Power Supply	Negative potential grounded or positive potential grounded or ungrounded
Degree of pollution	2
Maximum elevation	4,000 m ASL

## Digital Inputs

Discrete inputs – galvanically isolated	
Input range ( $V_{\text{cont. dig. input}}$ )	Rated voltage 12/24 Vdc (8 to 40.0 Vdc)
Input resistance	Approx. 20 k $\Omega$

## Digital Outputs

Discrete outputs – galvanically isolated, potential free		
Contact material	AgNi	
General purpose (GP) ( $V_{\text{cont. relays}}$ )	AC	2.00 AAC@250 VAC
	DC	2.00 ADC@24 Vdc
		0.36 ADC@125 VDC Not suitable for USA and Canada applications. Not evaluated by UL.
		0.18 ADC@250 VDC Not suitable for USA and Canada applications. Not evaluated by UL.
Pilot duty (PD) ( $V_{\text{cont. relays}}$ )	AC	B300

## Analog inputs AI 01-03 (Type 2: 0/4 to 20 mA | 0 to 10 V)

Analog inputs (not isolated) – freely scalable	
Maximum permissible voltage against PE (Ground)	100 V
Resolution	14 Bit
0/4 to 20 mA input	Internal load 249 $\Omega$
0 to 10 V input	Input resistance approx. 80 k $\Omega$
Accuracy	$\pm 0.5\%$ related to 10V



## Interfaces

Interface	
USB (slave) USB 2.0 interface	Galvanically isolated
• Type	USB 2.0 standard; slave (Type B)
• Data rate	max. 12 Mbit/s
• Bus Voltage	5 V
• Current consumption	approx. 10 mA
RS-485 interface	Galvanically isolated
• Insulation voltage (continuously)	100 Vac
• Insulation test voltage (1 s)	1700 VDC
• Version	RS-485 Standard
Ethernet interface	Galvanically isolated Only one MAC ID is required
• Insulation voltage (continuously)	100 VAC
• Insulation test voltage (1 s)	1700 VDC
• Version	Ethernet 10/100Base-T/TX
• Ethernet plug socket	RJ45 standard, shielded 2 LEDs to indicate communication.
• Ethernet cable	CAT 5 or 5e (class D) Shielding: F/UTP according to ISO/IEC 11801 (foil overall shielding, pairs unshielded)
• Green LED	Indicates link activity (blinking during data transmission)
• Yellow LED	Indicates link status (regarding speed): 10 Mb/s: LED switched-off 100 Mb/s: LED switched-on
• Internal shield termination	Available

## Real Time Clock Battery

Battery	
Type	Lithium
Life span (operation without power supply)	Approx. 5 years
Battery field replacement	Not allowed. Please contact your Woodward service partner.

## Housing

Housing	
Type	Sheet metal → Custom
Dimensions (W × H × D)	Sheet metal → 250 × 227 × 84 mm (9.84 × 9.00 × 3.30 in)
Wiring	Screw-plug-terminals 2.5 mm <sup>2</sup>
Recommended locked torque	4 inch pounds / 0.5 Nm Use 90°C copper wire only Use class 1 wire only or equivalent
Weight	approx. 2,480 g (5.46 lbs)

## Protection

Protection	
Protection system	IP 20



## Approvals


Certifications	
EMC test (CE)	Tested according to applicable EMC standards. Refer to  "8.2 Environmental Data" for details
Listings	CE marking UL, Ordinary Locations, File No.: E231544 UL recognized component, category FTPM2/8, File No.: E347132 cUL CSA EAC
Marine	Type approval: Lloyds Register (LR) Type approval: American Bureau of Shipping (ABS)
Generic note	
Accuracy	Is referred to full scale value

Table 0-1: Technical Data

## Environmental Data



## Vibration

Vibration	
Sine Sweep	Acceleration: 4G; Frequency Range: 5 Hz to 100 Hz
Standards	EN 60255-21-1 (EN 60068-2-6, Fc) EN 60255-21-3 Lloyd's Register, Vibration Test2 SAEJ1455 Chassis Data
Random vibration	Frequency Range: 10 Hz to 500 Hz
	Power Intensity: 0.015G <sup>2</sup> / Hz
	RMS Value: 1.04 Grms
Standards	MIL-STD 810F, M514.5A, Cat.4, Truck/Trailer tracked-restrained Cargo, Fig. 514.5-C1

## Shock

Shock	
Shock	40G, Saw tooth pulse, 11 ms
Standards	MIL-STD 810F, M516.5, Procedure 1

## Temperature

Temperature	
Cold, Dry Heat (storage)	-40 °C (-40 °F) / 80 °C (176 °F)
Cold, Dry Heat (operating)	-40 °C (-40 °F) / 70 °C (158 °F)
Standards	IEC 60068-2-2, Test Bb and Bd IEC 60068-2-1, Test Ab and Ad



## Humidity

Humidity	
Humidity	60 °C, 95% RH, 5 days
Standards	IEC 60068-2-30, Test DB

## Marine environmental categories

Marine Environmental Categories	
Lloyd's Register of Shipping (LRS)	ENV1, ENV2, ENV3 and ENV4

Table 0-2: Environmental data

## Electromagnetic Compatibility

Electromagnetic Compatibility	
EN 61000-6-2	2005 - Electromagnetic compatibility (EMC). Generic standards. Immunity for industrial environment
EN 61000-6-4	2007 + A1: 2011 - Electromagnetic compatibility (EMC). Generic standards. Emission standard for industrial environments
EN 61326-1	2013 - Electrical equipment for measurement, control and laboratory use. EMC requirements. General requirements (according to industrial electromagnetic environment)



## Accuracy



The accuracy declaration is defined by the according measurement ranges. The rated maximum of the single ranges are taken as 100%.

This results in the definitions:

- Range 1: 69/120 V rated = 100%
- Range 2: 277/480 V rated = 100%
- Range 3: 400/690 V rated = 100%

Measuring value	Display	Accuracy	Measuring start	Notes
Frequency				
Generator	15.0 to 85.0 Hz	0.1% (of 85 Hz)	5% (of PT secondary voltage setting) <sup>1</sup>	
Busbar	40.0 to 85.0 Hz			
Voltage				
Wye generator / mains / busbar	0 to 650 kV	0.5% , Class 0.5 <sup>2</sup> related to: 69/277/400 V (Wye) 120/480/690 V (Delta)	1.5% (of PT secondary voltage setting) <sup>1</sup>	
Delta generator / mains / busbar			2% (of PT secondary voltage setting) <sup>1</sup>	
Current				
Generator	0 to 32,000 A	0.5% (of 1/5 A) <sup>3</sup> Class 0.5	1% (of 1.3/6.5 A) <sup>3</sup>	
Mains / ground current				
Max. value				
Real power				
Actual total real power value	-2 to 2 GW	1% (of 69/277/400 V x 1/5 A) <sup>2/3</sup>	Starts with detecting the zero passage of current/voltage	
Reactive power				
Actual value in L1, L2, L3	-2 to 2 Gvar	1% (of 69/277/400 V x 1/5 A) <sup>2/3</sup>	Starts with detecting the zero passage of current/voltage	
Power factor				
Actual value power factor L1	Lagging 0.00 to 1.00 to leading 0.00	1%	1% (of 1.3/6.5 A) <sup>3</sup>	1.00 is displayed for measuring values below the measuring start
Miscellaneous				
Battery voltage	0 to 40 VDC	±0.5% related to 40 V	Related on the measurement range 8 to 40 V	0.5% equals 0.2 V (±0.2 V)
Phase angle	-180 to 180 °	± 1 degree	1.25% (of PT secondary volt. setting)	180 ° is displayed for measuring values below measuring start
Analog inputs 1-3				
0 to 20 mA / 0 to 10 V	Freely scalable	±0.5% related to 20 mA ±0.5% related to 10 V		

Table 0-3: Accuracy

<sup>1</sup> Setting of the parameter for the PT secondary rated voltage

<sup>2</sup> Depending on the used measuring range (120/480/690 V)

<sup>3</sup> Depending on the CT input definition (1/5 A) by customer settings. MSLC-2XT hardware covers both 1 A and 5 A ranges.



**Reference conditions (for measuring the accuracy):**

- Input voltage ..... sinusoidal rated voltage
- Input current..... sinusoidal rated current
- Frequency ..... rated frequency +/- 2%
- Power supply ..... rated voltage +/- 2%
- Power factor ( $\cos \phi$ ) .... 1.00
- Ambient temperature ... 23 °C +/- 2 K
- Warm-up period ..... 20 minutes



## Appendix B

### Useful Information

#### Connecting 24 V Relays



Interferences in the interaction of all components may affect the function of electronic devices. One interference factor is disabling inductive loads, like coils of electromagnetic switching devices. When disabling such a device, high switch-off induces voltages may occur, which might destroy adjacent electronic devices or result interference voltage pulses, which lead to functional faults, by capacitive coupling mechanisms.

Since an interference-free switch-off is not possible without additional equipment, the relay coil is connected with an interference suppressing circuit.

If 24 V (coupling) relays are used in an application, it is required to connect a protection circuit to avoid interferences. Figure 0-1 shows the exemplary connection of a diode as an interference suppressing circuit.




Figure 0-1: Interference suppressing circuit - connection

Advantages and disadvantages of different interference suppressing circuits are described in the following.

Connection diagram	Load current / voltage curve	Advantages	Disadvantages
		<ul style="list-style-type: none"> <li>Uncritical dimensioning</li> <li>Lowest possible induced voltage</li> <li>Very simple and reliable</li> </ul>	<ul style="list-style-type: none"> <li>High release delay</li> </ul>
		<ul style="list-style-type: none"> <li>Uncritical dimensioning</li> <li>High energy absorption</li> <li>Very simple setup</li> <li>Suitable for AC voltage</li> <li>Reverse polarity protected</li> </ul>	<ul style="list-style-type: none"> <li>No attenuation below <math>V_{VDR}</math></li> </ul>
		<ul style="list-style-type: none"> <li>HF attenuation by energy storage</li> <li>Immediate shut-off limiting</li> <li>Attenuation below limiting voltage</li> <li>Very suitable for AC voltage</li> <li>Reverse polarity protected</li> </ul>	<ul style="list-style-type: none"> <li>Exact dimensioning required</li> </ul>

Table 0-1: Interference suppressing circuit for relays



# Appendix C

## Data Protocols

### Data Protocol 5200



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
50000	450001	16	signed		Protocol-ID, always 5200		--
50001	450002	16	signed	3181	Scaling Power (16 bits) Exponent 10x W (5;4;3;2)		
50002	450003	16	signed	3182	Scaling Volts (16 bits) Exponent 10x V (2;1;0;-1)		
50003	450004	16	signed	3183	Scaling Amps (16 bits) Exponent 10x A (0;-1)		
50004	450005	16	signed	7732	Scaling kW, °C, kPa, bar, V, mA		
50005	450006	16			0 (reserve)		
50006	450007	16			0 (reserve)		
50007	450008	16			0 (reserve)		
50008	450009	16			0 (reserve)		
50009	450010	16			0 (reserve)		
<b>AC Measurement values</b>							
50010	450011	16	signed	144	System A frequency	0.01	Hz
50011	450012	16	signed	246	System A total power	scaled defined by index 3181 (modicon Address 450002)	kW
50012	450013	16	signed	247	System A total reactive power		kvar
50013	450014	16	signed	160	System A power factor	0.001	
50014	450015	16	signed	248	System A voltage L1-L2	scaled defined by index 3182 (modicon Address 450003)	V
50015	450016	16	signed	249	System A voltage L2-L3		V
50016	450017	16	signed	250	System A voltage L3-L1		V
50017	450018	16	signed	251	System A voltage L1-N		V
50018	450019	16	signed	252	System A voltage L2-N		V
50019	450020	16	signed	253	System A voltage L3-N		V
50020	450021	16	signed	255	System A current 1		A
50021	450022	16	signed	256	System A current 2		A
50022	450023	16	signed	257	System A current 3		A
50023	450024	16	signed	209	System B frequency	0.01	Hz
50024	450025	16	signed	254	System B voltage L1-L2 (or L1-N)	scaled defined by index 3182 (modicon Address 450003)	V



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
50025	450026	16	signed	147	Auxiliary System B frequency	0.01	Hz
50026	450027	16	signed	118	Auxiliary System B voltage L1-L2	scaled defined by index 3182 (modicon Address 450003)	V
50027	450028	16	signed	119	Auxiliary System B L2-L3		V
50028	450029	16	signed	120	Auxiliary System B L3-L1		V
50029	450030	16	signed	121	Auxiliary System B L1-N		V
50030	450031	16	signed	122	Auxiliary System B L2-N		V
50031	450032	16	signed	123	Auxiliary System B L3-N		V
50032	450033	16	signed	4639	Phase Angle System A / System B	0.1	°
50033	450034	16	signed	4627	Active Setpoint frequency to DSLC	0.01	Hz
50034	450035	16	signed	4628	Active Setpoint voltage to DSLC	0.01	%
50035	450036	16	signed	4629	Active Setpoint load level to DSLC	0.01	%
50036	450037	16	signed	4630	Active Setpoint reactive load level to DSLC	0.01	%
50037	450038	16	signed	4631	Active Setpoint constant generator pow.fac. To DSLC	(-500...1000...500)	
50038	450039	16			0 (reserve)		
50039	450040	16			0 (reserve)		
50040	450041	16			0 (reserve)		
50041	450042	16			0 (reserve)		
50042	450043	16			0 (reserve)		
50043	450044	16			0 (reserve)		
<b>DC Analogue Values (Engine Values)</b>							
50044	450045	16	signed	10110	Battery voltage	0.1	V
50045	450046	16	signed	10117	Remote Load / Process Reference Input (AI4)	000.0...100.0	%
50046	450047	16	signed	10151	Process Signal Input (AI5)	000.0...100.0	%
50047	450048	16	signed	7718	Power Factor (AI6)	(-500...1000...500)	
50048	450049	16	signed	5535	0 (reserve)		
50049	450050	16	signed	5635	0 (reserve)		
50050	450051	16			0 (reserve)		
50051	450052	16			0 (reserve)		
50052	450053	16			0 (reserve)		
50053	450054	16			0 (reserve)		
50054	450055	16			0 (reserve)		
<b>Control and Status</b>							



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
50055	450056	16			0 (reserve)		
50056	450057	16	signed	4636	Sync Control State 0: Off 1: Check mode active 2: Permissive mode active 3: Run mode active 4: Close Timer runs 5: Sync Timer runs 6: Breaker synchronized 7: Auto-Off position 8: Manual		
50057	450058	16	signed	4634	Load Control Mode 0: MSLC=Off (DSLCL=Inactive) 1: MSLC=Inactive (DSLCL=Droop) 2: MSLC=Off line (SLC=At Unload Trip) 3: MSLC=Frequency control (DSLCL=Load sharing) 4: Base load control 5: MSLC=Import/Export control (DSLCL=reserved) 6: Process control 7: MSLC=Remote process control (DSLCL=reserved) 8: Peak load control (reserved) 9: Zero power control (reserved) 10: Load share (reserved) 11: Process slave (reserved)		
50058	450059	16	signed	4635	Reactive Load Control Mode 0: MSLC=Off (DSLCL=Inactive) 1: MSLC=Inactive( DSLCL=Off) 2: MSLC=Off line (DSLCL=Droop) 3: MSLC=Voltage control (DSLCL=VAR sharing) 4: Reactive load control 5: MSLC=Import/Export reactive load (DSLCL=reserved) 6: MSLC=Const.Gen Power Factor (DSLCL=reserved) 7: Remote process control (reserved) 8: - (reserved) 9: Zero power control (reserved) 10: Reactive load share (reserved) 11: Process slave (reserved)		
50059	450060	16	bit array	4151	Condition Flags 1		
					0 (reserve)	Mask: 8000h	Bit
					0 (reserve)	Mask: 4000h	Bit
						Mask: 2000h	Bit
						Mask: 1000h	Bit
					Utility breaker is closed (in same segment)	Mask: 0800h	Bit
					System B is ok (in same segment)	Mask: 0400h	Bit
					System A is Dead	Mask: 0200h	Bit
					System B is Dead (in same segment)	Mask: 0100h	Bit
					System A is ok	Mask: 0080h	Bit
					Aux. System B anti clock wise system is recognized	Mask: 0040h	Bit
					Aux. System B clock wise system is recognized	Mask: 0020h	Bit
						Mask: 0010h	Bit
						Mask: 0008h	Bit



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
					System A counter clock wise system is recognized	Mask: 0004h	Bit
					System A clock wise system is recognized	Mask: 0002h	Bit
						Mask: 0001h	Bit
50060	450061	16	bit array	4156	Condition Flags 2		
					0 (reserve)	Mask: 8000h	Bit
					0 (reserve)	Mask: 4000h	Bit
					0 (reserve)	Mask: 2000h	Bit
					0 (reserve)	Mask: 1000h	Bit
					0 (reserve)	Mask: 0800h	Bit
					Breaker dead busbar closure request active	Mask: 0400h	Bit
					0 (reserve)	Mask: 0200h	Bit
					0 (reserve)	Mask: 0100h	Bit
					0 (reserve)	Mask: 0080h	Bit
					0 (reserve)	Mask: 0040h	Bit
					0 (reserve)	Mask: 0020h	Bit
					0 (reserve)	Mask: 0010h	Bit
					0 (reserve)	Mask: 0008h	Bit
					0 (reserve)	Mask: 0004h	Bit
					0 (reserve)	Mask: 0002h	Bit
					0 (reserve)	Mask: 0001h	Bit
50061	450062	16	bit array	4155	Condition Flags 3		
					0 (reserve)	Mask: 8000h	Bit
					0 (reserve)	Mask: 4000h	Bit
					0 (reserve)	Mask: 2000h	Bit
					0 (reserve)	Mask: 1000h	Bit
					Breaker is closed	Mask: 0800h	Bit
					0 (reserve)	Mask: 0400h	Bit
					0 (reserve)	Mask: 0200h	Bit
					Synchronization Breaker is active	Mask: 0100h	Bit
					Opening Breaker is active	Mask: 0080h	Bit
					Closing Breaker is active	Mask: 0040h	Bit
					0 (reserve)	Mask: 0020h	Bit
					0 (reserve)	Mask: 0010h	Bit
					0 (reserve)	Mask: 0008h	Bit
					Unloading system is active	Mask: 0004h	Bit



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
					0 (reserve)	Mask: 0002h	Bit
					0 (reserve)	Mask: 0001h	Bit
50062	450063	16	signed	4637	Automatic Segment Allocation (ASA)	1...8	
50063	450064	16	signed	4638	Collective Breaker State (CBS)	0...255	
50064	450065	16	signed	7706	0 (reserve)		
50065	450066	16	signed	4503	0 (reserve)		
50066	450067	16	signed	4600	Process Signal Input	000.00...100.0	%
50067	450068	16	bit array	4157	Interface Control Switch		
					0 (reserve)	Mask: 8000h	Bit
					Source: System update switch	Mask: 4000h	Bit
					Source: Modbus reset switch	Mask: 2000h	Bit
					Source: Droop switch	Mask: 1000h	Bit
					Source: Process switch	Mask: 0800h	Bit
					Source: Lower load switch	Mask: 0400h	Bit
					Source: Raise load switch	Mask: 0200h	Bit
					Source: Ramp pause switch	Mask: 0100h	Bit
					Source: Load/ Unload switch	Mask: 0080h	Bit
					Source: Base load switch	Mask: 0040h	Bit
					Source: Lower voltage switch	Mask: 0020h	Bit
					Source: Raise voltage switch	Mask: 0010h	Bit
					Source: CB Aux contact switch	Mask: 0008h	Bit
					Source: Synchronization GCB run switch	Mask: 0004h	Bit
					Source: Synchronization GCB permissive switch	Mask: 0002h	Bit
					Source: Synchronization GCB check switch	Mask: 0001h	Bit
50068	450069	16	signed	4605	Process reference	000.00...100.0	%
50069	450070	16	signed	7708	Power factor reference	(-0.500... 1.000...0.500)	
50070	450071	16			0 (reserve)		
Relay Outputs							
50071	450072	16	bit array	4626	Relay Outputs 1		
					0 (reserve)	Mask: 8000h	Bit
					0 (reserve)	Mask: 4000h	Bit
					0 (reserve)	Mask: 2000h	Bit
					0 (reserve)	Mask: 1000h	Bit
					Load switch 2 (R12)	Mask: 0800h	Bit
					Load switch 1 (R11)	Mask: 0400h	Bit



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
					Alarm 3 (R10)	Mask: 0200h	Bit
					Alarm 2 (R9)	Mask: 0100h	Bit
					Alarm 1 (R8)	Mask: 0080h	Bit
					LCL/Gen breaker open (R7)	Mask: 0040h	Bit
					Breaker Close Relay (R6)	Mask: 0020h	Bit
					Breaker Open Relay (R5)	Mask: 0010h	Bit
					Low Limit Relay (R4)	Mask: 0008h	Bit
					High Limit Relay (R3)	Mask: 0004h	Bit
					0 (reserve) (R2)	Mask: 0002h	Bit
					Alarm Relay (R1)	Mask: 0001h	Bit
50072	450073	16			0 (reserve)		
50073	450074	16			0 (reserve)		
50074	450075	16			0 (reserve)		
<b>Alarm Management</b>							
50075	450076	16	bit array	4623	Alarms 1		
					Alarm 16 Reserve	Mask: 8000h	Bit
					Deadbus closure mismatch	Mask: 4000h	Bit
					GCB Open Failure	Mask: 2000h	Bit
					Centralized Alarms	Mask: 1000h	Bit
					Missing member	Mask: 0800h	Bit
					0 (reserve)	Mask: 0400h	Bit
					Communication Error NW A	Mask: 0200h	Bit
					Voltage Range Limit	Mask: 0100h	Bit
					High Voltage Limit	Mask: 0080h	Bit
					Low Voltage Limit	Mask: 0040h	Bit
					Low Process Limit	Mask: 0020h	Bit
					High Process Limit	Mask: 0010h	Bit
					Low Load Limit	Mask: 0008h	Bit
					High Load Limit	Mask: 0004h	Bit
					Breaker Close Failure	Mask: 0002h	Bit
					Synchronizer Timeout	Mask: 0001h	Bit
50076	450077	16			0 (reserve)		
50077	450078	16			0 (reserve)		
50078	450079	16			0 (reserve)		
50079	450080	16			0 (reserve)		



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
50080	450081	16			0 (reserve)		
<b>Discrete Inputs</b>							
50081	450082	16	bit array	4624	Discrete Inputs 1		
					0 (reserve)	Mask: 8000h	Bit
					0 (reserve)	Mask: 4000h	Bit
					0 (reserve)	Mask: 2000h	Bit
					0 (reserve)	Mask: 1000h	Bit
					Process Control Switch (DI12)	Mask: 0800h	Bit
					Load Lower Switch (DI11)	Mask: 0400h	Bit
					Load Raise Switch (DI10)	Mask: 0200h	Bit
					Ramp Pause Switch (DI9)	Mask: 0100h	Bit
					Load/Unload Switch (DI8) (Energized=Load)	Mask: 0080h	Bit
					Base Load Control Switch (DI7)	Mask: 0040h	Bit
					Voltage Lower Switch (DI6)	Mask: 0020h	Bit
					Voltage Raise Switch (DI5)	Mask: 0010h	Bit
					Circuit Breaker Aux. is closed (DI4)	Mask: 0008h	Bit
					Synchronization Run switch is active (DI3)	Mask: 0004h	Bit
					Synchronization Permissive switch is active (DI2)	Mask: 0002h	Bit
					Synchronization Check switch is active (DI1)	Mask: 0001h	Bit
50082	450083	16	bit array	4625	Digital Inputs 2		
					0 (reserve)	Mask: 8000h	Bit
					0 (reserve)	Mask: 4000h	Bit
					0 (reserve)	Mask: 2000h	Bit
					0 (reserve)	Mask: 1000h	Bit
					0 (reserve)	Mask: 0800h	Bit
					System update (DI23)	Mask: 0400h	Bit
					Modbus reset (DI22)	Mask: 0200h	Bit
					Import/Export Control Switch (DI21)	Mask: 0100h	Bit
					Segment connection 81 is closed (DI20)	Mask: 0080h	Bit
					Segment connection 78 is closed (DI19)	Mask: 0040h	Bit
					Segment connection 67 is closed (DI18)	Mask: 0020h	Bit
					Segment connection 56 is closed (DI17)	Mask: 0010h	Bit
					Segment connection 45 is closed (DI16)	Mask: 0008h	Bit
					Segment connection 34 is closed (DI15)	Mask: 0004h	Bit
					Segment connection 23 is closed (DI14)	Mask: 0002h	Bit



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
					Segment connection 12 is closed (DI13)	Mask: 0001h	Bit
50083	450084	16	bit array	4601	Alarms 5		
					0 (reserve)	Mask: 8000h	Bit
					0 (reserve)	Mask: 4000h	Bit
					0 (reserve)	Mask: 2000h	Bit
					0 (reserve)	Mask: 1000h	Bit
					0 (reserve)	Mask: 0800h	Bit
					0 (reserve)	Mask: 0400h	Bit
					0 (reserve)	Mask: 0200h	Bit
					0 (reserve)	Mask: 0100h	Bit
					Aux. System B: AC wiring	Mask: 0080h	Bit
					System A: AC wiring	Mask: 0040h	Bit
					Devices not matched	Mask: 0020h	Bit
					Network B Error	Mask: 0010h	Bit
					Network A Error	Mask: 0008h	Bit
					Communication Error NW B	Mask: 0004h	Bit
					Phase rotation mismatch	Mask: 0002h	Bit
					Busbar mismatch	Mask: 0001h	Bit
50084	450085	16			0 (reserve)		
50085	450086	16			0 (reserve)		
50086	450087	16			0 (reserve)		
50087	450088	16			0 (reserve)		
50088	450089	16			0 (reserve)		
50089	450090	16			0 (reserve)		
50090	450091	16			0 (reserve)		
50091	450092	16			0 (reserve)		
50092	450093	16			0 (reserve)		
50093	450094	16			0 (reserve)		
50094	450095	16			0 (reserve)		
50095	450096	16			0 (reserve)		
50096	450097	16			0 (reserve)		
50097	450098	16			0 (reserve)		
50098	450099	16			0 (reserve)		
50099	450100	16			0 (reserve)		
AC Measurement values (32 bit size)							



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
50100	450101	32	signed	135	Total System A power	1	W
50102	450103	32	signed	136	Total System A reactive power	1	var
50104	450105	32	signed	137	Total System A apparent power	1	VA
50106	450107	32	signed	170	Average System A Wye-Voltage	0.1	V
50108	450109	32	signed	171	Average System A Delta-Voltage	0.1	V
50110	450111	32	signed	216	Average System B Delta-Voltage	0.1	V
50112	450113	32	signed	185	Average System A Current	0.001	A
50114	450115	32	signed	111	System A current 1	0.001	A
50116	450117	32	signed	112	System A current 2	0.001	A
50118	450119	32	signed	113	System A current 3	0.001	A
50120	450121	32	signed	108	System A voltage L1-L2	0.1	V
50122	450123	32	signed	109	System A voltage L2-L3	0.1	V
50124	450125	32	signed	110	System A voltage L3-L1	0.1	V
50126	450127	32	signed	114	System A voltage L1-N	0.1	V
50128	450129	32	signed	115	System A voltage L2-N	0.1	V
50130	450131	32	signed	116	System A voltage L3-N	0.1	V
50132	450133	32	signed	125	System A active power 1-N	1	W
50134	450135	32	signed	126	System A active power 2-N	1	W
50136	450137	32	signed	127	System A active power 3-N	1	W
50138	450139	32	signed	182	System B voltage (L1-N) L1-L2	0.1	V
50140	450141	32	signed	173	Average Aux.System B Wye-Voltage	0.1	V
50142	450143	32	signed	174	Average Aux.System B Delta-Voltage	0.1	V
50144	450145	32	signed	118	Aux.System B voltage L1-L2	0.1	V
50146	450147	32	signed	119	Aux.System B voltage L2-L3	0.1	V
50148	450149	32	signed	120	Aux.System B voltage L3-L1	0.1	V
50150	450151	32	signed	121	Aux.System B voltage L1-N	0.1	V
50152	450153	32	signed	122	Aux.System B voltage L2-N	0.1	V
50154	450155	32	signed	123	Aux.System B voltage L3-N	0.1	V
50156	450157	32	signed	7719	P Sum	0.001	kW
50158	450159	32	signed	7720	Q Sum	0.001	kvar
50160	450161	32	signed	7721	Import/Export reference	0.1	kW
50162	450163	32	signed	7722	Reactive load reference	0.1	kvar
50164	450165	32	signed	7726	Process reference input	0.1	
50166	450167	32	signed	7727	Process signal input	0.1	
50168	450169	32	signed	7737	Process reference toolkit	0.1	
50170	450171	32	signed	7738	Remote load reference input	0.1	kW



Modbus Address	Modicon Address	Size [bits]	Format	Parameter ID	Description MSLC-2XT	Multiplier (BUS-data * Multiplier = real value)	Units
50172	450173	32			0 (reserve)		
50174	450175	32	signed	2520	Syst.A.pos.act.energy	0.01	MWh
50176	450177	32	signed	2524	Syst.A.neg.act.energy	0.01	MWh
50178	450179	32	signed	2522	Syst.A.pos.react.energy	0.01	Mvar h
50180	450181	32	signed	2526	Syst.A.neg.react.energy	0.01	Mvar h
50182	450183	32	signed	2568	0 (reserve)	0.01	h

Table 0-1: Data Protocol 5200



# Appendix D

## Parameter Overview

### Introduction



### Parameter List Columns

The parameter list consists of the following columns, which provide important information for each parameter:

#### NamespaceX

The namespaces 1 and 2 are used to combine all parameters within functional groups.

#### ID

The parameter ID is a unique identifier for each individual parameter. It is mentioned besides each parameter in ToolKit and also required when configuring the unit via interface.

#### Parameter Text

The parameter text describes the parameter and appears on the configuration screens of the unit and ToolKit.

#### Setting Range

The setting range describes the range for possible parameter settings and may either be a range (e.g. 0 to 9), or a selection of different options (e.g. Yes or No). If the respective parameter allows configuring different options, the number behind each option is the number, which needs to be transmitted via interface to select this option.

#### Default Value

The default value is the parameter setting at delivery of the unit or after resetting the unit to factory settings. If the parameter allows configuring different options, the default value describes the number of the respective option.

#### Data Type

The data type indicates the data type of the respective parameter. The following data types are possible:

- UNSIGNED8      unsigned 8 bit integer
- UNSIGNED16    unsigned 16 bit integer
- UNSIGNED32    unsigned 32 bit integer
- SIGNED32        signed 32 bit integer
- INTEGER16      16 bit integer

#### Code Level (CL)

This is the minimum code level, which is required to access the respective parameter.



# Parameter List



(Sequence following ID number)

ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
521	-	Lamp test	No ; 0 Yes ; 1		UNSIGNED 16	0
1701	MENU 5.2	Reset factory default values	No ; 0 Yes ; 1	0	UNSIGNED 16	0
1750	MENU 5	System rated frequency	50Hz ; 0 60Hz ; 1	1	UNSIGNED 16	2
1770	MENU 4	System A voltage monitoring	Phase - phase ; 0 Phase - neutral ; 1	0	UNSIGNED 16	2
1850	MENU 5	System A current input	L1 L2 L3 ; 0 Phase L1 ; 1 Phase L2 ; 2 Phase L3 ; 3	0	UNSIGNED 16	2
1851	MENU 5	System A voltage measuring	3Ph 4W ; 0 3Ph 3W ; 1 1Ph 2W ; 2 n/a1 ; 3 3Ph 4W OD ; 4	1	UNSIGNED 16	2
1853	MENU 5	Aux system B voltage meas.	3Ph 4W ; 0 3Ph 3W ; 1	1	UNSIGNED 16	2
1858	MENU 5	1Ph2W voltage input	Phase - neutral ; 0 Phase - phase ; 1	1	UNSIGNED 16	2
1859	MENU 5	1Ph2W phase rotation	CW ; 0 CCW ; 1	0	UNSIGNED 16	2
2510	MENU 5.3	Syst. A active energy [0.00MWh]	No ; 0 Yes ; 1	0	UNSIGNED 16	2
2511	MENU 5.3	Syst. A react. energy [0.00Mvarh]	No ; 0 Yes ; 1	0	UNSIGNED 16	2
2512	MENU 5.3	Syst. A active energy -[0.00MWh]	No ; 0 Yes ; 1	0	UNSIGNED 16	2
2513	MENU 5.3	Syst. A react. energy -[0.00Mvarh]	No ; 0 Yes ; 1	0	UNSIGNED 16	2
3170	MENU 5.1	Baudrate	2400 Bd ; 0 4800 Bd ; 1 9600 Bd ; 2 19.2 kBd ; 3 38.4 kBd ; 4 56 kBd ; 5 115 kBd ; 6	2	UNSIGNED 16	2
3171	MENU 5.1	Parity	No ; 0 Even ; 1 Odd ; 2	0	UNSIGNED 16	2
3172	MENU 5.1	Stop bits	One ; 0 Two ; 1	0	UNSIGNED 16	2



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
3173	MENU 5.1	Full-, halfduplex mode	Halfduplex ; 0 Full duplex ; 1	1	UNSIGNED 16	2
5730	MENU 1	Synchronization CB	Slip frequency ; 0 Phase matching ; 1	0	UNSIGNED 16	2
7500	MENU 3	Process high limit alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7501	MENU 3	Process low limit alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7502	MENU 3	Process switches	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7504	MENU 2	High load limit alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7505	MENU 2	Low load limit alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7506	MENU 2	Load limit switch	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7509	MENU 4	Voltage low alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7510	MENU 4	Voltage high alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7511	MENU 4	Voltage switches	Disabled ; 0 Enabled ; 1	1	UNSIGNED 16	2
7512	MENU 4	Voltage range alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7513	MENU 1	Voltage matching	Disabled ; 0 Enabled ; 1	1	UNSIGNED 16	2
7514	MENU 1	Auto re-synchronization	Disabled ; 0 Enabled ; 1	1	UNSIGNED 16	2
7555	MENU 1	Dead bus closure	Disabled ; 0 Enabled ; 1	1	UNSIGNED 16	2
7556	MENU 1	Reclose limit alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7557	MENU 1	Synchronizer timeout alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7558	MENU 4	VAR PF control mode	PF Control ; 0 VAR Control ; 1 Constant Generator PF ; 2	1	UNSIGNED 16	2
7559	MENU 3	Process control action	Direct ; 0 Indirect ; 1	1	UNSIGNED 16	2
7584	MENU 0	Synchronizer timeout alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7585	MENU 0	Reclose limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
7586	MENU 0	High load limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7587	MENU 0	Low load limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7588	MENU 0	High process limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7589	MENU 0	Low process limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7590	MENU 0	Low voltage limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7591	MENU 0	High voltage limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7592	MENU 0	Voltage range limit alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7593	MENU 0	Communication error alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7595	MENU 0	Missing member alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7596	MENU 0	Centralized alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7597	MENU 0	CB open fail	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7598	MENU 0	Deadbus closure mismatch	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7616	MENU 2	Gen load high limit alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7617	MENU 2	Gen load low limit alarm	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
7618	MENU 2	Gen load limit switch	Disabled ; 0 Enabled ; 1	0	UNSIGNED 16	2
7625	MENU 5	Switch dead bus A -> dead bus B	No ; 0 Yes ; 1	1	UNSIGNED 16	2
7626	MENU 5	Switch alive bus A -> dead bus B	No ; 0 Yes ; 1	1	UNSIGNED 16	2
7627	MENU 5	Switch alive bus B -> dead bus A	No ; 0 Yes ; 1	1	UNSIGNED 16	2
7628	MENU 5	Type of MSLC breaker	Tie ; 0 Utility ; 1	1	UNSIGNED 16	2
7634	MENU 2	Load control setpoint source	Internal ; 0 Interface ; 1	0	UNSIGNED 16	2
7635	MENU 4	VAR control setpoint source	Internal ; 0 Interface ; 1	0	UNSIGNED 16	2
7649	MENU 5	Auxiliary system B available	No ; 0 Yes ; 1	0	UNSIGNED 16	2
7673	MENU 6	HW signal	0 - 20mA ; 0 4 - 20mA ; 1 0 - 10V ; 2 0 - 5V ; 3 1 - 5V ; 4	3	UNSIGNED 16	2
7674	MENU 6	HW signal	0 - 20mA ; 0 4 - 20mA ; 1 0 - 10V ; 2 0 - 5V ; 3 1 - 5V ; 4	4	UNSIGNED 16	2
7675	MENU 6	HW signal	0 - 20mA ; 0 4 - 20mA ; 1 0 - 10V ; 2 0 - 5V ; 3 1 - 5V ; 4	3	UNSIGNED 16	2
7732	MENU 6	Process engineering unit	kW ; 0 °C ; 1 kPa ; 2 bar ; 3 V ; 4 mA ; 5	0	UNSIGNED 16	2
7755	MENU 2	Interface switch Import Export	Export ; 0 Import ; 1	0	UNSIGNED 16	2
7771	MENU 0	System B mismatch alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7779	MENU 0	Phase rotation mismatch alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7783	MENU 1	Freq. control setpoint source	Internal ; 0 Interface ; 1	0	UNSIGNED 16	2



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
7784	MENU 4	Volt. control setpoint source	Internal ; 0 Interface ; 1	0	UNSIGNED 16	2
7786	MENU 5	Basic segment number source	Internal ; 0 Interface ; 1	0	UNSIGNED 16	2
7789	MENU 5	System update	Off ; 0 On ; 1	0	UNSIGNED 16	2
7809	MENU 5	Ethernet communication mode	Single ; 0 Redundant ; 1	0	UNSIGNED 16	2
7824	MENU 0	Communication error NW B alarm	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7825	MENU 0	Network A system error	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7826	MENU 0	Network B system error	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
7827	MENU 0	Devices not matched	Off ; 0 Alarm1 ; 1 Alarm2 ; 2 Alarm3 ; 3	0	UNSIGNED 16	2
8841	MENU 1	Phase angle compensation MCB	Off ; 0 On ; 1	0	UNSIGNED 16	2
10417	MENU 5.2	Factory default settings	No ; 0 Yes ; 1	0	UNSIGNED 16	0
1702	MENU 5	Device number	033 to 048	33	UNSIGNED 16	2
1752	MENU 2	System A rated load	000000.1 to 999999.9 kW	000250.0 kW	UNSIGNED 32	2
1754	MENU	System A rated current	00001 to 32000 A	00500 A	UNSIGNED 16	2
1758	MENU 4	System A rated react. power	000000.1 to 999999.9 kvar	000190.0 kvar	UNSIGNED 32	2
1766	MENU 5	System A rated voltage	000050 to 650000 V	000480 V	UNSIGNED 32	2
1781	MENU 5	System B rated voltage	000050 to 650000 V	000480 V	UNSIGNED 32	2
1800	MENU 5	System A PT secondary rated voltage	050 to 480 V	120 V	UNSIGNED 16	2
1801	MENU 5	System A PT primary rated voltage	000050 to 650000 V	000480 V	UNSIGNED 32	2
1803	MENU 5	System B PT secondary rated voltage	050 to 480 V	120 V	UNSIGNED 16	2
1804	MENU 5	System B PT primary rated voltage	000050 to 650000 V	000480 V	UNSIGNED 32	2



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
1806	MENU 5	System A CT primary rated current	00001 to 32000 A/x	00500 A/x	UNSIGNED 16	2
2515	MENU 5.3	Counter value preset	00000000 to 99999999	0	UNSIGNED 32	2
3063	MENU 1	Synchronizer timeout	003 to 999 s	060 s	UNSIGNED 16	2
3123	MENU 2	Utility unload trip time	003 to 999 s	060 s	UNSIGNED 16	2
3125	MENU 2	Generator unload trip	00.5 to 99.9 %	03.0 %	UNSIGNED 16	2
3181	MENU 5.1	Power [W] exponent 10^x	02 to 05	3	INTEGER 16	2
3182	MENU 5.1	Voltage [V] exponent 10^x	-01 to 02	0	INTEGER 16	2
3183	MENU 5.1	Current [A] exponent 10^x	-01 to 00	0	INTEGER 16	2
3185	MENU 5.1	Modbus slave ID	000 to 255	33	UNSIGNED 16	2
3186	MENU 5.1	Reply delay time	0.00 to 1.00 s	0.00 s	UNSIGNED 16	2
3188	MENU 5.1	Modbus slave ID	000 to 255	33	UNSIGNED 16	2
3189	MENU 5.1	Reply delay time	0.00 to 2.55 s	0.00 s	UNSIGNED 16	2
3417	MENU 1	CB close hold time	0.10 to 1.00 s	0.50 s	UNSIGNED 16	2
3419	MENU 1	CB maximum closing attempts	01 to 10	5	UNSIGNED 16	2
3421	MENU 1	CB open monitoring	0.10 to 5.00 s	2.00 s	UNSIGNED 16	2
4311	MENU 6	User defined min display value	-100.0 to 100.0 %	000.0 %	INTEGER 16	2
4312	MENU 6	User defined max display value	-100.0 to 100.0 %	100.0 %	INTEGER 16	2
4322	MENU 6	User defined min display value	-100.0 to 100.0 %	000.0 %	INTEGER 16	2
4323	MENU 6	User defined max display value	000.0 to 100.0 %	100.0 %	INTEGER 16	2
4333	MENU 6	User defined min display value	-00.999 to 00.999 PF	-00.990 PF	INTEGER 16	2
4334	MENU 6	User defined max display value	-00.999 to 00.999 PF	00.710 PF	INTEGER 16	2
4500	MENU 3	Process control proportional gain	000.01 to 100.00	003.00	INTEGER 16	2
4501	MENU 3	Process control integral gain	000.01 to 100.00 s	003.00 s	INTEGER 16	2
4502	MENU 3	Process control derivative ratio	000.01 to 100.00 s	000.01 s	INTEGER 16	2
4504	MENU 3	Raise reference rate	00.01 to 20.00 %/s	00.10 %/s	INTEGER 16	2
4505	MENU 3	Lower reference rate	00.01 to 20.00 %/s	00.10 %/s	INTEGER 16	2
4506	MENU 2	Utility unload trip	00000 to 30000 kW	00005 kW	INTEGER 16	2



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
4508	MENU 3	Process droop	000.0 to 100.0 %	000.0 %	INTEGER 16	2
4509	MENU 3	Process filter	0 to 8	0	INTEGER 16	2
4510	MENU 3	Process high limit PU	000.0 to 150.0 %	075.0 %	INTEGER 16	2
4511	MENU 3	Process high limit DO	000.0 to 150.0 %	075.0 %	INTEGER 16	2
4513	MENU 3	Process low limit PU	000.0 to 150.0 %	050.0 %	INTEGER 16	2
4514	MENU 3	Process low limit DO	000.0 to 150.0 %	050.0 %	INTEGER 16	2
4515	MENU 2	Raise load rate	000.01 to 100.00 %/s	001.00 %/s	INTEGER 16	2
4516	MENU 2	Lower load rate	000.01 to 100.00 %/s	001.00 %/s	INTEGER 16	2
4523	MENU 2	Import /export droop	000.0 to 100.0 %	000.0 %	INTEGER 16	2
4524	MENU 3	Unload ramp rate	000.01 to 100.00 %/s	003.00 %/s	INTEGER 16	2
4526	MENU 2	High load limit DO	-150 to 150 %	90%	INTEGER 16	2
4528	MENU 2	Low load limit DO	002 to 100 %	5%	INTEGER 16	2
4529	MENU 2	Gen load switch 1 PU	000 to 100 %	0%	INTEGER 16	2
4530	MENU 2	Gen load switch 1 DO	000 to 100 %	10%	INTEGER 16	2
4534	MENU 1	Reclose delay	0001 to 1000 s	0002 s	INTEGER 16	2
4536	MENU 4	Voltage low limit	000 to 150 %	90%	INTEGER 16	2
4537	MENU 4	Voltage high limit	000 to 150 %	110%	INTEGER 16	2
4538	MENU 2	Gen load switch 2 PU	000 to 100 %	100%	INTEGER 16	2
4539	MENU 1	Frequency synchronizer proportional gain	000.01 to 100.00	000.80	INTEGER 16	2
4540	MENU 1	Frequency synchronizer integral gain	000.00 to 020.00	000.50	INTEGER 16	2
4541	MENU 1	Voltage window	00.50 to 10.00 %	00.50 %	INTEGER 16	2
4543	MENU 2	Gen load switch 2 DO	000 to 100 %	90%	INTEGER 16	2
4544	MENU 5	Basic segment number	00001 to 00008	1	INTEGER 16	2
4700	MENU 2	Load ramp rate	000.01 to 100.00 %/s	003.00 %/s	INTEGER 16	2
4709	MENU 2	High load limit PU	-150 to 150 %	100%	INTEGER 16	2
4710	MENU 2	Low load limit PU	000 to 100 %	0%	INTEGER 16	2
4712	MENU 1	Slip frequency setpoint offset	-00.50 to 00.50 Hz	00.10 Hz	INTEGER 16	2
4713	MENU 1	DI raise frequency ramp	000.01 to 001.00 %rated/s	000.04 %rated/s	INTEGER 16	2
4714	MENU 1	DI lower frequency ramp	000.01 to 001.00 %rated/s	000.04 %rated/s	INTEGER 16	2



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
4715	MENU 4	DI raise voltage ramp	000.01 to 001.00 %rated/s	000.05 %rated/s	INTEGER 16	2
4716	MENU 4	DI lower voltage ramp	000.01 to 001.00 %rated/s	000.05 %rated/s	INTEGER 16	2
4717	MENU 1	Phase window ring structure	000.0 to 060.0 °	010.0 °	INTEGER 16	2
4718	MENU 1	Voltage window ring structure	00.50 to 20.00 %	10.00 %	INTEGER 16	2
5430	MENU 5.1	TCP/IP address 0	000 to 255		UNSIGNED 16	2
5431	MENU 5.1	TCP/IP address 1	000 to 255		UNSIGNED 16	2
5432	MENU 5.1	TCP/IP address 2	000 to 255		UNSIGNED 16	2
5433	MENU 5.1	TCP/IP address 3	000 to 255		UNSIGNED 16	2
5503	MENU 1	Frequency control setpoint ramp	00.10 to 60.00 Hz/s	02.50 Hz/s	UNSIGNED 16	2
5505	MENU 1	Phase matching gain	01 to 99	5	UNSIGNED 16	2
5506	MENU 1	Phase matching df-start	0.02 to 0.25 Hz	0.05 Hz	UNSIGNED 16	2
5510	MENU 2	Import/export control proportional gain	000.01 to 100.00	001.00	UNSIGNED 16	2
5511	MENU 2	Import/export control integral gain	000.01 to 100.00	000.50	UNSIGNED 16	2
5512	MENU 2	Import/export control derivative ratio	000.01 to 100.00	000.01	UNSIGNED 16	2
5516	MENU 1	Start frequency control level	00.00 to 70.00 Hz	55.00 Hz	UNSIGNED 16	1
5517	MENU 1	Start frequency control delay	000 to 999 s	001 s	UNSIGNED 16	1
5600	MENU 4	Voltage control setpoint	000050 to 650000 V	000480 V	UNSIGNED 32	1
5603	MENU 4	Voltage control setpoint ramp	001.00 to 300.00 %/s	005.00 %/s	UNSIGNED 16	2
5610	MENU 1	Voltage synchronizer proportional gain	000.01 to 100.00	001.00	UNSIGNED 16	2
5611	MENU 1	Voltage synchronizer integral gain	000.01 to 100.00	000.50	UNSIGNED 16	2
5613	MENU 4	VAR control proportional gain	000.01 to 100.00	001.00	UNSIGNED 16	2
5614	MENU 4	VAR control integral gain	000.01 to 100.00	000.50	UNSIGNED 16	2
5615	MENU 4	VAR control derivative ratio	000.01 to 100.00	000.01	UNSIGNED 16	2
5620	MENU 4	Power factor reference	-00.999 to 01.000	1,000	INTEGER 16	0



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
5621	MENU 4	Constant gen. PF reference	-00.999 to 01.000	00.950	INTEGER 16	0
5622	MENU 4	Reactive power setpoint ramp	000.01 to 100.00 %/s	010.00 %/s	UNSIGNED 16	2
5701	MENU 1	Positive frequency differential CB	00.02 to 00.49 Hz	00.18 Hz	INTEGER 16	2
5702	MENU 1	Negative frequency differential CB	-00.49 to 00.00 Hz	-00.10 Hz	INTEGER 16	2
5703	MENU 1	Max. positive phase window CB	000.0 to 060.0 °	005.0 °	INTEGER 16	2
5704	MENU 1	Max. negative phase window CB	-060.0 to 000.0 °	-005.0 °	INTEGER 16	2
5705	MENU 1	Breaker delay	0040 to 1000 ms	0080 ms	UNSIGNED 16	2
5707	MENU 1	Phase matching CB dwell time	00.0 to 60.0 s	00.5 s	UNSIGNED 16	2
5800	MENU 5	Upper voltage limit	100 to 150 %	110%	UNSIGNED 16	2
5801	MENU 5	Lower voltage limit	050 to 100 %	90%	UNSIGNED 16	2
5802	MENU 5	Upper frequency limit	100.0 to 150.0 %	110.0 %	UNSIGNED 16	2
5803	MENU 5	Lower frequency limit	050.0 to 100.0 %	090.0 %	UNSIGNED 16	2
5820	MENU 1	Dead bus detection max. volt.	000 to 030 %	10%	UNSIGNED 16	2
7717	MENU 2	Import / export level	-999999.9 to 999999.9 kW	000020.0 kW	SIGNED 32	0
7723	MENU 4	KVAR reference	-999999.9 to 999999.9 kvar	000010.0 kvar	SIGNED 32	0
7733	MENU 6	Process min value	-999999.9 to 999999.9	-000500.0	SIGNED 32	2
7734	MENU 6	Process max value	-999999.9 to 999999.9	000500.0	SIGNED 32	2
7735	MENU 6	Remote load ref min value	-999999.9 to 999999.9 kW	000000.0 kW	SIGNED 32	2
7736	MENU 6	Remote load ref max value	-999999.9 to 999999.9 kW	000500.0 kW	SIGNED 32	2
7737	MENU 3	Process reference	-999999.9 to 999999.9	000000.0	SIGNED 32	0
8842	MENU 1	Phase angle MCB	-0180 to 0180 °	0000 °	INTEGER 16	2
10411	MENU 5.2	Supercommissioning level code	0001 to 9999		UNSIGNED 16	5
10412	MENU 5.2	Temp. supercomm. level code	0001 to 9999		UNSIGNED 16	5
10413	MENU 5.2	Commissioning code level	0001 to 9999		UNSIGNED 16	3
10414	MENU 5.2	Temp. commissioning code level	0001 to 9999		UNSIGNED 16	3



ID	Menu	Parameter Text	Setting range	Default value	Data Type	CL
10415	MENU 5.2	Basic code level	0001 to 9999		UNSIGNED 16	1
10430	-	Password for serial interface2 (RS 485)	0000 to 9999	1805	UNSIGNED 16	0
10434	-	Password 1 for Modbus TCP	0000 to 9999	1805	UNSIGNED 16	0
10435	-	Password 2 for Modbus TCP	0000 to 9999	1805	UNSIGNED 16	0
<b>Note:</b>		10434 and 10435 can be used equally. They exist in order that the DSLC-2XT is backward compatible with the DSLC-2.				

Table 0-1: Parameter list



# Appendix E

## Service Options

### Product Service Options



The following factory options are available for servicing Woodward equipment, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is purchased from Woodward or the service is performed. If you are experiencing problems with installation or unsatisfactory performance of an installed system, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact Woodward technical assistance (see "How to Contact Woodward" later in this chapter) and discuss your problem. In most cases, your problem can be resolved over the phone. If not, you can select which course of action you wish to pursue based on the available services listed in this section.

### Returning Equipment for Repair



If a control (or any part of an electronic control) is to be returned to Woodward for repair, please contact Woodward in advance to obtain a Return Authorization Number. When shipping the unit(s), attach a tag with the following information:

- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part numbers (P/N) and serial number (S/N);
- description of the problem;
- instructions describing the desired type of repair.



#### CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards and Modules*.



## Packing a Control

Use the following materials when returning a complete control:

- protective caps on any connectors;
- antistatic protective bags on all electronic modules;
- packing materials that will not damage the surface of the unit;
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material;
- a packing carton with double walls;
- a strong tape around the outside of the carton for increased strength.

## Return Authorization Number RAN

Please call by phone our Customer Service Department in Stuttgart [+49 (0) 711 789 54-510]. They will help expedite the processing of your order through our distributors or local service facility. To expedite the repair process, contact Woodward in advance to obtain a Return Authorization Number and arrange for issue of a purchase order for the unit(s) to be repaired. No work can be started until a purchase order is received.



### NOTE

We highly recommend that you make arrangement in advance for return shipments. Contact a Woodward customer service representative at +49 (0) 711 789 54-0 for instructions and for a Return Authorization Number.

## Replacement Parts



When ordering replacement parts for controls, include the following information:

- the part numbers P/N (XXXX-XXX) that is on the enclosure nameplate;
- the unit serial number S/N, which is also on the nameplate.



## How to Contact Woodward



Please contact following address if you have questions or if you want to send a product for repair:

Woodward GmbH  
Handwerkstrasse 29  
70565 Stuttgart - Germany

Phone: +49 (0) 711 789 54-510 (8.00 - 16.30 German time)  
Fax: +49 (0) 711 789 54-101  
e-mail: stgt-info@woodward.com

For assistance outside Germany please contact the Woodward Customer Service Department or consult our worldwide directory on Woodward's website ([www.woodward.com](http://www.woodward.com)) for the name of your nearest Woodward distributor or service facility.

## Engineering Services



Woodward Industrial Controls Engineering Services offers the following after-sales support for Woodward products. For these services, you can contact us by telephone, by e-mail, or through the Woodward website.

- Technical support
- Product training
- Field service during commissioning

**Technical Support** is available through our many worldwide locations or through our authorized distributors depending on the product. This service can assist you with technical questions or problem solving during normal business hours. Emergency assistance is also available during non-business hours by phoning our toll-free number and stating the urgency of your problem. For technical engineering support, please contact us via our local phone numbers, e-mail us, or use our website and reference **technical support**.

**Product Training** is available on-site from several of our worldwide facilities. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability. For information concerning training, please contact us via our local phone numbers, e-mail us, or use our website and reference **customer training**.

**Field Service** engineering on-site support is available, depending on the product and location, from our facility in Colorado, or from one of many worldwide Woodward offices or authorized distributors. Field engineers are experienced on both Woodward products as well as on much of the non-Woodward equipment with which our products interface. For field service engineering assistance, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference **field service**.



## Technical Assistance



If you need to telephone for technical assistance, you will need to provide the following information.  
Please write it down here before phoning:

### Contact

Your company \_\_\_\_\_

Your name \_\_\_\_\_

Phone number \_\_\_\_\_

Fax number \_\_\_\_\_

### Control (see name plate)

Unit no. and revision: P/N: \_\_\_\_\_ REV: \_\_\_\_\_

Unit type \_\_\_\_\_

Serial number S/N \_\_\_\_\_

### Description of your problem

---

---

---

---

---

---

---

Please be sure you have a list of all parameters available. You can print this using ToolKit. Additionally you can save the complete set of parameters (standard values) and send them to our Service department via e-mail.



We appreciate your comments about the content of our publications.  
Please send comments to: [marketing\\_pg@woodward.com](mailto:marketing_pg@woodward.com)  
Please include the manual number from the front cover of this publication.



**Woodward GmbH**  
Handwerkstrasse 29 - 70565 Stuttgart - Germany  
Phone +49 (0) 711 789 54-510 • Fax +49 (0) 711 789 54-101  
[marketing\\_pg@woodward.com](mailto:marketing_pg@woodward.com)

**Homepage**

<http://www.woodward.com>

Woodward has company-owned plants, subsidiaries and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address/phone/fax/e-mail information  
for all locations is available on our website ([www.woodward.com](http://www.woodward.com)).

2024/02/Stuttgart