

Wiring Instructions for 2301A Controls
Replacing Caterpillar 2301 Controls



General Precautions

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26311**, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, on the *publications* page of the Woodward website:

www.woodward.com/publications

The latest version of most publications is available on the *publications* page. If your publication is not there, please contact your customer service representative to get the latest copy.



Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



Translated Publications

If the cover of this publication states "Translation of the Original Instructions" please note:

The original source of this publication may have been updated since this translation was made. Be sure to check manual **26311**, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Revisions—Changes in this publication since the last revision are indicated by a black line alongside the text.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Copyright © Woodward 2001
All Rights Reserved

Warnings and Notices

Important Definitions



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER**—Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- **WARNING**—Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- **CAUTION**—Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
- **NOTICE**—Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT**—Designates an operating tip or maintenance suggestion.

WARNING

**Overspeed /
Overtemperature /
Overpressure**

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.

WARNING

**Personal Protective
Equipment**

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.

WARNING

Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

WARNING

**Automotive
Applications**

On- and off-highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

NOTICE**Battery Charging
Device**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electrostatic Discharge Awareness

NOTICE**Electrostatic
Precautions**

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Follow these precautions when working with or near the control.

1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

Wiring Instructions for 2301A Controls

Replacing Caterpillar 2301 Controls

Introduction

The following 2301 speed control is no longer in production, and has been replaced by an updated 2301A speed control (both fixed speed and variable speed versions):


Old 2301		Recommended Replacement 2301A	
Woodward part number	Caterpillar part number	Woodward part number	Caterpillar part number
8272-689	4W-5790	9907-014	131-5453

Refer to Woodward manual 82020 for details on control installation, operation, adjustment, and troubleshooting.


Fixed Speed Version

Woodward 2301 speed control 8272-689 (Caterpillar part number 4W-5790) is no longer in current production. The improved standard 2301A speed control 9907-014 (Caterpillar part number 131-5453) is recommended for replacement. Due to internal control design differences, the customer wiring to the control terminals is different. This application sheet illustrates the differences in wiring. Refer to Woodward manual 82020 for control installation, operation, adjustment, and troubleshooting.

Old Standard Wiring Speed Control 8272-689 (Cat # 4W-5790)
(Fixed Speed)



New Standard Wiring Speed Control 9907-014 (Cat # 131-5453)
(Fixed Speed)




Wiring differences between 8272-689 (4W-5790) and 9907-014 (131-5453) used for standard wiring (fixed speed) speed control:


- Actuator connections have moved from terminals 5(–) & 6(+) to terminals 9(+) & 10(–).
- Optional external Accel Rate Capacitor removed—This function is internal and adjusted using the Ramp Time potentiometer on the 9907-014 control.
- Terminals 15 and 16 on 9907-014 control can be used for optional SPM Synchronizer input.
- Terminals 15(+) and 17(–) on the 9907-014 control can be used for optional Auxiliary input.
- Optional external Droop potentiometer slider is moved from terminal 14 to 13, and the clockwise lead is moved from terminal 13 to 14.
- Close for Rated speed and Open for Idle speed contact is moved from terminals 9 & 10 to terminals 2 and 5.

Variable Speed Version

Old Customer Remote Idle and Rated Speed Control 8272-689 (Cat # 4W-5790) (Variable Speed)



New Customer Remote Rated Speed Control 9907-014 (Cat # 131-5453) (Variable Speed)



Wiring differences between 8272-689 (4W-5790) and 9907-014 (131-5453) used for Customer Remote Idle and Rated Speed Adjustment:

- Actuator connections have moved from terminals 5(-) & 6(+) to terminals 9(+) & 10(-).
- Optional external Accel. Rate Capacitor removed—This function is internal and adjusted using the Ramp Time potentiometer on the 9907-014 control.
- Terminals 15 and 16 on 9907-014 control can be used for optional SPM Synchronizer input.
- Terminals 15(+) and 17(-) on the 9907-014 control can be used for optional Auxiliary input.

- Optional external Droop potentiometer slider is moved from terminal 14 to 13, and the clockwise lead is moved from terminal 13 to 14.
- If the application used the remote mounted Idle and Rated Potentiometers, the single pole double throw Switch connected to terminals 9, 10 or 11, and 12 should be wired between terminals 2 and 5 on the control (Close for Rated and Open for Idle).
- The Remote Potentiometer Assembly should be replaced by a single 10-turn 1K potentiometer as illustrated.
- Terminal 11 on the control is wired to the CCW lead of the Remote Rated Speed potentiometer.
- Terminal 12 on the control is wired to the CW lead of the Remote Rated Speed potentiometer.

Refer to Woodward manual 82020 for installation, checkout, and setting instructions.

The following procedure is for setting up the Remote Rated Speed Setting potentiometer:

- Install jumper between control terminals 11 and 12.
- Install single-pole double-throw switch between control terminals 2 and 5.
- Adjust Rated Speed potentiometer on the control to produce 1980 rpm.
- Open switch between terminals 2 and 5 on the control.
- Adjust Low Idle Speed potentiometer on the control to 700–1000 rpm range.
- Shut engine down, then remove jumper from terminals 11 and 12.
- Prior to attaching the Remote Rated potentiometer assembly to terminals 11 and 12, rotate the potentiometer to minimum resistance. Attach an ohmmeter to the potentiometer leads to assure less than 5 Ω reading.
- Attach leads from the Remote Rated potentiometer assembly to terminals 11 and 12 on the control as illustrated.
- Put switch in Rated position and verify engine goes to 1980 rpm.
- Adjust Remote Rated potentiometer for 1960 rpm.
- Put switch in Idle position, and verify that engine speed is within the 700–1000 rpm range.

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication 51191.



PO Box 1519, Fort Collins CO 80522-1519, USA
1000 East Drake Road, Fort Collins CO 80525, USA
Phone +1 (970) 482-5811 • Fax +1 (970) 498-3058

Email and Website—www.woodward.com

**Woodward has company-owned plants, subsidiaries, and branches,
as well as authorized distributors and other authorized service and sales facilities throughout the world.**

Complete address / phone / fax / email information for all locations is available on our website.