

EGCP-2 Differences



General Precautions

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26311**, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, on the *publications* page of the Woodward website:

www.woodward.com/publications

The latest version of most publications is available on the *publications* page. If your publication is not there, please contact your customer service representative to get the latest copy.




Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



Translated Publications

If the cover of this publication states "Translation of the Original Instructions" please note:

The original source of this publication may have been updated since this translation was made. Be sure to check manual **26311**, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Revisions—Changes in this publication since the last revision are indicated by a black line alongside the text.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Copyright © Woodward 2002
All Rights Reserved

Warnings and Notices

Important Definitions



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER**—Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- **WARNING**—Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- **CAUTION**—Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
- **NOTICE**—Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT**—Designates an operating tip or maintenance suggestion.

WARNING

**Overspeed /
Overtemperature /
Overpressure**

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.

WARNING

**Personal Protective
Equipment**

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.

WARNING

Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

WARNING

**Automotive
Applications**

On- and off-highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

NOTICE**Battery Charging
Device**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electrostatic Discharge Awareness

NOTICE**Electrostatic
Precautions**

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Follow these precautions when working with or near the control.

1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

EGCP-2 Differences

Description of Changes

Old EGCP-2 Part Numbers	Description	Installation Manual	Set Builder Manual	Servlink & HMI Manual	Security Levels Manual
8406-115	150–300 Vac PT	26076	26086	26099	26108
8406-116	50–150 Vac PT	26076	26086	26099	26108

New EGCP-2 Part Numbers	Description	Installation & Operation Manual	Application Manual	Communications Manual	Security Levels Manual
8406-120	150–300 Vac PT	26174	26175	26181	26108
8406-121	50–150 Vac PT	26174	26175	26181	26108

Hardware Changes

The only change to the hardware package is an improvement to the back cover, which now has a notched-out area around the CT input (terminals 89 through 94) to make it easier to install the CT wires. Existing stock will be used before the new back cover is introduced.

Additional Software Features

1. Voltage Trim

- The EGCP-2 will now control the generator voltage to the Voltage Reference setpoint when:
 - Single unit, isolated
 - Multiple unit, only unit running, isolated

2. Pre-Alarms for

- Low Oil Pressure
- High Water Temperature

3. Sanity Checks

- Performs Sanity Check on Power Cycle.
- Added Alarm Display when Sanity Check fails.

4. Manual Operation

- The Run with Load input will activate the Generator Breaker Trip Relay once the generator is stable. This action allows the breaker to be closed manually. When in Manual mode, full engine and generator protection will now be provided.

5. Remote Faults 1 and 2 Enable Delay

- Added configuration to Enable or Disable the delay for these inputs.

6. Process Configuration

- You can now configure the Process Reference to be shown with units of mA, V, kW, MW, kVA, MVA, kVR, MVR, PF, °C, °F, PSI, kPA, and BAR. Once configured, it will be possible to set a reference using the same units being displayed.

7. Auto Sequencing Delay

- This additional delay allows all units time to synchronize to the Bus before the Master unit starts to sequence units off. This delay time begins when the Master unit closes its generator breaker and is in addition to the minimum generator load delay.

8. Modbus additions and changes

- a. Added Boolean Write (BW) address
 - 00024 - Auto Sequencing Enable/Disable
 - 00037 Cool-Down Override
- b. Added Boolean Reads (BR) addresses
 - 10063 – Load Surge Status
 - 10064 – Mains Under Volt Alarm Status
 - 10065 – Mains Over Volt Alarm Status
 - 10066 – Mains Over Freq Alarm Status
 - 10067 – Mains Under Freq Alarm Status
 - 10068 – Not Used
 - 10069 – Generator Output Stable
 - 10070 – Generator Sense Configuration
 - 10073 – High H2O Temp Pre-Alarm Status
 - 10075 – Low Oil Press Pre-Alarm Status
- c. Incremented Analog Read (AR) addresses 30054 to 30071 by one
 - 30054 – Not Used in new controls
 - 30055 is now what 30054 used to be, and so on to 30071
- d. Added Analog Reads (BR) addresses
 - 30215 – Actual Baseload Reference
 - 30216 – Actual Process Reference
 - 30229 – Actual PF Reference
 - 30230 – Actual VAR Reference
 - 30250 - Network Address Setpoint
 - 30253 – AC Frequency Setpoint Value
 - 30254 – Rated RPM Setpoint Value
 - 30255 – Rated KW Setpoint Value
 - 30256 – Rated KVA Setpoint Value
 - 30257 – Rated KVAR Setpoint Value
 - 30267 – Operating Mode Setpoint Value
 - 30268 – Number of Units Setpoint Value
 - 30269 – Preglow Time Setpoint Value
 - 30270 – Crank Time Setpoint Value
 - 30271 – Crank Cutout Setpoint Value
 - 30272 – Crank Delay Setpoint Value
 - 30273 – Crank Repeats Setpoint Value
 - 30276 – Idle Time Setpoint Value
 - 30277 – Cooldown Time Setpoint Value
 - 30280 – Sync Mode Setpoint Value
 - 30291 – Sync Timeout Setpoint Value
 - 30294 – Load Control Mode Setpoint Value
 - 30300 – Base Load Reference Setpoint Value
 - 30303 – Load Time Setpoint Value
 - 30304 – Unload Time Setpoint Value
 - 30305 – Raise Load Rate Setpoint Value
 - 30306 – Lower Load Rate Setpoint Value
 - 30311 – KVA Switch Low Setpoint Value
 - 30312 – KVA Switch High Setpoint Value
 - 30315 – Voltage Ramp Time Setpoint Value
 - 30318 – KVAR Reference Setpoint Value
 - 30319 – Power Factor Reference Setpoint Value
 - 30321 – Process Action Setpoint Value
 - 30328 – Process Reference Setpoint Value
 - 30329 – Process Raise Rate Setpoint Value

- 30330 – Process Lower Rate Setpoint Value
- 30334 – Fast Transfer Delay Setpoint Value
- 30335 – Mains Stable Delay Setpoint Value
- 30336 – Gen Stable Delay Setpoint Value
- 30342 – Loss of Mains Action Delay Setpoint Value
- 30344 – Max Gen Load Setpoint Value
- 30345 – Next Genset Delay Setpoint Value
- 30346 – Rated Load Delay Setpoint Value
- 30347 – Max Start Time Setpoint Value
- 30348 – Min Gen Load Setpoint Value
- 30349 – Reduced Load Delay Setpoint Value
- 30350 – Max Stop Time Setpoint Value
- e. Added Analog Write (AW) addresses
 - 40002 – Remote Process Control Reference
 - 40003 – Remote Baseload Reference
 - 40005 – Remote PF Reference
 - 40007 – Remote VAR Reference
 - 40250 - Network Address Setpoint Command
 - 40253 – AC Frequency Setpoint Command
 - 40254 – Rated RPM Setpoint Command
 - 40255 – Rated KW Setpoint Command
 - 40256 – Rated KVA Setpoint Command
 - 40257 – Rated KVAR Setpoint Command
 - 40267 – Operating Mode Setpoint Command
 - 40268 – Number of Units Setpoint Command
 - 40269 – Preglow Time Setpoint Command
 - 40270 – Crank Time Setpoint Command
 - 40271 – Crank Cutout Setpoint Command
 - 40272 – Crank Delay Setpoint Command
 - 40273 – Crank Repeats Setpoint Command
 - 40276 – Idle Time Setpoint Command
 - 40277 – Cooldown Time Setpoint Command
 - 40280 – Sync Mode Setpoint Command
 - 40291 – Sync Timeout Setpoint Command
 - 40294 – Load Control Mode Setpoint Command
 - 40300 – Base Load Reference Setpoint Command
 - 40303 – Load Time Setpoint Command
 - 40304 – Unload Time Setpoint Command
 - 40305 – Raise Load Rate Setpoint Command
 - 40306 – Lower Load Rate Setpoint Command
 - 40311 – KVA Switch Low Setpoint Command
 - 40312 – KVA Switch High Setpoint Command
 - 40315 – Voltage Ramp Time Setpoint Command
 - 40318 – KVAR Reference Setpoint Command
 - 40319 – Power Factor Reference Setpoint Command
 - 40321 – Process Action Setpoint Command
 - 40328 – Process Reference Setpoint Command
 - 40329 – Process Raise Rate Setpoint Command
 - 40330 – Process Lower Rate Setpoint Command
 - 40334 – Fast Transfer Delay Setpoint Command
 - 40335 – Mains Stable Delay Setpoint Command
 - 40336 – Gen Stable Delay Setpoint Command
 - 40342 – Loss of Mains Action Delay Setpoint Command
 - 40344 – Max Gen Load Setpoint Command
 - 40345 – Next Genset Delay Setpoint Command
 - 40346 – Rated Load Delay Setpoint Command
 - 40347 – Max Start Time Setpoint Command
 - 40348 – Min Gen Load Setpoint Command

40349 – Reduced Load Delay Setpoint Command
40350 – Max Stop Time Setpoint Command

Changes to Existing Features

1. Dead Bus Closure Time

- Will now close to a dead bus in less than 1 second after the generator is stable.

2. Master Flag Transfer

- Master Flag will now be passed in less than 5 seconds.

3. Overcurrent Alarm

- The Overcurrent alarm was changed so that Amp-Seconds start to accumulate after the generator reaches the Overcurrent Level. The present system starts to accumulate Amp-Seconds after the generator reaches Rated Current.

4. Loss of Excitation

- Is now called Reverse KVAR. The name was changed to more accurately reflect the protection provided.
- Added a Reverse KVAR Delay time of 0.1 to 5.0 seconds.

5. Reverse Power

- The Reverse Power Level setting now provides an Instant trip. The Minimum Reverse Power Level setting still provides a delayed trip.

6. Oil Pressure High Limit

- Changed from 120 to 150.

Compatibility with Existing Controls

The new EGCP-2 control will operate with all existing EGCP-2 and EGCP-1 controls.

The Analog Read (AR) Modbus address changes (30054 to 30071) are different between new and old controls.

Replacing the 8406-115 or 8406-116 controls in applications that are using the old Modbus addresses may create an incompatibility for an HMI or PLC already configured to use the old addresses. Since not all the addresses changed, it is possible that the new control software might still work with the old HMI or PLC program. In order to provide backward compatibility, old part numbers 8406-115 and 8406-116 are still available.

Setpoint Files (.spt)

The .spt files from existing 8406-115 or 8406-116 controls will NOT work in the new software. After converting an EGCP-2 control, all Configuration items will return to the default values and must be changed through the Keypad on the EGCP-2.

Watch Window Professional Software

Watch Window Professional software allows you to configure the EGCP-2 over a Servlink connection. The Watch Window Professional software is not included with the EGCP-2 panel. The software (part number 8928-800) must be purchased separately.

Communications manual 26181 (Chapter 5) gives details on how this tool can save you time and money.

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication 51199.



PO Box 1519, Fort Collins CO 80522-1519, USA
1000 East Drake Road, Fort Collins CO 80525, USA
Phone +1 (970) 482-5811 • Fax +1 (970) 498-3058

Email and Website—www.woodward.com

**Woodward has company-owned plants, subsidiaries, and branches,
as well as authorized distributors and other authorized service and sales facilities throughout the world.**

Complete address / phone / fax / email information for all locations is available on our website.