



**Product Manual 35144**  
**(Revision -, 07/2019)**  
Original Instructions

**L-Series ITB / LC-50**  
**RoHS Compliant**

**Installation and Operation Manual**



### General Precautions

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



### Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, on the *publications* page of the Woodward website:

[www.woodward.com/publications](http://www.woodward.com/publications)

The latest version of most publications is available on the *publications* page. If your publication is not there, please contact your customer service representative to get the latest copy.



### Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



### Translated Publications

If the cover of this publication states "Translation of the Original Instructions" please note:

The original source of this publication may have been updated since this translation was made. Be sure to check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

**Revisions**— A bold, black line alongside the text identifies changes in this publication since the last revision.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

# Contents

---

<b>WARNINGS AND NOTICES .....</b>	<b>3</b>
<b>ELECTROSTATIC DISCHARGE AWARENESS.....</b>	<b>4</b>
<b>REGULATORY COMPLIANCE.....</b>	<b>5</b>
<b>CHAPTER 1. GENERAL INFORMATION .....</b>	<b>7</b>
Purpose and Scope .....	7
Intended Applications .....	7
L-Series Description .....	7
Determining Proper Valve Size .....	8
<b>CHAPTER 2. APPLICATION OVERVIEW .....</b>	<b>11</b>
Hardware Configuration Application Process.....	11
<b>CHAPTER 3. INSTALLATION.....</b>	<b>13</b>
Mechanical Installation .....	14
LC-50 Applications (Mixer Applications).....	20
<b>CHAPTER 4. TROUBLESHOOTING .....</b>	<b>22</b>
<b>CHAPTER 5 PRODUCT SUPPORT AND SERVICE OPTIONS .....</b>	<b>23</b>
Product Support Options .....	23
Product Service Options.....	23
Returning Equipment for Repair .....	24
Replacement Parts .....	24
Engineering Services.....	25
Contacting Woodward's Support Organization .....	25
Technical Assistance .....	26
<b>L-SERIES ITB SPECIFICATIONS.....</b>	<b>27</b>
<b>APPENDIX. ACRONYMS/ABBREVIATIONS.....</b>	<b>28</b>
<b>REVISION HISTORY.....</b>	<b>29</b>
<b>DECLARATIONS.....</b>	<b>30</b>

## Illustrations and Tables

Figure 1-1. Cv vs Angle for L-Series ITBs .....	9
Figure 1-2. Cv vs Angle for L-Series Trim Valves .....	10
Figure 2-1. Application Matrix .....	11
Figure 3-1. Spring-Loaded Throttle Plate .....	15
Figure 3-2. L-Series ITB Outline Drawings .....	17
Figure 3-3a. LC-50 Outline Drawing (small bore) .....	18
Figure 3-3b. LC-50 Outline Drawing (large bore) .....	19
Figure 3-4. Zirconia Oxygen Sensor Response .....	21
Figure 3-5. Pre-Catalyst Emissions .....	21
Figure 3-6. Post-Catalyst Emissions .....	21
Table 1-1. Cv (Flow Coefficient) .....	8
Table 3-1. MAS and ZPR Initial Settings .....	20

## Warnings and Notices

### Important Definitions



This is the safety alert symbol used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER** - Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
- **WARNING** - Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
- **CAUTION** - Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
- **NOTICE** - Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT** - Designates an operating tip or maintenance suggestion.

#### **WARNING**

##### Overspeed / Overtemperature / Overpressure

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.

#### **WARNING**

##### Personal Protective Equipment

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.

#### **WARNING**

##### Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

#### **WARNING**

##### Automotive Applications

On- and off-highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

**NOTICE****Battery Charging  
Device**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

## Electrostatic Discharge Awareness

**NOTICE****Electrostatic  
Precautions**

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Follow these precautions when working with or near the control.

1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
  - Do not touch any part of the PCB except the edges.
  - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
  - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

**IMPORTANT**

External wiring connections for reverse-acting controls are identical to those for direct-acting controls.

## Regulatory Compliance

### European Compliance for CE Marking:

These listings are limited only to those units bearing the CE Marking:

**EMC Directive:** Declared to Directive 2014/30/EU of the European Parliament and of the Council of 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility (EMC).

These listings are limited only to those L-Series ITB Control units (not mixers) bearing the ATEX markings as well as the CE Mark (8404-7226, 8404-7227 only):

**ATEX Directive:** Directive 2014/34/EU of the European Parliament and of the Council of 26 February 2014 on the harmonization of the laws of the Member States relating to equipment and protective systems intended for use in potentially explosive atmospheres  
Zone 2, Category 3, Group II G, Ex nA IIC T3 Gc X  
 $-40\text{ }^{\circ}\text{C} \leq T_{\text{amb}} \leq +105\text{ }^{\circ}\text{C}$ , IP56

**Special Condition for Safe Use:** *The installer of the L-Series must take responsibility for meeting Clause 26.4.2 of EN60079-0 (Ed. 6 or 7) regarding impact testing. The actuator by itself does not meet this requirement and therefore must be sufficiently protected when installed. See Chapter 2, Mechanical Installation, for more details.*

### Other European and International Compliance:

Compliance with the following European Directives or standards does not qualify this product for application of the CE Marking:

**Machinery Directive:** Compliant as partly completed machinery with Directive 2006/42/EC of the European Parliament and the Council of 17 May 2006 on machinery.

**Pressure Equipment Directive:** Exempt per Article 1.2(j) of 2014/68/EU where pressure is not a significant design factor

**Restriction of Hazardous Substances (RoHS):** Declared to 2011/65/EC COUNCIL DIRECTIVE of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.  
Exemption in use: 6(a), 6(c), 7(a), 7(c)-I

### North American Compliance:

These listings are limited only to those units bearing the CSA identification

**CSA:** CSA Certified for Class I, Division 2, Groups A, B, C, & D, T3C at 105 °C Ambient for use in Canada and the United States.  
Certificate 1380416

This product is certified as a component for use in other equipment. The final combination is subject to acceptance by the authority having jurisdiction.

Wiring must be in accordance with North American Class I, Division 2 or European Zone 2, Category 3 wiring methods as applicable, and in accordance with the authority having jurisdiction.

Field wiring must be suitable for at least 105 °C.

Connect ground terminal to earth ground.

The actuator should be protected from exposure to sunlight and rain.

**! WARNING**

**EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.**

**Substitution of components may impair suitability for Class I, Division 2 or Zone 2 applications.**

**Do not clean equipment unless power has been switched off or the area is known to be non-hazardous.**

**! AVERTISSEMENT**

**RISQUE D'EXPLOSION—N'effectuez aucune connexion ou déconnexion tandis que le circuit est sous tension, sauf s'il s'est avéré que la zone n'est pas dangereuse.**

**Le remplacement de composants peut rendre ce matériel inacceptable pour les emplacements de Classe I, Division 2 ou Zone 2.**

# Chapter 1.

## General Information

### Purpose and Scope

The purpose of this manual is to provide OEMs with the necessary background information for applying the L-Series ITB and LC-50 control to gas/gasoline reciprocating engines. Topics covered include mechanical installation and setup and troubleshooting. For application setup, please refer to manual 35154 (Position Control), manual 35141 (L-Series Speed Control), or manual 35153 (L-Series Process Control). While the ITB/LC-50 manual is primarily targeted at OEM customers, OEMs themselves may find it useful to copy some of the information from this manual into their application user manuals.

### Intended Applications

The L-Series ITB and LC-50 controls are designed primarily for various industrial applications, including generator sets, welders, portable refrigeration units, irrigation pumps, chipper shredders, and mobile industrial gas or gasoline reciprocating engines. Key environmental characteristics of these applications include industrial operating temperatures (−40 to +105 °C/−40 to +221 °F).



**WARNING**

Use of an independent device for positive shutdown, such as a fuel shutoff valve, is highly recommended. Failure to comply with this recommendation can cause personal injury and/or property damage.

Use of a predicted min-fuel-shutdown procedure is highly recommended. Failure to comply with this recommendation can cause personal injury and/or property damage.



**WARNING**

**Automotive  
Applications**

On- and Off-Highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

### L-Series Description

The L-Series ITB and LC-50 provide a building block approach to total engine management. The modular design consist of a die-cast aluminum throttle body, a mixer, and a fully programmable integrated digital speed, position or process control, and bi-directional actuator. The L-Series ITB incorporates the Woodward L-Series control with a throttle plate. The LC-50 adds a venturi-style annular ring mixer to the L-Series ITB.

## Determining Proper Valve Size

The proper valve size can be determined using the equation below. The required Cv (Flow Coefficient) should be calculated for both the minimum and maximum flows expected on the application. This design allows for 80 degrees of throttle plate rotation.

Using the graph and table below, select the closest valve that has a Cv equal to or greater than the maximum flow value at approximately 80% opening (64 degrees) to ensure reasonable flow margin. Also, check that the particular valve's minimum Cv listed below is less than the minimum calculated Cv for good low idle performance.

$$C_v = \frac{Q * 0.00976}{P_1} \sqrt{\frac{(T + 460) * P_1 * S_g}{P_1 - P_2}}$$

Where:

Cv = Flow Coefficient

Q = Mass Flow (PPH [pounds/hour] (1 pound = 0.45 kg)

Sg = Specific Gravity of Gas (use 1.0 for air)

T1 = Upstream Gas Temperature (°F) (°F = 1.8\* °C + 32)

P1 = Inlet Pressure (psia) (1 psi = 6.895 kPa = .06895 bar)

P2 = Downstream Pressure (psia)

**NOTE: P2 must be greater than 0.528\*P1 or flow becomes choked. If P2 less than 0.528\*P1, then use P2=.528\*P1**

Table 1-1. Cv (Flow Coefficient)

Plate Angle	25 mm	30 mm	36 mm	43 mm	50 mm
0	0.56	0.71	0.74	0.97	1.06
5	0.59	0.93	1.13	1.48	1.85
10	0.63	1.33	1.71	2.66	3.18
20	0.98	2.84	4.10	6.23	8.31
30	1.89	5.53	8.24	12.15	16.99
40	3.54	9.57	14.53	21.24	29.48
50	6.02	15.41	23.96	35.83	49.51
60	9.48	23.55	38.27	56.93	78.80
70	14.37	33.39	59.26	88.25	127.75
80	20.03	41.18	82.45	119.95	171.32

## Cv vs Angle for L-Series ITB s




Figure 1-1. Cv vs Angle for L-Series ITBs

The proper valve size can be determined using the equation below. The required Cv (Flow Coefficient) should be calculated for both the minimum and maximum flows expected on the application. This design allows for 60 degrees of throttle plate rotation.

Table 1-2. 16 mm Trim Valve Position vs CV Value

16 mm	
Pos (%)	Cv
100	9.19
95	8.85
90	8.15
85	7.35
80	6.43
75	5.56
70	4.75
65	4.04
60	3.42
55	2.86
50	2.37
45	1.92
40	1.56
35	1.26
30	1.02
25	0.86
20	0.76
15	0.73
10	0.73
5	0.73
2.5	0.72
0	0.72




Figure 1-2. Cv vs Angle for L-Series Trim Valves

## Chapter 2. Application Overview

### Hardware Configuration Application Process

The first step in configuring a new system is to choose the appropriate hardware for the application. An ITB, a mixer, and a version of the actuator must be selected. The ITBs and mixers come in five different sizes.

For both the L-Series ITB and LC-50, the user must choose the appropriately sized ITB for the application. The chart below illustrates how to choose the proper size. The intersection of the operating rpm and the engine displacement will fall within a specific ITB band. For example, a 4.0 L engine that will run at 2000 rpm would need a 43 mm ITB, as that point falls between the two lines for the 43 mm (square marker lines).

If the application will have multiple speed set points, some judgment needs to be used to appropriately size the throttle. In general, the highest speed where the engine will spend any significant percentage of its time, or the highest speed where efficiency (or power) is important, should be used for sizing.




Figure 2-1. Application Matrix

If the application is an LC-50 product, there are appropriately sized mixers for each throttle size. A complete gaseous fuel delivery system requires:

- a fixed main adjustment screw (MAS) or closed-loop trim valve
- a zero-pressure regulator (ZPR)
- a fuel shut-off valve

The LC-50 comes with a venturi-style mixer. By locally increasing the air speed in a pipe, the static pressure at the location of the restriction will be lower than the pressure before this restriction. When a number of orifices are made in the circumference of the venturi, the medium to be mixed (natural gas) will be drawn into the venturi throat. If the pressure of the gas is kept equal to the pressure before the venturi, the gas will be mixed with the air in a constant ratio. The pressure is kept equal to the air pressure directly before the mixer by means of a zero pressure regulator and a compensation line. The venturi mixer is maintenance free.

A main adjustment screw (MAS) is provided to adjust the full-power air/fuel ratio by means of an adjustable restriction in the fuel line between the zero pressure regulator and the venturi mixer. For more advance A/F ratio control, an L-Series O<sub>2</sub> sensing A/F ratio trim valve is available separately as a replacement for the MAS. The LC-50 Mixer fuel inlet connection is designed to match the L-Series trim valve bolt pattern. For more information, refer to product specification 03255.

The compensation line ensures that the gas pressure is kept equal to the air pressure before the venturi mixer. When no compensation line is used, the outlet pressure of the ZPR will not be balanced as the air filter becomes dirty. As the air filter gets dirty, there is an increased pressure drop after the air filter, and the air/fuel ratio will become richer.

## Chapter 3. Installation

**! WARNING**

When included with an ITB, the actuator depends solely on the return spring inside the throttle body assembly to drive toward minimum fuel when not powered. Therefore other positive shutdown devices like fuel shut-off solenoids are recommended to ensure shutdown on loss of signal to the control system. Also, separate overspeed trip devices are always mandatory.

**! WARNING**

External fire protection is not provided in the scope of this product. It is the responsibility of the user to satisfy any applicable requirements for their system.

**! WARNING**

The installer of the L-Series must take responsibility for meeting Clause 26.4.2 of EN60079-0 (Ed. 6 or 7) regarding impact testing. The actuator by itself does not meet this requirement and therefore must be sufficiently protected when installed.

**! WARNING**

Wiring must be in accordance with North American Class I, Division 2 or European Zone 2, Category 3 wiring methods as applicable, and in accordance with the authority having jurisdiction.

**! WARNING**

Field wiring must be suitable for at least 105 °C.

**! WARNING**

Connect ground terminal to earth ground.

**! CAUTION**

The L-Series is used on prime movers that typically have a high noise level. Always use appropriate hearing protection while working around the L-Series.

**! CAUTION**

The surface of this product can become hot enough or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.

**WARNING**

**EXPLOSION HAZARD**—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.

Substitution of components may impair suitability for Class I, Division 2 or Zone 2 applications.

Do not clean equipment unless power has been switched off or the area is known to be non-hazardous.

**AVERTISSEMENT**

**RISQUE D'EXPLOSION**—N'effectuez aucune connexion ou déconnexion tandis que le circuit est sous tension, sauf s'il s'est avéré que la zone n'est pas dangereuse.

Le remplacement de composants peut rendre ce matériel inacceptable pour les emplacements de Classe I, Division 2 ou Zone 2.

## Mechanical Installation

Locate the L-Series control a distance from sources of extreme radiant heat, such as exhaust manifolds or turbochargers. The operating temperature range of the control is  $-40$  to  $+105$  °C ( $-40$  to  $+221$  °F). In spark-ignited applications, make sure the control is located away from the ignition coil, and that harness wires are not routed next to the spark plug wires.

While it is not a requirement, it is good practice to orient the connector feature on the control in a horizontal or downward orientation to minimize fluid accumulation between the enclosure and the mating connector's gasket.

**IMPORTANT**

For ATEX Hazardous Location applications, the installer of the L-series ITB Control must ensure that the mounting screws provide sufficient grounding for the ITB.

The 25, 30, and 36 mm throttles mount with 5 mm fasteners in a 43 mm square bolt pattern. The 43 and 50 mm throttles use 6 mm mounting screws in a 57 mm square pattern.

**IMPORTANT**

The actuator should be protected from exposure to sunlight and rain.

**CAUTION**

The L-Series ITB valve output shaft represents a pinch hazard with the power connected. To prevent bodily harm or injury, keep all hands, fingers, etc. away from the valve element at all times when electrically connected.

**WARNING**

The L-Series ITB should be used in a well-ventilated area. A methane detector should be used if the valve will be used in an enclosed installation.

**NOTICE**

Secondary retention of the bolts should be utilized. Consult the OEM regarding retention methods.

**WARNING**

The L-Series ITB is not intended to support the inlet or outlet piping. A suitable bracket must be constructed to support the valve and piping separately to prevent damage to the throttle body.

**WARNING**

Know in advance how to safely shut off the engine during normal and emergency stop conditions. Shutting off power to the governor does not always guarantee a controlled shutdown; it depends on the final application. Safety needs to be the overriding thought during this procedure.

**WARNING**

The control will only meet ingress protection specifications while the Deutsch connector is installed in the unit. The unit should not be exposed to operating environments unless the mating connector is installed. In addition, if a wire is not used for each of the 12 pins on the control, a Deutsch 114017 plug must be used in place of each missing wire. Failure to adhere to these guidelines may result in product failure or decreased life.

**WARNING**

See Manual 35141, 35147, or 35153 as appropriate for electrical and software installation, application, troubleshooting, and safety information.

**NOTICE**

The L-Series actuator output shaft is integral to the unit's accuracy and performance. Take special care to prevent damage to the output shaft or ITB bore. Do not use a sharp or metallic object to open the ITB.

Mounting gaskets are not included with the Integrated Throttle Bodies (ITB), but these can be ordered separately as needed. For the 25, 30, and 36 mm ITBs, order gasket part number 0014-00-034. For the 43 and 50 mm ITBs, order gasket part number 0108-00-021.

The L-Series actuator has a rotation of 0–60 degrees. To get full blade rotation on the ITB, a mechanical linkage exists inside the ITB that converts 0 to 60 degrees actuator rotation to 3 to 85 degrees blade position. In addition, the ITB incorporates the use of an internal return spring. The spring load drives the throttle plate to the closed position with the clocking outlined in the figure below.




Figure 3-1. Spring-Loaded Throttle Plate

The LC-50 mixer can be mounted in any of three orientations of the ITB to allow convenient fuel system connections. The L-Series ITB and LC-50 are intended to be used with gaseous fuels from low quality pipeline natural gas to HD-5 LPG. The quality of this range of fuel varies from a lower heating value of 850 BTU/SCF (34.0 MJ/m<sup>3</sup>) to 2325 BTU/SCF (93.0 MJ/m<sup>3</sup>), and the specific gravity varies from 0.55 to 1.56 relative to air. When using a Woodward supplied ZPR, fuel pressure should be 0.25 psi (7" water column) (1.7 kPa [178 mm water column]) to 1 psi (28" water column) (6.9 kPa [711 mm water column]). Pressure supply range is 4–14" water for the R500Z, and 4–28" water for the R600Z.

The LC-50 mixer has two inlet sizes for air filter attachment. The smaller throttles (25, 30, and 36 mm) have a 2.0-inch (50.8 mm) inlet. The larger throttles (43 and 50 mm) have a 2.5 inch (63.5 mm) inlet.





It is recommended that all components of the gas system, such as air filter, main adjustment screw, and throttle valve, be installed in a symmetric way to minimize the possibility of unequal mixture distribution.

Curved pipes should not be installed closer to the venturi than 3D (where D is the diameter of the venturi at the air inlet side).

Woodward recommends that you install a compensation line between the ZPR and the air inlet to maintain consistent air/fuel ratio throughout the life of the system. If a compensation line is not installed, the air/fuel ratio will be affected by the changing restriction of the air cleaner as it accumulates dirt.

If the Maxitrol ZPR is obtained from Woodward (part numbers 0055-55-062 for the R500Z [1/2" bore], 0055-00-063 for the R600Z [3/4" bore]), the following installation instructions apply. If another brand of ZPR is used, consult that manufacturer for installation guidelines. The ZPR should be mounted with the spring tower up. If it is not, the weight of the diaphragm and spring can offset the pressure setting. The ZPR should be mounted as close to the MAS as possible to prevent pressure drop across excessively long pipe lengths. This pressure drop and associated system lag can cause stability and response issues with the mixer air/fuel ratio control.

BORE  $\varnothing$ : 25MM, 30MM, & 36MM  
MM [INCH]



262-131  
05-5-10

BORE  $\varnothing$ : 43MM & 50MM  
MM [INCH]







Figure 3-2. L-Series ITB Outline Drawings




Figure 3-3a. LC-50 Outline Drawing (small bore)




Figure 3-3b. LC-50 Outline Drawing (large bore)

On a turbo-charged engine, the mixer should be located before the turbo compressor. This will yield very high mixture homogeneity as well as allowing the use of a standard ZPR and the ability to use low-pressure gas. To increase safety, some engine manufacturers have mounted flame arrestors between the inlet manifold and the cylinder head, ensuring that a backfire does not lead to an explosion in the inlet manifold, aftercooler, etc., which are filled with ignitable mixture.

The initial settings for the MAS and ZPR are indicated in the table below. These settings should provide the ability to consistently start and run at an approximately stoichiometric air/fuel ratio. The procedure for adjusting these settings for optimum air/fuel ratio is described in the air/fuel ratio tuning section (Chapter 4). The main adjustment screw (MAS) settings are measured from the MAS valve body (not the jam nut) to the exterior end of the MAS screw. The zero-pressure regulator settings are measured from the top of the spring adjustment screw to the top of the spring tower.

For dual-fuel configurations, the standard NG fuel set up should have a tee added between the ZPR and MAS. The side-leg of the tee should then have the MAS and ZPR for the LP fuel. The initial settings for dual-fuel NG and LP are the same as the single-fuel settings below. The final air/fuel ratio adjustments should be done on NG first, then LP, using the procedure in Chapter 4 for each fuel.

Table 3-1. MAS and ZPR Initial Settings

ITB Size	Natural Gas	Propane
	Screw Setting Position (mm)	
<b>50 mm</b>		
MAS	19	16
ZPR	16	14
<b>43 mm</b>		
MAS	17	15
ZPR	16	14
<b>36 mm</b>		
MAS	11	9.5
ZPR	14	14
<b>30 mm</b>		
MAS	11	9
ZPR	14	14
<b>25 mm</b>		
MAS	10	8
ZPR	14	14

## LC-50 Applications (Mixer Applications)

After the initial program is configured, the air/fuel ratio should be optimized before extensive engine speed governor tuning is done. Start with low gain values and step slowly through load changes until the air/fuel ratio is tuned.

Initial settings are described in the Hardware Configuration section Chapter 2. These settings should get the gensets up and running for final adjustment with an oxygen sensor or exhaust analyzer.



**WARNING**

Leak-check all gaseous fuel connections. Leaking gaseous fuel can cause explosion hazards, property damage, or loss of life.

## Air/Fuel Ratio Tuning

1. Insert an oxygen sensor or exhaust gas analyzer into the exhaust stream as directed by the manufacturer of the sensor or analyzer.
2. Start the engine and allow it to warm up for about 15 minutes.
3. Apply 75% to 90% load to the engine.



**WARNING**

The load may need to be applied gradually to avoid underspeed and overspeed conditions.

4. Adjust the MAS to achieve the desired air/fuel ratio. The figures below show the characteristic response of the oxygen sensors and exhaust gas. Clockwise rotation of the MAS will cause the air/fuel ratio to become leaner. Counterclockwise rotation will cause the air/fuel ratio to become richer.




Figure 3-4. Zirconia Oxygen Sensor Response




Figure 3-5. Pre-Catalyst Emissions




Figure 3-6. Post-Catalyst Emissions

5. The ZPR should then be adjusted at no-load. Clockwise rotation of the screw will cause the mixture to become richer, counterclockwise rotation will cause the mixture to become leaner. When the cover is removed from the ZPR, extra air leakage is introduced into the system. So, a final setting cannot be determined until the ZPR spring tower is covered.
6. One or two more iterations at full load for the MAS and no load for the ZPR should provide the correct air/fuel ratio over the entire operating range.

## Chapter 4. Troubleshooting

This chapter presents several broad categories of application failures typically experienced in the field, possible causes, and some tests used to verify the causes. Because the exact failure experienced in the field is the product of the mechanical/electrical failure combined with the control configuration, it is left as the OEM's responsibility to create a more detailed troubleshooting chart for the end user. Ideally, this end-user troubleshooting chart will contain information about mechanical, electrical, engine, and load failures in addition to the possible governor failures. For more detailed information about governor system failure modes and effects, contact Woodward for a copy of the system DFMEA.

The troubleshooting scenarios listed below assume that the application has been engineered and tested thoroughly.

Problem	Possible Cause	Suggested Test/Correction
Engine does not start	Stuck throttle/frozen shaft	Move throttle by hand. Assess smoothness, friction, and return spring force.
Engine starts, runs, but is unstable	Air/fuel ratio not correct	If using LC-50 mixer, MAS, & ZPR, follow air/fuel ratio tuning guidelines in Chapter 4. Otherwise, follow fuel system manufacturer's guidelines.
	Position, Speed, or Process Control is has not been adequately tuned.	See manual 35141, 35147, or 35153 for application setup procedures.



**The L-Series is used on prime movers that typically have a high noise level. Always use appropriate hearing protection while working around the L-Series.**



**Following a detected error, the L-Series actuator will not attempt to operate again until power to the valve is cycled. If an error persists, the actuator must be replaced.**



**See Manual 35141, 35147, or 35153 as appropriate for electrical and software installation, application, troubleshooting, and safety information.**

# Chapter 5

## Product Support and Service Options

### Product Support Options

If you are experiencing problems with the installation, or unsatisfactory performance of a Woodward product, the following options are available:

1. Consult the troubleshooting guide in the manual.
2. Contact the **OE Manufacturer or Packager** of your system.
3. Contact the **Woodward Business Partner** serving your area.
4. Contact Woodward technical assistance via email ([EngineHelpDesk@Woodward.com](mailto:EngineHelpDesk@Woodward.com)) with detailed information on the product, application, and symptoms. Your email will be forwarded to an appropriate expert on the product and application to respond by telephone or return email.
5. If the issue cannot be resolved, you can select a further course of action to pursue based on the available services listed in this chapter.

**OEM or Packager Support:** Many Woodward controls and control devices are installed into the equipment system and programmed by an Original Equipment Manufacturer (OEM) or Equipment Packager at their factory. In some cases, the programming is password-protected by the OEM or packager, and they are the best source for product service and support. Warranty service for Woodward products shipped with an equipment system should also be handled through the OEM or Packager. Please review your equipment system documentation for details.

**Woodward Business Partner Support:** Woodward works with and supports a global network of independent business partners whose mission is to serve the users of Woodward controls, as described here:

- A **Full-Service Distributor** has the primary responsibility for sales, service, system integration solutions, technical desk support, and aftermarket marketing of standard Woodward products within a specific geographic area and market segment.
- An **Authorized Independent Service Facility (AISF)** provides authorized service that includes repairs, repair parts, and warranty service on Woodward's behalf. Service (not new unit sales) is an AISF's primary mission.
- A **Recognized Engine Retrofitter (RER)** is an independent company that does retrofits and upgrades on reciprocating gas engines and dual-fuel conversions, and can provide the full line of Woodward systems and components for the retrofits and overhauls, emission compliance upgrades, long term service contracts, emergency repairs, etc.

A current list of Woodward Business Partners is available at [www.woodward.com/directory](http://www.woodward.com/directory).

### Product Service Options

Depending on the type of product, the following options for servicing Woodward products may be available through your local Full-Service Distributor or the OEM or Packager of the equipment system.

- Replacement/Exchange (24-hour service)
- Flat Rate Repair
- Flat Rate Remanufacture

**Replacement/Exchange:** Replacement/Exchange is a premium program designed for the user who is in need of immediate service. It allows you to request and receive a like-new replacement unit in minimum time (usually within 24 hours of the request), providing a suitable unit is available at the time of the request, thereby minimizing costly downtime.

This option allows you to call your Full-Service Distributor in the event of an unexpected outage, or in advance of a scheduled outage, to request a replacement control unit. If the unit is available at the time of the call, it can usually be shipped out within 24 hours. You replace your field control unit with the like-new replacement and return the field unit to the Full-Service Distributor.

**Flat Rate Repair:** Flat Rate Repair is available for many of the standard mechanical products and some of the electronic products in the field. This program offers you repair service for your products with the advantage of knowing in advance what the cost will be.

**Flat Rate Remanufacture:** Flat Rate Remanufacture is very similar to the Flat Rate Repair option, with the exception that the unit will be returned to you in “like-new” condition. This option is applicable to mechanical products only.

## Returning Equipment for Repair

If a control (or any part of an electronic control) is to be returned for repair, please contact your Full-Service Distributor in advance to obtain Return Authorization and shipping instructions.

When shipping the item(s), attach a tag with the following information:

- return number;
- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part number(s) and serial number(s);
- description of the problem;
- instructions describing the desired type of repair.

## Packing a Control

Use the following materials when returning a complete control:

- protective caps on any connectors;
- antistatic protective bags on all electronic modules;
- packing materials that will not damage the surface of the unit;
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material;
- a packing carton with double walls;
- a strong tape around the outside of the carton for increased strength.

### NOTICE

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

### IMPORTANT

There are no serviceable parts on the L-Series.

## Replacement Parts

When ordering replacement parts for controls, include the following information:

- the part number(s) (XXXX-XXXX) that is on the enclosure nameplate;
- the unit serial number, which is also on the nameplate.

## Engineering Services

Woodward's Full-Service Distributors offer various Engineering Services for our products. For these services, you can contact the Distributor by telephone or by email.

- Technical Support
- Product Training
- Field Service

**Technical Support** is available from your equipment system supplier, your local Full-Service Distributor, or from many of Woodward's worldwide locations, depending upon the product and application. This service can assist you with technical questions or problem solving during the normal business hours of the Woodward location you contact.

**Product Training** is available as standard classes at many Distributor locations. Customized classes are also available, which can be tailored to your needs and held at one of our Distributor locations or at your site. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability.

**Field Service** engineering on-site support is available, depending on the product and location, from one of our Full-Service Distributors. The field engineers are experienced both on Woodward products as well as on much of the non-Woodward equipment with which our products interface.

For information on these services, please contact one of the Full-Service Distributors listed at [www.woodward.com/directory](http://www.woodward.com/directory).

## Contacting Woodward's Support Organization

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory at [www.woodward.com/directory](http://www.woodward.com/directory), which also contains the most current product support and contact information.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

<b>Products Used in Electrical Power Systems</b>	
<u>Facility</u>	<u>Phone Number</u>
Brazil	+55 (19) 3708 4800
China	+86 (512) 6762 6727
Germany:	
Kempen	+49 (0) 21 52 14 51
Stuttgart	+49 (711) 78954-510
India	+91 (124) 4399500
Japan	+81 (43) 213-2191
Korea	+82 (51) 636-7080
Poland	+48 12 295 13 00
United States	+1 (970) 482-5811

<b>Products Used in Engine Systems</b>	
<u>Facility</u>	<u>Phone Number</u>
Brazil	+55 (19) 3708 4800
China	+86 (512) 6762 6727
Germany	+49 (711) 78954-510
India	+91 (124) 4399500
Japan	+81 (43) 213-2191
Korea	+82 (51) 636-7080
The Netherlands	+31 (23) 5661111
United States	+1 (970) 482-5811

<b>Products Used in Industrial Turbomachinery Systems</b>	
<u>Facility</u>	<u>Phone Number</u>
Brazil	+55 (19) 3708 4800
China	+86 (512) 6762 6727
India	+91 (124) 4399500
Japan	+81 (43) 213-2191
Korea	+82 (51) 636-7080
The Netherlands	+31 (23) 5661111
Poland	+48 12 295 13 00
United States	+1 (970) 482-5811

## Technical Assistance

If you need to contact technical assistance, you will need to provide the following information. Please write it down here before contacting the Engine OEM, the Packager, a Woodward Business Partner, or the Woodward factory:

### General

Your Name \_\_\_\_\_

Site Location \_\_\_\_\_

Phone Number \_\_\_\_\_

Fax Number \_\_\_\_\_

---

### Prime Mover Information

Manufacturer \_\_\_\_\_

Engine Model Number \_\_\_\_\_

Number of Cylinders \_\_\_\_\_

Type of Fuel (gas, gaseous, diesel, dual-fuel, etc.) \_\_\_\_\_

Power Output Rating \_\_\_\_\_

Application (power generation, marine, etc.) \_\_\_\_\_

---

### Control/Governor Information

#### Control/Governor #1

Woodward Part Number & Rev. Letter \_\_\_\_\_

Control Description or Governor Type \_\_\_\_\_

Serial Number \_\_\_\_\_

---

#### Control/Governor #2

Woodward Part Number & Rev. Letter \_\_\_\_\_

Control Description or Governor Type \_\_\_\_\_

Serial Number \_\_\_\_\_

---

#### Control/Governor #3

Woodward Part Number & Rev. Letter \_\_\_\_\_

Control Description or Governor Type \_\_\_\_\_

Serial Number \_\_\_\_\_

---

### Symptoms

Description \_\_\_\_\_

*If you have an electronic or programmable control, please have the adjustment setting positions or the menu settings written down and with you at the time of the call.*

# L-Series ITB Specifications

	<b>Specifications</b>
Mass/Weight	425 g (15 oz)
	<b>Control Characteristics</b>
Engine Type	2-cycle or 4-cycle gasoline, diesel, or gaseous fuel
Actuator Torque	High-efficiency torque motor delivers 0.34 N·m (0.25 lb-ft) (standard model) over 60° travel range to operate fuel or air control
	<b>Environment</b>
Ambient Operating Temperature	−40 to +105 °C (−40 to +221 °F)
Process Fluid Operating Temperature	−40 to +105 °C (−40 to +221 °F)
Process Fluid Operating Pressure	60 psig
Storage Temperature	−40 to +125 °C (−40 to +257 °F)
Humidity	US MIL-STD 810E, Method 507.3, Procedure III
Salt Spray	US MIL-STD 810E, Method 509.3, Procedure I
Shock	MS1-40G 11ms sawtooth
Vibration	Random: 0.3 G <sup>2</sup> /Hz , 10–2000 Hz (22.1Grms) 3 h/axis Sine: 5 G 2.5 mm peak-to-peak, 5–2000 Hz, 3 h/axis, 90 min dwells, 1 octave/min
Drop	SAE J1211, Paragraph 4.8.3 (modified)
Thermal Shock	SAE J1455, Paragraph 4.1.3.2
Ingress Protection	IP56 per EN60529
Inlet Pressure	Sealed shaft bearings: 2 bar (29 psi) gage Standard shaft bearings: 0.068 bar (1 psi) gage

## Regulatory Compliance

**Note:** Refer to the appropriate L-Series control manual (35141, 35147, or 35153) for actuator compliance

Compliance with the following European directives or standards does not qualify this product for application of the CE Marking:

**Pressure Equipment Directive:** Exempt per Article 1-3.10

## Reliability and Quality Goals

The L-Series control system has a reliability target of 17 500 hours MTBF. It also has a quality goal of less than 25 PPM when measuring out-of-the-box defects. This quality goal is a target based on continuous improvement.



**WARNING**

See Manual 35141, 35147, or 35153 as appropriate for electrical and software installation, application, troubleshooting, and safety information.

## Appendix. Acronyms/Abbreviations

A/F	air/fuel ratio
ITB	integrated throttle body
LC-50	Woodward system that incorporates L-Series with an ITB and mixer
MAP	manifold air pressure
MAS	main adjustment screw
OEM	original equipment manufacturer
Stoichiometric	chemically balanced air/fuel ratio
ZPR	zero pressure regulator

---

# Revision History

---

New Manual—

# Declarations

## EU DECLARATION OF CONFORMITY

**EU DoC No.:** 00240-04-EU-02-09  
**Manufacturer's Name:** WOODWARD INC.  
**Manufacturer's Contact Address:** 3800 Wilson Avenue  
 Loveland, CO 80538 USA  
**Model Name(s)/Number(s):** L-Series ITB and LC-50

**The object of the declaration described above is in conformity with the following relevant Union harmonization legislation:** Directive 2014/30/EU of the European Parliament and of the Council of 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility (EMC)

Units marked for ATEX (8404-7226, 8404-7227 only):  
 Directive 2014/34/EU of the European Parliament and of the Council of 26 February 2014 on the harmonization of the laws of the Member States relating to equipment and protective systems intended for use in potentially explosive atmospheres

Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment  
 Exemption in use: 6(a), 6(c), 7(a), 7(c)-I

**Markings in addition to CE marking:**  II 3 G, Ex nA IIC T3 X Gc

**Applicable Standards:** EN61000-6-2, 2005: EMC Part 6-2: Generic Standards - Immunity for Industrial Environments  
 EN61000-6-4, 2011: EMC Part 6-4: Generic Standards - Emissions for Industrial Environments  
 EN60079-15, (2003) Electrical apparatus for explosive gas atmospheres – Part 15: Type of protection 'n'

**Conformity Assessment:** Woodward EMC Conformity Assessment 00240-04-EU-EMC-06-03

This declaration of conformity is issued under the sole responsibility of the manufacturer  
 We, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s).

### MANUFACTURER

Signature



Full Name

Mike Row

Position

Compliance Engineering Supervisor

Place

Woodward, Fort Collins, CO, USA

Date

12-July-2019

<b>DECLARATION OF INCORPORATION Of Partly Completed Machinery 2006/42/EC</b>
--

**File Name:** 00240-04-EU-02-03  
**Manufacturer's Name:** WOODWARD INC  
**Manufacturer's Address:** 3800 N. Wilson Ave.  
 Loveland, CO, USA 80538

**Model Names:** L-Series Actuator

**This product complies, where applicable, with the following Essential Requirements of Annex I:** 1.1, 1.2, 1.3, 1.4, 1.5, 1.6, 1.7

---

The relevant technical documentation is compiled in accordance with part B of Annex VII. Woodward shall transmit relevant information if required by a reasoned request by the national authorities. The method of transmittal shall be agreed upon by the applicable parties.

The person authorized to compile the technical documentation:

**Name:** Dominik Kania, Managing Director  
**Address:** Woodward Poland Sp. z o.o., ul. Skarbowa 32, 32-005 Niepolomice, Poland

This product must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of this Directive, where appropriate.

The undersigned hereby declares, on behalf of Woodward, Inc., of Loveland and Fort Collins, Colorado that the above referenced product is in conformity with Directive 2006/42/EC as partly completed machinery:

**MANUFACTURER**

  
 \_\_\_\_\_  
**Signature**

**Mike Row**  
 \_\_\_\_\_  
**Full Name**

**Engineering Supervisor**  
 \_\_\_\_\_  
**Position**

**Woodward, Inc, Fort Collins, CO, USA**  
 \_\_\_\_\_  
**Place**

**March 20<sup>th</sup>, 2019**  
 \_\_\_\_\_  
**Date**

We appreciate your comments about the content of our publications.

Send comments to: [icinfo@woodward.com](mailto:icinfo@woodward.com)

Please reference publication **35144**.



B 3 5 1 4 4 : -



PO Box 1519, Fort Collins CO 80522-1519, USA  
1041 Woodward Way, Fort Collins CO 80524, USA  
Phone +1 (970) 482-5811

Email and Website—[www.woodward.com](http://www.woodward.com)

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world. Complete address / phone / fax / email information for all locations is available on our website.